
SYNCING TWO OR MORE MOTHER-32 ANALOG SYNTHESIZERS

There are a number of ways to synchronize multiple Mother-32 Analog Synthesizers for greater musical flexibility. This tutorial will walk you through the basics of synchronizing two or more units.

TWO UNITS

Select one Mother-32 to be the master clock and transport controller for all linked units.

Connect the **ASSIGN** output jack from the selected Mother-32 (*Master*), to the **TEMPO** input jack of a second Mother-32.




Master

THREE UNITS

Select one Mother-32 to be the master clock and transport controller for all linked units.


If you are syncing 3 or more units, you will need to patch the **ASSIGN** output jack into a **MULT** input. Then patch the **MULT 1** and **MULT 2** outputs to the **TEMPO** inputs on units two and three.



NOTE: Learn more about the Mult and Assignable output jacks on pages 43-44 of your Mother-32 manual.


Master

MASTER MOTHER-32 UNIT




1. Enter **SETUP MODE** on the first Mother-32 (*Master*) by pressing the **(SHIFT)+RESET+SET END+STEP 8** buttons.


NOTE: Learn more about Setup Mode on page 49 of your Mother-32 manual.



2. Use the (KB)/(STEP) buttons to select PAGE 1.




3. Now press the STEP 2 button to select SEQUENCER CLOCK as the Assignable output type.




4. Exit **SETUP MODE** by holding **(SHIFT)** and pressing the **(KB)** or **(STEP)** button.

SECOND MOTHER-32 UNIT


NOTE: Repeat the following steps for each additional unit you wish to sync.




5. Enter **SETUP MODE** on the second Mother-32 (*Non-Master*) by pressing the **(SHIFT)+RESET+SET END+STEP 8** buttons.




6. Use the (KB)/(STEP) buttons to select PAGE 3.



7. Now press the STEP 2 button to select SINGLE CLOCK ADVANCE MODE as the tempo input type.



8. Exit **SETUP MODE** by holding **(SHIFT)** and pressing the **(KB)** or **(STEP)** button.



12. Press RUN/STOP on the first Mother-32 (Master) to start and stop all units simultaneously.