

VTY Configuration



Telnet Configuration

Step 1) Modify Telnet Server/Client

Switch(config)# interface vlan *vlan-id*
Switch(config-if)# no shutdown
Switch(config-if)# ip address *ip-address subnet-mask*

Example

Switch(config)# interface vlan *1*
Switch(config-if)# no shutdown
Switch(config-if)# ip address *192.168.1.1 255.255.255.0*



Telnet Configuration

Step 2) Device needs an IP address

LAN Switch Interface Status Codes

Line Status	Protocol Status	Interface Status	Typical Root Cause
Administratively Down	Down	disabled	The interface is configured with the **shutdown** command.
Down	Down	notconnect	No cable; bad cable; wrong cable pinouts; the speeds are mismatched on the two connected devices; the device on the other end of the cable is powered off or the other interface is **shutdown**.
Up	Down	notconnect	An interface up/down state is not expected on LAN switch interfaces.
Down	down (err-disabled)	err-disabled	Port security has disabled the interface.
Up	Up	connected	The interface is working.



Telnet Configuration

Step 2) Device needs an IP address

```
Switch (config)# interface type mod/num
Switch (config-if)# no shutdown
Switch (config-if)# ip address ip-address subnet-mask
```

```
Switch (config)# interface fastEthernet 0/1
Switch (config-if)# no shutdown
Switch (config-if)# ip address 192.168.1.1 255.255.255.0
```



Telnet Configuration

Step 3) Providing Security for the User mode

Cisco(config)#Line VTY *first-line last-line*
Cisco(config-line)#Password *password*
Cisco(config-line)#Login

Example

Cisco(config)#Line VTY *0 15*
Cisco(config-line)#Password *test*
Cisco(config-line)#Login



Telnet Configuration

Step 3) Providing Security for the User mode

Cisco(config)#Username *username* **password** *password*
Cisco(config)#Line VTY *first-line last-line*
Cisco(config-line)#Login Local

Example

Cisco(config)#Username ***Beygi*** **password** *test*
Cisco(config)#Line VTY *0 15*
Cisco(config-line)#Login Local



Telnet Configuration

Step 4) Providing Security for the Privilege mode

Cisco(config)#enable password *password*
Cisco(config)#enable secret *password*



Telnet Configuration

Switch sample configuration

Switch(config)# interface Vlan *1*
Switch(config-if)# no shutdown
Switch(config-if)# ip address *192.168.3.235 255.255.255.0*
Switch(config)# Line vty *0 15*
Switch(config-if)# Pasword *cisco*
Switch(config-if)#Login
Switch(config)#Enable password *cisco*



SSH Configuration

Step 1) Do all the things you need to do to configure Telnet

Note: User mode should be protected by Username/Password



SSH Configuration

Step 2) Modify SSH Server/Client

Note : Device IOS must support security features for enabling SSH.

Enable SSH Server

Cisco(config)#Line VTY *first-line last-line*
Cisco(config-line)#Transport input [Telnet|SSH|All|None]

Example

Cisco(config)#Line VTY *0 15*
Cisco(config-line)#Transport input All



SSH Configuration

Step 3) Key configuration

Switch(config)# hostname *hostname*
Switch(config)# ip domain-name *domain-name*
Switch(config)# Crypto key generate RSA

Switch# show crypto key mypublickey rsa

Example

Switch(config)# hostname ***Sadjad***
Sadjad **(config)# ip domain-name** ***Sadjad.local***
Sadjad **(config)# Crypto key generate RSA**