





FlashCAT (FlashcatUSB Mach1 / XPORT) adapter for Intel/Micron P30 StrataFlash in 64-ball Easy BGA (e.g. PC28F256P30T85 / RC28F256P30T85), using a Sensata CBG064-087G BGA socket.



- NOTES
- Ball names follow the P30 datasheet (row letter A-H along the 13 mm side, column number 1-8). Pads of the socket footprint carry the same names; mapping remapped from the S29 footprint supplied by Embedded Computers.
 - x16 WORD addressing: FlashcatUSB drives header A1..A27 in x16 mode, so P30 A1 (LSB) -> header A1. Header A0 is unused. A25 is only used by 512 Mbit (dual-die) parts, A26/A27 are unused.
 - P30 VCC (core) is 1.7-2.0 V, ABS MAX 2.5 V. U2 makes 1.8 V from the programmer VCC: programmer at 3.3 V -> regulated 1.8 V; programmer at 1.8 V -> U2 in dropout, ~1.78 V. VCCQ (I/O, 1.7-3.6 V) is fed from header VCC, header VIO is unused (same as the EC P30 TSOP-56 Type-D adapter). VPP (VPPL 0.9-3.6 V) is tied to header VCC; U2 feeds VCC only.
 - ADV# and CLK tied to GND (asynchronous mode). WAIT -> header RB0 with 4.7k pull-up. RFU open.
 - RST#, WP# are not on the EC header. WP# is tied to header VCC (lock-down off, as the EC TSOP-56 Type-D adapter); RST# is pulled up to header VCC with a ~1 ms power-on delay. CE#, OE#, WE# are driven directly by the programmer (no pull-ups, as the EC adapters).
 - Unused EC header pins (VPP, VIO, CLE, ALE, RE/B#, DQS, A0, A26, A27) are left open.