

Engineering the Tactical FPV Drone

by Alexandru Bratosin

1. System Architecture & Component Selection

A tactical FPV drone prioritizes range, payload capacity, and RF penetration over agility.

- **Frame:** 7-inch to 10-inch carbon fiber "Deadcat" or True-X geometry (thick 6mm arms for durability).
- **Powertrain:** 2806.5 (for 7") or 3115 (for 10") brushless motors.
- **Stack (FC + ESC):** SpeedyBee F405 V3/V4 stack with a 50A+ 4-in-1 ESC. F405 chips are cheap, reliable, and have enough processing power for Betaflight 4.4+.
- **Control Link:** 900MHz ExpressLRS. 900MHz penetrates foliage and concrete better than 2.4GHz, making it strictly better for tactical environments.
- **Video Link:** 1.2GHz or 5.8GHz Analog VTX (2.5W+ output). Analog is used because it degrades gracefully to static, rather than freezing entirely like digital systems, giving the pilot crucial seconds to react.

2. The Assembly Procedure

Phase A: Power Delivery

1. **Prep the ESC:** Secure the ESC to the frame using silicone gummies (vibration isolation).
2. **Tin the Pads:** Apply flux to all motor pads and battery pads. Heat your iron to ~400°C and apply generous domes of solder.
3. **Install the Pigtail:** Pre-tin the XT60 power wires. Solder the red wire to the positive pad and black to negative.
4. **Install the Capacitor:** Solder a 1000uF 35V Low-ESR capacitor across the battery pads. The negative leg (indicated by a stripe on the cylinder) **MUST** go to the ground pad. *Failure to do this will cause the capacitor to explode.*

Phase B: Drivetrain

1. **Mount Motors:** Use loctite (blue) on the motor screws. Route the three wires from each motor along the arms, securing them with electrical tape, passing them *inside* the frame.
2. **Solder Motors:** Cut the wires to length, strip 2mm, twist, and tin. Solder the three wires to the corresponding three pads on the ESC.
3. **Smoke Check #1:** Plug the smoke stopper into the battery, and the drone into the smoke stopper. A green light means no short circuits.

Phase C: Avionics & RF

1. **Mount Flight Controller:** Place the FC on top of the ESC. Connect them using the provided 8-pin wiring harness.
2. **Solder the Camera:** Route the camera wires (5V, GND, CAM) to the front of the FC.
3. **Solder the VTX:** Route the VTX wires to the rear. Power the VTX directly from the battery pad or a dedicated 9V pad. Solder the video wire to VTX/VO and the SmartAudio wire to an open TX UART.
4. **Solder the ELRS Receiver:** Solder to an open UART. Remember: **RX on Receiver -> TX on FC** and **TX on Receiver -> RX on FC**.

3. Weatherproofing & Final Hardware Checks

- Clean all solder joints vigorously with 99% isopropyl alcohol and a toothbrush to remove corrosive flux residue.
- Apply a conformal coating (acrylic or silicone) over the FC and ESC to waterproof the electronics. Do NOT get conformal coating inside the USB port or the barometer hole.
- Secure all loose wires with zip-ties to ensure spinning propellers cannot catch them.

4. Software Initialization (Betaflight)

1. **Flash Firmware:** Ensure the FC is running the latest stable Betaflight target.
2. **Sensor Alignment:** Place the drone on a flat surface and calibrate the accelerometer.
3. **UART Mapping:** In the Ports tab, identify where you soldered your hardware. Enable "Serial RX" on the UART connected to the ELRS receiver, and select "VTX (TBS SmartAudio)" on the UART connected to your VTX.
4. **Motor Direction Configuration:** Plug in the battery (no props attached). Go to the Motors tab, spin up the motors via the wizard, and ensure they are spinning according to the "Props In" or "Props Out" diagram. Reverse any incorrect motors directly in the software.
5. **Failsafe:** Configure your failsafe to "Drop" (motors cut instantly upon signal loss). In tactical applications, you do not want a drone to fly away or trigger a GPS rescue that reveals operator location.

5. The Payload Release Mechanism

Phase 1: Hardware Selection & Mechanical Mounting

1. The Servo Never use cheap plastic-gear servos (like the standard blue SG90). Under the g-forces of flight and the weight of a payload, plastic gears strip instantly.

- **Requirement:** Use a **Metal Gear Servo** (like the MG90S or Emax ES08MD). They are slightly heavier but will not fail under load.

2. The Dropper Mechanism Most tactical mechanisms are 3D-printed out of durable filaments like PETG, Polycarbonate, or TPU. They usually rely on a single carbon-fiber or steel pin attached to the servo horn, which slides through a loop attached to the payload. When the servo actuates, it pulls the pin out, releasing the loop.

3. Center of Gravity (CG) Constraints

- **Crucial Rule:** The payload must hang *exactly* under the drone's Center of Gravity (usually dead center, right below the flight controller).
- If you mount the payload too far forward or backward, the flight controller will have to heavily overdrive the front or rear motors to keep the drone level. When the payload is dropped, the sudden shift in weight will cause the drone to shoot upward or flip violently out of control.

Phase 2: Wiring and Power Management (The Danger Zone)

Servos have three wires:

1. **Ground** (Brown/Black)
2. **5V Power** (Red)
3. **PWM Signal** (Orange/Yellow/White)

The 5V Brownout Risk (Correction/Warning): The most common mistake engineers make is wiring the servo's 5V power wire directly to a standard 5V pad on the Flight Controller (FC). Standard FC 5V regulators are usually rated for 1.5A to 2A and are already powering your Receiver, GPS, and sometimes the Camera. If the dropper pin gets stuck, the servo will "stall." A stalling servo pulls a massive spike of current. This will instantly overload the FC's 5V regulator, causing the flight controller to reboot. The drone will fall out of the sky.

The Solution:

- Check your FC specs. Some modern stacks (like the SpeedyBee F405) have a dedicated, high-output BEC (Battery Eliminator Circuit) specifically rated for servos/LEDs at 3A+.
- If your FC does not have a high-amp BEC, you must install an **External 5V BEC**. Wire the external BEC directly to the battery pads, and use it to power the servo's Red wire.

Wiring the Signal: Wire the Orange/Yellow signal wire to an unused pad on the FC. Because it is a quadcopter, you are only using Motor pads 1 through 4. Solder the servo signal wire to **Motor Pad 5 (M5)**, **Motor Pad 6 (M6)**, or the **LED pad**.

Phase 3: Betaflight Configuration

Betaflight is designed for racing, not servos, so you have to "trick" the software into sending a radio signal to a motor pad. This is done via the CLI (Command Line Interface).

Step 1: Resource Remapping Let's assume you soldered the servo signal to the M5 pad.

1. Go to the **CLI Tab** in Betaflight.
2. Type `resource` and hit Enter. Look for `MOTOR 5` in the list and note its hardware ID (e.g., `B03`).
3. Type: `resource MOTOR 5 none` (This frees the pad).
4. Type: `resource SERVO 1 B03` (This tells the FC that pad B03 is now a servo).
5. Type: `save` and hit Enter. The FC will reboot.

Step 2: Enable Servos

1. Go to the **Configuration Tab**.
2. Toggle on the switch for **Channel Forwarding** or **SERVO_TILT** (depending on your Betaflight version). Save and reboot.

Step 3: Assigning the Switch

1. Go to the **Servos Tab**.
2. Check the box to map `Servo 0` (which is what Betaflight calls Servo 1) to an AUX channel from your radio (e.g., AUX 3).
3. **Set Endpoints:** Adjust the Min and Max sliders. *Do not let the servo travel further than the physical dropper mechanism allows.* If the servo tries to push past its physical limit, it will stall and burn out.

Phase 4: Tactical Radio Setup & Failsafes

Your drone is now mechanically able to drop payloads, but the radio configuration determines if it is safe to use.

1. The "Safety" Switch Do not put the dropper on a switch you can easily bump. Use a momentary switch (a switch that springs back to its original position when you let go) or a two-stage switch.

2. Configuring the Failsafe (CRITICAL) If your drone loses radio signal from the controller, Betaflight enters Failsafe mode.

- By default, Betaflight might center all AUX channels or drop them to their lowest value.

- If your failsafe alters the dropper's AUX channel, the drone will automatically release the payload the second it loses signal — which means it could drop an explosive on friendly positions or right above your own head if the signal drops on takeoff.
- **The Fix:** Go to the **Failsafe Tab** in Betaflight. Find your dropper channel (e.g., AUX 3) and set its failsafe behavior to **Hold**. This ensures the mechanism stays locked in its current position if the signal is lost.