SIMCom

SIM7020 Series LWM2M Application Note

Version: 1.1
Release Date: April 19, 2018

Simplify Communication.
www.simcomm2m.com

About Document

Document Information

Document	
Title	SIM7020 Series LWM2M Application Note
Version	1.1
Document Type	Application Note
Document Status	Released/Confidential

Revision History

Revision	Date	Owner	Status / Comments
1.0	April 10, 2018	Linshu Guan	First Release.
1.1	April 19, 2018	Albert Meng	Revised

Related Documents

[1] SIM7020 Series AT Command Manual V1.0.pdf

This document applies to the following products:

Name	Type	Size (mm)	Comments
SIM7020C	NB1	17.6*15.7	Band 1/3/5/8
SIM7020E	NB1	17.6*15.7	Band 1/3/5/8/20/28

Copyrights

Contents

1 Purpose of this document

Based on module AT command manual, this document will introduce LWM2M application process.

Developers could understand and develop application quickly and efficiently based on this document.

2 Bearer Configuration

Usually module will register PS service automatically.

2.1 PDN Auto-activation

AT Command	Response	Description
AT+CPIN?	+CPIN:READY OK	Check SIM card status
AT+CSQ	+CSQ: 20,0 OK	Check RF signal
AT+CGREG?	+CGREG: 0,1 OK	Check PS service
AT+CGACT?	+CGACT: 1,1 OK	Activated automatically
AT+COPS?	+COPS: 0,0,"CHN-UNICOM",9 OK	Check operator info CHN-UNICOM is operator's name 9 is NB-IOT network
AT+CGCONTRDP	+CGCONTRDP: 1,5,"shnbiot","10.250.0.213.255.255.255.0" OK	Get APN and IP address from network

2.2 APN Manual configuration

If not attached, could configure correct APN setting.

AT Command	Response	Description
AT+CFUN=0	+CPIN: NOT READY OK	Disable RF
AT*MCGDEFCONT="IP","3GNET"	OK	Configure new APN
AT+CFUN=1	OK +CPIN: READY	Enable RF
AT+CGREG?	+CGREG: 0,1 OK	Inquiry PS service
AT+CGCONTRDP	+CGCONTRDP: 1,5,"3GNET","10.250.0.253.255.255.255.0" OK	Attached PS domain and got IP address automatically

3 LWM2M Service

AT Command	Response	Description
AT+CLMCONF="182.150.27.21","5683","1222","sim7020test","IPv4",100	+CLMCONF: 0 OK	Create LWM2M connection. If succeed, LWM2M server instance id will return
AT+CLMADDOBJ=0,5,2,8,0,1,2,3,4,5,6,7	OK	Create object
AT+CLMDELOBJ=0,5	OK	Delete object
	+CLMREAD: 0,5,2,1,1	Got READ message
AT+CLMREAD=0,5,2,1,1,"S",5,"abcde"	OK	Read
	+CLMWRITE: 0,5,2,1,1,"S",4,"abcd"	Got WRITE message
AT+CLMWRITE=0,0	OK	Write
	+CLMEXECUTE: 0,5,2,1,3,"abc"	Got execute message
AT+CLMEXECUTE=0,0	OK	Execute
	+CLMOBSERVE: 0,0,5,2,3 +CLMPARAMETER:0,5,2,3,1,0,200,300,2.0,5.0,1	Got OBSERVE message With parameters
AT+CLMNOTIFY=0,5,2,3	OK	Notify configuration
AT+CLMDEL=0	OK	Disconnect and delete instance

Contact

Headquarters

Add: Building A, No.633 Jinzhong Road, Changning District, Shanghai P.R.China 200335

Tel: +86 21 3252 3424

Fax: +86 21 3252 3020

Email: simcom@sim.com

Technical Support

EMEA	APAC	America
West Europe we-support@sim.com	**ASEAN** asean-support@sim.com	**North America** us-support@sim.com
East Europe ee-support@sim.com	**Australia and New Zealand** anz-support@sim.com	**Central and South America** la-support@sim.com
Middle East me-support@sim.com	**Big China** China-support@sim.com	
Africa af-support@sim.com		