HC12 Assembly Language Programming

Programming Model

Addressing Modes

Assembler Directives

HC12 Instructions

Flow Charts

Assembler Directives

- In order to write an assembly language program it is necessary to use *assembler directives*.
- These are not instructions which the HC12 executes but are directives to the assembler program about such things as where to put code and data into memory.
- All of the assembler directives can be found in Pages 46 through 49 of the manual for the evaluation version of the Cosmic Compiler. A PDF version of this manual can be found on the EE 308 home page.
- We will use only a few of these directives. (Note: In the following table, [] means an optional argument.) Here are the ones we will need:

Directive Name	Description	Example		
equ	Give a value to a symbol	len:	equ	100
org	Set starting value of location counter		org	\$0800
	where code or data will go			
section	Define a new program section	CODE:	section	.text
	For example, code or data			
dc[.size]	Allocate and initialize storage	var:	dc.b	2,18
	for variables. Size can be b (byte),			
	w (two bytes) or 1 (4 bytes)			
	If no size is specified, b is uses			
ds[.size]	Allocate specified number of	table:	ds.w	10
	storage spaces. size is the same			
	as for dc directive			

Using labels in assembly programs

A **label** is defined by a name followed by a colon as the first thing on a line. When the label is referred to in the program, it has a numerical value of the location counter when the label was defined.

Here is a code fragment using labels and the assembler directives dc and ds:

```
DATA: section .data ;The stuff which follows is data org $0900 table1: dc.b $23,$17,$f2,$a3,$56 table2: ds.b 5 var: dc.w $43af
```

Here is the listing from the assembler:

```
9
                         DATA:
                                    section .data
                                                       ;The stuff w
10
    0900
                                             $0900
                                    orq
                                             $23,$17,$f2,$a3,$56
11
    0900 2317f2a356
                         table1:
                                    dc.b
12
    0905 0000000000
                         table2:
                                    ds.b
                                             5
13
    090a 43af
                                    dc.w
                                             $43af
                         var:
```

And here is the map file:

```
Map of demo.h12 from link file demo.lkf - Thu Jan 25 09:56:12 2
```

```
table1 00000900
table2 00000905
var 0000090a
```

Note that, table1 is a name with the value of \$0900, the value of the location counter defined in the org directive. Five bytes of data are defined by the dc.b directive, so the location counter is increased from \$0900 to \$0905. table2 is a name with the value of \$0905. Five bytes of data are set aside for table2 by the ds.b 5 directive. The Cosmic assembler initialized these five bytes of data to all zeros.

HC12 Assembly Language Programming

Programming Model

Addressing Modes

Assembler Directives

HC12 Instructions

Flow Charts

1. Data Transfer and Manipulation Instructions — instructions which move and manipulate data (**CPU12 Reference Manual**, Sections 5.2, 5.3, and 5.4).

• Load and Store — load copy of memory contents into a register; store copy of register contents into memory.

```
LDAA $0900 ; Copy contents of addr $0900 into A STD 0,X ; Copy contents of D to addrs X and X+1
```

• Transfer — copy contents of one register to another.

```
TBA ; Copy B to A TFR X Y ; Copy X to Y
```

• Exhange — exchange contents of two registers.

```
XGDX ; Exchange contents of D and X EXG A B ; Exchange contents of A and B
```

• Move — copy contents of one memory location to another.

```
MOVB $0900 $09A0 ; Copy byte at $0900 to $09A0

MOVW 2,X+ 2,Y+ ; Copy two bytes from address held

; in X to address held in Y

; Add 2 to X and Y
```

2. Arithmetic Instructions — addition, subtraction, multiplication, divison (**CPU12 Reference Manual**, Sections 5.5, 5.6, 5.7 5.11).

```
ABA ; Add B to A; results in A

SUBD $09A1 ; Subtract contents of $09A1 from D

INX ; Increment X by 1

MUL ; Multiply A by B; results in D
```

- 3. Logic and Bit Instructions perform logical operations (**CPU12 Reference Manual**, Sections 5.9, 5.10, 5.12, 5.13).
 - Logic Instructions

```
ANDA $0900; Logical AND of A with contents of $0900
NEG -2,X; Negate (2' comp) contents of address (X-2)
LSLA; Logical shift left A by 1
```

• Bit manipulate and test instructions — work with one bit of a register or memory.

```
BITA #$08 ; Check to see if Bit 4 of A is set BSET $0002,#$18 ; Set bits 3 and 4 of address $002
```

4. Data test instructions — test contents of a register or memory (to see if zero, negative, etc.), or compare contents of a register to memory (to see if bigger than, etc.) (**CPU12 Reference Manaul**, Section 5.7).

```
TSTA ; (A)-0 -- set flags accordingly CPX #$8000 ; (X) - $8000 -- set flags accordingly
```

5. Jump and Branch Instructions — Change flow of program (e.g., goto, it-thenelse, switch-case) (**CPU12 Reference Manual**, Sections 5.18, 5.19, 5.20).

```
JMP 11 ; Start executing code at address label 11 BEQ 12 ; If Z bit zero, go to label 12 DBNE X 13 ; Decrement X; if X not 0 then goto 13 BRCLR $1A, #$80 14 ; If bit 7 of addr $1A set, goto 14
```

- 6. Function Call and Interrupt Instructions initiate or terminate a subroutine; initiate or terminate and interrupt call (**CPU12 Reference Manual**, Sections 5.20, 5.21).
 - Subroutine instructions:

```
JSR sub1 ; Jump to subroutine sub1 RTS ; Return from subroutine
```

• Interrupt instructions

```
SWI ; Initiate software interrupt
```

RTI ; Return from interrupt

7. Stacking Instructions — push data onto and pull data off of stack (**CPU12 Reference Manual**, Section 5.23).

PSHA ; Push contents of A onto stack

PULX ; Pull two top bytes of stack, put into X

8. Stop and Wait Instructions — put HC12 into low power mode (**CPU12 Reference Manual**, Section 5.26).

STOP ; Put into lowest power mode

WAI ; Put into low power mode until next interrupt

9. Instructions we won't discuss or use — BCD arithmetic, fuzzy logic, minimum and maximum, multiply-accumulate, table interpolation (**CPU12 Reference Manual**, Sections 5.6, 5.14, 5.15, 5.16, 5.17).

Branch if A > B

```
Is 0xFF > 0x00?
```

If unsigned, 0xFF = 255 and 0x00 = 0, so 0xFF > 0x00

If signed, 0xFF = -1 and 0x00 = 0, so 0xFF < 0x00

Using unsigned numbers: BHI (checks C bit of CCR)

Using signed numbers: BGT (checks V bit of CCR)

For unsigned numbers, use branch instructions which check C bit For signed numbers, use branch instructions which check V bit

Will the branch be taken?

LDAA	#\$FF	LDAA	#\$FF
CMPA	#\$0	CMPA	#\$0
BLO	label1	BLT	label2

LDX	#\$C000	LDX	#\$C000
CMPX	#\$8000	CMPS	#\$8000
BGT	label3	BHI	label4