
Maintenance Job Planning/Estimating Worksheet									
Planner: WO#:				Date:					
Job Contact: Location:			Asset ID#:						
Job Desc		This job plan is to guide you on dete	rmining which ve	rsion firmwar	e is present o				
Job Scope									
Job Plan Seq.		Task Description	Task Duration	Number of Resources Required	Total Estimated Labor Hours	Estimated Labor			
PLEASE READ									
DG1's come with three main firmware versions, V34, V35, and V36. V34 and V35 are compatible with each other, but V36 IS NOT . There is an internal hardware change in the drive that prevents V36 firmware from working with V34/V35 drives, and V34/V35 firmware from working on a V36 drive. Due to this, the standard firmware going forward will be V35 and V36 . Below is a chart to help determine which version firmware you have.									
	Firm	ware Version and File Na	ıme	Internal Drive Parameter Firmware Name (Parameter #: P21.2.2/3)					
	V24 F	irrayyaya (fila namay DC4, C0004N/00	224)	24 22 2000					
	V34 F	irmware (file name: DG1_C0034/V00	134)	01.03.XXXX or C0034					
V35 Firmware (file name: DG1_C0035-ETN/V0035-ETN)				02.00.XXXX or C0035-ETN					
V36 Firmware (File name: DG1_C36.05/V36.05)				02.01.XXXX or V36.05					
		Determini	ng Firmware Vei	rsion using t	he DG1 Key	pad			
0	Using th	e keypad buttons click on "MENU"				IRUN EMD DC-link Ut References Hotor Curr 17	I SUSI FROM 1014a1 622 U 114551.991721 eent: 4.5 A 72:34 MENU		
10	Para	e keypad buttons navigate to the "P: meters" option and press "OK"				EGURU III hi: Honsi F: Faul BACK REDE	tor		



Determining Firmware Version using Power Xpert InControl Software

Connect to the DG1 using a laptop with the required firmware installed, and the DG1 0 Ethernet to USB cable from Eaton.		
Connect to the DG1 using a laptop with the required firmware installed, and the DG1 0 Ethernet to USB cable from Eaton.	P20: Communication P21: System	
Connect to the DG1 using a laptop with the required firmware installed, and the DG1 0 Ethernet to USB cable from Eaton.	P21: System	
required firmware installed, and the DG1 0 Ethernet to USB cable from Eaton. 0.00	P21: System	
, , , , , , , , , , , , , , , , , , ,	P21: System	
Once connected payingte to parameter	P21.3: Application Info P21.4: User Info Optional Boards	
PowerXLOG1		
Open "P21.2: Version Info", look at parameter "P21.2.2/3/4". This is the current firmware version.		
Total Job Plan Duration: 0.00 Total Backlog Labor Hours:	Hours: 0.00	
Materials Required		
Seq# Material Description/Specification Quantity Price/Unit Total Cos		
\$0.00 \\$ \$0.00 \\$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \$	-	
\$0.00 \\$	-	
	-	
\$	-	
Total Material Cost: \$	-	

Additional Comments:	Permits: Confined Space Entry Hot Work X Lockout/Tagout PPE: Safety Glasses, Safety Shoes, Gloves						
Additional Comments:							
Special Tools Needed: Laptop, Eaton DG1 Ethernet to USB cable							

(Insert Job Site Photos)