

Fprint DLL - developers guide for Albanian devices

Functions.....	2
OPEN_PORT.....	2
OPEN_PORT_Ext.....	2
CLOSE_PORT.....	3
OPEN_TCPIP.....	3
OPEN_TCPIP_Ext.....	3
CLOSE_TCPIP.....	4
EXECUTE_STRING.....	4
EXECUTE_FILE.....	5
EXECUTE_FILE_Ext.....	5
GET_SERIAL_NUMBER.....	6
GET_SERIAL_NUMBER_Ext.....	6
GET_SERIAL_NUMBER_TCPIP.....	7
GET_LAST_ERROR.....	8
GET_LAST_ERROR_MESSAGE.....	8
GET_LAST_ERROR_MESSAGE_Ext.....	8
Device indexes.....	9
Errors - active keyboard ECRs.....	10
Errors - devices without active keyboard.....	10

Fprint DLL - developers guide

{document version 3.1.4.97; program version 3.1.4.97}

Functions

OPEN_PORT	
Syntax	<pre>function OPEN_PORT(ComPort : byte; BaudRate : integer; StopBits : byte; Parity : byte; ByteSize : byte; DEVICE_INDEX : integer; Logical_number : integer; SERIAL_KEY : WideString) : integer; stdcall;</pre>
Description	Opens the serial port. Returns current status of the device, specified by the DEVICE_INDEX.
Parameters	ComPort : byte; - defines serial port number BaudRate : integer; - defines port speed StopBits : byte; - serial port setting Parity : byte; - serial port setting ByteSize : byte; - serial port setting DEVICE_INDEX : integer; - list of devices: Logical_number : integer; - network/logical number of the device SERIAL_KEY – this is the key (given by our resellers when you purchase this DLL or FPrint) that corresponds to the serial number of your device.
Return values	Return codes
OPEN_PORT_Ex	
Syntax	<pre>function OPEN_PORT(ComPort : byte; BaudRate : integer; StopBits : byte; Parity : byte; ByteSize : byte; DEVICE_INDEX : integer; Logical_number : integer; SERIAL_KEY : PByteArray) : integer; stdcall;</pre>

CLOSE_PORT	
Syntax	function CLOSE_PORT : integer;stdcall;
Description	Closes the serial port and destroys the current device object
Parameters	none
Return values	Return codes
OPEN_TCPIP	
Syntax	function OPEN_TCPIP(IP_Address : WideString; TCP_Port : integer; DEVICE_INDEX : integer; SERIAL_KEY : WideString) : integer; stdcall;
Description	Opens a socket connection, defined by the IP and Port of the device. Returns current status of the device, specified by the DEVICE_INDEX.
Parameters	IP_Address : WideString; - IP address of the device (eg. 192.168.0.1) TCP_Port : integer; - the port number of the device DEVICE_INDEX : integer; - list of devices : SERIAL_KEY – this is the key (given by our resellers when you purchase this DLL or FPrint) that corresponds to the serial number of your device.
Return values	Return codes
Notes	Currently this function works with FP2000 only. Use DEVICE_INDEX = 1008 (TCPIP interface)

OPEN_TCPIP_Ex	
Syntax	function OPEN_TCPIP(IP_Address : WideString; TCP_Port : integer; DEVICE_INDEX : integer; SERIAL_KEY : PByteArray) : integer ; stdcall ;

CLOSE_TCPIP	
Syntax	function CLOSE_TCPIP : integer ; stdcall ;
Description	Closes the socket connection and destroys current device object.
Parameters	none
Return values	Return codes
Notes	Currently this function works with FP2000 only.

EXECUTE_STRING	
Syntax	function EXECUTE_STRING(var Execute_Value : Widestring) : integer ;stdcall;
Description	Sends one command string to the device. The format of the strings and commands is described in the FPrint manual
Parameters	Execute_Value : Widestring – the string to be executed - one command only. See the Fprint documentation for detailed description of the commands.
Return values	Return codes
	<u>NOTE:</u> In firmware version "75.x1.13 / 28.05.2009" for Albanian devices DP500, DP50D, MP55LD, commands Y and P will return that the command has not succeeded (11,12,13) even if the ECR prints the texts. This is known firmware bug and pending a fix in next firmware versions.

EXECUTE_FILE	
Syntax	function EXECUTE_FILE(Execute_file_name, Answer_file_name : WideString; Dos_text : boolean; ClassicAnswer : boolean) : integer ;stdcall;
Description	Executes the commands within a file (Fprint format) and saves the answer for each command in answer file. See the Fprint documentation for detailed description of the commands.
Parameters	Execute_file_name : WideString – file name of the file to be printed Answer_file_name : WideString – answer file (if you dont pass file name, the answer is saved in the execute_file_name) Dos_text : boolean; if true - converts chars (0x80 - 0xBF) into letters (0xC0 – 0xFF); useful if you pass DOS generated strings to the device ClassicAnswer : boolean; specifies the type of answer (status) in the answer file – see Fprint documentation; if true – Classic answer, if false – Error number
Return values	Return codes

EXECUTE_FILE_Ex	
Syntax	function EXECUTE_FILE(Execute_file_name, Answer_file_name : PByteArray; Dos_text : boolean; ClassicAnswer : boolean) : integer ;stdcall;

GET_SERIAL_NUMBER

Syntax	<pre>function GET_SERIAL_NUMBER(ComPort : byte; BaudRate : integer; StopBits : byte; Parity : byte; ByteSize : byte; DEVICE_INDEX : integer; Logical_number : integer; var SERIAL_NUMBER : WideString) : integer; stdcall;</pre>
Description	Retrieves serial number for a device.
Parameters	ComPort : byte; - defines serial port number BaudRate : integer; - defines port speed StopBits : byte; - serial port setting Parity : byte; - serial port setting ByteSize : byte; - serial port setting DEVICE_INDEX : integer; - list of devices; Logical_number : integer; - network/logical number of the device; SERIAL_NUMBER : WideString – output parameter, the serial number is stored here
Return values	Return codes

GET_SERIAL_NUMBER_Ex

Syntax	<pre>function GET_SERIAL_NUMBER(ComPort : byte; BaudRate : integer; StopBits : byte; Parity : byte; ByteSize : byte; DEVICE_INDEX : integer; Logical_number : integer; var SERIAL_NUMBER : PByteArray) : integer; stdcall;</pre>
---------------	--

GET_SERIAL_NUMBER_TCPIP

Syntax	<pre>function GET_SERIAL_NUMBER_TCPIP(IP_Address : WideString; TCP_Port : integer; DEVICE_INDEX : integer; var SERIAL_NUMBER : WideString) : integer; stdcall;</pre>
Description	Retrieves serial number for a device, connected over TCP_IP.
Parameters	IP_Address : WideString; - IP address of the device (eg. 192.168.0.1) TCP_Port : integer; - the port number of the device DEVICE_INDEX : integer; - list of devices: SERIAL_KEY – this is the key (given by our resellers when you purchase this DLL or FPrint) that corresponds to the serial number of your device.
Return values	Return codes
Notes	Currently this function works with FP2000 only. Use DEVICE_INDEX = 1008 (TCPIP interface)

GET_LAST_ERROR

Syntax	function GET_LAST_ERROR : integer; stdcall
Description	Returns the result code of the last executed function
Parameters	none
Return values	Return codes

GET_LAST_ERROR_MESSAGE

Syntax	function GET_LAST_ERROR_MESSAGE : WideString; stdcall;
Description	Returns message, corresponding to the last result code
Parameters	none
Return values	Return codes

GET_LAST_ERROR_MESSAGE_Ex

Syntax	function GET_LAST_ERROR_MESSAGE : PByteArray; stdcall;
Description	Returns message, corresponding to the last result code
Parameters	none
Return values	Return codes

Device indexes

INDEX	DEVICE
Albania	
1000	DT 50D with active keyboard (table2, field 8 is with value 3)
1001	DP 500 with active keyboard (table2, field 8 is with value 3)
1002	MP 55LD with active keyboard (table2, field 8 is with value 3)
1003	FP 550
1004	MP 55L with active keyboard (table2, field 8 is with value 3)
1005	DP 50 with active keyboard (table2, field 8 is with value 3)
1006	MP 55B with active keyboard (table2, field 8 is with value 3)
1007	FP 2000 with RS232 communication interface
1008	FP 2000 with TCP IP communication interface
1009	DP 25
1010	WP 50

VALUE	MEANING
Errors - active keyboard ECRs	
14	Error, the last command not executed
13	Status number: - the last command was not executed; - the keyboard is unlocked and only "H","F" commands accepted;
12	Status number: - the last command was not executed; - the keyboard is locked;
11	Status number: - the last command was not executed; - the keyboard is locked; - open receipt;
10	ECR is not in active keyboard mode (table 2,row 8,value 3). The DLL operates only in this mode.
>	NOTE: messages 11,12,13,14 are always returned when the last command (except for "H" and "F") was not executed, but the input parameters are correct.
4	Status number: - the last command successfully executed; - the keyboard is locked; - open receipt;
3	Status number: - the last command successfully executed; - the keyboard is locked;
2	Status number: - the last command was successfully executed; - the keyboard is unlocked and only "H","F" commands accepted;
1	Status number: - Successful "H" or "F" command; - Input parameters for all commands (not "H" , "F") are correct;
-1 till -9	Device communication exceptions (generally you get those from device turned off or not in REG mode)
-100	Wrong input parameters or the keyboard is unlocked
-101 till -113	Class exceptions due to wrong parameters/bugs
Errors - devices without active keyboard	
-40 till -46	Device communication exceptions, check if the device is on.

-50	The printer is out of paper.
-51	General/syntax error – could be one of the following: - command returned error while executing; - command syntax error or invalid cmd number; - RAM failiure after power ON; - operational memory was cleared;
-52	Incorrect command number in the string
-53	Opened fiscal receipt, command not allowed
-54	Opened nonfiscal receipt, command not allowed
-55	No opened receipt, command not allowed
-56	Fiscal memory full
-57	Fiscal memory error (read/write failed/corrupt, memory in read-only state or last entry is corrupt)
-58	Command cannot be executed in current fiscal mode
-59	Ram reset after powering the device
-60	Incoming data has syntax error or wrong command number
-61	Failure in the printing mechanism
-62	Fiscal memory is in read only mode
-63	Tax terminal not responding
-64	Electronic journal is full
-201 till -220	Class exceptions due to wrong parameters/bugs
0	No errors or exceptions
-10000	Wrong logical number, check your string or file
-10001	Function "EXECUTE_FILE" - execute file does not exist
-10002	Function "EXECUTE_FILE" - wrong file format. Something is wrong in the string within the file – check Fprint documentation for help about the commands structure.
-10003	Function "OPEN_TCPIP" - wrong IP address string
-100000	Function "OPEN_PORT" – the serial key is wrong
-5000	Exception in "OPEN_PORT" function - check your parameters
-5001	Exception in "EXECUTE_STRING" function - check your parameters
-5002	Exception in "EXECUTE_FILE" function - check your parameters
-5003	Exception in "CLOSE_PORT" function
-5004	Exception in "GET_SERIAL_NUMBER" function - check your parameters
-5005	Exception in "GET_SERIAL_NUMBER_TCPIP" function - check your parameters
-5006	Exception in "OPEN_TCPIP" function - check your parameters

-5007	Exception in "CLOSE_TCPIP" function
--------------	-------------------------------------