Coffee Grinder: General User Guide

1. Safety

- Unplug the grinder before cleaning, assembling, or disassembling it.
- Never put the base or motor unit in water.
- Keep hands and utensils away from moving parts.
- Use only whole coffee beans. Don’t grind ice, nuts, spices with high oil content, or anything hard like rice.
- Keep the appliance out of reach of children and away from heat sources.
- Don’t use the grinder if the cable, plug, or housing is damaged.

2. Before First Use

1. Check that all parts are present and undamaged.
2. Wash removable parts (bean hopper, lid, grounds container) in lukewarm water with mild detergent. Dry them completely.
3. Wipe the housing with a damp cloth.
4. Don’t wash the grinding burrs or blades. Keep them dry and clean them with a brush.

3. Basic Operation

1. Place the grinder on a flat, stable surface near a power outlet.
2. Make sure the hopper is correctly seated and the grounds container is in place.
3. Fill the hopper with the amount of beans you need. Don’t overfill.
4. Choose a grind size (see section 4).
5. Plug in the grinder and start it using the power or grind button.
6. Stop grinding when you have enough, or let an automatic timer finish.
7. Remove the container, tap it gently to settle the grounds, and use them right away.

4. Choosing the Grind Size

Brewing method	Grind size
Espresso, moka pot	Fine
Pour-over, drip machine	Medium
French press, cold brew	Coarse

- If coffee tastes **bitter or harsh**, the grind is probably too fine. Make it coarser.
- If coffee tastes **sour or weak**, the grind is probably too coarse. Make it finer.
- Adjust in small steps and change one thing at a time.
- If your grinder adjusts while running, change the setting only while it is on.

5. Tips for Better Coffee

- Grind just before brewing. Ground coffee loses aroma quickly.
- Store beans in an airtight container, away from light, heat, and moisture.
- Grind only what you need. Store any leftover grounds airtight.
- Avoid long continuous grinding. If you grind several times in a row, let the motor rest.
- Use a consistent amount of coffee for repeatable results. A kitchen scale helps.

6. Cleaning and Maintenance

1. Unplug the grinder.
2. Empty the hopper and the grounds container.
3. Remove any removable parts and wash them as described in section 2.
4. Brush the grinding chamber and burrs to remove grounds and fine powder.
5. Use a vacuum cleaner with a narrow nozzle to remove stubborn residue.
6. Reassemble only when all parts are fully dry.
7. Clean regularly, and more often if you switch between coffee types or grind oily beans.

7. Troubleshooting

Problem	Possible cause	Solution
Grinder won’t start	Not plugged in, or hopper/container not seated properly	Check the plug and reseat all parts
Grinder stops during use	Motor overheated	Unplug, let it cool for 15–30 minutes
Very little coffee comes out	Hopper empty, clogged chamber, or worn burrs	Refill, clean the chamber, replace burrs if worn
Grounds are uneven	Dirty or worn burrs	Clean thoroughly, replace burrs if needed
Grinder is unusually loud	Foreign object in the chamber	Unplug and inspect, remove the object
Grounds clump or stick	Static or humidity	Lightly tap the container, keep beans and grinder dry

8. Storage and Disposal

- Store the grinder clean and dry.
- Wind the cable loosely, without kinking it.
- Dispose of the appliance at a local electronics recycling point. Don’t put it in household waste.