

#	Status	Pin	Pin Label	GPIO	Purpose	Pull-Up/Down	Config.
1	Busy	4	SENSOR_VP	GPIO36	RFID_MISO		Input
2	Busy	5	SENSOR_VN	GPIO39	QR_RX		Input
3	Busy	6	IO34	GPIO34	RS485_RX		Input
4	Busy	7	IO35	GPIO35	RFID_IRQ		Input
5	Busy	8	IO32	GPIO32	TSM_SDA		IN/OUT
6	Busy	9	IO33	GPIO33	TSM_SCL		IN/OUT
7	Busy	10	IO25	GPIO25	QR_TX		Output
8	Busy	11	IO26	GPIO26	RS485_TX		Output
9	Busy	12	IO27	GPIO27	TSM_OUT		Input
10	Busy	13	IO14	GPIO14	TSM_INT		Input
11	Busy	14	IO12	GPIO12	BUZZER-En	Pull-Down	Output
12	Busy	16	IO13	GPIO13	ShiftReg-Latch2		Output
13	Busy	17	SHD/SD2	GPIO9			
14	Busy	18	SWP/SD3	GPIO10			
15	Busy	19	SCS/CMD	GPIO11			
16	Busy	20	SCK/CLK	GPIO6			
17	Busy	21	SDO/SD0	GPIO7			
18	Busy	22	SDI/SD1	GPIO8			
19	Busy	23	IO15	GPIO15	RFID_SCK	Pull-Up	Output
20	Free	24	IO2	GPIO2		Pull-Down	
21	Busy	25	IO0	GPIO0	RFID_CS	Pull-Up	Output
22	Busy	26	IO4	GPIO4	ShiftReg-Clock		Output
23	Busy	27	IO16	GPIO16	ShiftReg-Data		Output
24	Busy	28	IO17	GPIO17	ShiftReg-Latch1		Output
25	Busy	29	IO5	GPIO5	RFID_MOSI	Pull-Up	Output
26	Busy	30	IO18	GPIO18	RS485_DE		Output
27	Busy	31	IO19	GPIO19	DIGITAL_INPUT1		Input
28	Busy	33	IO21	GPIO21	DIGITAL_INPUT2		Input
29	Busy	34	RXD0	GPIO3			Input
30	Busy	35	TXD0	GPIO1			Output
31	Busy	36	IO22	GPIO22	Wiegand-D0		Output
32	Busy	37	IO23	GPIO23	Wiegand-D1		Output

Reason	74HC595-1	Purpose
Input only GPIO, cannot be configured as output	QA	LED_EN_1
Input only GPIO, cannot be configured as output	QB	LED_EN_2
Input only GPIO, cannot be configured as output	QC	LED_EN_3
Input only GPIO, cannot be configured as output	QD	LED_EN_4
	QE	LED_EN_5
	QF	LED_EN_6
	QG	LED_EN_7
	QH	LED_EN_8
	74HC595-2	
	QA	LED_EN_9
must be LOW during boot	QB	LED_EN_10
	QC	LED_EN_11
Connected to Flash memory	QD	LED_EN_12
Connected to Flash memory	QE	WiFi_LED_EN
Connected to Flash memory	QF	Status_LED_EN
Connected to Flash memory	QG	RELAY1
Connected to Flash memory	QH	TSM_RST
Connected to Flash memory		
must be HIGH during boot, prevents startup log if pulled LOW		
must be LOW during boot and also connected to the on-board LED		
must be HIGH during boot and LOW for programming		
must be HIGH during boot		
Rx pin, used for flashing and debugging		
Tx pin, used for flashing and debugging		

[illegible]