CGOLDENWALL

Instruction manual

Electronic Balance



- Experiment analysis
- Medicinal weighing
- Jewelry weighing

Catalogue

Analytical Electronic Balance

A01 Common Question

We have summed up some common questions that our customers encountered before and listed their solutions.
If your question is not listed, please CONTACT US and we will give you a satisfied solution.

A02 Overview

A brief introduction of our scale is explained in this part.

A03 Operation

Detailed operation instruction is introduced in this part.
If any question while using, please CONTACT US.
We will reply to you asap.

A04 other products

We have multiple kinds of scales including 0.1g, 0.01g, 0.001g and 0.1mg scales.

The following content is the common problems and questions that our customers encountered before.
Please read carefully before use.

If any problem occurs during use, please **CONTACT US FIRST**. We promise we will help you solve them and give you a satisfied solution.

Notice: All of our scales has already been calibrated and are ready for use!
If the scale get inaccurate after some time of use, please calibrate it following the instructions.

Scan the following QR code or enter the YouTube link to watch the instruction video about how to install the plate, how to count and calibrate.

YouTube link: https://youtu.be/-6Oh13s75wg

How to contact us?

You can contact us through Amazon or service email or Whatsapp.
Service email: sunflowersmile20130401@hotmail.com
Facebook:Mary Cgoldenwall
WhatsApp:+8613758246804

I. Common Questions

(1) Q: What to do if the scale get inaccurate after some time of use?
A: Please calibrate it according to the instruction. (see in (4))

(2) Q: Why the reading is always fluctuating and it can't set zero or get a sable weighing results?
A: Please check whether your under-plate is installed reversed. The incorrect installation will cause fluctuating reading.
See in part 1, how to install the under-plate correctly.

(3) Q: Why the 5000g scale is without calibration weights?
A: This lab scale with range from 200g-3000g all has calibration weights except 5000g. Because the 5000g scale needs 2000g calibration weights, which is too heavy and might damage the scale during international shipment. If you need calibration weights, you can purchase on Amazon easily.
Here is the link of 2kg calibration weights:
https://www.amazon.com/2000g-Calibration-Weight-Chrome-Scales/dp/B 07SY8FV32/

(4) Q: How to calibrate?
A: Take the 1000g scale for example, please choose the correct weights according to the scale display.
The following is one point calibration step:
1.Press and hold "CAL" until the scale displays "CAL"
2.Put the 500g calibration weights when the balance displays twinkles 500g.Remove the calibration after stabilization.If the scale displays "0.00", it is finished.
(Friendly remind:Please kindly make sure that you place the balance on a smooth and steady table and adjust the four black screws at the button to make it stable.)

(5) Q: Why the panel display like the following picture and then shut down?



A: It means that the scale is out of power now.
If you have powered it by battery, please change battery. If you power the scale by power cord, then the cord may be damaged. Please check it by trying to power it by battery first. If the scale can work properly with the battery, then it's the power cord problem. Please contact us and we will help you free replace the power cord within one year.
You can also purchase power cord from us if it's out of one year warranty.

(6) Q: What should I do if some accessories like connection screws/power cable are lost or damaged within one year?
A: Please CONTACT US FIRST. We will free replace or resend them to you.

(7) Q: What to do if the scale does not go to zero after weighing?
A: 1. If it can't return to ZERO before weighing, press TARE/ZERO button to return to zero.
2. If it can't return to ZERO after weighing. Please check whether it is overload and calibrate it following the instruction.

(8) Q：How to tare the container weight?
A: 1. Start the scale and wait it until it displays 0.0 or 0.00 or 0.000.
2. Put the container on the weighing pan and press TARE button to subtract the container weight.
3. Tare finished and you can start weighing.

Part 1 Under-plate Pan Installation





If the central part of the pan is dented, then it is installed correctly.





If it is raised, then it is installed incorrectly.

II.Overview and Specification

1. Overview

This analytical electronic balance has the functions of peeling weight, self correcting, memory, counting, fault display and the like. And it features automatic fault detection, over-load alarm, a large easy-to-read digital display, and most importantly fast accurate readings. As the advantages of accurate weighing, fast stability, simple operation and complete function, and is suitable for rapidly determining the quality and quantity of objects in industry, agriculture, commerce, school, scientific research and other units.

2. Button Function：



ON/OFF—"ON/OFF"
PCS—"COUNT" key;
TARE— "TARE" key
UNIT—"Unit Conversion" key;
CAL— "Calibration" key
ZERO— "Zero" key

3. Specifications and Performance Indicators

JM series electronic balance is divided into following specifications according to different ranges.

Model	2002	3002	5002	10002	20002	30002	50002	5001	10001	12001	20001
Maximum range	200g	300g	500g	1000g	2000g	3000g	5000g	500g	1000g	1200g	2000g
Resolution	0.01g	0.01g	0.01g	0.01g	0.01g	0.01g	0.01g	0.1g	0.1g	0.1g	0.1g
Verification index	10d	10d	10d	10d	10d	10d	10d	10d	10d	10d	10d
Peeling range	200g	300g	500g	1000g	2000g	3000g	5000g	500g	1000g	1200g	2000g
Calibration weight	200g	200g	500g	500g	1000g	1000g		500g	500g	500g	1000g
Scale size	Φ110		Φ130								
Size	195mm*55mm*260mm										
Power	External power supply(AC110V)，DC9V										
Operating temperature	5~35℃										
Use humidity	50-85%										

III. Operation

1. Prepare for operation

Place the balance on a stable, level table and adjust the leveling feet to make the level bubble in the circle(not necessarily in the center). Avoid vibrations, sunlight,strong airflow, and strong electromagnetic interference.

Connect an external power supply or install a 9V battery.
Press "ON/OFF" button to display 8.8.8.8.","maximum weighing value, "---", "where" --- "The display time depends on the stability of the sensor. Therefore, do not place the balance on the unstable worktable. Finally, the weighing mode “0 or 0.0 or 000” is displayed. If the “O” symbol in the upper left corner shines, the workplace is stable.

2. Calibration Balance

(1)Place the balance on a stable, level table and avoid vibration, sunlight, airflow, and strong electromagnetic interference.

(2)Calibration process
Hold down the "CAL calibration" button without holding any object on the weighing pan. After about 3 seconds, immediately release the

message when "--CAL--" is displayed. Wait until the standard weight value is displayed. ", place the weight of the "standard weight value" that shines on the plate, display "---" waiting state, wait a moment, display "standard weight value", take the weight, the display becomes "---" wait Status, wait, "0 or 0.0 or 0.00" is displayed and the calibration is completed. If the weighing after calibration is still inaccurate, repeat the calibration several times as described above.

(3)Calibration Video
We have record a video how to calibrate of 5000g,0.01g balance for your reference,please kindly check it.
Calibration Video： Scan code (1’30’’ in the video)

Friendly remind: Please kindly make sure the balance steadily. Place the balance on a smooth and steady table and adjust balance through tightening four black screws at the button of the balance.

3. Weighing

(1) After power-on stabilization or calibration, display weighing mode 0 or 0.0 or 0.00”.
(2) Set the weight on the weighing pan, which shows the weight of the item.

4. Tare

(1) Place the container on the weighing pan and the balance shows the quality of the container.
(2) After pressing the "TARE" TARE key, "0.0 or 0.00 or 0.000" is displayed, which means that it has been tared.
(3) Placed in the container, that shows the quality of the object.

5. Balance Counting Operation

(1) Enter to set a single count object average state:
Place the weighing container on the weighing pan and use the container. If you do not need to hold the container, press the “TARE” key to display “0 or 0.0 or 0.00”. Then press the “PCS count” key to display “10”. In the lower right corner, "g to PCS" is displayed, and then 10 objects to be

counted are placed on the weighing pan, and then the "PCS count" key is pressed. The display changes to "---" wait state, and the display changes later. The averaging operation is done for “10”, and the balance can perform the counting operation.(In this operation, the zero point must be: “0 or 0.0 or 0.00”, the weight of a single count must be greater than the balance minimum readable, ie resolution)

6. Balance Unit Conversion Operation

Press “UNIT” unit conversion key. Each press can be displayed in turn, “CT (carat)”, “OZ (ounce)”, “LB” (pound), g, or Kg “(grams or kilograms), according to Users need to display different weighing units. The default value of the balance boot is "g" (grams).

7. Overweight Alarm

When the mass of the object is said to exceed (1+2%) of the value displayed on the display, the horizontal "---" sign indicates that the accumulative item exceeds the specified range, and the scale should be removed immediately, otherwise it will damage the balance.

8. Attention

(1) Before using it should be energized preheating.
(2) The tare weight and the weight of the object must not exceed the weighing range.
(3) If the weighing is not accurate, use standard weights to calibrate the balance.

(4) To remove the weighing pan from the balance, turn the weighing pan clockwise and remove it. Do not push the weighing pan upwards to avoid damaging the sensor.
(5) If there is an error message, please check the table.

Error message	Reason	Treatment
underline —	The weight on the balance is negative	Recalibrate with weights
Upper horizontal line —	Overweight alarm, see Article 10	Recalibrate with weights
ERR-1	Continuous switch caused	Shut down for 3 seconds before booting
ERR-2	Weighing is not stable	Wait a moment
□	Low battery voltage	Change the battery

9. Product standard

Product standard: Electronic GBT 26497-2001

	Pan Size (mm)	Windbreak	Weight	Amazon ASIN	
200g/0.1g	Φ140	×	×	B074PMMNVF	
500g/0.1g	Φ140	×	×	B074PNTTC9	
1000g/0.1g	Φ140	×	×	B074PNWXLX	
2000g/0.1g	180*140	×	×	B074PNH7ZJ	
3000g/0.1g	180*140	×	×	B074PNF8C3	
5kg/0.1g	180*140	×	×	B074PQL6F9	
10kg/0.1g	180*140	×	×	B074PR3FTY	
15kg/0.1g	180*140	×	×	B074PQNWZR	
20kg/0.1g	180*140	×	×	B074Q693FJ	
30kg/0.1g	180*140	×	×	B074PR2QCH	
200g/0.01g	Φ130	√	100g*1	B074QGCR7P	
300g/0.01g	Φ130	√	100g*2	B074Q9V5HQ	
500g/0.01g	Φ130	√	100g*2	B074QCD6MM	
600g/0.01g	Φ130	√	500g*1	B074QHH2N1	
1000g/0.01g	Φ130	√	500g*1	B074QDPPBY	
2000g/0.01g	Φ130	√	500g*2	B074Q9DNXR	
3000g/0.01g	Φ130	√	500g*2	B074QGFJL3	
2000g/0.01g	180*140	×	500g*2	B07CC4QVHL	
3000g/0.01g	180*140	×	500g*2	B07C3Q538F	
5000g/0.01g	180*140	×	×	B074Q9QSF4	
100g/0.001g	Φ110	√	100g*1	B073CHHFDR	
200g/0.001g	Φ110	√	100g*1	B073CFGSZL	
300g/0.001g	Φ110	√	100g*2	B073CCSR7H	
500g/0.001g	Φ110	√	100g*2	B073CFR2FY	

Amazon seller:Great Wall Instruments
Service Email:sunflowersmile20130401@hotmail.com
Facebook:Mary Cgoldenwall
WhatsApp: +8613758246804
Phone: +8613758246804