CALIBER MINING AND LOGISTICS LIMITED · PULSE-II · REPORTS

ELB Reports

Operating manual

For site in-charges, MIS staff and reviewers · Matches the system as of 9 November 2026

1. What this report shows

ELB Reports shows every Equipment Log Book (ELB) entry saved in a batch of one site, one date and one Shift. For each machine it gives the operator, the HMR readings, the working, breakdown and idle hours, and it counts how many machines still have no ELB. MIS users and administrators use it to check the equipment entries of a Shift and to download or print them.

> **One row.** One row is one saved ELB entry: one machine with its operator for the Shift of the chosen batch. A machine has more than one row when more than one ELB was saved for it in the same Shift.

2. Open the report and choose what to see

In the left menu open **Reports** → **ELB Reports**. Then set the selectors described below.

Selector or button	What it does
Find batch	Type part of a batch name, site, date, Shift or batch status. Only matching batches stay in the Operational batch list. The date is matched as year-month-day, for example 2026-11-09. It does not filter the rows of the table.
Operational batch	List of batches of the sites allowed for your login. Batches that are not closed come first, then the newest. Each line reads: batch name · number of ELB · batch status. Type in the box to search the list. When the page opens it picks the first batch in the list.

3. What is on the screen

On the screen	What it shows
Refresh reports	Reads the batch list and the chosen batch again. Use it to see ELB entries saved after the page was opened.
Batch status	Shown in the Operational batch list and under the batch name. VLB open: the VLB of the batch is not locked yet. ELB open: VLB is locked and the ELB stage is open. ELB locked · Batch closed: the batch has been closed.
(Batch name) heading	Names the chosen batch. The line under it reads: batch name · site · date · Shift · batch status.
ELB entries · VLB cards · Machines · ELB remaining	Count line above the table. ELB entries is the number of rows in the table. VLB cards is the number of saved VLB cards in the same batch. Machines is the number of machines on the machine list of the batch. ELB remaining is the number of those machines that loaded trips on the VLB cards and still have no saved ELB.

ELB batch report · (batch name)	Heading of the table. Its download button is named Print / Export and gives the same choices as Generate: Download as PDF, Download as Excel and Smart Print.
A table row or View ELB	Pressing a row, or the View ELB button in it, opens that ELB below the table under the heading Batch (batch name) · (ELB number). Back to batch report closes it.
Saved ELB values	All saved values of the opened ELB: Book NO, Book date, Location, Equipment / Door number, Equipment, Employee ID / Caliber ID, Operator, WO / Contract, Shift HRS, Shift, Job card NO, OPN HMR, CLO HMR, Total HMR, Availability HRS, Running HRS, BD HRS, BD hours source, Idle HRS and Remark. An empty value shows as —. BD hours source tells where the breakdown hours came from: Pulse, manual entry, or Unavailable. If an HMR reading failed a check, two more boxes show HMR / KMR errors in red and Corrected HMR / KMR readings in green.
Original scan	When the ELB was saved from a scanned job card, it shows the picture and an Open full-size scan link. Otherwise it says 'This entry was saved without a source scan.' If the picture cannot be read it says 'The original scan is unavailable.'
Report (inside the opened ELB)	The same ELB as a report table named ELB report · (ELB number), with the columns Field and Saved value and its own Print / Export button. A second table, Meter corrections · (ELB number), appears when there were meter corrections.
Edit this ELB	Shown in the opened ELB only when the batch status is ELB open, the login is an MIS administrator and the ELB is not one shared by two operators. It opens the entry form headed Edit ELB (ELB number). Back to saved details returns to the saved values. After a save the page reads the batch again.
Messages	'Loading ELB batch report…' shows while the batch is being read. 'No ELB has been saved in this batch yet.' means the chosen batch has no ELB entry. A red line such as 'Only authorized MIS users and site Project Managers can use VLB batches.' means the login is not allowed to read batches.

4. The columns

Column	Meaning
Sr. No.	Running number of the row in the table.
No.	Order of the ELB entry inside the batch, in the order the entries were saved.
ELB number	ELB book number that Pulse-II gave the entry when it was saved.
Equipment / Door	Door number of the machine.
Equipment name	Name of the machine.
VLB trips	Trips this machine loaded, taken from the VLB cards of the same batch.

Status	Shift status saved with the ELB, shown as a code word. working: Working. working_partial_breakdown: Working, partial breakdown. breakdown: Breakdown. maintenance: Maintenance. no_operator: No operator. not_in_use: Not in use. Shows — when no status was saved.
Operator	Operator name saved in the ELB.
Caliber ID	Caliber ID of the operator, for example CMPL90001.
Opening HMR	Opening HMR saved in the ELB.
Closing HMR	Closing HMR saved in the ELB.
Working HMR	Total working HMR saved in the ELB.
BD hours	Breakdown hours saved in the ELB.
Idle hours	Idle hours saved in the ELB.
Availability hours	Availability hours saved in the ELB.
Job card	Job card number saved in the ELB.
Remarks	Remark of the ELB. When there is no remark, the reason entered for the status.
Entry source	How the ELB was saved. batch-fleet: saved from the machine list of the batch. Scan / upload: saved from a scanned job card. Manual: typed in by hand.
Saved by	Login of the user who saved the ELB.
Details	Holds the View ELB button that opens the entry.

5. Keep in mind

- ELB Reports uses the same site, date and Shift batches as VLB Reports. Only batches of the sites allowed for your login and dated 01-11-2026 or later are listed.
- While the batch status is VLB open, Machines and ELB remaining show 0, because the machine list of the batch is made when VLB is locked.
- ELB remaining counts only machines that loaded trips. A machine whose door or name starts with LDM is counted as having no trips.
- The Status column shows the saved code word, not a full label. An empty value in any column shows as —.
- The page does not reload by itself. Press Refresh reports to see new entries.
- Outside the Edit this ELB case, the opened ELB can only be read on this page.

6. Download, print and search

- Tables on this page have a **Generate** button: **Download as PDF**, **Download as Excel** or **Smart Print**. The file contains the whole table, not only the rows visible on screen.
- Type in **Search this report** to find a door number, driver or card inside a table.
- Press a column heading to sort by that column.
- If the page looks old after an update, press **Ctrl + F5** once.

7. Review checklist

Step	Do this
1	Open Reports → ELB Reports and choose the batch of the site, date and Shift in Operational batch. Use Find batch to shorten the list.
2	Read the count line. ELB remaining shows how many machines that loaded trips still have no ELB.
3	For each row compare Opening HMR, Closing HMR and Working HMR with the job card or the meter record of the machine.
4	Check that Status agrees with BD hours, Idle hours and Availability hours of the same row.
5	Open any doubtful row with View ELB. Read Saved ELB values, BD hours source and Remark, and look at Original scan when there is one.
6	Press Print / Export to download or print the batch table.

> **This manual shows how to read and verify the report.** What action to take on its findings is as instructed by management.

8. Common questions

Question	Answer
The table says 'No ELB has been saved in this batch yet.' Why?	No ELB entry has been saved in the chosen batch. If the batch status is VLB open, the ELB stage has not started. Choose another batch, or press Refresh reports later. The number of ELB in each line of the Operational batch list tells which batches have entries.
Why is the Edit this ELB button not there?	It shows only when the batch status is ELB open, your login is an MIS administrator and the ELB is not one shared by two operators. In every other case the opened ELB is read-only.
What does ELB remaining count?	Machines on the machine list of the batch that loaded trips on the VLB cards of this batch and do not yet have a saved ELB. Machines with no trips are not counted.
The Status column shows words like working_partial_breakdown. What do they mean?	They are the saved status codes. working is Working, working_partial_breakdown is Working, partial breakdown, breakdown is Breakdown, maintenance is Maintenance, no_operator is No operator and not_in_use is Not in use.