CALIBER MINING AND LOGISTICS LIMITED · PULSE-II · TRIPS & PRODUCTIVITY

Day-wise Machine Number Report

Operating manual

For site in-charges, MIS staff and reviewers · Matches the system as of 9 November 2026

1. What this report shows

This report shows, for one site and one date, how many tipper trips each loading machine loaded in each Shift, the quantity in cubic metres (CUM) of those trips, and the machine's working HMR from its saved ELB cards. The trips come from saved VLB cards whose batch has been locked with Save & lock batch. A site in-charge or MIS clerk uses it to check production machine by machine.

> **One row.** One row is one machine at the selected site on the selected date. Every active machine (equipment) listed at that site in the Equipment master gets a row, even when it has no ELB card and loaded no trips. The last row, TOTAL (complete selection), adds up all the rows.

2. Open the report and choose what to see

In the left menu open **Reports** → **Trips & Productivity** → **Day-wise Machine Number Report**. Then set the selectors described below.

Selector or button	What it does
1. Site	Choose the site. Only sites allowed for your login are listed. Changing the site clears the Shift and Applicable schedule choices.
2. Date	The card date for the report. It opens on today's date. Dates before 1 November 2026 cannot be chosen. Changing the date clears the Shift and Applicable schedule choices.
3. Report type	Shift-wise shows one Shift. Day-wise shows every Shift of that date side by side, with totals for the day.
Shift	Shown when Report type is Shift-wise. It lists only the Shifts found in the Shift Master for that site and date (Shift 1, Shift 2, Shift 3, Day shift, Night shift). One must be chosen.
Applicable schedule	Shown only when Report type is Day-wise and the Shift Master has both a three-shift schedule and a Day/Night schedule for that site and date. Choose Shift 1 / 2 / 3 or Day / Night.
Show report	Loads the report for the choices made. The button stays disabled until Site, Date and Shift (or schedule) are filled. While loading it reads Checking batches…. If any choice is changed afterwards, the result is cleared; press Show report again.

3. What is on the screen

On the screen	What it shows

Door number / Machine number	Two buttons under the heading. Machine number is this report. Door number opens the Day-wise Door Number Report; the choices already made stay as they are.
No active, unambiguous Shift Master schedule is available for this site and date.	Shown after a site is chosen when no usable Shift is found in the Shift Master for that site and date. Show report stays disabled in that case.
Message in the red box	Shown under the selection when the report cannot be loaded, for example This location is not assigned to your login. or Too many cards or unresolved handovers for one report. Review the outstanding trip links first.
Shift status boxes	After Show report, one box for each Shift in the report. It shows the Shift name and its status, the number of saved VLB cards and the batch name (or Batch not created). The statuses are Processed, Not processed, Missing / duplicate batch, No saved VLB cards and Batch snapshot needs review. Processed means there is exactly one batch for that Shift, it is locked, and every VLB card of the Shift is in it unchanged since the lock.
Report not generated	Shown in place of the table when any check fails. Each line states the problem and the card number, batch name or machine number it refers to. After the corrections, press Show report again. Print and export appear only when all checks pass.
Completed trips	Total completed trips in the selection. It is the same figure as in the Door number report.
Quantity (CUM)	Total quantity of the selection: counted trips × approved tipper capacity. It is the same figure as in the Door number report.
Matched · Door and machine trip / quantity totals	Tells that the trip and quantity totals of the door-wise table and the machine-wise table are equal. The report is generated only when they are equal.
Source data review	Shown when some cards need a look but do not stop the report. Each line gives the card number and the remark, for example Driver / operator ID is missing. or ELB hours that do not add up to the scheduled hours.
Line under the table heading	Site, date, Shifts covered, the processed batch names with their revision number (the number goes up each time the batch is locked), and the date and time the report was generated (IST).
TOTAL (complete selection)	The last row of the table. It adds the trips, HMR and quantity columns of all rows.
Sources, capacity versions and calculation rules	Press to open. It lists the calculation rules, the capacity approvals used (site, job type, make / model, CUM/trip, effective date and approval number) and how to refresh the report after a correction.

4. The columns

Column	Meaning
Sr. No.	Running number. Rows are in machine number order.
Machine / M No.	Number of the machine as in the Equipment master. In the last row it reads TOTAL (complete selection).

Shift 1 operator	Operators named on the saved ELB cards of this machine in that Shift, as name and Employee ID, for example SAMPLE DRIVER 01 (CMPL90001). More than one operator is separated by a semicolon. Unresolved driver / operator means the card has no Employee ID saved. — means no card. The same column repeats for every Shift in the report (Shift 2 operator, Shift 3 operator, Day shift operator, Night shift operator).
Shift 1 HMR	Working HMR of the machine in that Shift, added over all its saved ELB cards of that Shift. For each card it is the total working HMR saved on the card, or closing HMR − opening HMR when that total is not saved. — when there is no card. Repeats for every Shift in the report.
Shift 1 trips	Tipper trips loaded by this machine in that Shift. Every counted trip on a VLB card is added to the loading machine recorded against that trip. — means no saved ELB card and no trips; 0 means an ELB card is saved but no counted trip names this machine. Repeats for every Shift in the report.
Shift 1 quantity (CUM)	Quantity loaded by the machine in that Shift: each trip × the approved capacity of the tipper that carried it. — and 0 follow the same rule as the trips column. Repeats for every Shift in the report.
Total HMR	Sum of the Shift HMR columns of the row. — when no Shift has HMR.
Total trips	Sum of the Shift trips columns of the row.
Quantity (CUM)	Sum of the Shift quantity columns of the row.
Card coverage	Cards available when an ELB card is saved for every Shift in the report. Otherwise it names the Shifts without a card, for example S1: no saved ELB card (S1, S2, S3 are Shift 1, 2, 3; D is Day; N is Night).

5. Keep in mind

- Quantity (CUM) uses the approved capacity of the tipper that carried each trip. It is not a weighbridge measurement and not a bucket count of the machine.
- Trips and quantity belong to the Shift in which the tipper was loaded.
- The loading machine of a trip is taken from the equipment link saved on the VLB trip row. If there is no link, the machine name written on the row must match exactly one machine of the site by its number, equipment name or a saved card alias; otherwise the report is not generated.
- If a machine has loaded trips in a Shift but no ELB card is saved for it in that Shift, the report is not generated and the machine is named in the list.
- An ELB card whose opening and closing HMR cannot give working hours stops the report. ELB hours that do not add up to the scheduled hours are only listed under Source data review; the saved values are not changed.
- The report also stops when the combined working HMR of a machine in one Shift is more than the Shift length: 8 hours for Shift 1, 2 and 3, 12 hours for Day and Night.

6. Download, print and search

- Tables on this page have a **Generate** button: **Download as PDF**, **Download as Excel** or **Smart Print**. The file contains the whole table, not only the rows visible on screen.
- Type in **Search this report** to find a door number, driver or card inside a table.
- Press a column heading to sort by that column.

- If the page looks old after an update, press **Ctrl + F5** once.

7. Review checklist

Step	Do this
1	Choose 1. Site, 2. Date and 3. Report type (and Shift or Applicable schedule), then press Show report.
2	Check that every Shift status box reads Processed. If Report not generated appears, read each line and note the card, batch or machine it names.
3	In Card coverage, find the machines that show no saved ELB card and check whether that machine worked in that Shift.
4	For a machine that shows HMR but 0 trips, check on the VLB cards of that Shift whether its number was written as the loading machine.
5	Compare the Completed trips and Quantity (CUM) figures above the table with the TOTAL (complete selection) row and with the Door number report.
6	Read each line under Source data review and open the named card to check it.

> **This manual shows how to read and verify the report.** What action to take on its findings is as instructed by management.

8. Common questions

Question	Answer
What does Loading machine number is missing, ambiguous or outside this site. Correct the VLB equipment link. mean?	A counted trip on the named VLB card has a loading machine that is blank, matches more than one machine, or is not a machine of this site. The line shows the card number and the machine name as written on the card.
What does Saved ELB is missing for loading machine … mean?	VLB cards show trips loaded by that machine in the named Shift, but no ELB card of that machine is saved for the same date and Shift. Until that ELB card is saved, the report is not generated.
What is the difference between — and 0 in a trips column?	— means no ELB card is saved for that machine in that Shift. 0 means an ELB card is saved but no counted trip on the VLB cards names this machine.
Why are the machine totals always equal to the door totals?	Each counted trip is added once to its tipper and once to its loading machine, with the same quantity. If the two totals differ, the report is not generated.