CALIBER MINING AND LOGISTICS LIMITED · PULSE-II · REPORTS

Equipment Deployment

Operating manual

For site in-charges, MIS staff and reviewers · Matches the system as of 9 November 2026

1. What this report shows

Counts the equipment currently assigned to each location by equipment group.

> **One row.** One equipment group, such as Excavator or Dumper/Tipper.

2. Open the report and choose what to see

In the left menu open **Reports** → **Equipment Deployment**. Then set the selectors described below.

Selector or button	What it does
Search this report	Find a model or equipment group.

3. What is on the screen

On the screen	What it shows
Location columns	Show the locations available to your login.
Total	Adds the counts across the displayed locations.
Match with Pulse equipment list	Below the table. Shows whether this list agrees with the Pulse equipment list, and when it was last checked. The check runs by itself every 6 hours.
Matches Pulse / machines differ	Green means both lists agree. Red shows how many machines differ.
Where the counts differ	One line for each equipment group and site where the Pulse-II count and the Pulse count are not the same.
Machines that differ	Each machine that explains the difference: in Pulse but not in Pulse-II, in Pulse-II but not in Pulse, at a different site, or in a different equipment group.
Check now	Administrators only. Reads Pulse again at once and refreshes the result. It sends no message.
Pop-up notice	When a 6-hourly check finds a difference, a notice opens on screen for administrators and the people chosen in the Automation Centre. Press OK to close it, or Open full list to come to this report. It returns after the next check until the lists match.

4. The columns

Column	Meaning
Location	Equipment population

5. Keep in mind

- Counts come from current Equipment Master assignments.
- Vehicles from the LMV Master in Pulse are not part of the match.
- A difference also goes out by Telegram to the people set in the Automation Centre.

6. Download, print and search

- Tables on this page have a **Generate** button: **Download as PDF**, **Download as Excel** or **Smart Print**. The file contains the whole table, not only the rows visible on screen.
- Type in **Search this report** to find a door number, driver or card inside a table.
- Press a column heading to sort by that column.
- If the page looks old after an update, press **Ctrl + F5** once.

7. Review checklist

Step	Do this
1	Verify the location and count against Equipment Master.
2	If the match shows red, correct the machine in Pulse or complete the pending transfer, then press Check now.

> **This manual shows how to read and verify the report.** What action to take on its findings is as instructed by management.

8. Common questions

Question	Answer
What does a zero mean?	No matching equipment is assigned to that location. In Fleet Capacity, a zero daily rate also gives zero volume.
Why does the notice keep coming back?	It returns after every check, every 6 hours, for as long as the two lists differ. It stops by itself once they match.
A machine shows In Pulse-II, not in Pulse. What should I do?	It was added or moved in Pulse-II and is not yet entered in Pulse. Enter it in Pulse; the next check clears it.