CALIBER MINING AND LOGISTICS LIMITED · PULSE-II · TRIPS & PRODUCTIVITY

Meter Continuity Report

Operating manual

For site in-charges, MIS staff and reviewers · Matches the system as of 9 November 2026

1. What this report shows

This report checks whether the meter readings of each tipper follow on from one VLB card to the next. It compares the opening KMR and opening HMR of every saved tipper card with the closing KMR and closing HMR of the same tipper's previous card, taken in date and Shift order. It only reports; no card is changed. A site in-charge or MIS clerk uses it to find cards where a reading was skipped, went backwards or was written wrongly.

> **One row.** In Card by card, one row is one saved VLB card in the date range, compared with the previous card of the same tipper; rows are in date, Shift and tipper order. In By driver and By tipper, one row is one driver or one tipper with the counts of its cards.

2. Open the report and choose what to see

In the left menu open **Reports** → **Trips & Productivity** → **Meter Continuity Report**. Then set the selectors described below.

Selector or button	What it does
1. Site	Choose the site. Only sites allowed for your login are listed.
2. From	First card date of the range. It opens on the 1st of the current month. Dates before 1 November 2026 cannot be chosen.
3. To	Last card date of the range. It opens on today's date. It cannot be before From, and it can be at most 92 days after From; a longer range gives the message Choose a range of at most 92 days.
4. KM tolerance	How many km the opening KMR may be above the previous closing KMR and still count as Within tolerance. It starts at 2. Values from 0 to 500 are accepted; any other value is treated as 2.
5. HMR tolerance	How many hours the opening HMR may be above the previous closing HMR and still count as Within tolerance. It starts at 0.5. Values from 0 to 24 are accepted; any other value is treated as 0.5.
Run report	Runs the comparison for the choices made. The button stays disabled until a site is chosen and the dates are in order. While loading it reads Running…. If any choice is changed afterwards, the result is cleared; press Run report again.

3. What is on the screen

On the screen	What it shows
Meter continuity	A single button under the heading. It only marks this report as open.

Message in the red box	Shown under the selection when the report cannot be run, for example Choose a range of at most 92 days., Too many cards for one report. Choose a shorter range. or This location is not assigned to your login.
Card by card / By driver / By tipper	Three views of the same result. Card by card lists every card. By driver and By tipper give counts for each driver or each tipper. Changing the view does not run the report again.
Match	Legend label and Result: the opening reading is equal to the previous closing reading (gap 0).
Within tolerance	Legend label and Result: the opening reading is above the previous closing reading, by not more than the tolerance. These rows have a light blue background.
Below previous closing	Legend label and Result: the opening reading is lower than the previous closing reading (the gap is negative). These rows have a light red background.
Jump above tolerance	Legend label and Result: the opening reading is above the previous closing reading by more than the tolerance. These rows have a light amber background.
No previous card	Legend label and Result: no earlier card of that tipper was found, so nothing was compared.
Reading missing	Legend label and Result: the card has a previous card, but no reading could be compared on either meter (KM gap and HMR gap both show —). These rows have a light grey background. A blank reading on one meter alone shows as — in that gap column only.
Line under the table heading	Before a run it reads Run the report to compare each tipper card with its previous card. After a run it shows the site, the date range, the two tolerances, the number of cards, the number compared, the counts of match, within tolerance, below previous closing and jumps, the number of reading missing cards when there are any (marked not compared), and the time the report was generated.
Run the report to see results. / No cards in this range.	Messages in the empty table: the first before a run, the second when a run finds no card.

4. The columns

Column	Meaning
Card by card · Date	Date of the card.
Card by card · Shift	Shift of the card: I, II, III, Day or Night.
Card by card · Tipper	Door number written on the card, for example V9001.
Card by card · Driver on card	Driver named on this card with Employee ID, for example SAMPLE DRIVER 01 (CMPL90001). — when no name is saved.
Card by card · Card	Book number of this card.

Card by card · Source	Scan when the card was saved from a scanned card. Manual when it was entered by hand.
Card by card · Previous card	Book number of the card just before this one for the same tipper, with its date and Shift in brackets. — when no previous card was found.
Card by card · Prev. closing KMR	Closing KMR on the previous card.
Card by card · Opening KMR	Opening KMR on this card.
Card by card · KM gap	Opening KMR − Prev. closing KMR. A + sign means the opening is higher; a − sign means it is lower. — when either reading is blank or there is no previous card.
Card by card · Prev. closing HMR	Closing HMR on the previous card.
Card by card · Opening HMR	Opening HMR on this card.
Card by card · HMR gap	Opening HMR − Prev. closing HMR, shown the same way as KM gap.
Card by card · Result	The more serious of the KM finding and the HMR finding, in this order: Below previous closing, Jump above tolerance, Within tolerance, Match. A blank reading on one meter leaves the Result to the other meter. Reading missing when there is a previous card but no reading to compare on either meter. No previous card when no earlier card was found.
By driver · Driver	Driver name and Employee ID as on the cards. Cards are grouped by Employee ID, or by name when no ID is saved; cards with neither are left out of this view. Unknown driver is shown when a card has an Employee ID but no name. Each card counts for the driver named on that card.
By tipper · Tipper	Door number as written on the cards. Cards with a blank door number are left out of this view.
By driver / By tipper · Cards	Number of cards in the date range for that driver or tipper.
By driver / By tipper · Compared	Cards that had a previous card and at least one meter that could be compared. Cards with Result Reading missing are not included.
By driver / By tipper · Match	Compared cards with Result Match.
By driver / By tipper · Within tolerance	Compared cards with Result Within tolerance.
By driver / By tipper · Below previous	Compared cards with Result Below previous closing.
By driver / By tipper · Jumps	Compared cards with Result Jump above tolerance.
By driver / By tipper · Reading missing	Cards of that driver or tipper with Result Reading missing: a previous card exists but nothing could be compared on either meter. They are not part of Compared or Issue %.
By driver / By tipper · Issue %	(Below previous + Jumps) ÷ Compared × 100. — when no card was compared.

By driver / By tipper · Avg. KM gap	Average KM gap of the compared cards, taken without the + or − sign.
By driver / By tipper · Avg. HMR gap	Average HMR gap of the compared cards, taken without the + or − sign.

5. Keep in mind

- The previous card is found by card date and Shift order (I, II, III, Day, Night), not by the time the card was saved.
- To find the previous card, the report also reads cards up to 7 days before From, but never before 1 November 2026. If the tipper's last card is older than that, the row shows No previous card.
- Cards of the same tipper are joined through the Equipment master link of the card. A card without that link is matched by its door number.
- When a reading is blank on one meter, Result is decided by the other meter alone. When both KM gap and HMR gap show — on a card that has a previous card, Result reads Reading missing. Such a card is not counted under Compared; it is counted under Reading missing.
- By driver and By tipper are sorted with the highest total of Below previous and Jumps at the top.
- The report cannot say which of the two cards is wrong. It only shows that the opening reading of one card and the closing reading of the card before it do not agree.

6. Download, print and search

- Tables on this page have a **Generate** button: **Download as PDF**, **Download as Excel** or **Smart Print**. The file contains the whole table, not only the rows visible on screen.
- Type in **Search this report** to find a door number, driver or card inside a table.
- Press a column heading to sort by that column.
- If the page looks old after an update, press **Ctrl + F5** once.

7. Review checklist

Step	Do this
1	Choose 1. Site, 2. From and 3. To, set 4. KM tolerance and 5. HMR tolerance if needed, then press Run report.
2	In Card by card, look first at the rows with Result Below previous closing, then at the rows with Jump above tolerance.
3	For each such row, check the readings of the Card and the Previous card against the two paper cards.
4	Find the rows with Result Reading missing, and look for — in KM gap or HMR gap on the other rows that have a previous card. In each case a reading is blank on one of the two cards.
5	Open By tipper and By driver to see where Below previous and Jumps repeat.

> **This manual shows how to read and verify the report.** What action to take on its findings is as instructed by management.

8. Common questions

Question	Answer
Why does a card show No previous card?	No earlier card of that tipper was found at the site, looking back up to 7 days before From. This happens for the first card of a tipper, or when its last card is older than that.
Why is the Result Match when a gap column shows —?	If one gap is —, that meter could not be compared and the Result comes from the other meter, so it can read Match. If both gaps are —, nothing could be compared and the Result reads Reading missing. Read the KM gap and HMR gap columns together with Result.
What do KM tolerance and HMR tolerance change?	They decide where Within tolerance ends and Jump above tolerance begins. With a tolerance of 0, any opening reading above the previous closing is a Jump above tolerance. A negative gap is always Below previous closing.
A tipper had two cards in one Shift. How are they compared?	Cards of the same tipper, date and Shift are taken in the order in which they were first saved. The second card is compared with the first, and the first card with the card just before it in date and Shift order.