

Compressor Manual

Common compressor failures:

Bearing wear

Lubrication degradation

Seal leakage

Rotor imbalance

Recommended actions:

Inspect bearings

Check lubrication circuit

Monitor vibration

Replace damaged seals