

8. “M” FUNCTIONS LIST

SIEMENS 828D / ONE

M00	Program STOP	
M01	Conditional program STOP	
M02	Program END	
M03	Spindle CW	
M04	Spindle CCW	
M05	Spindle STOP / Spindle released	
M06	Tool change START	
M07	Air Blow ON	
M08	Coolant ON	
M09	Coolant/CTS/Air Blow/ATS/Probes STOP	
M10	4 th axis clamp	(Option)
M11	4 th axis unclamp	(Option)
M13	Spindle CW + Coolant ON	
M14	Spindle CCW + Coolant ON	
M15	Automatic door opening	
M16	Automatic door closing	
M17	Subprogram END	
M19	Spindle positioning	
M20	5 th axis clamp	(Option)
M21	5 th axis unclamp	(Option)
M29	Rigid tapping ON	
M30	Program END	
M31	Tool set blow ON	
M34	Flushing pump START	(Option)
M35	ATS START	(Option)
M36	CTS START	(Option)
M37	Chip conveyor CW	(Option)
M38	Chip conveyor CCW	
M39	Chip conveyor STOP	
M50	Oil mist collector ON	
M51	Oil mist collector OFF	
M52	Probe ON	
M53	Probe OFF	
M98	Calling Subroutine Program	(ISO MODE)
M99	Return to Main Program	(ISO MODE)
M333	Motorized spindle daily warm-up	
M334	Motorized spindle after long storage warm-up	

(version 2025-05-23)

**NOTICE 24**

Please make sure, that M-functions used by PRIMINER are comply with you CAM post-processor. If not, modify your post-processor file according our above specification.