

Crestron AirMedia Series 3 Receiver AM-3100-WF Manual

1. Official Crestron Sources

This manual is based on official Crestron documentation for the AirMedia Series 3 Receivers, especially the AirMedia Series 3 Receivers Product Manual, the AM-3100-WF(-I) Features page, the AM-3100-WF(-I) Specifications page, and the AM-3100-WF / AM-3100-WF-I Quick Start guide.

The uploaded source manual identifies the Crestron AM-3100-WF as an AirMedia Series 3 wireless presentation receiver used for secure wireless collaboration and screen presentation in meeting rooms, huddle rooms, lounges, lobbies, and similar spaces.

Practical setup, installation, operation, troubleshooting, maintenance, and support notes were added to make this manual more useful for real deployment and service work. Exact options may vary depending on firmware version, room design, network design, connected display, wireless access point, AirMedia client method, and XiO Cloud deployment.

2. Device Description

The Crestron AirMedia AM-3100-WF is a Series 3 wireless presentation receiver. Its main role is to allow users to share content from laptops, mobile devices, and AirMedia Connect adaptors to a room display.

In a meeting room or smart office environment, the AM-3100-WF acts as the **wireless presentation gateway**. It receives content from user devices and sends the presentation output to the room display through HDMI.

The receiver is commonly used in:

- Conference rooms
- Huddle rooms
- Meeting rooms
- Classrooms
- Lounges
- Lobbies
- Collaboration spaces
- Smart office presentation areas

The device supports secure presentation workflows and can be managed locally through a web configuration interface or remotely through XiO Cloud where deployed.

The AM-3100-WF is not a wireless access point replacement for general client Wi-Fi. The source manual notes that software-client wireless presentation requires an external Wi-Fi access point. The receiver includes built-in Wi-Fi used for AirMedia Connect adaptors, while normal wireless presentation from software clients depends on the room or building Wi-Fi network.

In the project topology, this device should be documented as the **wireless presentation receiver** connected to the room display by HDMI and connected to the network by Ethernet.

3. Technical Specifications

The AM-3100-WF is manufactured by Crestron and belongs to the AirMedia Series 3 receiver family.

Main function:

Wireless screen presentation to a room display

Supported presentation sources may include:

- Laptops
- Mobile devices
- AirMedia software clients
- AirMedia Connect adaptors
- Wired Ethernet-connected laptops where supported by network design

Power options:

- PoE / IEEE 802.3af
- PoE+ / IEEE 802.3at
- Optional PW-2412WU power pack

Network and wireless:

- Wired Ethernet LAN
- Built-in Wi-Fi used for AirMedia Connect adaptors
- External Wi-Fi access point required for software-client wireless presentation
- Web configuration interface
- XiO Cloud management support

Audio/video:

- HDMI output to room display
- Video inputs are scaled to the HDMI output resolution
- Supports up to 4K30 through an AirMedia Connect adaptor, according to the uploaded source manual
- Supports up to four simultaneous sources through AirMedia Canvas during normal operation, according to the uploaded source manual

Security and enterprise support:

- AES content encryption
- 802.1X support
- Active Directory support
- User creation at first sign-on
- Does not currently support TLS 1.3, according to the uploaded source manual

Mounting:

- Surface mounting

- Wall mounting using included wall-mount hardware

Approximate physical size:

Height: 1.21 in.
Width: 5 in.
Depth: 5 in.

Operating environment:

Not found in the provided official-source manual

4. Ports, Buttons, and Indicators

The AM-3100-WF includes ports and indicators for power, network, video output, setup, and system status.

4.1 Ethernet LAN Port

The Ethernet LAN port connects the receiver to the wired network.

It is used for:

- Network connectivity
- Web configuration access
- XiO Cloud connectivity
- Control-system communication
- AirMedia presentation traffic
- PoE or PoE+ power input when powered through Ethernet

The Ethernet connection is very important because the receiver depends on stable network access for management and presentation workflows.

4.2 HDMI Output

The HDMI output connects the receiver to the room display, projector, or AV switching system.

It is used to send the presentation image to:

- Commercial display
- Smart display
- Projector
- AV matrix
- HDMI input on a conferencing system
- Room video distribution device

The receiver scales presentation sources to the HDMI output resolution.

If the display shows no image, always check the HDMI output, cable, display input selection, and output resolution.

4.3 Built-In Wi-Fi

The uploaded source manual states that the device includes built-in Wi-Fi used for AirMedia Connect adaptors.

Important note:

Software-client wireless presentation requires an external Wi-Fi access point. This means the room Wi-Fi infrastructure must be working properly for users presenting from laptops or mobile devices through software clients.

4.4 Setup Button

The Setup button is used for device setup and setup-related actions.

The source manual notes that the Setup LED becomes white when the setup button has been pressed.

The Setup button should be used according to the official product manual, especially for setup or recovery operations.

4.5 Power LED

The Power LED reports device power and boot status.

The uploaded source manual states:

```
White: Device is operational  
Amber: Device is booting
```

4.6 Setup LED

The Setup LED reports setup-button activity.

The uploaded source manual states:

```
White: Setup button has been pressed
```

4.7 Online LED

The Online LED reports control-system connection status.

The uploaded source manual states:

```
White: Receiver is connected to a Crestron control system
```

If the Online LED is not white, the receiver may still function for some local presentation use cases, but the Crestron control-system connection should be checked if the room control system depends on it.

4.8 HDMI LED

The HDMI LED reports HDMI video transmission.

The uploaded source manual states:

```
White: Video is being transmitted to the HDMI output
```

This LED is important when diagnosing a no-video issue.

4.9 LAN LED

The LAN LED reports Ethernet link state.

The uploaded source manual states:

```
Green: Ethernet link is established
```

If the LAN LED is off, check Ethernet cabling, switch port status, PoE, and network connection.

5. Installation and Setup Notes

Before installation, confirm the receiver model, power method, network port, external Wi-Fi access point, HDMI display connection, mounting location, and management method.

Basic installation steps:

1. Confirm the device is the Crestron AM-3100-WF or AM-3100-WF-I.
2. Select a mounting location near the display or AV equipment.
3. Mount the receiver using the included wall-mount hardware if required.
4. Connect the HDMI output to the display, projector, or AV system.
5. Connect the Ethernet LAN port to the network.
6. Provide power through PoE, PoE+, or optional PW-2412WU power pack.
7. Verify that the Power LED changes from boot state to operational state.
8. Verify that the LAN LED shows an Ethernet link.
9. Confirm that the display shows the AirMedia welcome screen.
10. Find the receiver IP address from the display or network tools.
11. Open the web configuration interface using the device IP address.
12. Create a user account during first sign-on.
13. Configure network, security, display, and AirMedia settings.
14. Configure XiO Cloud if enterprise management is required.
15. Test wireless presentation from a laptop or mobile device.
16. Test presentation through AirMedia Connect adaptor if used.

17. Document IP address, room name, display connection, switch port, and firmware version.

Important installation notes:

- The PoE ports are for intra-building use only, according to the uploaded source manual.
- Software-client wireless presentation requires an external Wi-Fi access point.
- Laptops may alternatively connect using wired Ethernet depending on network design.
- The display should be set to the correct HDMI input.
- Network stability is critical for reliable wireless presentation.
- The receiver should not be installed where it is overheated, blocked, or difficult to service.

6. Network and Wi-Fi Requirements

The AM-3100-WF depends on the network for presentation, management, and optional cloud connectivity.

6.1 Wired Network

The wired Ethernet LAN connection is used for:

- Device management
- Presentation traffic
- Control-system communication
- XiO Cloud connectivity
- Firmware updates
- Network discovery
- Authentication services where used

Recommended checks:

```
Ethernet cable is connected
Switch port is enabled
LAN LED is green
Device has valid IP address
Gateway and DNS are correct
Web interface is reachable
```

6.2 External Wi-Fi Access Point

The uploaded source manual notes that software-client wireless presentation requires an external Wi-Fi access point.

This external AP provides Wi-Fi connectivity for:

- Laptops
- Mobile devices
- Wireless users
- Guest users where allowed
- Corporate users presenting wirelessly

If users cannot present wirelessly, the issue may be with the Wi-Fi network, not necessarily the AirMedia receiver.

6.3 Built-In Wi-Fi for Connect Adaptors

The built-in Wi-Fi is used for AirMedia Connect adaptors.

The uploaded source manual states that the receiver supports up to eight Connect adaptors per receiver.

6.4 Enterprise Network Features

The receiver supports enterprise security features such as:

- 802.1X
- Active Directory
- AES content encryption

If the receiver is deployed on an enterprise network, confirm that certificates, authentication settings, credentials, VLANs, firewall rules, and access policies are correctly configured.

7. Web Configuration and Management Access

The AM-3100-WF is configured through its web configuration interface.

7.1 Accessing the Web Interface

Basic access process:

1. Connect the receiver to the network.
2. Confirm the LAN LED is green.
3. Find the receiver IP address.
4. Open a browser.
5. Enter the receiver IP address.
6. Create a user account on first sign-on.
7. Sign in with valid credentials.

The web interface may be used to configure or verify:

- Network settings
- Display output settings
- AirMedia presentation settings
- Security settings
- Control-system connection status
- Firmware updates
- XiO Cloud settings
- User access
- Device status

7.2 XiO Cloud Management

XiO Cloud can be used for enterprise deployment and remote management.

It may help with:

- Device monitoring
- Firmware management
- Remote status checks
- Fleet management
- Configuration management
- Deployment at scale

If XiO Cloud is unavailable, check:

- Internet access
- DNS
- Gateway
- Firewall rules
- Device claim status
- Cloud settings
- Firmware version

7.3 Control-System Connection Status

The web interface exposes control-system connection status.

This is useful when the AM-3100-WF is integrated with a Crestron control processor such as a CP4.

If the room touch panel cannot control AirMedia functions, check both the receiver and the control-system connection.

8. Display and HDMI Output Setup

The HDMI output is the main AV output of the receiver.

It should be connected to:

- Room display
- Projector
- HDMI matrix
- AV switcher
- Video conferencing input
- Commercial display input

Normal expected display behavior:

- Display powers on
- Correct HDMI input is selected
- AirMedia welcome screen appears when idle
- Connection instructions are visible
- Presentation content appears after a user connects

The uploaded source manual notes that when idle, the receiver shows a customizable welcome screen with connection instructions on the display.

If no image appears, check:

- HDMI cable
- Display input
- Display power
- HDMI LED
- Output resolution
- AV switcher path
- EDID or compatibility issues
- Presentation source status

9. AirMedia Presentation Operation

The AM-3100-WF allows users to present content wirelessly or through compatible AirMedia methods.

Typical presentation workflow:

1. User enters the meeting room.
2. Display shows AirMedia welcome screen.
3. User follows connection instructions.
4. User connects from laptop, mobile device, or AirMedia Connect adaptor.
5. Receiver displays the content through HDMI output.
6. Multiple sources may be shown using AirMedia Canvas where configured.

Supported use cases:

- Single presenter
- Multiple presenters
- Wireless laptop presentation
- Mobile device presentation
- Connect adaptor presentation
- Meeting-room collaboration
- Guest presentation where allowed by policy

The uploaded source manual states that AirMedia Canvas supports up to four simultaneous sources.

Presentation quality depends on:

- Network stability
- Wi-Fi signal strength
- External AP performance
- Client device performance
- Firmware version
- Display resolution
- Room network policy

- Bandwidth availability
-

10. Security Configuration

The AM-3100-WF supports secure presentation and enterprise deployment features.

Security-related features from the uploaded source manual include:

- AES content encryption
- 802.1X support
- Active Directory support
- User creation at first sign-on
- No current TLS 1.3 support

Recommended security practices:

- Create strong administrator credentials.
- Restrict web management access to trusted networks.
- Use enterprise authentication where required.
- Use 802.1X when required by network policy.
- Keep firmware updated.
- Use XiO Cloud according to organizational policy.
- Separate guest presentation traffic from corporate traffic where required.
- Control who can present to room displays.
- Review display welcome-screen information before public deployment.
- Avoid exposing management interfaces to untrusted networks.
- Document admin accounts and access method.

If the receiver is deployed in a guest-access room, coordinate with IT security to define guest Wi-Fi, VLANs, firewall rules, and presentation access rules.

11. Normal Operation

During normal operation:

- Power LED is white.
- LAN LED is green.
- Receiver has a valid network connection.
- Web interface is reachable by authorized administrators.
- Display shows the AirMedia welcome screen when idle.
- HDMI LED becomes white when video is being transmitted.
- Users can connect from supported devices.
- Presentations appear on the room display.
- AirMedia Canvas works if configured.
- Connect adaptors can connect if used.
- Online LED is white when connected to a Crestron control system.
- XiO Cloud management works if deployed.
- Firmware is on a supported version.

- No repeated network or presentation errors appear.

Useful normal-operation checks:

```
Check Power LED
Check LAN LED
Check HDMI LED during presentation
Check Online LED if integrated with a control system
Check display welcome screen
Check web configuration access
Check user presentation from laptop
Check AirMedia Connect adaptor
Check XiO Cloud status if used
```

12. Troubleshooting

Troubleshooting should move from physical and network checks upward:

1. Power source
2. Ethernet link
3. IP address
4. Web configuration access
5. Display and HDMI output
6. External Wi-Fi access point
7. User device connection
8. Presentation method
9. Security/authentication
10. Control-system integration
11. Firmware
12. Factory reset or recovery
13. Hardware fault

12.1 Receiver Does Not Power On

Symptom:

- Power LED is off
- Device does not boot
- No welcome screen appears
- Web interface is unreachable

Possible causes:

- No PoE or PoE+ power
- Switch port does not provide PoE
- PoE injector not working
- Optional power pack disconnected

- Bad Ethernet cable
- Switch port disabled
- Hardware fault

Checks:

```
Check Power LED
Check PoE switch port
Check Ethernet cable
Check PoE injector if used
Check optional PW-2412WU power pack if used
Check switch port status
```

Switch-side checks:

```
show interfaces status
show power inline
show power inline <interface>
```

Fix actions:

- Connect to a working PoE/PoE+ switch port.
- Enable PoE on the switch port.
- Replace the Ethernet cable.
- Test with another PoE port.
- Use the optional power pack if PoE is unavailable.
- Verify the Power LED becomes white after boot.

Expected result:

The receiver powers on, boots, and becomes operational.

12.2 Receiver Boots but Is Offline

Symptom:

- Power LED shows device is powered
- LAN LED is off or unstable
- Web interface is unreachable
- XiO Cloud reports offline
- Control system cannot see receiver

Possible causes:

- Ethernet cable disconnected
- Switch port disabled
- Wrong VLAN

- DHCP issue
- Static IP misconfigured
- Gateway or DNS issue
- Network instability
- Firewall blocking management or cloud access

Checks:

Check LAN LED
Check Ethernet cable
Check switch port
Check IP address
Check VLAN
Check DHCP or static IP settings
Check gateway and DNS

Fix actions:

- Reseat or replace Ethernet cable.
- Enable switch port.
- Correct VLAN assignment.
- Verify DHCP server.
- Correct static IP settings if used.
- Restore gateway and DNS settings.
- Test web interface from same subnet.

12.3 Web Configuration Interface Cannot Be Accessed

Symptom:

- Browser cannot open receiver page
- Login page does not appear
- Credentials fail
- Admin cannot manage the device

Possible causes:

- Wrong IP address
- Device not on network
- Management computer on different VLAN
- Firewall blocks access
- User account not created
- Wrong credentials
- Browser/HTTPS issue
- Device still booting

Checks:

```
Find correct IP address
Ping receiver IP
Try access from same VLAN
Check LAN LED
Check switch port
Confirm user account exists
Confirm credentials
```

Fix actions:

- Use the correct device IP address.
- Create a user account on first sign-on.
- Sign in with valid credentials.
- Test from same network segment.
- Check firewall or ACL rules.
- Reboot only if necessary after network checks.

12.4 Wireless Presentation Does Not Work

Symptom:

- Users cannot connect from laptop or mobile device
- AirMedia app cannot find receiver
- Connection instructions are visible but presentation fails
- Wireless users cannot start sharing

Possible causes:

- External Wi-Fi access point missing
- Wi-Fi network down
- User device on wrong network
- Receiver and client networks cannot communicate
- Firewall blocks presentation traffic
- AirMedia client issue
- Wrong connection code or room selection
- Network discovery blocked
- Guest network restrictions

Checks:

```
Verify external Wi-Fi AP is working
Confirm user device is connected to correct Wi-Fi
Confirm receiver is online
Confirm client can reach receiver network
Check firewall/VLAN rules
```

Check AirMedia instructions on welcome screen
Try another client device

Fix actions:

- Restore Wi-Fi network service.
- Connect user device to correct SSID.
- Allow required network communication.
- Confirm the receiver IP/room code.
- Restart AirMedia client software.
- Test from wired Ethernet if supported.
- Check IT security rules for guest networks.

Important note:

If software-client wireless presentation fails, the issue may be with the external Wi-Fi access point or network policy, not the receiver itself.

12.5 AirMedia Connect Adaptor Does Not Work

Symptom:

- Connect adaptor does not pair
- Presentation through adaptor fails
- Adaptor cannot connect to receiver
- Receiver does not show adaptor source

Possible causes:

- Adaptor not powered or connected correctly
- Built-in receiver Wi-Fi issue
- Too many adaptors already associated
- Receiver configuration issue
- Firmware mismatch
- Wireless interference
- Adaptor not assigned to this receiver

Checks:

Check adaptor power
Check adaptor connection
Confirm receiver supports adaptor use
Confirm adaptor is assigned/presenting to correct receiver
Check number of adaptors in use
Check firmware compatibility

Fix actions:

- Reconnect adaptor.
- Verify adaptor pairing or assignment.
- Reduce adaptor count if limits are reached.
- Update firmware if needed.
- Test with another adaptor if available.
- Check receiver configuration.

The uploaded source manual states that up to eight Connect adaptors are supported per receiver.

12.6 No Video Output on Display

Symptom:

- Display is blank
- Display says no signal
- Welcome screen does not appear
- Presentation starts but nothing shows

Possible causes:

- Display powered off
- Wrong HDMI input selected
- HDMI cable disconnected
- Bad HDMI cable
- HDMI output issue
- Resolution mismatch
- AV switcher path issue
- Display compatibility issue
- Receiver not fully booted

Checks:

```
Check display power
Check selected HDMI input
Check HDMI cable seating
Check HDMI LED
Check receiver Power LED
Check output resolution
Bypass AV switcher if possible
Try another HDMI cable
```

Fix actions:

- Select correct display input.
- Replace HDMI cable.
- Confirm receiver welcome screen.
- Adjust output resolution in configuration if needed.
- Test direct HDMI connection to display.

- Check AV switcher or matrix path if used.

Expected result:

The AirMedia welcome screen or presentation content appears on the room display.

12.7 HDMI Output Works but Presentation Does Not Appear

Symptom:

- Welcome screen appears
- User connects successfully
- HDMI output is active
- Presentation content does not display or freezes

Possible causes:

- Client device issue
- AirMedia app issue
- Network bandwidth issue
- Wi-Fi interference
- Presentation permission issue
- Content protection limitation
- Firmware issue
- Multiple-source Canvas configuration issue

Checks:

```
Try another client device
Restart AirMedia client
Check Wi-Fi signal
Check network bandwidth
Check AirMedia Canvas configuration
Check receiver logs/status if available
Check firmware version
```

Fix actions:

- Reconnect presenter.
 - Restart client application.
 - Move client closer to Wi-Fi AP.
 - Reduce wireless congestion.
 - Update firmware.
 - Test single-source presentation.
 - Verify content source compatibility.
-

12.8 Poor Presentation Quality or Lag

Symptom:

- Video is delayed
- Mouse movement is laggy
- Audio/video sync issue
- Presentation freezes
- Low frame rate

Possible causes:

- Weak Wi-Fi signal
- Congested wireless network
- Network latency
- External AP overloaded
- Client device performance issue
- High-resolution content
- Bandwidth limitation
- Firmware issue

Checks:

```
Check Wi-Fi signal strength
Check AP load
Check network latency
Try wired client if supported
Test with another laptop
Check receiver firmware
Check if multiple sources are active
```

Fix actions:

- Improve Wi-Fi coverage.
- Reduce interference.
- Use 5 GHz or better wireless design where applicable.
- Reduce simultaneous sources.
- Update firmware.
- Use wired Ethernet for critical presentations if supported.
- Optimize AP placement.

12.9 Control System Connection Problem

Symptom:

- Online LED is not white
- CP4 or touch panel cannot control AirMedia receiver
- Room control buttons for AirMedia do not work
- Receiver works manually but not from Crestron UI

Possible causes:

- CP4/control processor offline
- Receiver not configured for control-system connection
- Wrong IP address in control program
- Network routing issue
- Credentials/authentication issue
- Firewall blocks control traffic
- Control program issue

Checks:

```
Check Online LED
Check web interface control-system status
Check CP4 network connection
Check receiver IP address
Check control program configuration
Check VLAN and routing
```

Fix actions:

- Correct receiver IP in the control program.
- Verify control-system connection settings.
- Restore CP4 or control processor connectivity.
- Check credentials if required.
- Fix VLAN/firewall issue.
- Test AirMedia functions directly and through the touch panel.

12.10 XiO Cloud Management Unavailable

Symptom:

- Receiver does not appear online in XiO Cloud
- Remote management fails
- Local operation works but cloud status is offline

Possible causes:

- XiO Cloud not configured
- Internet access missing
- DNS issue
- Gateway issue
- Firewall blocks outbound cloud traffic
- Device not claimed
- Firmware issue

Checks:

```
Check XiO Cloud settings
Check receiver internet access
Check DNS and gateway
Check firewall policy
Check claim/assignment status
Check firmware version
```

Fix actions:

- Enable or configure XiO Cloud.
- Restore internet/DNS/gateway.
- Allow required outbound connectivity.
- Claim the device in XiO Cloud if required.
- Update firmware if needed.

12.11 802.1X or Active Directory Issue

Symptom:

- Receiver cannot authenticate to network
- Network access denied
- Admin login or enterprise authentication fails
- Device is online only on non-enterprise network

Possible causes:

- Wrong credentials
- Missing certificate
- Incorrect 802.1X configuration
- RADIUS or directory service unreachable
- Time/date issue
- VLAN assignment issue
- Account not authorized

Checks:

```
Check 802.1X configuration
Check certificates
Check credentials
Check RADIUS/AD reachability
Check network policy
Check VLAN assignment
Check device time/date if relevant
```

Fix actions:

- Correct 802.1X settings.

- Load required certificates.
 - Verify Active Directory settings.
 - Confirm account permissions.
 - Check enterprise network policy.
 - Test on a known-good switch port or VLAN.
-

12.12 Firmware or Software Issue

Symptom:

- Receiver behaves unexpectedly
- Presentation fails after update
- Web interface errors
- Device freezes or becomes unstable
- Known bug suspected

Possible causes:

- Outdated firmware
- Failed firmware update
- Incompatible firmware
- Configuration corruption
- Auto Update issue

Fix actions:

```
Check current firmware version
Update firmware through Auto Update
Or perform manual update according to the product manual
Do not interrupt power during update
Verify operation after update
```

After update, test:

```
Web interface access
HDMI output
Wireless presentation
Connect adaptor
XiO Cloud if used
Control-system connection if used
```

12.13 Persistent Configuration Problem

Symptom:

- Receiver remains unstable after normal fixes

- Incorrect settings cannot be corrected
- Presentation behavior remains broken
- Network or display configuration appears corrupted

Possible causes:

- Corrupt configuration
- Incorrect saved settings
- Failed previous setup
- Firmware/configuration mismatch

Fix actions:

- Back up or document current settings if possible.
- Review configuration through web interface.
- Update firmware if needed.
- Perform factory reset according to the AirMedia Series 3 Receivers Product Manual.
- Reconfigure the device after reset.
- Test presentation and display output again.

13. Factory Reset and Recovery

The uploaded source manual states that the AirMedia Series 3 Receivers Product Manual documents restoring the receiver to factory settings to resolve software or configuration issues, as well as updating or resetting network settings.

Factory reset may be used when:

- Configuration is corrupted
- Management settings are incorrect
- Network settings cannot be recovered normally
- Presentation behavior remains unstable
- Device is being moved to another room or site
- A clean reconfiguration is required

Important warning:

Factory reset restores default settings. After reset, the receiver must be reconfigured.

Before reset, document:

```
Device IP address
Room name
Network settings
Display settings
AirMedia settings
Security settings
XiO Cloud status
```

Control-system connection
Firmware version

After reset, verify:

Power LED
LAN LED
IP address
Web interface access
User account creation
HDMI output
Welcome screen
Wireless presentation
Connect adaptor if used
XiO Cloud if used
Control-system connection if used

Do not use undocumented reset procedures unless confirmed in the official AirMedia Series 3 Receivers Product Manual for the exact model and firmware.

14. Maintenance and Best Practices

Recommended practices:

- Keep firmware current using Auto Update or manual update.
- Keep the receiver connected to a stable wired network.
- Verify the external Wi-Fi access point is working.
- Keep HDMI and Ethernet cabling secure.
- Label the HDMI cable and network port.
- Document the receiver IP address and room name.
- Use strong administrator credentials.
- Restrict management access to trusted networks.
- Use enterprise authentication where required.
- Monitor through XiO Cloud where deployed.
- Keep the device physically accessible for service.
- Avoid blocking ventilation.
- Keep the exterior clean with a dry cloth.
- Power-cycle only when required.
- Test presentation after firmware updates.
- Verify the welcome screen instructions are accurate.
- Keep AirMedia Connect adaptors updated and assigned properly.
- Document control-system integration if connected to CP4 or another processor.

Useful maintenance checks:

- Check Power LED
- Check LAN LED
- Check Online LED if control-system connected
- Check HDMI LED during output
- Check web configuration access
- Check firmware version
- Check XiO Cloud status
- Check external Wi-Fi AP status
- Check presentation from laptop
- Check presentation from mobile device
- Check AirMedia Connect adaptor
- Check HDMI display output

15. Quick Reference

Power Check

- Check PoE or PoE+ source
- Check optional PW-2412WU power pack if used
- Check Ethernet cable
- Check Power LED
 - White = operational
 - Amber = booting

LAN Check

- Check Ethernet cable
- Check switch port
- Check LAN LED
 - Green = Ethernet link established
- Verify IP address
- Ping receiver if allowed

HDMI Check

- Check HDMI cable
- Check display power
- Check selected input
- Check HDMI LED
 - White = video transmitted to HDMI output
- Check output resolution

Web Management Access

- Find receiver IP address
- Open browser
- Enter device IP
- Create user on first sign-on
- Sign in with valid credentials

Wireless Presentation Check

- Verify external Wi-Fi access point
- Connect laptop/mobile to correct Wi-Fi
- Follow welcome screen instructions
- Check network reachability to receiver
- Try another client device

AirMedia Connect Adaptor Check

- Check adaptor power and connection
- Verify adaptor is assigned to correct receiver
- Check built-in Wi-Fi/adaptor behavior
- Confirm receiver adaptor limit
- Update firmware if needed

Control System Check

- Check Online LED
- White = connected to Crestron control system
- Check web interface control-system status
- Check CP4/control processor connectivity
- Check control program IP settings

XiO Cloud Check

- Check internet access
- Check DNS and gateway
- Check XiO Cloud settings
- Check firewall policy
- Check device claim status

Security Check

Use AES encrypted presentation
Configure 802.1X if required
Verify Active Directory settings if used
Use strong admin credentials
Note: TLS 1.3 is not currently supported according to the source manual

Firmware Update

Use Auto Update
Or perform manual update according to product manual
Do not interrupt power during update
Test presentation after update

Restart

Power-cycle through PoE only when required
Or restart through management interface if available
Verify normal operation after restart

Factory Reset / Recovery

Use factory reset according to the AirMedia Series 3 Receivers Product Manual
Document settings before reset if possible
Reconfigure network, display, security, and control settings afterward