

Crestron AirMedia Connect Adaptor AM-TX3-100 Manual

1. Official Crestron Sources

This manual is based on official Crestron documentation for the Crestron AirMedia Connect Adaptor AM-TX3-100, especially the AM-TX3-100 Features page, the AM-TX3-100 Operational Instructions, the AM-TX3-100 Specifications page, and the AM-TX3-100 Product Information document.

The uploaded source manual identifies the AM-TX3-100 as an AirMedia Series 3 Connect Adaptor used for wireless presentation and conferencing. It connects to a personal device through USB-C, receives power from that USB-C connection, and pairs wirelessly with a compatible Wi-Fi-capable AirMedia Series 3 Receiver such as the AM-3100-WF or AM-3200-WF.

Practical setup, operation, troubleshooting, maintenance, and support notes were added to make this manual more useful for real deployment and service work. Exact behavior may vary depending on receiver model, receiver firmware version, wireless environment, laptop USB-C capability, AirMedia configuration, and conferencing peripheral setup.

2. Device Description

The Crestron AirMedia Connect Adaptor AM-TX3-100 is a portable wireless presentation and conferencing adaptor from the AirMedia Series 3 family.

Its purpose is to let users quickly share content from a personal device to a room display without installing software. The user connects the adaptor to a laptop or compatible device through the integrated USB-C connector, then uses the adaptor buttons to start or stop screen sharing and conferencing.

The AM-TX3-100 is commonly used in:

- Conference rooms
- Meeting rooms
- Huddle rooms
- Training rooms
- Lounges
- Lobbies
- Collaboration spaces
- Smart office AV systems

In a meeting room topology, the AM-TX3-100 should be treated as the **user-side wireless presentation adaptor**. It works together with an AirMedia Series 3 receiver, such as the AM-3100-WF, which is connected to the room display through HDMI.

Typical workflow:

Laptop USB-C port → AM-TX3-100 adaptor → wireless link → AirMedia receiver → HDMI display

The adaptor is designed for walk-up use. A user can plug it into their device, press the Screenshare button, and present to the display through the paired receiver.

The adaptor can also support wireless conferencing when used with a compatible receiver and conferencing peripherals.

3. Technical Specifications

The AM-TX3-100 is manufactured by Crestron and belongs to the AirMedia Series 3 Connect Adaptor family.

Main characteristics include:

- Wireless presentation adaptor
- Wireless conferencing support when paired with a compatible receiver
- Integrated USB-C connector
- Powered by the connected device USB-C port
- No separate power supply required
- Wi-Fi Direct pairing with a compatible AirMedia Series 3 receiver
- No software installation required on the personal device
- Screenshare capacitive button
- Peripherals capacitive button
- LED ring for state and update indication
- AES content encryption
- Up to 4K30 content support through the adaptor
- Up to eight adaptors can be paired with one compatible receiver
- Firmware update through paired receiver, XiO Cloud, or Crestron Toolbox
- Optional AM-TX3-100-CRADLE for storing up to four adaptors

Power:

Power source: Connected device USB-C port
Separate power supply: Not required

Connection to personal device:

Connector: Integrated USB-C
Requirement: USB-C port must support DisplayPort Alt Mode for video output

Wireless connection:

Wireless method: Wi-Fi Direct pairing to compatible AirMedia Series 3 receiver
Receiver requirement: Wi-Fi-capable AirMedia Series 3 receiver
Firmware requirement: Receiver firmware 3.0000.0067 or greater

Video capability:

Maximum supported content: Up to 4K30 under supported conditions

Physical installation:

Device type: Handheld portable adaptor
Optional storage: AM-TX3-100-CRADLE
Operating environment: Not found in the provided official-source manual
Physical dimensions: Not found in the provided official-source manual

4. Ports, Buttons, and Indicators

The AM-TX3-100 is a compact adaptor with an integrated USB-C connector, capacitive buttons, and LED indicators.

4.1 Integrated USB-C Connector

The integrated USB-C connector connects directly to the user laptop or personal device.

It is used for:

- Power from the connected device
- Video/content connection from the device
- Presentation signal source
- Wireless presentation workflow

Important requirement:

The USB-C port on the laptop or personal device must support **DisplayPort Alt Mode**. If the port does not support DisplayPort Alt Mode, the adaptor may power on but video sharing may not work.

4.2 Screenshare Button

The backlit capacitive Screenshare button is used to control presentation.

Typical behavior:

- Press once to start sharing
- Press once again to stop sharing
- Double-press to pause or resume sharing

The exact behavior can depend on receiver configuration and current session state.

4.3 Peripherals Button

The capacitive Peripherals button is used for wireless conferencing.

It can start or stop access to in-room conferencing peripherals when supported by the receiver and room configuration.

Button color behavior from the source manual:

Green: Conferencing will start automatically
White: User must tap to start conferencing

Wireless conferencing requires a compatible receiver and properly connected room peripherals.

4.4 LED Ring

The LED ring provides visual feedback.

It can indicate:

- Button press acknowledgment
- Sharing state
- Conferencing state
- Pairing or connection state
- Firmware update progress
- Reconnection after update

Firmware update indication from the source manual:

Amber: Firmware update in progress
Solid green: Adaptor has reconnected after update

Important warning:

Do not disconnect the adaptor during a firmware update.

5. Installation and Setup Notes

The AM-TX3-100 does not require traditional installation like a rack-mounted device. It must be paired with a compatible AirMedia Series 3 receiver before normal use.

Basic setup requirements:

1. Use a Wi-Fi-capable AirMedia Series 3 receiver.
2. Confirm the receiver model supports AM-TX3-100 pairing.

3. Confirm receiver firmware is version 3.0000.0067 or greater.
4. Confirm the personal device has a USB-C port that supports DisplayPort Alt Mode.
5. Pair the adaptor with the receiver using the Wi-Fi Direct method described in the Crestron product manual.
6. Confirm the receiver is connected to the display.
7. Confirm the receiver is connected to the network.
8. Confirm wireless presentation is enabled on the receiver.
9. Test screen sharing from a supported laptop.
10. Test conferencing if the room supports wireless conferencing peripherals.

Important setup notes:

- The adaptor does not need a separate power supply.
- The adaptor is powered through USB-C.
- No software installation is required on the personal device.
- The adaptor must be paired with a compatible receiver.
- Wireless conferencing requires a wireless conferencing-capable receiver.
- Wireless conferencing also requires in-room peripherals to be connected and configured.
- A non-WF AirMedia receiver may not support the required wireless pairing behavior.

6. Pairing with an AirMedia Receiver

The AM-TX3-100 must be paired with a compatible AirMedia Series 3 receiver before it can be used.

The source manual notes that the adaptor pairs point-to-point with a Wi-Fi-capable receiver using Wi-Fi Direct.

Pairing is usually handled through the receiver configuration interface.

General pairing concept:

```
Open receiver web interface
Go to Connect Devices or adaptor pairing section
Start the pairing process
Connect or activate the adaptor as instructed
Wait for pairing to complete
Verify adaptor appears in the receiver configuration
Test screen sharing
```

Pairing requirements:

- Receiver must support AM-TX3-100.
- Receiver must have Wi-Fi capability.
- Receiver firmware must be 3.0000.0067 or greater.
- Adaptor must be within wireless range of the receiver.
- Wireless conditions must be stable.

Up to eight adaptors can be paired with a single compatible receiver.

This is useful in rooms where multiple adaptors are stored for users, guests, or different meeting participants.

7. Using the Adaptor for Presentation

Normal presentation use is simple and user-facing.

Basic user steps:

1. Connect the AM-TX3-100 to the laptop USB-C port.
2. Wait for the adaptor to power on and connect.
3. Press the Screenshare button.
4. Confirm content appears on the room display.
5. Press Screenshare again to stop sharing.
6. Double-press Screenshare to pause or resume if needed.

Expected behavior:

- The adaptor powers on from the laptop.
- The adaptor connects to the paired receiver.
- The receiver sends video to the display through HDMI.
- The display shows the laptop content.
- Button presses are acknowledged by the LED ring.

If the adaptor powers on but does not share video, the most common cause is that the laptop USB-C port does not support DisplayPort Alt Mode.

8. Using the Adaptor for Wireless Conferencing

Wireless conferencing allows the user device to access in-room conferencing peripherals through the AirMedia system, depending on receiver capability and configuration.

Examples of room peripherals may include:

- USB camera
- Microphone
- Speakerphone
- Audio DSP
- Room audio system
- Conferencing soundbar

Wireless conferencing requirements:

- Compatible wireless conferencing-capable AirMedia receiver
- Receiver properly configured
- Required room peripherals connected to the receiver or system
- Supported laptop and conferencing application
- Stable wireless connection
- Proper firmware versions

Basic user concept:

```
Connect adaptor to laptop
Start or join video meeting
Tap Peripherals button if required
Select room camera/microphone/speaker in meeting application if needed
Use room peripherals during call
```

If conferencing is unavailable, verify receiver support, peripheral connection, receiver firmware, and room configuration.

9. Normal Operation

During normal operation:

- The adaptor is plugged into a USB-C port.
- The laptop provides power to the adaptor.
- The USB-C port supports DisplayPort Alt Mode.
- The adaptor connects to the paired AirMedia receiver.
- The receiver is online and functioning.
- The display connected to the receiver is powered on and on the correct input.
- The Screenshare button starts and stops sharing.
- Double-pressing Screenshare pauses or resumes sharing.
- The Peripherals button starts or stops conferencing where supported.
- The LED ring provides state feedback.
- The adaptor remains connected during presentation.
- Firmware is compatible with the paired receiver.

Useful normal-operation checks:

```
Check adaptor is fully inserted into USB-C port
Check laptop USB-C supports DisplayPort Alt Mode
Check receiver is powered and online
Check display input
Check Screenshare button response
Check Peripherals button response if conferencing is used
Check LED ring state
Check receiver web interface for adaptor status
```

10. Troubleshooting

Troubleshooting should move from the user device toward the receiver and room system:

1. Laptop USB-C capability
2. Adaptor connection

3. Power from USB-C
 4. Pairing state
 5. Receiver firmware
 6. Receiver Wi-Fi capability
 7. Wireless link
 8. Display output
 9. Conferencing peripherals
 10. Firmware/update state
 11. Hardware fault
-

10.1 Adaptor Does Not Power On

Symptom:

- No LED activity
- Buttons do not light
- Adaptor appears dead
- Receiver does not detect adaptor

Possible causes:

- Laptop USB-C port does not provide power
- USB-C connector not fully inserted
- Laptop is off or sleeping
- USB-C port disabled or damaged
- Adaptor hardware fault

Checks:

Confirm laptop is powered on
Reconnect adaptor firmly
Try another USB-C port on the laptop
Try another compatible laptop
Inspect the USB-C connector for damage
Check LED ring response

Resolution:

If the adaptor powers on with another laptop, the issue is likely the original laptop or USB-C port. If it does not power on with any known-good device, the adaptor may require service or replacement.

10.2 Adaptor Powers On but Does Not Present

Symptom:

- LED/button activity appears
- Adaptor is powered

- No content appears on room display
- Screenshare does not start presentation

Possible causes:

- Adaptor is not paired to receiver
- Receiver is offline
- Receiver is not Wi-Fi-capable
- Receiver firmware is too old
- Wireless connection problem
- Display is on wrong input
- HDMI output issue from receiver
- Laptop USB-C does not support DisplayPort Alt Mode

Checks:

```
Check receiver power and online status
Check adaptor pairing status in receiver web interface
Check receiver firmware version
Check receiver model supports Wi-Fi pairing
Check display input
Check HDMI output from receiver
Try another laptop with DisplayPort Alt Mode
```

Fix actions:

- Pair the adaptor to the receiver.
- Update receiver firmware to a supported version.
- Use a compatible Wi-Fi-capable receiver.
- Confirm display and HDMI output are working.
- Use a laptop USB-C port that supports DisplayPort Alt Mode.

10.3 USB-C Port Does Not Support DisplayPort Alt Mode

Symptom:

- Adaptor powers on
- No video is shared
- Laptop does not detect external display
- Presentation fails even though the adaptor is connected

Possible cause:

The connected USB-C port does not support DisplayPort Alt Mode.

Checks:

Try a different USB-C port on the same laptop
Try a different laptop known to support USB-C video output
Check laptop specifications
Check whether external monitor output works from the same port

Fix:

Use a USB-C port that supports DisplayPort Alt Mode.

Important note:

Not all USB-C ports support video output. Some USB-C ports support only data and charging.

10.4 Pairing or Connection Issue

Symptom:

- Adaptor does not connect to receiver
- Receiver does not show adaptor
- Pairing fails
- Sharing cannot start

Possible causes:

- Adaptor not paired
- Receiver firmware below required version
- Receiver does not support Wi-Fi pairing
- Receiver Wi-Fi disabled or unavailable
- Adaptor out of range
- Wireless interference
- Receiver configuration issue

Checks:

Check receiver firmware version
Confirm receiver is AM-3100-WF, AM-3200-WF, or another compatible Wi-Fi-capable model
Check pairing list in receiver web interface
Move adaptor closer to receiver
Check wireless environment
Re-pair adaptor if needed

Fix actions:

- Update receiver firmware.
- Use a compatible WF receiver.
- Pair the adaptor again.

- Improve wireless conditions.
 - Reboot receiver if pairing state appears stuck.
-

10.5 Receiver Firmware Too Old

Symptom:

- Adaptor cannot pair
- Receiver does not recognize adaptor
- Pairing option is missing
- Connection is unstable

Possible cause:

The receiver firmware is older than the required minimum version.

Requirement from the source manual:

Series 3 receiver firmware must be 3.0000.0067 or greater

Fix actions:

- Update the AirMedia receiver firmware.
 - Use Auto Update where configured.
 - Update manually through the receiver web interface if needed.
 - Use Crestron Toolbox where appropriate.
 - Restart or reboot the receiver after firmware update if required.
 - Re-pair or retest the adaptor.
-

10.6 No Video on Display

Symptom:

- Adaptor appears connected
- Screen sharing starts
- Room display remains blank
- Display shows no signal

Possible causes:

- Display is powered off
- Display is on wrong HDMI input
- HDMI cable disconnected
- HDMI cable faulty
- Receiver HDMI output not working
- Resolution or compatibility issue
- Laptop is not outputting video through USB-C

Checks:

```
Check display power
Check display input source
Check HDMI cable between receiver and display
Check receiver HDMI output LED/status
Try another HDMI cable
Try another display input
Try a known-good laptop
```

Fix actions:

- Select the correct display input.
 - Reseat or replace HDMI cable.
 - Verify receiver output resolution.
 - Confirm laptop USB-C video output.
 - Test receiver with another source or adaptor.
-

10.7 Presentation Disconnects or Becomes Unstable

Symptom:

- Sharing starts then stops
- Display freezes
- Adaptor disconnects
- User must reconnect repeatedly
- Presentation fails after long session

Possible causes:

- Wireless interference
- Weak wireless link
- Receiver issue
- Firmware mismatch
- Extended session recovery issue
- Laptop sleep or power management
- USB-C connection movement

Checks:

```
Move closer to receiver
Check wireless environment
Check receiver firmware
Check laptop sleep settings
Check USB-C connector stability
Check receiver logs if available
```

Fix actions:

- Reconnect the adaptor.
 - Reboot the AirMedia receiver if the adaptor fails to reconnect after a long presentation.
 - Update receiver and adaptor firmware.
 - Improve wireless conditions.
 - Prevent laptop from sleeping during presentation.
-

10.8 Firmware Update in Progress

Symptom:

- LED ring shows firmware update behavior
- Adaptor is temporarily unavailable
- User cannot present during update

Source manual update indication:

```
LED ring may turn amber during firmware update
Do not disconnect adaptor during update
Solid green indicates adaptor has reconnected after update
```

Required action:

Do not unplug the adaptor until the update completes.

If update fails:

- Reconnect the adaptor.
 - Check receiver firmware/update status.
 - Update again through receiver web interface or Crestron Toolbox.
 - Do not interrupt the process.
-

10.9 Wireless Conferencing Unavailable

Symptom:

- Peripherals button does not start conferencing
- Room camera or microphone not available on laptop
- Meeting app does not show room peripherals
- Button is not in expected state

Possible causes:

- Receiver does not support wireless conferencing
- Conferencing peripherals are not connected
- Receiver configuration missing
- Firmware incompatible

- Laptop application not selecting room peripherals
- Wireless conferencing disabled
- Network or wireless issue

Checks:

```
Confirm receiver supports wireless conferencing
Check peripheral connections
Check receiver configuration
Check receiver firmware
Check Peripherals button state
Check meeting app device selection
```

Fix actions:

- Use a wireless conferencing-capable receiver.
- Connect and configure room camera/microphone/speaker.
- Update receiver firmware.
- Select the correct devices in the conferencing application.
- Tap the Peripherals button if required.

10.10 Peripherals Button Does Not Behave as Expected

Symptom:

- Button does not start conferencing
- Button color does not match expected operation
- Conferencing starts manually instead of automatically

Button state note from source manual:

```
Green: Conferencing will start automatically
White: User must tap to start conferencing
```

Possible causes:

- Wireless conferencing setting differs from expected behavior
- Receiver configuration issue
- Peripherals not detected
- Meeting application not using room devices
- Firmware mismatch

Fix actions:

- Check receiver wireless conferencing configuration.
- Confirm peripherals are connected and recognized.
- Check meeting application audio/video device selection.

- Update firmware if required.
 - Test with another laptop.
-

10.11 Adaptor Disconnects After Long Presentation Session

Symptom:

- Long presentation ends
- User tries to restart sharing
- Adaptor fails to reconnect
- Receiver does not accept the session again

Source-based recovery note:

The uploaded source manual notes that if the device disconnects after a long presentation, especially after an extended session is stopped and restarted, rebooting the AirMedia receiver can restore reconnection.

Fix actions:

```
Stop sharing
Unplug and replug adaptor
If still failing, reboot the AirMedia receiver
Wait for receiver to come back online
Reconnect adaptor
Start sharing again
```

10.12 Adaptor Management or Firmware Update Not Available

Symptom:

- Admin cannot update adaptor
- Adaptor does not appear in management interface
- XiO Cloud does not show expected status
- Crestron Toolbox cannot update adaptor

Possible causes:

- Adaptor not paired with receiver
- Receiver not online
- Receiver firmware issue
- Network access issue
- XiO Cloud not enabled
- Toolbox connection issue

Checks:

```
Check receiver web interface
Check adaptor pairing status
Check receiver network connectivity
Check XiO Cloud status if used
Check Crestron Toolbox connection
```

Fix actions:

- Pair or re-pair the adaptor.
- Bring the receiver online.
- Update receiver firmware.
- Use receiver web interface, XiO Cloud, or Crestron Toolbox for update.

10.13 Physical Connector or Hardware Damage

Symptom:

- Adaptor works only when held at an angle
- USB-C connector feels loose
- Laptop does not detect adaptor
- Adaptor disconnects when moved

Possible causes:

- Damaged USB-C connector
- Bent connector
- Worn laptop USB-C port
- Physical stress from handling
- Dropped adaptor

Checks:

```
Inspect USB-C connector
Try another laptop
Check for looseness
Check for visible damage
Avoid forcing connector
```

Fix actions:

- Use another known-good laptop to confirm.
- Stop using the adaptor if connector damage is visible.
- Replace the adaptor if hardware damage is confirmed.
- Store adaptors properly in the cradle when not in use.

11. Factory Reset and Recovery

Factory reset and recovery steps were not found in the official documentation used in the uploaded source manual.

Because no official factory-reset procedure was provided in the referenced documentation, this manual should not invent an undocumented reset sequence.

Recommended recovery approach:

1. Unplug and replug the adaptor.
2. Confirm the laptop USB-C port supports DisplayPort Alt Mode.
3. Confirm the adaptor is paired with the correct receiver.
4. Check receiver firmware version.
5. Re-pair the adaptor if necessary.
6. Update adaptor firmware through the paired receiver, XiO Cloud, or Crestron Toolbox.
7. Reboot the paired AirMedia receiver if reconnection fails.
8. Use a known-good laptop for testing.
9. Replace the adaptor if hardware failure is confirmed.

Important note:

The adaptor depends heavily on the paired receiver. Many recovery actions are performed from the receiver side rather than directly on the adaptor.

12. Maintenance and Best Practices

Recommended practices:

- Keep receiver firmware updated.
- Keep adaptor firmware matched with the receiver.
- Update the adaptor through the receiver web interface, XiO Cloud, or Crestron Toolbox.
- Do not disconnect the adaptor during firmware updates.
- Store adaptors in the AM-TX3-100-CRADLE when not in use.
- Keep the USB-C connector clean and undamaged.
- Avoid bending or forcing the USB-C connector.
- Label adaptors by room if multiple rooms are deployed.
- Pair adaptors only with their intended room receiver.
- Test adaptors after receiver firmware updates.
- Keep spare adaptors available for important meeting rooms.
- Confirm laptops support DisplayPort Alt Mode before troubleshooting the AV system.
- Reboot the receiver if adaptor reconnection fails after a long session.
- Wipe the adaptor with a soft, dry cloth.
- Avoid liquid cleaners and harsh chemicals.

Useful maintenance checks:

```
Check adaptor physical condition
Check USB-C connector
Check receiver pairing list
```

- Check receiver firmware
- Check adaptor firmware/update status
- Check Screenshare button response
- Check Peripherals button response
- Check LED ring behavior
- Test presentation with known-good laptop
- Test conferencing if room supports it

13. Quick Reference

Power Check

- Plug adaptor into laptop USB-C port
- Confirm laptop is powered on
- Try another USB-C port
- Try another compatible laptop
- Check LED ring or button response

USB-C Video Requirement

- Laptop USB-C port must support DisplayPort Alt Mode
- Some USB-C ports support only charging/data and not video
- Try known-good USB-C video-capable laptop

Pairing Check

- Use compatible Wi-Fi-capable AirMedia Series 3 receiver
- Open receiver web interface
- Check adaptor pairing status
- Re-pair adaptor if needed

Receiver Requirement

- Use AM-3100-WF, AM-3200-WF, or compatible Wi-Fi-capable AirMedia Series 3 receiver
- Receiver firmware must be 3.0000.0067 or greater

Presentation Start / Stop

- Connect adaptor to laptop
- Press Screenshare to start sharing

Press Screenshare again to stop sharing
Double-press Screenshare to pause or resume

Conferencing Start / Stop

Use compatible wireless conferencing-capable receiver
Confirm room peripherals are connected
Tap Peripherals button if required
Select room camera/microphone/speaker in meeting app if needed

Peripherals Button Color

Green: Conferencing will start automatically
White: User must tap to start conferencing

Firmware Update

Update through receiver web interface, XiO Cloud, or Crestron Toolbox
Do not disconnect adaptor during update
Amber LED may indicate update in progress
Solid green indicates reconnection after update

No Video

Check DisplayPort Alt Mode support
Check receiver pairing
Check display input
Check HDMI output from receiver
Check receiver firmware
Try another laptop

Reconnect Problem

Unplug and replug adaptor
Stop and restart sharing
Reboot AirMedia receiver if adaptor fails to reconnect
Check receiver firmware and pairing

Management

Manage adaptor through paired receiver web interface
Or XiO Cloud if deployed
Or Crestron Toolbox where supported

Factory Reset / Recovery

Official factory reset steps were not found in the provided official-source manual
Recover by replugging adaptor, re-pairing, updating firmware, or rebooting paired receiver