

Crestron TST-1080 Touch Screen Manual

1. Official Crestron Sources

This manual is based on official Crestron documentation for the Crestron TST-1080 Touch Screen, especially the TST-1080 Product Manual, the TST-1080 Features documentation, the TST-1080 Initial Setup guide, and the TST-1080 Device Configuration guide.

The uploaded source manual identifies the Crestron TST-1080 as a 10.1-inch wireless capacitive touch screen controller used as a portable or docked user interface for Crestron control systems. It supports Wi-Fi connectivity, docking-based charging, web configuration, local setup, XiO Cloud management, virtual buttons, streaming video, Rava SIP intercom, voice recognition, and enterprise security features.

Practical setup, operation, troubleshooting, maintenance, and support notes were added to make this manual more useful for real installation and service work. Exact options may vary depending on firmware version, configured Crestron control system, wireless network design, docking hardware, and deployed applications.

2. Device Description

The Crestron TST-1080 is an advanced 10.1-inch tablet-style wireless touch screen controller. It is designed to provide a user-friendly control interface for Crestron-based AV, lighting, HVAC, shades, room scheduling, intercom, and automation systems.

The TST-1080 can be used portably or docked. It is commonly used in:

- Corporate meeting rooms
- Boardrooms
- Classrooms
- Government rooms
- High-end residential spaces
- Smart office environments
- Conference rooms
- AV control systems
- Building control systems

The touch screen connects to the Crestron control system over Wi-Fi. It does not use wired Ethernet for normal network connectivity. Power is supplied by its internal rechargeable Lithium-Ion battery, and charging is done through a table dock or optional wall dock.

The TST-1080 acts as the **user interface** for the room or building control system. Users interact with the touch screen to control devices and functions such as:

- Display power
- Source selection
- Volume
- Lighting scenes
- Shades

- HVAC settings
- Video conferencing
- Microphone mute
- Room mode
- Intercom
- Streaming video display
- Custom Crestron HTML5 user interfaces

In a smart office topology, this device should be treated as the **wireless touch control interface** that communicates with the Crestron control processor, such as the Crestron CP4.

3. Technical Specifications

The Crestron TST-1080 is manufactured by Crestron and is designed as a wireless touch screen controller for Crestron systems.

Main characteristics include:

- 10.1-inch capacitive touch display
- Tablet-style wireless design
- Wi-Fi network connectivity
- Rechargeable Lithium-Ion battery
- Charging through TST-1080-DS table dock
- Optional TST-1080-DSW wall dock
- Web configuration interface
- Local on-screen configuration
- XiO Cloud management support
- Crestron HTML5 user interface support
- Integrated microphone
- Integrated speakers
- H.264 streaming video display support
- MJPEG streaming video display support
- Rava SIP intercom support
- Voice recognition support
- Programmable virtual buttons
- Authentication enabled by default
- 802.1X support
- Active Directory support
- SSH
- TLS
- HTTPS
- SNMP support

The touch screen supports handoff between up to four predesignated wireless access points. This helps maintain Wi-Fi connectivity when the device is moved around a room or area.

The uploaded source manual states that the device can operate for roughly up to nine hours of continuous operation, depending on use case, configuration, battery condition, screen brightness, wireless activity, and

enabled features.

Physical information:

Display size: 10.1-inch capacitive touch panel
Full physical dimensions: Not found in the provided official-source manual
Operating environment: Not found in the provided official-source manual

Power:

Battery type: Rechargeable Lithium-Ion battery
Charging method: TST-1080-DS table dock or optional TST-1080-DSW wall dock

Network:

Network type: Wi-Fi
Wired Ethernet: Not used for normal network connection

4. Ports, Buttons, Docking, and Indicators

The TST-1080 is primarily controlled through its touch display and docking system rather than through traditional wired ports.

4.1 Touch Display

The main control surface is the 10.1-inch capacitive touch display.

It is used for:

- Room control
- AV control
- Lighting control
- Shades control
- HVAC control
- Intercom functions
- Custom Crestron HTML5 interface
- Setup and configuration screens
- Application selection
- Status display

The display can show different states such as:

- Active control interface
- Splash screen

- Standby
- Screensaver
- Setup wizard
- Local configuration screens

The IP address may be shown on the splash screen, which is useful for accessing the web configuration interface.

4.2 Virtual Buttons

The TST-1080 includes preconfigured virtual buttons that can be programmed or hidden individually.

Common virtual buttons include:

- Power
- Home
- Lights
- Up
- Down
- Microphone

These buttons may be mapped to room-control functions depending on the loaded Crestron program and user interface design.

Examples:

```
Power → Turn room system on/off  
Home → Return to main control page  
Lights → Open lighting control page  
Up/Down → Adjust shades, volume, or navigation  
Microphone → Mute or unmute microphone
```

Actual behavior depends on the Crestron configuration and programming.

4.3 Five-Finger Local Setup Access

The touch screen can open local setup screens using a five-finger press when the Local Setup Sequence toggle is enabled.

This is useful for:

- Wi-Fi configuration
- IP information
- Device setup
- Local troubleshooting
- Checking configuration without web access

If local setup cannot be opened, the Local Setup Sequence may be disabled.

4.4 Microphone

The integrated microphone supports functions such as:

- Voice recognition
- Rava SIP intercom
- Audio input for supported workflows

If microphone-related functions do not work, check the configuration, mute status, permissions, and related Crestron system settings.

4.5 Speakers

Integrated speakers support:

- Intercom audio
- System sounds
- Audio feedback
- Rava SIP intercom output

If audio output is missing, check volume, mute settings, intercom configuration, and system programming.

4.6 Dock Connector

The touch screen charges through the dock connector when placed into a supported dock.

Supported docking options include:

- TST-1080-DS table dock
- Optional TST-1080-DSW wall dock

The dock is essential for charging and stable stationary use.

If the device does not charge, inspect the dock, charging contacts, power supply, seating position, and battery status.

4.7 Battery

The internal Lithium-Ion battery allows portable use when the device is removed from the dock.

Battery life depends on:

- Screen brightness
- Wi-Fi signal strength
- Streaming video use
- Intercom use
- Standby timeout
- Application activity
- Battery age
- Charging habits

4.8 Status and Display States

The TST-1080 uses its display and interface states to provide operational information.

Important states include:

- Powered on
- Charging
- Standby
- Screensaver
- Splash screen
- Setup wizard
- Wi-Fi connected
- Wi-Fi disconnected
- Application running

These states should be checked during troubleshooting.

5. Installation and Setup Notes

Before installing or deploying the TST-1080, confirm the touch screen, dock, wireless network, Crestron control processor, and required application are available.

Basic setup steps:

1. Place the TST-1080 into the TST-1080-DS table dock.
2. Allow the internal battery to charge.
3. Power on the touch screen.
4. Complete the setup wizard on first startup or after restore.
5. Select the required language.
6. Set the correct time zone.
7. Connect the device to the correct Wi-Fi network.
8. Select or configure the required application.
9. Confirm the device receives an IP address.
10. Create the required administrator account.
11. Access the web configuration interface if needed.
12. Connect the touch screen to the Crestron control system.
13. Confirm that the correct user interface is loaded.
14. Test room control functions.
15. Test docking and charging.
16. Document the device name, IP address, location, dock, and associated control processor.

Important setup notes:

- The TST-1080 ships with DHCP enabled.
- A DHCP server is required for automatic IP addressing.
- A static IP can be configured if needed.
- The IP address can be found on the splash screen.
- Authentication is enabled out of the box.
- An administrator account must be created.
- WPA2-Enterprise requires 802.1X certificates to be loaded onto the touch screen.
- There is no wired network cabling for normal operation; the device uses Wi-Fi.

6. Docking and Charging

The TST-1080 uses its dock for charging and stationary use.

6.1 Table Dock

The included TST-1080-DS table dock is used to charge the touch screen on a table or flat surface.

Use the table dock when:

- The touch screen is used in a meeting room
- Portable use is required
- Users need to pick up and return the device
- Charging should be convenient and visible

6.2 Wall Dock

The optional TST-1080-DSW wall dock allows wall-mounted charging and use.

The uploaded source manual notes that the wall dock requires additional back-box hardware and allows a maximum of 16° of back tilt.

Use the wall dock when:

- A fixed wall location is preferred
- The device should remain in one place
- The room requires a permanent control point
- Table placement is not suitable

6.3 Charging Problems

If the device does not charge:

- Confirm the dock has power.
- Confirm the touch screen is seated correctly.
- Inspect dock charging contacts.
- Clean contacts gently if needed.
- Try another compatible dock if available.
- Check whether the battery is fully depleted.
- Leave the device charging long enough before assuming failure.

7. Wi-Fi and Network Configuration

The TST-1080 connects to the network over Wi-Fi.

It requires wireless connectivity to communicate with the Crestron control system and management services.

7.1 Wi-Fi Setup

Wi-Fi can be configured during the setup wizard or through network settings.

Typical Wi-Fi setup steps:

```
Open setup wizard or network settings
Scan for available Wi-Fi networks
Select the correct SSID
Enter the correct password or enterprise settings
Connect to the network
Verify IP address
Verify communication with the Crestron control system
```

7.2 DHCP and Static IP

The device ships with DHCP enabled.

DHCP is recommended when:

- The network has a reliable DHCP server
- Centralized IP management is used
- The device does not require a fixed manual IP

Static IP may be used when:

- The AV network requires fixed addressing
- DHCP is unavailable
- The system program expects a known IP address
- Site policy requires static addressing

If the web interface cannot be accessed, check the IP address shown on the splash screen.

7.3 Access Point Handoff

The TST-1080 can hand off between up to four predesignated access points.

This is useful when:

- The device is moved around a room or area
- Multiple APs cover the same space
- Roaming is required
- Wireless reliability is important

For best performance:

- Use strong Wi-Fi coverage.
- Avoid weak signal areas.
- Use properly placed access points.
- Avoid interference.
- Keep the touch screen near designed wireless coverage zones.
- Make sure the selected APs are part of the intended wireless design.

7.4 WPA2-Enterprise and 802.1X

For WPA2-Enterprise networks, 802.1X certificates must be loaded onto the touch screen.

If enterprise Wi-Fi fails, check:

- Correct SSID
 - Correct identity
 - Correct password or credentials
 - Correct certificate loaded
 - Certificate validity
 - RADIUS server reachability
 - Network time and date
 - Authentication policy
 - VLAN assignment
-

8. Management Access

The TST-1080 can be managed through several methods.

Management options include:

- Web configuration interface
- Local on-screen configuration
- XiO Cloud

8.1 Web Configuration Interface

The web configuration interface is accessed by entering the touch screen IP address in a browser.

Use it to:

- Configure device settings
- Update firmware
- Check network status
- Manage authentication
- Adjust system behavior
- Review device information

To access it:

```
Find the IP address on the splash screen
Open a browser
Enter the IP address
Log in with administrator credentials
```

If the web interface does not open, verify Wi-Fi connectivity, IP address, DHCP/static IP settings, and network reachability.

8.2 Local On-Screen Configuration

Local setup allows configuration directly from the touch screen.

It may be used for:

- Wi-Fi setup
- Language
- Time zone
- Application selection
- Device settings
- Local diagnostics

The five-finger press can open local setup only when the Local Setup Sequence is enabled.

8.3 XiO Cloud

XiO Cloud can be used for cloud-based device monitoring and management where deployed.

It may support:

- Device status monitoring
- Configuration management
- Firmware management
- Remote administration
- Fleet management

If XiO Cloud does not work, check internet access, DNS, cloud settings, authentication, and firewall rules.

9. Security Configuration

The TST-1080 includes several security-related features.

Security features include:

- Authentication enabled out of the box
- Administrator account requirement
- 802.1X support
- Active Directory support
- SSH
- TLS
- HTTPS
- SNMP

Recommended security practices:

- Create a strong administrator password.
- Use HTTPS for management.
- Avoid weak shared credentials.
- Use 802.1X for enterprise Wi-Fi where required.
- Load valid certificates for WPA2-Enterprise.
- Restrict management access to trusted networks.

- Keep firmware updated.
 - Use centralized authentication where appropriate.
 - Remove unused accounts.
 - Document administrator access.
 - Avoid connecting the device to untrusted Wi-Fi networks.
-

10. Application and User Interface Operation

The TST-1080 displays the configured Crestron user interface.

It may run:

- Crestron HTML5 user interface
- Room control application
- AV control interface
- Lighting or shades control interface
- Intercom interface
- Custom project interface

The loaded interface determines what the user can control.

Common user interface functions:

- Start meeting
- End meeting
- Power system on/off
- Select source
- Control display
- Control projector
- Adjust volume
- Mute microphones
- Control lighting
- Control shades
- Start video conference
- View camera or video stream
- Use intercom

If the interface loads but devices do not respond, the issue may be with the Crestron control processor, control program, network communication, or controlled device—not necessarily the touch screen.

11. Streaming Video, Rava Intercom, and Voice Features

The TST-1080 supports advanced interface functions including streaming video, intercom, and voice-related features.

11.1 Streaming Video

The device supports H.264 and MJPEG streaming video display.

Streaming video may be used for:

- Camera preview
- Door station video
- Room monitoring
- AV preview
- Security or intercom video

If video does not display, check:

- Stream URL or source
- Network connectivity
- Supported format
- Control system configuration
- Bandwidth
- Wi-Fi signal quality
- Authentication if required by stream source

11.2 Rava SIP Intercom

The touch screen supports Rava SIP intercom where configured.

Intercom may be used for:

- Room-to-room communication
- Door station communication
- Front desk communication
- Help desk call
- Internal communication

If intercom fails, check:

- SIP/Rava configuration
- Microphone mute state
- Speaker volume
- Network reachability
- Firewall or VLAN restrictions
- Control system programming

11.3 Voice Recognition

The integrated microphone can support voice recognition where configured.

If voice recognition does not work, check:

- Microphone setting
- Voice feature configuration
- Network access
- Room noise level
- Application support
- Firmware version

12. Standby, Screensaver, and Power Behavior

The TST-1080 supports configurable standby behavior.

The uploaded source manual states the standby timeout is configurable as follows:

```
Docked: 0 to 7200 seconds
Undocked: 0 to 120 seconds
```

Standby settings affect:

- Battery life
- Screen availability
- User experience
- Room readiness
- Charging behavior
- Power consumption

If the screen turns off too quickly, increase the standby timeout.

If the battery drains quickly, reduce timeout, reduce brightness if available, and keep the device docked when not in use.

13. Normal Operation

During normal operation:

- The battery has sufficient charge.
- The touch screen powers on.
- The device connects to the configured Wi-Fi network.
- The device receives a valid IP address.
- The control interface loads correctly.
- The touch screen communicates with the Crestron control system.
- Virtual buttons trigger their programmed functions.
- Docking charges the device.
- Standby and screensaver behavior matches configuration.
- Web or local configuration is accessible to authorized administrators.
- XiO Cloud works if deployed.
- Streaming video works if configured.
- Rava intercom works if configured.
- Voice recognition works if configured.
- Room devices respond correctly through the control system.

Useful normal-operation checks:

```
Check battery level
Check dock charging
Check Wi-Fi connection
Check IP address
Check control interface loading
Check touch response
Check virtual buttons
Check room control commands
Check standby timeout
Check web interface access
Check local setup access
Check XiO Cloud status if used
```

14. Troubleshooting

Troubleshooting should move from the physical layer and user-facing symptoms upward:

1. Battery and charging
2. Dock and charging contacts
3. Power state
4. Touch display state
5. Wi-Fi connection
6. IP addressing
7. Authentication
8. Control system communication
9. Application/interface loading
10. Room device response
11. Streaming/intercom/voice features
12. Firmware
13. Hardware fault

14.1 Touch Screen Does Not Power On

Symptom:

- Screen is black
- Device does not respond
- No interface appears
- Device appears dead

Possible causes:

- Battery depleted
- Device not seated properly in dock
- Dock has no power
- Charging contacts dirty or misaligned
- Battery problem

- Firmware or boot issue
- Hardware fault

Checks:

1. Place the touch screen in the TST-1080-DS dock.
2. Confirm the dock is powered.
3. Confirm the device is seated correctly.
4. Inspect charging contacts.
5. Leave the device charging if the battery is fully depleted.
6. Try another compatible dock if available.
7. Check whether the screen wakes after charging.

Resolution:

If the device powers on after charging, the issue was likely battery depletion or dock seating. If it remains off after confirmed charging, escalate for service.

14.2 Device Does Not Charge

Symptom:

- Battery level does not increase
- Device shuts down after removal from dock
- Charging indicator does not appear
- Device only works briefly

Possible causes:

- Dock not powered
- Dirty charging contacts
- Device not seated correctly
- Faulty dock
- Faulty power supply
- Battery degradation
- Hardware issue

Checks:

Check dock power
Reseat the device in the dock
Inspect charging contacts
Clean gently with proper non-abrasive method
Try another dock if available
Check battery status after charging

Fix actions:

- Restore dock power.
 - Seat the device correctly.
 - Clean contacts carefully.
 - Replace faulty dock or power source if confirmed.
 - Escalate if battery appears faulty.
-

14.3 Web Configuration Interface Cannot Be Accessed

Symptom:

- Browser cannot open device page
- IP address does not respond
- Login page unavailable
- Admin cannot configure remotely

Possible causes:

- Device not connected to Wi-Fi
- No DHCP server
- Unknown IP address
- Wrong IP address
- Static IP misconfigured
- Management device on different network
- Firewall or VLAN issue
- Device not fully booted

Checks:

```
Check Wi-Fi connection
Check IP address on splash screen
Confirm DHCP server is available
Ping the touch screen IP address
Try access from same VLAN
Check static IP settings if configured
Check network routing/firewall
```

Fix actions:

- Connect to the correct Wi-Fi network.
 - Use the IP address shown on the splash screen.
 - Enable or fix DHCP service.
 - Configure a valid static IP if needed.
 - Move admin laptop to the same network for testing.
 - Check VLAN and firewall rules.
-

14.4 Wi-Fi Connection Problem

Symptom:

- Device cannot join Wi-Fi
- Wi-Fi disconnects repeatedly
- Control interface loses connection
- Web interface becomes unreachable

Possible causes:

- Wrong SSID
- Wrong password
- Weak signal
- AP coverage issue
- Device not assigned to allowed network
- MAC filtering
- WPA2-Enterprise certificate issue
- DHCP issue
- Interference
- AP handoff issue

Checks:

```
Confirm correct SSID
Confirm password
Check signal strength
Move closer to access point
Check DHCP
Check enterprise certificate if used
Check AP coverage
Check interference
Check allowed access points
```

Fix actions:

- Reconnect through setup wizard or Network settings.
- Enter correct credentials.
- Load required 802.1X certificates for enterprise Wi-Fi.
- Improve Wi-Fi coverage.
- Verify AP handoff configuration.
- Check access point and controller logs if available.

14.5 WPA2-Enterprise / 802.1X Failure

Symptom:

- Device connects to personal Wi-Fi but not enterprise Wi-Fi
- Authentication fails
- Wi-Fi profile rejects credentials

- Device cannot obtain network access

Possible causes:

- Missing 802.1X certificate
- Wrong credentials
- Wrong EAP method
- Certificate expired
- RADIUS server unreachable
- Time/date incorrect
- Network policy blocks device
- Wrong VLAN assignment

Fix actions:

```
Load required certificates onto the touch screen
Verify enterprise Wi-Fi credentials
Check certificate validity
Check RADIUS server
Verify device time/date
Confirm network policy
Confirm VLAN assignment
```

Expected result:

After valid certificates and credentials are configured, the device should connect to the enterprise Wi-Fi network.

14.6 Local Setup Cannot Be Accessed

Symptom:

- Five-finger press does not open setup
- Admin cannot access local setup screens
- Device stays on user interface only

Possible cause:

- Local Setup Sequence toggle is disabled

Fix:

```
Enable the Local Setup Sequence
Use a five-finger press to open local setup
```

If the setting cannot be changed locally, use the web configuration interface if accessible.

14.7 Screen Enters Standby Too Quickly

Symptom:

- Screen dims unexpectedly
- Screen turns off too quickly
- Users think the device is off
- Interface disappears while room is in use

Possible causes:

- Standby timeout too short
- Undocked timeout set low
- Docked timeout set incorrectly
- Power-saving configuration
- Battery-saving behavior

Fix:

```
Adjust standby timeout settings
Docked range: 0 to 7200 seconds
Undocked range: 0 to 120 seconds
Save settings
Test behavior again
```

Recommended approach:

Use a longer docked timeout for fixed room use and a shorter undocked timeout to preserve battery.

14.8 Touch Input Does Not Work Properly

Symptom:

- Touch response is delayed
- Wrong area responds
- Buttons do not respond
- Interface appears frozen

Possible causes:

- Application freeze
- Firmware issue
- Dirty screen
- User interface problem
- Low battery
- Device performance issue
- Control processor not responding
- Network delay

Checks:

```
Clean screen with soft cloth
Check battery level
Restart device if needed
Check Wi-Fi connection
Check whether only one page or all touch input is affected
Check control processor communication
```

Fix actions:

- Clean display.
 - Restart through configuration interface if possible.
 - Charge the device.
 - Verify Wi-Fi.
 - Check the Crestron control program if buttons respond visually but do not control devices.
-

14.9 Interface Loads but Room Devices Do Not Respond

Symptom:

- Touch screen UI appears normal
- Buttons can be pressed
- Display, lights, shades, or AV devices do not react

Possible causes:

- CP4 or control processor offline
- Touch screen not connected to the correct processor
- Wi-Fi/network issue
- Control program issue
- Device IP address changed
- Serial/IR/relay device issue downstream
- Wrong project loaded
- Authentication or communication issue

Checks:

```
Check touch screen Wi-Fi
Check control processor status
Check whether CP4 is reachable
Check loaded interface/project
Check room control program
Check controlled device power
Check device communication from processor
```

Fix actions:

- Verify the touch screen is connected to the correct Crestron system.
- Check the CP4 or processor.
- Verify network communication.
- Test controlled devices individually.
- Confirm correct UI/project is loaded.

Important note:

If the touch screen is working but room devices do not respond, the fault may be in the control processor, control program, or controlled equipment rather than the touch screen itself.

14.10 Streaming Video Does Not Display

Symptom:

- Camera or video preview is blank
- Stream fails to load
- Video freezes
- Error appears in video window

Possible causes:

- Unsupported stream format
- Wrong stream URL
- H.264/MJPEG source unavailable
- Wi-Fi bandwidth issue
- Weak signal
- Authentication required by stream source
- Firewall/VLAN issue
- Source camera or encoder offline

Checks:

```
Check stream source
Check stream format
Check Wi-Fi signal
Check bandwidth
Check URL/configuration
Check camera/encoder status
Check network access
```

Fix actions:

- Use supported H.264 or MJPEG stream.
- Correct stream address.
- Improve Wi-Fi.
- Check source device.
- Verify firewall and VLAN access.

- Reduce bandwidth load if needed.
-

14.11 Rava SIP Intercom Does Not Work

Symptom:

- Intercom call fails
- No audio
- Microphone does not transmit
- Speaker does not play audio
- Incoming call does not appear

Possible causes:

- Rava/SIP configuration missing
- Microphone muted
- Speaker volume low
- Network issue
- Firewall blocks intercom traffic
- Wrong extension or endpoint
- Control system configuration issue

Checks:

```
Check Rava/SIP configuration
Check microphone mute
Check speaker volume
Check Wi-Fi connectivity
Check network routing
Check intercom endpoint settings
```

Fix actions:

- Correct intercom configuration.
 - Unmute microphone.
 - Increase volume.
 - Verify network access.
 - Check related Crestron system settings.
-

14.12 Voice Recognition Does Not Work

Symptom:

- Voice commands are ignored
- Microphone appears inactive
- Commands work inconsistently

Possible causes:

- Voice feature not configured
- Microphone muted
- Room noise too high
- Wrong command phrases
- Network issue
- Firmware issue
- Application does not support voice command

Checks:

```
Check microphone status
Check voice recognition configuration
Check supported commands
Reduce background noise
Check network access
Check firmware version
```

Fix actions:

- Enable and configure voice feature if required.
- Verify microphone operation.
- Use supported voice commands.
- Reduce background noise.
- Update firmware if needed.

14.13 XiO Cloud Management Unavailable

Symptom:

- Device not visible in XiO Cloud
- Cloud status offline
- Remote management unavailable
- Local use works but cloud access fails

Possible causes:

- XiO Cloud not enabled
- No internet access
- DNS issue
- Firewall blocks cloud communication
- Device not claimed or assigned
- Authentication issue
- Firmware issue

Checks:

```
Check Wi-Fi internet access
Check DNS
Check XiO Cloud settings
Check firewall rules
Check device claim status
Check firmware version
```

Fix actions:

- Enable XiO Cloud if required.
- Restore internet access.
- Fix DNS/gateway.
- Allow required outbound cloud communication.
- Claim or assign the device properly.
- Update firmware if needed.

14.14 Firmware or Software Issue

Symptom:

- Interface freezes
- Configuration pages behave incorrectly
- Wireless behavior is unstable
- Known bug suspected
- Device requires feature update

Possible causes:

- Outdated firmware
- Failed update
- Configuration corruption
- Application compatibility issue
- PUF update required

Fix actions:

```
Check current firmware version
Update firmware through the configuration interface
Use the proper PUF update package
Keep device charged during update
Do not interrupt update process
Verify operation after update
```

Important note:

Firmware updates should be planned and tested, especially in active meeting rooms.

15. Factory Reset and Recovery

The setup wizard appears after first power-up or after a restore. It allows reconfiguration of:

- Language
- Time zone
- Wi-Fi
- Application selection

Specific factory-reset button steps were not found in the official Crestron documentation used in the uploaded source manual.

Because no official reset button sequence was provided in the referenced documentation, this manual should not invent an undocumented reset method.

Recommended recovery approach:

1. Try local configuration first.
2. Try the web configuration interface using the device IP address.
3. Confirm Wi-Fi connectivity.
4. Confirm administrator credentials.
5. Restart the device through the configuration interface if available.
6. Update firmware if a software issue is suspected.
7. Use the setup wizard after restore when available.
8. Contact the system programmer or Crestron support if recovery steps are unclear.
9. Avoid undocumented reset procedures unless confirmed from official Crestron documentation for the exact firmware and model.

Important warning:

A restore or reset may remove configuration, Wi-Fi settings, application selection, authentication settings, and connection to the Crestron control system. The device may need to be re-provisioned afterward.

16. Maintenance and Best Practices

Recommended practices:

- Keep firmware updated through the configuration interface.
- Keep the device charged when not in use.
- Return the touch screen to the dock after meetings.
- Verify dock power regularly.
- Clean the screen with a soft, non-abrasive cloth.
- Avoid harsh chemicals on the display.
- Keep Wi-Fi coverage strong in the room.
- Avoid using weak or unstable wireless networks.
- Document the device IP address, room name, and associated control processor.
- Use strong administrator credentials.
- Use HTTPS for management.
- Use 802.1X certificates for enterprise Wi-Fi where required.

- Monitor through XiO Cloud where deployed.
- Keep the local setup sequence enabled only according to site policy.
- Avoid unnecessary restarts.
- Plan firmware updates during maintenance windows.
- Test room control functions after updates.
- Keep docking contacts clean.
- Replace or service the dock if charging becomes unreliable.

Useful maintenance checks:

```
Check battery charge
Check dock charging
Check Wi-Fi connection
Check IP address
Check firmware version
Check web interface access
Check local setup access
Check room control functions
Check standby timeout
Check streaming video if used
Check Rava intercom if used
Check XiO Cloud status if used
```

17. Quick Reference

Power Check

```
Check battery level
Place device in dock
Confirm dock power
Inspect charging contacts
Allow charging if battery is depleted
```

Charging Check

```
Use TST-1080-DS table dock
Or optional TST-1080-DSW wall dock
Confirm device is seated correctly
Check dock power supply
Check charging contacts
```

Wi-Fi Check

- Confirm correct SSID
- Confirm password
- Check signal strength
- Verify DHCP or static IP
- Check enterprise certificates if using WPA2-Enterprise

IP Address Check

- Check IP address on splash screen
- Use DHCP by default
- Configure static IP if required
- Verify network reachability

Web Management Access

- Open browser
- Enter touch screen IP address
- Use administrator credentials
- Verify Wi-Fi and IP settings if page does not load

Local Setup Access

- Enable Local Setup Sequence
- Use five-finger press
- Open local setup screens

WPA2-Enterprise Check

- Load required 802.1X certificates
- Verify credentials
- Check certificate validity
- Check RADIUS/network policy

Standby Timeout

- Docked: 0 to 7200 seconds
- Undocked: 0 to 120 seconds
- Adjust based on room use and battery needs

Room Control Issue

- Check touch screen Wi-Fi
- Check control processor status
- Check correct interface/project
- Check controlled device power
- Check CP4/control program

Streaming Video Issue

- Verify H.264 or MJPEG source
- Check stream URL
- Check Wi-Fi bandwidth
- Check source camera/encoder
- Check network access

Rava Intercom Issue

- Check Rava/SIP configuration
- Check microphone mute
- Check speaker volume
- Check Wi-Fi/network access

Firmware Update

- Use configuration interface
- Apply correct PUF update
- Keep device charged
- Do not interrupt update
- Test after update

Restart

- Restart through on-screen or configuration interface when available
- Avoid unnecessary restarts
- Verify Wi-Fi and control functions afterward

Factory Reset / Recovery

Setup wizard appears after first power-up or restore
Specific factory-reset button steps were not found in the provided official-source manual
Use local setup, web configuration, firmware update, or Crestron support for recovery
