

**Manufacturer: Panasonic** 

**Model: Projectors** 

**Device Type: Projector** 

### **TABLE OF CONTENTS**

GENERAL INFORMATION	2
INITIAL SETUP	
PLUGIN CONTROLS ( SETUP)	4
PLUGIN CONTROLS ( CONTROL)	5
PLUGIN CONTROLS ( INPUTS)	7
KNOWN ISSUES	8
ADDITIONAL INFORMATION	ρ



**Manufacturer: Panasonic** 

**Model: Projectors** 

GENERAL INFORMATION	
Q-SYS PLUGIN NAME	Panasonic Projectors
VERSION	1.0
AUTHORED BY	Control Concepts, Inc.
SUMMARY	This plugin controls a Panasonic projector using TCP.
GENERAL NOTES	Supported Models:  • All Panasonic projector models.  Device Setup:  Confirm the authentication setting on the projector's web interface →[NETWORK SECURITY]  → [COMMAND PROTECT].
DEVICE USED FOR TESTING	Q-SYS Core 110f (v9.10.1) Panasonic PT-MZ880 (v1.11)



**Manufacturer: Panasonic** 

**Model: Projectors** 

INITIAL SETUP	
PROPERTIES	Authentication: Specifies the Command Protect setting of the projector. When the property is set to [Enabled] a username and password field will be provided in the connection settings area.  Debug_Level: Set the level to determine the trace statements that will print to the debug window.  Off: No trace statements from the plugin  Device Communication: Only trace statements related to establishing and maintaining communication  Troubleshooting: All trace statements
ESTABLISHING CONNECTION	Using either the text box inputs or the input pins, enter the IP Address and, if authentication is enabled, the administrator username and password of the projector. When all applicable information is filled in, the plugin will automatically connect and reconnect.  To initialize, the plugin will query for all states on startup. Once the plugin has successfully gathered all states the plugin will be initialized and control will be allowed. It is recommended to not control anything prior to initialization.



**Manufacturer: Panasonic** 

**Model: Projectors** 

Sets the IP Address of the projector.   [Input   String ]	PLUGIN CONTROLS ( SETU	P)
is set to Enabled. [Input   String ]  The password of the administrator account. Available when the Command Protect property is set to Enabled. [Input   String ]  Projector Name	IP Address	
The password of the administrator account. Available when the Command Protect property is set to Enabled. [Input   String ]  The projector name as reported by the projector. [Output   String ]  Serial Number The serial number reported by the projector. [Output   String ]  Model Numer The model number reported by the projector. [Output   String ]  The software version reported by the projector. [Output   String ]  True indicates that the plugin is communicating with the projector. [Output   Boolean ]  Initialized True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  Plugin Version [Output   String ]  The plugin version. [Output   String ]  The plugin status.	Username	is set to Enabled.
Password is set to Enabled. [Input   String ]  Projector Name The projector name as reported by the projector. [Output   String ]  Serial Number [Output   String ]  Model Numer The model number reported by the projector. [Output   String ]  Software Version True indicates that the plugin is communicating with the projector. [Output   Boolean ]  Initialized True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  Plugin Version The plugin version. [Output   String ]  The plugin status  The plugin status.		[Input   String ]
The projector name as reported by the projector.  [Output   String ]  The serial number reported by the projector. [Output   String ]  Model Numer  The model number reported by the projector. [Output   String ]  Software Version  The software version reported by the projector. [Output   String ]  True indicates that the plugin is communicating with the projector. [Output   Boolean ]  True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  Plugin Version  The plugin version. [Output   String ]  The plugin status.	Password	
Coutput   String		[Input   String ]
The serial number reported by the projector. [Output   String ]  The model number reported by the projector. [Output   String ]  Software Version  The software version reported by the projector. [Output   String ]  True indicates that the plugin is communicating with the projector. [Output   Boolean ]  True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  The plugin version. [Output   String ]  The plugin status.	Projector Name	
[Output   String ]  The model number reported by the projector. [Output   String ]  Software Version  The software version reported by the projector. [Output   String ]  Communicating  True indicates that the plugin is communicating with the projector. [Output   Boolean ]  True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  Plugin Version  [Output   String ]  The plugin status.	Carial Number	
Communicating   Coutput   String	Serial Nulliber	[Output   String ]
The software version reported by the projector.  [Output   String ]  True indicates that the plugin is communicating with the projector.  [Output   Boolean ]  True indicates that the plugin has successfully queried for the current state.  [Output   Boolean ]  Plugin Version  The plugin version.  [Output   String ]  The plugin status.	Model Numer	The model number reported by the projector.
Communicating   True indicates that the plugin is communicating with the projector.   Communicating   True indicates that the plugin is communicating with the projector.   Coutput   Boolean		[Output   String ]
[Output   String ]  True indicates that the plugin is communicating with the projector. [Output   Boolean ]  True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  Plugin Version  [Output   String ]  The plugin status.	Coftware Version	The software version reported by the projector.
Communicating  [Output   Boolean ]  True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  Plugin Version  The plugin version. [Output   String ]  The plugin status.	Software version	[Output   String ]
[Output   Boolean ]  True indicates that the plugin has successfully queried for the current state. [Output   Boolean ]  Plugin Version  [Output   String ]  The plugin status.		True indicates that the plugin is communicating with the projector.
Initialized  [Output   Boolean ]  The plugin version. [Output   String ]  The plugin status.	Communicating	[Output   Boolean ]
Initialized  [Output   Boolean ]  The plugin version. [Output   String ]  The plugin status.	Initialized	True indicates that the plugin has successfully queried for the current state.
Plugin Version  [Output   String ]  The plugin status.		[Output   Boolean ]
[Output   String ]  The plugin Status.	Plugin Version	The plugin version.
Plugin Status Plugin Status		[Output   String ]
Plugin Status  [Output   String	Plugin Status	The plugin status.
[output   outing ]		[Output   String ]



**Manufacturer: Panasonic** 

**Model: Projectors** 

PLUGIN CONTROLS ( CONTROL)	
Power On	Sends the power on command to the projector. Output is true when the projector power state is on.
	[ Both   Boolean ]
Power Off	Sends the power off command to the projector. Output is true when the projector power state is off.
	[ Both   Boolean ]
Shutter Open	Sends the shutter open command to the projector. Output is true when the projector shutter state is open.
	[ Both   Boolean ]
Shutter Close	Sends the shutter close command to the projector. Output is true when the projector shutter state is close.
	[ Both   Boolean ]
	Sends the lens focus in slow command to the projector when pressed. Sends the lens focus in normal command to the projector when held.
Lens Focus In	*Control is disabled if not supported by projector model.
	[Input   Boolean ]
	Sends the lens focus out slow command to the projector when pressed. Sends the lens focus out normal command to the projector when held.
Lens Focus Out	*Control is disabled if not supported by projector model.
	[Input   Boolean ]
	Sends the lens zoom in slow command to the projector when pressed. Sends the lens zoom in normal command to the projector when held.
Lens Zoom In	*Control is disabled if not supported by projector model.
	[Input   Boolean ]
	Sends the lens zoom out slow command to the projector when pressed. Sends the lens zoom out normal command to the projector when held.
Lens Zoom Out	*Control is disabled if not supported by projector model.
	[Input   Boolean ]
Lens Shift Up	Sends the lens shift up slow command to the projector when pressed. Sends the lens shift up normal command to the projector when held.
	*Control is disabled if not supported by projector model.
	[Input   Boolean ]
	Sends the lens shift down slow command to the projector when pressed. Sends the lens shift down normal command to the projector when held.
Lens Shift Down	*Control is disabled if not supported by projector model.
	[Input   Boolean]



**Manufacturer: Panasonic** 

**Model: Projectors** 

Lens Shift Left	Sends the lens shift left slow command to the projector when pressed. Sends the lens shift left normal command to the projector when held.  *Control is disabled if not supported by projector model.
	[Input   Boolean ]
	Sends the lens shift right slow command to the projector when pressed. Sends the lens shift right normal command to the projector when held.
Lens Shift Right	*Control is disabled if not supported by projector model.
	[Input   Boolean ]
	Sends the audio mute on command to the projector. Output is true when the projector audio mute state is on.
Audio Mute On	*Control is disabled if not supported by projector model.
	[Both   Boolean ]
	Sends the audio mute off command to the projector. Output is true when the projector audio mute state is off.
Audio Mute Off	*Control is disabled if not supported by projector model.
	[Both   Boolean ]
	Sends the audio volume up command to the projector.
Audio Vol Up	*Control is disabled if not supported by projector model.
	[Input   Boolean ]
	Sends the audio volume up command to the projector.
Audio Vol Down	*Control is disabled if not supported by projector model.
	[Input   Boolean]
Self Check	Output indicates if errors are reported by the self-diagnosis query. True when no errors are reported.
Gen Grieck	[ Output   Boolean ]
Test On	Input sends the test pattern on command.
	Output is true when the test pattern is active.
	[Both   Boolean]
Test Off	Input sends the test pattern off command.
	Output is true when the test pattern is not active.
	[Both   Boolean ]



**Manufacturer: Panasonic** 

**Model: Projectors** 

PLUGIN CONTROLS ( INPUTS)	
	Sends the corresponding input command to the projector. The output state is true when the projector reports the input as the current input.
<input name=""/>	* All possible input select options are provided regardless of projector model.  [ Both   Boolean ]



**Manufacturer: Panasonic** 

**Model: Projectors** 

KNOWN ISSUES	
V1.0	No known issues.

ADDITIONAL INFORMATION	
Change Log	V1.0 - Initial Release
Support	Company: Control Concepts, Inc.  Phone: (201) 797-7900  Email: <a href="mailto:support@controlconcepts.net">support@controlconcepts.net</a> Website: <a href="mailto:https://www.controlconcepts.net">https://www.controlconcepts.net</a>