

User Guide



AT&T Mobile Hotspot MiFi® Liberate

©2013 Novatel Wireless, Inc. All rights reserved. The information contained in this document is subject to change without notice and should not be construed as a commitment by Novatel Wireless, Inc.

Patents and Licenses

Visit www.novatelwireless.com/about/contact-us for a complete list of all Novatel Wireless patents.

Software License

Proprietary Rights Provisions:

The software drivers provided with this product are copyrighted by Novatel Wireless and/or Novatel Wireless' suppliers. Although copyrighted, the software drivers are unpublished and embody valuable trade secrets proprietary to Novatel Wireless and/or Novatel Wireless' suppliers. The disassembly, decompilation, and/or reverse engineering of the software drivers for any purpose is strictly prohibited by international law. The copying of the software drivers, except for a reasonable number of back-up copies, is strictly prohibited by international law. It is forbidden by international law to provide access to the software drivers to any person for any purpose other than processing the internal data for the intended use of the software drivers.

U.S. Government Restricted Rights Clause:

The software drivers are classified as "Commercial Computing Device Software" and the U.S. Government is acquiring only "Restricted Rights" in the software drivers and their Documentation.

U.S. Government Export Administration Act Compliance Clause:

It is forbidden by US law to export, license or otherwise transfer the software drivers or Derivative Works to any country where such transfer is prohibited by the United States Export Administration Act, or any successor legislation, or in violation of the laws of any other country.

Trademarks and Service Marks

Novatel Wireless is a trademark of Novatel Wireless, Inc., and the other trademarks, logos, and service marks (collectively the "Trademarks") used in this user manual are the property of Novatel Wireless or their respective owners. Nothing contained in this user manual should be construed as granting by implication, estoppel, or otherwise, a license or right of use of Novatel Wireless or any other Trademark displayed in this user manual without the written permission of Novatel Wireless or its respective owners.

- Novatel Wireless and the Novatel Wireless logo are all trademarks of Novatel Wireless, Inc.
- MiFi and the MiFi logo are registered trademarks of Novatel Wireless, Inc.
- AT&T is a registered trademark of AT&T, Inc.
- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Apple®, Mac®, and Mac OS® are trademarks of Apple, Inc., registered in the U.S. and other countries.
- microSDHC, microSD, SD Card, and the SD logo are trademarks of SD-3C LLC.
- DLNA is a registered trademark, DLNA disc logo is a service mark, and DLNA Certified is a trademark of the Digital Living Network Alliance. Digital Living Network Alliance is a service mark of the Digital Living Network Alliance.

The names of actual companies and products mentioned in this user manual may be the trademarks of their respective owners.

Novatel Wireless Revision History

Part Number	Revision	Description	Date
90026650	R1	Initial release	15 Nov 2012
	R2	Enterprise release	16 Jul 2013
	R3	Updated 4G LTE/UMTS/HSPA/HSPA+ bands , pg 108	26 Sep 2013

FCC ID: PKRNVWMIFI5792

PN: 90026650 R3 MASTER UG MiFi5792 AT&T 26Sep2013

Please visit www.novatelwireless.com for the latest information about your device.

Contents

Getting Started	5
Device Overview	6
Package Contents	6
System Requirements	6
Device Setup and Power On	7
Connect to Your AT&T Mobile Hotspot MiFi Liberate	7
Components	8
Power Sources for Your MiFi Liberate	9
Service Status Icons	10
Touchscreen Icons	11
MiFi Liberate Manager	12
MiFi Liberate Manager Navigation	12
Battery Usage	14
Charge the Battery	14
Remove the Battery	
Remove the SIM Card	
Battery Advisory	
Wi-Fi Setup	19
Set Up a Wi-Fi Connection	19
Log into the MiFi Liberate Manager Web Interface	21
Configure Security	23
Change the Admin Login	23
Change the Wi-Fi Password	25
Accessing MiFi Liberate Features	26
MiFi Liberate Manager	
MiFi Liberate Manager Home Page	
Data Usage	
On the MiFi Liberate Manager	
Connected Devices	30
On the MiFi Liberate Touchscreen	30
On the MiFi Liberate Manager	32
Settings	36
On the MiFi Liberate Manager	40
Device Settings	41
Preferences	42
Admin Login	46
Backup and Restore	
General	51
Advanced	54
Mobile Settings	56
Mobile	57

APN Profiles	58
Network Selection	59
Manual DNS	60
SIM Lock	61
Advanced Settings	62
Firewall	
LAN	64
Port Filtering	65
Messages	
On the MiFi Liberate Manager	67
File Sharing	68
Enable File Sharing	68
Accessing Shared Files	69
On the MiFi Liberate Manager	
Settings	71
View Files	72
Media Center	73
On the MiFi Liberate Manager	74
Status	75
Media	78
Photos	79
Videos	80
Music	81
On the MiFi Liberate Manager	83
Enable GPS	84
Wi-Fi Protected Setup	
About	88
On the MiFi Liberate Manager	90
Current Status	91
Internet Status	91
Wi-Fi	91
Device	92
Device Info	93
Customer Care	94
Diagnostics	95
Modem Status	96
HSPA Status	96
4G LTE Status	96
Logs	97
Software Update	
Troubleshooting	99
Overview	100
Common Problems and Solutions	
Using the Master Reset Button	105

Technical Support	106
Customer Service	106
More Information	106
Product Specifications and Regulatory Information	107
Product Specifications	108
General	108
Display	108
Technology/Bands	
Environmental	
Regulatory	
Safety Hazards	110
Proper Battery Use and Disposal	112
Guidelines for Safe and Responsible Battery Use	112
Limited Warranty and Liability	113
Glossary	114
Glossary	
<u> </u>	

Getting Started

Device Overview
Components
Battery Usage
Wi-Fi Setup
Configure Security
Data Usage

Device Overview

With the powerful, easy-to-use AT&T Mobile Hotspot MiFi® Liberate you can connect up to 10 Wi-Fi enabled devices to fast 4G LTE™ Internet* and use a brilliant interactive touchscreen to manage your connection. With this next generation intelligent mobile hotspot from Novatel Wireless you can keep your tablets, laptops, gaming consoles, smartphones, e-Readers and other devices connected for up to 12 hours without recharging**.

With a tap on the full color touchscreen you can manage data usage, access connection details including Wi-Fi network name and password, view and block connected devices, enable MiFi Media Center and more. See battery level, network and signal strength at a glance. Connect with confidence—global MiFi Liberate provides a secure, reliable connection when and where you need it, in more than 200 countries† around the world.

Package Contents

The AT&T Mobile Hotspot MiFi Liberate package includes:

- MiFi Liberate
- Preinstalled SIM Card
- Preinstalled rechargeable battery
- Charger
- USB cable
- Quick Start Guide

System Requirements

To manage your MiFi Liberate, you need the following:

- A computer or computing device supporting Wi-Fi 802.11 b/g/n
- Internet browser software: i.e., Android[™], Microsoft Internet Explorer[®] 8.0 or higher, Firefox[®],
 Safari[®], Opera[™], Google Chrome[®], etc.
 - **NOTE** Enterprise variant available with File Sharing, Media Center, microSD™ functionality, WPS and tethering disabled.
- * Limited 4G LTE availability in select markets. Compatible data plan required. LTE is a trademark of ETSI. Learn more at att.com/network.
- **Battery usage varies according to number of connected devices and level of activity.
- † International Roaming: Requires compatible device. Availability, quality of coverage and services while roaming are not guaranteed. International roaming rates apply outside the U.S., Puerto Rico and U.S.V.I.

 Visit att.com/worldpackages and select Data Plans/Packages to view rates and available discount plans.

Device Setup and Power On

Your MiFi Liberate comes with the SIM card and battery already installed. Remove the battery pull-tab prior to use.

- Press and release the power button. When the touchscreen displays the interactive icons, your device is ready to use.
- 2 To lock the touchscreen, press and release the power button. To unlock, press and release the power button and slide the lock tab.
- To power off the device, press and hold the power button for 3 seconds to display the Shut Down window, then tap **Yes**.

Connect to Your AT&T Mobile Hotspot MiFi Liberate

You can connect up to 10 compatible Wi-Fi enabled devices. To connect wireless devices (computers, tablets, e-readers, cameras, media players, smartphones, etc.):

- ① Open the Wi-Fi menu on the device you would like to connect and view the list of available networks.
- Select your MiFi Liberate Wi-Fi Network Name (SSID) (e.g., MIFI-LIBERATE-XXXX).
- Select **Connect** and enter the Wi-Fi password displayed under **Connection Details** on the MiFi Liberate. Your device should automatically connect to the AT&T network.
- After you connect your computer to your MiFi Liberate using Wi-Fi, you can access the MiFi Liberate Manager web interface to customize settings, change your password, access applications and more. Browse to (http://att.mifiliberate), and use the default password to log in, attadmin. (See Log into the MiFi Liberate Manager Web Interface on page 21.)
- **6** Configure security for your MiFi Liberate. (See <u>Configure Security</u> on page 23.)

Components




- **1** Power Button Powers the MiFi Liberate on and off.
- **Status Bar** Displays current device status information, including signal strength, time, GPS, messages, connected devices and battery level.
- **3** Touchscreen Icons Provides touchscreen access to the MiFi Liberate applications.
- Micro USB Port The A/C charger and USB cable connect here.
- **Screen Sleep Indicator** Flashes blue when the device is in sleep mode.
- **Touchscreen** The interactive device display screen.
- **Battery Door** Remove to access battery and SIM card slot.
- **SIM Card Slot** Active SIM card must be installed for network access. MiFi Liberate's SIM Card comes preinstalled.
- **9 Reset Button** Resets the device to factory default settings.
- microSD™ Slot Removable memory storage slot supports microSD and microSDHC cards up to 32GB (card not included).
 - **NOTE** Enterprise variant available with File Sharing, Media Center, microSD™ functionality, WPS and tethering disabled.



Power Sources for Your MiFi Liberate

Your MiFi Liberate will work from its battery or when plugged into a power source.

• **Battery** — The battery lasts up to 12 hours. Charge the battery by plugging in the A/C charger. While the battery is charging the charging battery status icon displays on the MiFi Liberate touchscreen status bar. When the battery is fully charged, the message "Battery is fully charged, please disconnect power" displays on the touchscreen. When disconnected from power and fully charged, the battery status icon displays fully charged.



• **A/C wall charger** — Charge your device by plugging it into either an A/C charger connected to a wall socket or to your computer USB port via cable.

Service Status Icons

Status icons at the top of the MiFi Liberate Touchscreen, and on the Status bar of the MiFi Liberate Manager indicate the device status. The appearance of each icon varies according to the current device status.

Status Icon		Status	Description
No icons		The display is off, and the LED is also off.	The device is powered off or not receiving power.
Network signal strength status	all	Network signal strength icon displaying 0-5 bars.	More bars indicate a stronger signal.
Network connection status	4G	Network connection icon.	Identifies the type of network the MiFi Liberate is currently connected to.
GPS status	(§)	Active GPS icon.	The icon displays when GPS is turned ON and position information is available.
Message status	 10	An unread message(s) icon.	The icon and number of messages displays when there are unread SMS messages.
Connected device status	WFI 10	Connected device(s) icon.	The icon and number of connected devices displays when there are devices connected to the MiFi Liberate.
Battery status		Battery level icon.	The icon fills to indicate the amount of remaining battery life.

Touchscreen Icons

Display Icon		Description	
No icons		The device is powered off or not receiving power.	
Connection Details	((•))	Displays the Wi-Fi Network Name and the Wi-Fi Password for your MiFi device.	
Data Usage		Enables you to check your data plan summary, data used, remaining days in your billing cycle, and more.	
Connected Devices	WIE	Displays details of devices currently connected to or blocked from your MiFi Liberate.	
Settings	Ö	Allows you to access and configure your MiFi Liberate device settings.	
Messages		Connects you to text messages delivered to your MiFi Liberate, including AT&T service notifications.	
File Sharing		Allows you to upload and download files stored on your microSD card from compatible connected devices.	
Media Center		Provides access to movies, music and photos stored on your microSD card from connected devices.	
GPS	(S)	Allows you to share location information with connected devices.	
Wi-Fi Protected Setup	1,0(1	Allows you to connect WPS-enabled devices to MiFi Liberate without using a keyboard.	
About	1	Provides access to current status and device information, help, software updates and customer care. Tap Customer Care to view your wireless number.	

NOTE

MiFi Liberate Manager

The MiFi Liberate Manager is part of your MiFi device. It's a web interface you can log into to customize settings, change your password, get information and access applications.



MiFi Liberate Manager Navigation

Each page contains a menu bar to help you navigate. The navigation panel is at the left of the browser interface on each page and contains the following:

- **MiFi Home** takes you to the MiFi Liberate Manager Home page. (See <u>MiFi Liberate Manager Home Page</u> on page 27.)
- **Data Usage** takes you to the Data Usage page, where you can view your current data usage and manage your AT&T account. (See <u>Data Usage</u> on page 28.)
- Connected Devices takes you to the Connected Devices page, where you can view devices currently connected to your MiFi Liberate, and blocked devices. (See <u>Connected Devices</u> on page 30.)
- Settings takes you to the Settings page, where you can customize your device, hotspot, mobile and advanced settings. (See Settings on page 36.)
- **Messages** takes you to the Messages page, where you can view your unread messages sent to your MiFi Liberate. (See <u>Messages</u> on page 67.)
- File Sharing takes you to the File Sharing page, where you can customize your file sharing settings, and view all files stored on a microSD card installed in the MiFi device. (See <u>File Sharing</u> on page 68.)
- NOTE

- **Media Center** takes you to the Media Center page, where you can view and share your movies, music with connected devices. (See <u>Media Center</u> on page 73.)
- **GPS** takes you to the GPS page, where the GPS receiver on the MiFi device can determine your current location. (See Enable GPS on page 84.)
- **About** takes you to the About page, where you can get details regarding current status, device information, software updates, customer care and diagnostics, and enable troubleshooting logs. (See About on page 88.)



Battery Usage

Charge the Battery

The MiFi Liberate comes with the SIM card and battery installed. Remove the battery pull tab prior to use.



To charge the battery, connect the A/C charger to the USB cable and plug into the MiFi Liberate's micro USB port. The charging battery status icon displays on the MiFi Liberate touchscreen status bar while the battery is charging. When the battery is fully charged, the message "Battery is fully charged, please disconnect power." displays on the touchscreen. When disconnected from power and fully charged, the battery status icon displays fully charged.

IMPORTANT The battery door cover on your MiFi Liberate device lifts off to open and snaps on to close. No tools are required to remove or install the battery or battery door. Using any type of tool could result in damage to the device and to the battery. If excessive force appears necessary to move the door or remove the battery, please return the MiFi Liberate to where you purchased the device.

Remove the Battery

WARNING! Never use tools, knives, keys, pens or any type of object to force the door open or to remove the battery. Using any of these types of objects could result in puncturing the MiFi Liberate battery.

• Place your MiFi Liberate device on a flat surface with the battery door facing up. Be sure to remove the battery pull tab before use.



2 Steady the MiFi Liberate with one hand and place the thumb of your other hand on the battery door thumb notch.



3 Using normal thumb pressure on the thumb notch, lift the battery door up to remove the door completely.



4 Use your forefinger to pull the battery up slightly so that it moves out of the battery well.



Lift the battery out of the battery well.



Remove the SIM Card

Your MiFi Liberate comes with the SIM card already installed. To remove the SIM card:

• Open the battery compartment and remove the battery from the battery well to reveal the SIM card slot.



2 To release the SIM card from the slot, push and release the top of the SIM card.



3 To remove the SIM card, hold the card with two fingers and pull gently, being careful not to touch the gold contacts on the back of the card.



Battery Advisory

- As with any battery-operated mobile device being used for a certain amount of time, the MiFi Liberate device can get warm to the touch. This is normal and within standard specifications, and poses no hazard.
- The MiFi Liberate device is configured to automatically stop charging and disconnect the battery if the temperature rises above a set threshold. When the temperature falls below that threshold, the battery reconnects and the unit starts charging again.
- Always use Novatel Wireless original batteries and chargers.
- It normally takes at least four hours to fully charge the battery. If the device is in use the battery may take longer to charge.
- Do not use sharp objects to access the battery well; this may damage the device and the battery.
- Do not use excessive force to remove the battery or to access the battery well.
- Battery life depends on the network, signal strength, temperature, features, and accessories you use.
- New batteries or batteries stored for a long time may take more time to charge.
- When charging your battery, keep it near room temperature.
- When storing your battery, keep it uncharged in a cool, dark, dry place.
- Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F).
- Never leave the device in an unattended vehicle due to uncontrollable temperatures that may be outside the specified temperature for this device.
- Some batteries perform best after several full charge/discharge cycles.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.
- Avoid placing the device on vibrating surfaces for long period of time (such as a washer or dryer).
- Avoid placing the device near 802.11-radiating devices such as microwave ovens and 2.4 GHz cordless telephones.
- Do not place the device in a closed space where there is no air circulation (e.g., do not wrap the device in a blanket or place it under a pillow).
- Whenever you remove or insert either the battery or the SIM card, ensure your MiFi Liberate device is not connected to any device or power source.
- Never use tools, knives, keys, pens or any type of object to force the door open or to remove the battery. Using any of these types of objects could result in puncturing the MiFi Liberate device battery.
- Battery disposal: Contact your local recycling center for proper battery disposal.
- In the event of a battery leak: Do not allow the liquid to come in contact with skin or eyes. If contact is made, wash the area with large amounts of water and seek medical advice.

Wi-Fi Setup

To properly set up your MiFi Liberate device, you need to do both of the following tasks:

- Set Up a Wi-Fi Connection
- Log Into the MiFi Liberate Home Page

Set Up a Wi-Fi Connection


To connect to your MiFi Liberate:

- Press the **Power** button.
- 2 Tap the **Connection Details** icon **to** display your device's Wi-Fi Network Name (SSID) and password.



Use your normal Wi-Fi manager on your computer to locate the MiFi Liberate Wi-Fi Network Name (SSID) and select it.





- Windows: Click Connect.
 - Mac OS X: Click the MiFi device network name.
 - Windows only: The steps to connect to a Wi-Fi network vary depending on your operating system version and whether you use the native application or third-party software.
- A window prompts you for the Wi-Fi password. Type the Wi-Fi password (found on the device) and click **OK**.






The Wi-Fi password is found on the device and is case-sensitive. Be sure to type it in exactly as it is printed.

Log into the MiFi Liberate Manager Web Interface


From your computer's Web browser, type http://att.mifiliberate (alternatively, http://192.168.1.1) without adding "www" in the address bar and press the **Enter** or **Return** key.

The MiFi Liberate Manager Home page launches.




Click Login.

3 Type the Admin Login: xxxxxxxx (case sensitive) into the login field (the default is attadmin).



4 Click Login.

The MiFi Liberate Home page opens.



Configure Security

Although your device is pre-configured to have security enabled, you should change the password to a password you can easily remember and that is hard for others to guess.


Using security with your wireless network is very important. It is recommended that you configure security immediately by changing the following:

- Change the Admin Login
- · Change the Wi-Fi Password

Change the Admin Login

- Open your browser, go to http://att.mifiliberate, and then click **Login**. (See Login. (See Loginto the MiFiliberate on page 21).
- 2 Enter the device password and then click **Login**.
- 6 Click Change Liberate Manager Login in the MiFi Quick Links panel.

The **Settings > Device Settings > Admin Login** page opens.




4 Type your current Admin Login password into the Enter Current Login field.



There are two types of passwords:

- The Admin Login password to access the MiFi Liberate Manager Web interface to configure settings.
- The Wi-Fi password (also called the Wi-Fi key or network security key) that you need to connect your MiFi Liberate to your computing device(s).
- Select a new Admin Login password and type it into both **Enter new password** fields.
- **6** Click **Save Changes**.



This is the new Admin Login password you use when you log into the browser interface.




You can find your current Admin Login password by tapping **Connection Details** on the MiFi Liberate touchscreen.

Change the Wi-Fi Password

You can use WEP (64- or 128-bit), WPA-PSK, WPA2-PSK, or WPA/WPA2 mixed mode security.

IMPORTANT Record your Wi-Fi password (also referred to as the Wi-Fi key or network security key depending on your operating system).

- Open your browser, go to http://att.mifiliberate, then click **Login**.
- Enter the Admin Login password and then click Login.
- Click Settings on the Navigation panel and then select Hotspot Settings. The Hotspot Settings > General window opens.
- 4 Enter your new Wi-Fi password in the Wi-Fi Password (Key) field. The password must be 8-63 ASCII characters.
- 6 Click **Save Changes**. A confirmation message will display in the green bar near the top of the page when the changes have been successfully saved. You will need to reconnect all Wi-Fi devices using the new Wi-Fi password.



Accessing MiFi Liberate Features

MiFi Liberate Manager
Data Usage
Connected Devices
Settings
Messages
File Sharing
Media Center
GPS
About

MiFi Liberate Manager

MiFi Liberate Manager Home Page

The MiFi Liberate Manager Home page is the first page you see when you connect to your MiFi Liberate. This is where you click **Login** to go to the MiFi Liberate Login page and enter your 8-digit password to login and customize your device and access advanced features and settings.

The MiFi Liberate Manager web interface allows you to check data usage and available data storage, view details for connected devices, access the Media Center, read messages, enable file sharing and GPS, and change the MiFi settings.



NOTE


Data Usage

You can quickly and easily check your data usage directly on the MiFi Liberate touchscreen, or on the MiFi Liberate Manager.

On the MiFi Liberate Touchscreen

- To display your data plan summary, data used, and days remaining in your billing cycle, tap the **Data Usage** icon on the touchscreen.
- **1** To update the data plan summary, click **Refresh**.






3 To purchase additional data, go to http://att.com/dataplans.

On the MiFi Liberate Manager

To access the Data Usage page, click Data Usage on the Navigation panel. The Data Usage page contains the following.

- Account Summary
- International Roaming



- To display your data plan summary, manage your AT&T account, and access information about global data packages, select the **Data Usage** tab on the Navigation panel on the MiFi Liberate Manager Home page.
- To connect to the AT&T Online Account Management page, click the <u>Click here to manage</u> your account link at the top of the page.
- **3** To purchase additional data, go to http://att.com/dataplans.
- For more information about global data packages, go to http://att.com/globaldata.
 - Actual billed usage can be higher than estimated data usage displayed on the usage meter. See www.attwifi.com for details.

Connected Devices

The Connected Devices page allows you to view devices currently connected or blocked from connection to your MiFi Liberate. You can also block and unblock devices from this page.

The Connected Devices page contains the following.

- **Connected Devices** a list of compatible devices currently connected to your MiFi Liberate.
- Blocked Devices a list of compatible devices currently blocked from connecting to your MiFi Liberate.

On the MiFi Liberate Touchscreen

1 Tap the Connected Devices icon a to display the Connected Devices page.






2 Tap the connected device name to display detailed information about the device, including the device type, time connected, and Mac and IP address. Tap **Block** at the top right side of the page to add the device to the Blocked Devices list.






Tap Unblock at the top right side of the page to remove a device from the Blocked Devices list. **G** Go to http://att.mifiliberate/connecteddevices to manage your connected devices.




On the MiFi Liberate Manager

To access the Connected Devices page, click **Connected Devices** on the Navigation panel. The Connected Devices page contains the following:


- **Connected Devices** a list of compatible devices currently connected to your MiFi Liberate.
- **Blocked Devices** a list of compatible devices currently block from connecting to your MiFi Liberate. To view devices currently connected to your MiFi Liberate, select the **Connected Devices** tab on the Navigation panel on the MiFi Liberate Manager Home page.




Click the pencil icon
✓ to assign a name to a connected device.



2 Enter the desired name into the name field, then select the type of device from the device type drop-down menu.




3 Click the check mark ✓ to finalize the changes.




4 Click **Block** to add a connected device to the Blocked Device list.

There are currently no blocked devices



6 Click **Unblock** to remove a device from the Blocked Devices list.

Connected Devices



Settings

The Settings page allows you to configure and customize your MiFi device. You can enable/disable Airplane Mode, Cellular Data access, and International Roaming; configure Screen Timeout and Brightness settings; set Sound Alerts and device Wi-Fi range; and configure USB Mode..

On the MiFi Liberate Touchscreen

1 Tap the **Settings** icon 1 to display the Settings page.





To enable **Airplane Mode**, slide the Airplane Mode ON/OFF button to **ON**. Wi-Fi and cellular radios will be turned off, and File Sharing and Media Center will still be accessible over USB. An airplane icon will display in the upper left corner of the touchscreen to indicate the device is in Airplane Mode, and the ON/OFF buttons will fade for unavailable options.





3 To disable all Internet traffic, slide the **Cellular Data** ON/OFF button to **OFF**.





To enable International Roaming, slide the International Roaming button to ON, then click

Yes to accept data roaming charges that will apply to data usage outside the U.S., Puerto Rico and the U.S. Virgin Islands.






Screen Timeout. Scroll to select a timeout interval from 30 seconds to 5 minutes, or never to disable Screen Timeout. If Screen Timeout is set to never, Automatic Shutdown is disabled.






6 To adjust touchscreen brightness, tap **Screen Brightness**. Slide the brightness indicator button to set the desired level.







To enable or disable sound alerts, tap **Sound Alerts**. Scroll to select from available alerts, including Battery, International Roaming, Connecting Devices, microSD Card and Power. Slide the ON/OFF button **ON** to enable the selected alert.





To configure the device Wi-Fi Range, tap **Device Wi-Fi Range**. Select **High** for the largest network area, or **Low** to conserve battery power.





To configure your USB Mode connection, tap **USB Mode**. Select **Charge Only** to recharge the battery via USB cable, or **Tethering over USB** to connect the device over a USB cable with a data connection. Windows XP users must install drivers from the MiFi Liberate Manager.






Personalize at http://att.mifiliberate





To access and configure additional features and settings, login to the MiFi Liberate Manager at http://att.mifiliberate, then select Settings > Device Settings > Preferences.






NOTE

Enterprise variant available with File Sharing, Media Center, microSD™ functionality, WPS and tethering disabled.

On the MiFi Liberate Manager

To access Advanced, Hotspot, and Mobile Setting options, select the **Settings** tab on the Navigation panel on the MiFi Liberate Manager Home page.




The Settings page contains the following:

- **Device Settings** (See <u>Device Settings</u> on page 41.)
- Hotspot Settings (See <u>Hotspot Settings</u> on page 50.)
- Mobile Settings (See <u>Mobile Settings</u> on page 56.)
- Advanced Settings (See <u>Advanced Settings</u> on page 62.)

Device Settings

The Device Settings menu includes the following additional menu options.


- **Preferences** (See <u>Preferences</u> on page 42.)
- Admin Login (See Admin Login on page 46.)
- Backup and Restore (See <u>Backup and Restore</u> on page 48.)



Preferences

The Preferences section allows you to customize your MiFi device settings and preferences. The Preferences section displays the following:


- Device Preferences allows you to set auto shutdown preferences and to enable Ethernet over USB. Select your shutdown preference from the Automatic Shutdown drop-down menu. Click Enable Ethernet over USB to enable.
- **User Preferences** allows you to change date and time, temperature, distance and numeric format preferences.



Setting Device Preferences

To set device preferences:

1 Select the USB mode you want to use from the **USB Mode** drop-down menu.



2 Select the automatic shutdown time interval you want to use from the **Automatic Shutdown** drop-down menu. If Screen Timeout is set to never, Automatic Shutdown is disabled.




Click **Save Changes**.

Setting User Preferences


To set the date and time format, temperature, and distance and number format preferences:

1 Select the date/time format you want to use from the Date & Time drop-down menu.


You can choose between 24- and 12-hour time display and European (dd/mm/yyyy) and U.S. (mm/dd/yyyy) date formats.



2 Select the distance units you want to use from the **Distance** drop-down menu.



Select the number format units you want to use from the **Number Format** drop-down menu.




Click **Save Changes**.

Admin Login

The Admin Login section displays the following:

- **Display the Admin Login for the MiFi Liberate Manager on the touchscreen** allows you to turn the MiFi Liberate Manager Admin Login display on the Connection Details page of the touchscreen **ON** or **OFF**. The default setting is **ON**.
- **Change MiFi Liberate Manager Login** allows you to change the Admin Login on your MiFi device.



Displaying the Admin Login on the Touchscreen


To change the display of the Admin Login on the MiFi Liberate touchscreen:

- 1 To turn the Admin Login display ON, slide the ON/OFF button to ON.
- 2 To turn the Admin Login display OFF, slide the ON/OFF button to **OFF**.

Changing the MiFi Liberate Manager Login

To change your current Admin Login:


- Enter your current Admin Login in the Enter Current Login field.
- Enter your new Admin Login in the Enter New Login field.
- **3** Enter your new Admin Login in the **Confirm New Login** field.
- **6** Click **Save Changes** to save the changes made to your Admin Login.



Backup and Restore

The Backup and Restore section displays the following:

- **Backup** allows you to save your device settings to your computer.
- **Restore Backup** allows you restore settings from a previously saved backup file.
- Restore to Factory Defaults restores all settings and preferences to the factory default.



Backing Up Your MiFi Liberate Settings

To save your MiFi Liberate settings to your computer:


• Enter your device Admin Login in the Admin Login field and click **Back Up Now**.



Restoring Your MiFi Liberate Settings

To restore settings from a previously saved backup file on your computer:


- Enter your Admin Login in the Enter your Admin Login field.
- Click Choose File to select a file to restore.
- Click Restore to restore the selected backup file.



Restoring Your MiFi Liberate to Factory Defaults

To restore all device settings to the original factory settings:


• Click Restore Factory Defaults.



Hotspot Settings

The Hotspot Settings menu includes the following additional menu options.

- **General** (See <u>General</u> on page 51.)
- Advanced (See Advanced on page 54.)



General

The General section displays the following:


- Network Name (SSID) name of the network you are connected to. You can change the
 name to something more descriptive if you want; for example, if there are several MiFi
 devices in your area you might put your name in the network name; for example, "Sarah's
 MiFi".
- **802.11 Mode** the type of wireless networking you are currently using. The available modes are:
 - 802.11b +802.11g
 - 802.11b only
 - 802.11g only
 - 802.11n only
 - 802.11b+802.11g+802.11n
 - 802.11g+802.11n
- Wi-Fi Security the type of security the profile is using.
- **Wi-Fi Password (Key)** password used to access the Wi-Fi network. The required format varies by the type of security.
- Maximum Wi-Fi Connected Devices select the number of devices you want to allow to connect to your MiFi device (1 10).
- **Display the Wi-Fi Password** turn off to prevent the Wi-Fi Password (Key) from displaying on the touchscreen.

Changing Your Network Name (SSID) and Settings

Your MiFi device allows you to change the network name and Wi-Fi password.


To change your network name and settings:

- Enter the new network name in the Network Name (SSID) field.
- 2 Select the 802.11 mode from the **802.11 Mode** drop-down menu.



3 Select the desired security from the **Security** drop-down menu.


WEP 64 bit is the least secure but the most compatible with other systems. WPA/WPA2 is the most secure but the least compatible with other systems. Choose the most secure protocol that works with the computers and other computing devices you want to connect to your MiFi Liberate.



- 6 Enter the new network key in the Wi-Fi Password (Key) field.
- Write down the new network name and network key. In the example, they are "MIFI-LIBERATE-XXXX" and "12345".

6 Select the maximum number of Wi-Fi connections (1 - 10) from the **Number of Wi-Fi** Connections drop-down menu.





Click Save Changes.


IMPORTANT You must write down the new network name and Wi-Fi password before you click **Save Changes**. You need these settings to reconnect to the MiFi device. Click **Save Changes**.

IMPORTANT Your wireless connection will be disabled at this point. You must reconnect with the new settings you just established.

Advanced

The Advanced section displays the following:

- **Broadcast Wi-Fi Network Name (SSID)** makes your MiFi Liberate device SSID visible to other compatible Wi-Fi enabled devices.
- Wi-Fi Privacy Separation prevents devices connected to your MiFi Liberate from communicating with each other.
- WMM (Wi-Fi Multimedia) allows you to give a higher priority to real time applications.
- **Channel** allows you to select a specific communication channel, or to let the MiFi Liberate automatically select a channel.
- Wi-Fi Power enables you to select the size of your Wi-Fi network.



To configure your Hotspot Advanced Settings:


- 1 To make your MiFi Liberate visible to other compatible, Wi-Fi enabled devices, click the Broadcast Wi-Fi Network Name (SSID) check box.
- 2 To prevent connected devices from communicating with each other, click the Wi-Fi Privacy Separation check box.

- To give higher priority to real-time applications like video and Skype, click the WMM (Wi-Fi Multimedia) check box. It is mandatory to enable WMM when using 802.11n, and recommended for all other protocols.
- To select a specific communication channel, choose from the drop-down menu options. To allow the device to automatically select the channel, choose the **Automatic** option.
- To configure the Wi-Fi coverage area for your MiFi Liberate, select from the drop-down menu options. Select **Low Power longer battery life** to limit the size of your Wi-Fi network and conserve battery life, or **High Power shorter battery life** to maximize the size of your Wi-Fi network.
- **6** Click **Save Changes**.

Mobile Settings

The Mobile Settings menu includes the following menu options.

- Mobile (See Mobile on page 57.)
- APN Profiles (See APN Profiles on page 58.)
- Network Selection (See <u>Network Selection</u> on page 59.)
- Manual DNS (See Manual DNS on page 60.)
- SIM Lock (See <u>SIM Lock</u> on page 61.)




Mobile

The Mobile section displays the following:

- **Cellular Data** turn off cellular data to prevent all internet traffic from using the mobile broadband connection.
- International Roaming turn on to access the Internet when traveling internationally.






Slide the **ON/OFF** button to enable or disable cellular data or international roaming.

APN Profiles

This section is for **enterprise use only**. Changing default settings may adversely affect your Internet connection. The APN Profiles section displays the following:

- Active APN Profile choose between AT&T Default or Custom.
- **APN** enter a name for your Custom APN Profile in the APN field.




To change your active APN profile:

- 1 Select an available profile from the Active APN Profile drop-down menu.
- 2 Enter the name of the APN profile in the APN field.
- Click Save Changes.

Network Selection

Your MiFi Liberate automatically connects to the optimal mobile network available. In many cases you can also connect to a network manually if multiple networks are available. Manual network selection will not be available if there are no additional available networks.






Manual DNS


The Manual DNS section displays the following:

- **Enable Manual DNS** allows you to select a specific DNS address.
- **DNS Address 1** allows you to enter your primary DNS address.
- **DNS Address 2** allows you to enter a secondary DNS address if you have one. This field can also be left blank.



To enable Manual DNS:

- Olick the **Enable Manual DNS** check box.
- Enter the primary DNS address in the DNS Address 1 field.
- **3** Enter a second DNS address in the CNS Address 2 field. This field may be left blank if you do not have a second DNS address.
- Click Save Changes.




SIM Lock

The SIM Lock section displays the following:

- SIM Status displays the current SIM status.
- **Desired Action** allows you to select Enable PIN Lock from the drop-down menu.
- Enter current SIM PIN allows you to enter your desired PIN.

The SIM card in your MiFi device can be locked using a PIN. If the SIM card is locked, you must enter a PIN before connecting to the Internet. To lock your SIM card:


- Select **Enable PIN Lock** in the **Desired Action** drop-down menu.
- Contact AT&T Customer Care to request a SIM PIN code.
- **3** Enter a PIN in the **Enter Current SIM PIN** field.
- Click Save Changes.



Advanced Settings

The Advanced Settings menu includes the following menu options:


- **Firewall** (See <u>Firewall</u> on page 63.)
- LAN (See LAN on page 64.)
- **Port Filtering** (See <u>Port Filtering</u> on page 65.)



Firewall

The Firewall section displays the following:

• **VPN Passthrough** – allows connected devices to establish a VPN tunnel to a remote server or device.




To allow connected devices to establish a VPN tunnel to a remote server or device:

• Slide the ON/OFF button to **ON**.

LAN

The LAN section displays the following:


- IP Address the address that identifies the MiFi Liberate on the network.
- Subnet Mask the standard address for the MiFi Liberate subnet.
- MAC Address the physical address or hardware address of your MiFi device.
- **Enable DHCP Server** allows the device to automatically assign a local IP address to a new device joining your network (such as a wireless printer or another computer).
- **Start DHCP Address Range at** the current range of IP addresses assigned by the MiFi DHCP server.
- **Current DHCP Address Range** the beginning range of IP addresses assigned by the MiFi DHCP server.



Port Filtering


Port Filtering allows you to enhance the security of your system by only allowing certain applications to reach the Internet. The Port Filtering section displays the following:

- **Port Filtering** restricts internet traffic to specific applications. Select the check box next to Port Filtering to turn Port Filtering on.
- Applications select the check box next to one or more application (DNS, NNTP, SNMP, FPO, POP3, Telnet, HTTP, SMTP) to turn the particular application on.
- **Custom Applications** select **Add Custom Application** to add an application not included in the applications section.




To enable Port Filtering and restrict Internet traffic to specific applications:

- Click the **Port Filtering** check box.
- ② Click the application check box to enable/disable the selected application.
- 6 Click **Save Changes** to apply any changes made to the Port Filtering application settings.



To enable Port Filtering for custom applications:

- Click Add Custom Applications.
- Enter the desired name in the App Name field.
- **6** Enter the appropriate values in the Begin Port and End Port fields.
- **3** Select either TCP or UDP from the Protocol drop-down menu.
- 6 Click the check mark to finish editing the application.
- 6 Click **Save Changes** to save and apply the settings.




Messages

The Messages page lists the SMS messages delivered to your MiFi Liberate by your service provider. All messages are listed in order by date, with unread messages indicated in bold on a colored background. All messages are marked as read once they are displayed on this page.

On the MiFi Liberate Touchscreen

Tap the **Messages** icon to display the Messages page. The number of unread messages appears at the top of the page. To delete a message, tap the garbage can.






On the MiFi Liberate Manager

Select the **Messages** tab on the Navigation panel on the MiFi Liberate Manager Home page.

- Click **Delete** next to a message to delete only that message.
- Click Delete All Messages to delete all messages listed.



File Sharing

Your MiFi Liberate includes a microSD card slot that allows you to store files and share them with connected devices. microSD cards are sold separately.

The File Sharing page enables you to share files stored on the microSD card with other compatible devices, like your laptop and tablet, that are connected to the MiFi Liberate.



Enterprise variant available with File Sharing, Media Center, microSD™ functionality, WPS and tethering disabled.

Enable File Sharing

Insert a microSD card. File sharing is not enabled by default. If file sharing is enabled, devices connected to your MiFi Liberate can access the files on your microSD card.



- Be careful not to touch the contacts.
- Do not force the card into the slot. Check the orientation of the card if you have difficulties, and be sure it slides easily into the slot.
- Your MiFi Liberate supports both microSD and microSDHC (High Capacity) cards up to 32GB. (For the purposes of this User Guide, microSD is used.)

On the MiFi Liberate Touchscreen

Tap the File Sharing icon to display the File Sharing page.





② Slide the File Sharing ON/OFF button to ON.





Scroll to the lower part of the page to access instructions for using File Sharing on Windows, Mac or Tablets. For more File Sharing options, go to http://att.mifiliberate/filesharing.

Accessing Shared Files

Instructions for Windows:

- Click the Windows Start button and select Computer. The microSD card appears under Networks.
- ② If the microSD card does not appear under Networks, go to Start and type in \\MiFi-Liberate.
- **3** If prompted for a user name, enter **guest**. Do not enter a password.

Instructions for Mac:

► The microSD card will appear automatically under the 'shared' menu in the finder.

Instructions for iOS, Android, and other Mobile Devices:

Files may be downloaded and viewed from a connected mobile device through the web browser by going to http://att.mifiliberate/files.




Enterprise variant available with File Sharing, Media Center, microSD™ functionality, WPS and tethering disabled.

On the MiFi Liberate Manager

To access the File Sharing page, click **File Sharing** on the Navigation panel. The File Sharing page contains the following menu options:

- Settings (See <u>Settings</u> on page 71.)
- **View Files** (See <u>View Files</u> on page 72.)



From this page you can enable file sharing and see how much free space you have available on the microSDHC card. You can also decide to protect your files with a password or make them available to everyone connected to your MiFi Liberate.

Settings


The Settings section allows you to enable/disable File Sharing, check your microSD card status, and provides instructions for accessing shared files. The Settings section displays the following:

- File Sharing slide the ON/OFF button to enable/disable File Sharing.
- microSD Card Status displays microSD card availability and amount of unused storage.
- Accessing Shared Files provides instructions for accessing files from Windows, Mac and Tablets.



View Files

The View Files section allows you to view all files on the microSD card installed in the MiFi Liberate.



To view or download and save files on the microSD:

- Olick on the folder name to display all files in the folder.
- ② Click on the desired file to view an image of the file, or to download and save.

Media Center

The Media Center page allows you to play movies, music and photos on connected devices including DVD and Blue-ray® players, game consoles, televisions, tablets, mobile devices, computers, audio video systems, digital frames, and home theater devices. Connect over Wi-Fi to the MiFi Liberate. Use your Wi-Fi enabled or DLNA-capable device to access the files on your microSD card, and enjoy your content, hassle-free.

To access the Media Center page and enable the Media Center, tap the **Media Center** icon on the MiFi Liberate Touchscreen, or select **Media Center** on the Navigation panel on the MiFi Liberate Manager.

On the MiFi Liberate Touchscreen

1 Tap the Media Center icon 1 to display the Media Center page.





2 To access the Media Center and display a list of available video, audio and image media files, slide the ON/OFF button to **ON**.





For more Media Center options, go to http://att.mifiliberate/mediacenter.

NOTE Enterprise variant available with File Sharing, Media Center, microSD™ functionality, WPS and tethering disabled.

On the MiFi Liberate Manager

To view and share your media files with connected devices, play your media files in your web browser, and access Media Center applications, select the **Media Center** tab on the Navigation panel on the MiFi Liberate Manager Home page.




The Media Center page contains the following.

- **Status** (See <u>Status</u> on page 75.)
- **Media** (See <u>Media</u> on page 78.)

Status


Turning on the MiFi Media Center makes the media content on the microSD card available to connected devices. To view and share your media files with other DLNA capable devices:

• Select the **Status** tab to display the Media Center Status page.




Slide the ON/OFF button to ON to enable the Media Center and display Media Center status details and options.

Media Center



To rescan the contents on the microSD card, click **Rescan Content**. Click **Confirm** to begin the rescan.





To clear your cache and ensure that you have the latest versions of stored files, click **Clear Cache**. Click **Confirm** to delete the cached files.





To restart the Media Center Server, click **Restart Server**. Click **Confirm** to begin the restart.






Media

The Media menu displays these additional menu options.

- **Photos** (See <u>Photos</u> on page 79.)
- **Videos** (See <u>Videos</u> on page 80.)
- Music (See Music on page 81.)




Photos

The My Library drop-down menu allows you to browse and sort the photo files on the MiFi Liberate microSD card using these options:

- All Photos sorts all photo files.
- **By Date** sorts photo files by date.
- **By Folder** sorts photo files by folder.






Videos

The My Library drop-down menu allows you to browse and sort the video files on the MiFi Liberate microSD card using these options:

- All Videos sorts all video files.
- **By Date** sorts video files by date.
- **By Folder** sorts video files by folder.

Media Center




Music

The My Library drop-down menu allows you to browse and sort the music files on the MiFi Liberate microSD card using these options:

- **Album** sorts music files by album.
- All Tracks sorts music files by track.
- Artist sorts music files by artist.
- Artist/Album sorts music files by artist/album.
- **By Folder** sorts music files by folder.






GPS

The GPS page allows you to enable GPS and to enable GPS over Wi-Fi (NMEA). The GPS receiver on the MiFi Liberate can determine your current location, often even indoors.

On the MiFi Liberate Touchscreen

1 Tap the GPS icon 1 to display the GPS page.







To accept the GPS Privacy Agreement and enable GPS, slide the ON/OFF button to **ON**.





3 Scroll to the lower part of the page to view all current GPS location details.






On the MiFi Liberate Manager

To access the GPS page, click **GPS** on the Navigation panel. The GPS page contains the following:


- Enable GPS (See Enable GPS on page 84.)
- Current Position
 - GPS Over Wi-Fi
 - Port Number
- Download Enable GPS Over Wi-Fi Drivers



Enable GPS

To enable GPS and GPS over Wi-Fi:

- Slide the Enable GPS ON/OFF button to ON.
- Click the Enable GPS over Wi-Fi check box.
- Click **Save Changes** to activate and save your selections.



- You must download and install the GPS Over Wi-Fi Drivers to create a virtual NEMA (GPS) port on your computer before you can use the GPS Over Wi-Fi feature.


To download GPS Over Wi-Fi Drivers:

• Click Download GPS Over Wi-Fi Drivers.



A Help page displays a download overview and links to the available downloads.

Click the appropriate link to download the driver to your computer.



Wi-Fi Protected Setup

The Wi-Fi Protected Setup page allows you to setup WPS (Wi-Fi Protected Setup) on your MiFi Liberate to easily connect to other WPS-enabled devices.

On the MiFi Liberate Touchscreen

1 Tap the Wi-Fi Protected Setup icon to display the Wi-Fi Protected Setup page.





2 To enable WPS, slide the ON/OFF button to **ON**. Wi-Fi must be restarted and existing connections may be briefly interrupted.





To enable the WPS Push button method, tap **WPS Push button method** >. Find and push the WPS button on your connecting device.





To enable the WPS PIN method, tap **WPS PIN method** >. Find the WPS PIN on your connecting device, then click **Enter WPS PIN**.





NOTE

Enterprise variant available with File Sharing, Media Center, microSD™ functionality, WPS and tethering disabled.


About

The About page allows you to view current Internet, Wi-Fi, microSD card and configuration status; device details; and software update history. You can also manage your AT&T account, and view detailed diagnostic information and logs used for troubleshooting.

On the MiFi Liberate Touchscreen


1 Tap the **About** icon 1 to display the About page.






2 Tap **Current Status** > to display the network, network status, technology, signal strength, media center, file sharing, and GPS status details.






3 Tap **Device Info** > to display your wireless number, the device manufacturer, model number, IMEI, SIM#, and software version.






4 Tap **Help and Customer Care** > to display a link to tutorials, customer care, your wireless number, the device model number, and the current software version.




Tap **Software Update** > to display the current software version, last update, and to **Check for Updates**.



On the MiFi Liberate Manager

To access the About page, click **About** on the Navigation panel. The About page contains the following.

- Current Status (See <u>Current Status</u> on page 91.)
- **Device Info** (See <u>Device Info</u> on page 93.)
- **Customer Care** (See <u>Customer Care</u> on page 94.)
- **Diagnostics** (See <u>Diagnostics</u> on page 95.)
- Logs (See Logs on page 97.)
- Software Update (See <u>Software Update</u> on page 95.)



Current Status

The Current Status section displays the following:

- Internet Status (See Internet Status on page 91.)
- **Wi-Fi** (See Wi-Fi on page 91.)
- **Device** (See <u>(See Device on page 92.).</u>)

Internet Status

- **Connection Status** displays the connection status for the Internet connection and indicates if an error condition exists.
- **Network Name** network to which the MiFi Liberate is currently connected.
- **Technology** network technology used for the current connection.
- **Connection Time** the period of time that has elapsed since the current session started.
- **Data Sent** —the amount of data transmitted during the current Internet session. Each session restarts from zero.
- **Data Received** the amount of data received for the current Internet session. Each session restarts from zero.
- **IP Address** the IP address assigned to the MiFi Liberate.
- **Subnet Mask** the network mask associated with the IP address of the MiFi Liberate.
- **Gateway** the gateway IP address associated with the IP address of the MiFI Liberate.
- **DNS** the Domain Name Server currently used by the MiFi Liberate.

Wi-Fi

- Wi-Fi Network Name (SSID) name of the network (SSID) that you are connected to.
- **Wi-Fi Security** security type for the current profile.
- Wi-Fi Password (Key) the network key (Wi-Fi Key, password) for the wireless network.
- Channel channel that is being used.
- **Wi-Fi Mode** current wireless mode.
- Connected Devices clients that are currently connected to the device.
- Maximum Devices Allowed maximum number of clients that are allowed to connect to the
 device.

Device

- **microSD Card** indicates whether the microSD card is available.
- **Total Space** indicates the size of the microSD card.
- Available Space indicates how much free space is available on the microSD card.
- **File Sharing** indicates if File Sharing is enabled or disabled.
- **Media Center** indicates if the Media Center is enabled or disabled.
- **GPS Status** shows the current status of the GPS receiver.

Device Info

The Device Info section displays the following:


- Manufacturer the manufacturer of the MiFi Liberate device.
- **Model** the official model name and number for the MiFi Liberate device.
- MiFi Liberate Software Version the currently installed version of MiFi Liberate software.
 - **MiFi OS Version** the currently installed version number for the OS (Operating System) and its components.
 - **Modem FW Version** the currently installed version of the firmware used to control the MiFi's 4G modem function.
 - **Wi-Fi FW Version** the currently installed version of the Wi-Fi firmware.
 - **Web UI Version** the currently installed version of the MiFi Liberate Manager.
 - **LCD UI Version** the currently installed version of the software controlling the LCD touchscreen.
 - **PRI Version** the current configuration version applied to the MiFi Liberate.



Customer Care

The Customer Care section displays the following:

- Quick Links provides quick access to the AT&T website.
- **Self-Service Support** provides links to MiFi Liberate tutorials and support.
- **Contact AT&T** provides customer support contact information.



To access the Customer Care Advanced page:

- O Click Advanced.
- Enter the code provided by AT&T Customer Care in the code field.
- Click Submit.




Diagnostics

The Diagnostics section displays the following:

- Modem Status (See Modem Status on page 96.)
- HSPA Status (See <u>HSPA Status</u> on page 96.)
- 4G LTE Status (See <u>4G LTE Status</u> on page 96.)

NOTE - Diagnostics details are used only for troubleshooting and technical support.





Modem Status

- **IMEI** the International Mobile Equipment Identity (IMEI) for this device. This number does not change when the SIM is changed.
- **IMSI** the International Mobile Subscriber Identity (IMSI) is a unique identification associated with all GSM, UMTS and LTE mobile subscribers. It is stored in the SIM and changes if the SIM is changed.
- **Wireless Number** the wireless telephone number for the MiFi Liberate. This number changes if the SIM is changed.
- **FW Version** the current version of firmware installed on the MiFi Liberate.
- **SIM Status** indicates current status of the SIM card.
- **ICCID** the unique identification number assigned to the SIM card. It does not display if there is no SIM installed, or a SIM error condition exists.

HSPA Status

- **Status** refers to 4G HSPA and all preceding technologies. The following states are supported: disabled, not available, available.
- **Technology** displays current technology in use for the GSM/WCDMA/HSPA network.
- **Network ID** the name or ID of the GSM/WCDMA/HSPA network.
- **Cell ID** identifies the cell tower currently in use.
- **RSSI** displays the RSSI measure of signal strength in decibels. This is always a negative number, and higher absolute values indicate a stronger signal.
- **Roaming** indicates if the current connection is a roaming connection.

4G LTE Status

- **Status** displays current LTE network status. Possible status values are disabled, not available, or available.
- **Signal Strength** indicates the strength of the LTE signal. This is always a negative number, and higher absolute values indicate a stronger signal.
- **SINR** indicates the signal quality. Higher numbers indicate a better signal.
- **Roaming** indicates if the current connection is a roaming connection.


Logs

The Logs section displays the following:

- **Mobile Network** records details regarding network connections.
- **System** records details for events other than network connections.

NOTE - Logs are used only for troubleshooting and technical support.






Click Refresh List to update the Mobile Network or System Log.

Software Update

The Software Update section displays the following:

- Current Software displays the current version of software installed, last check for updates, and any updates available. If an update is available it is automatically downloaded and you will be prompted on the MiFi Liberate touchscreen to install it.
- Last Update displays the details of the last update installed.
- Update History displays the details of all updates that have been downloaded and installed.



Troubleshooting

Overview Common Problems and Solutions Using the Master Reset Button

Overview

When properly set up, your MiFi Liberate is a highly reliable product.

- Ensure that you are in the coverage area.
- Ensure you have an active subscription plan.
- Ensure the SIM card is correctly installed.
- Restarting your computer and your MiFi device can resolve many issues.
- Ensure the battery is fully charged.

IMPORTANT Before contacting support, be sure to restart your computer and restart your device.

Common Problems and Solutions

Before you read on, all of the steps mentioned here are given in more detailed form elsewhere in the user guide. When a reference is given, click the link to go to more detailed information.

The following are some common problems and solutions.

The MiFi Liberate touchscreen status bar displays no service available.

- Ensure that you are in the coverage area.
- Ensure you have an active rate plan.
- Ensure the SIM card is correctly installed.
- Restarting your MiFi Liberate can resolve many issues.
- If you are inside a building or near a structure that might block the signal, change the position or location of the device. For example, try moving your MiFi Liberate close to a window.

The device has no power.

The MiFi Liberate does not turn on when the **Power** button is pressed.

- Ensure the battery is properly seated in the device.
- Ensure the battery is fully charged. Plug in the A/C charger for at least four hours.

I forgot my password.

- ➤ Tap **Connection Details** on the MiFi LIberate touchscreen to find your Wi-Fi and Admin Passwords.
- You can reset the device to factory defaults using the **Master Reset** button. See <u>Using the Master Reset Button</u> on page 105.

I cannot connect to my MiFi Liberate.

- Make sure the MiFi Liberate is powered on.
- Make sure your Windows PC Wi-Fi / Mac AirPort is turned on. (Check your computer's Help if you need assistance.)
- **3** Open your wireless network connection list.
 - Windows: Right-click the wireless icon and select View Available Networks.
 - Mac: Click the AirPort icon in the menu bar and pull down the list of networks.
- Select the Liberate's Wi-Fi network name.

Windows: Click Connect.

Mac: Connects automatically after you select the network name.

When your computer is connected to your MiFi Liberate, the MiFi Liberate touchscreen will display the message "Connected Devices: A device has connected to the MiFi Liberate." The number of connected devices will also display on the status bar of the touchscreen

My network does not appear in the wireless network list.

- Verify that the MiFi Liberate is powered on.
- Refresh your network list.
 - **Windows:** Click the refresh button on the upper right corner of the Wireless Network Connection page. If that does not work you can try the following:
 - 1. Open Network Connections.
 - 2. Right-click Wireless Network Connection and select Properties.
 - 3. Click the Wireless Networks tab.
 - 4. Delete any unused wireless connections from the **Preferred Networks** list and click **OK**.
 - 5. Restart your computer.
 - Mac: Click the AirPort icon in the menu bar and select **Turn AirPort Off**. Then click it again and select **Turn AirPort On**.

I can connect to my MiFi Liberate but I cannot connect to the Internet.

Check the user name, password, and access point name (APN) in your connection profile. If any of these are wrong, you cannot connect to the network.

I see the network name but I cannot connect to my MiFi Liberate.

- Check that you are connecting to your MiFi Liberate device. If another MiFi Liberate device is in the area, you may be trying to connect to the wrong MiFi Liberate device.
- If your MiFi device has a Wi-Fi password, check that you entered the correct password.

How do I disconnect from the network?

- From the MiFi Liberate touchscreen:
 - 1. Hold the power button until the **Shut Down** message displays.
 - 2. Tap **Yes** to shut down the MiFi Liberate device and disconnect from the network.

How can I find out how many users are connected to my MiFi device?

- From the MiFi Liberate touchscreen:
 - » Check the **Connected Devices** icon on the status bar at the top of the touchscreen. The number of connected devices displays to the right of the icon. You can also swipe the carousel to display the **Connected Devices** icon and the number of connected devices.

Where can I find information about Internet connectivity and my Wi-Fi setup?

➤ Tap **About** > **Current Status** on the MiFi Liberate touchscreen.

How do I check the wireless number, model number and firmware versions of my MiFi Liberate?

- From the MiFi Liberate touchscreen:
 - » Tap the **About** icon (1), then tap **Device Info** > to display your wireless number, manufacturer, model number, IMEI, SIM# and software version.
- From the MiFi Liberate Manager:
 - » Select **About** > **Device Info** to display the manufacturer, model number and MiFi Liberate software version details.

How can I check the battery level of my MiFi Liberate?

- From the MiFi Liberate touchscreen:
 - » Check the Battery status icon displayed on the status bar at the top right side of the touchscreen. A warning message displays when the remaining battery charge reaches 10%, and the battery icon turns red to indicate that the battery needs to be recharged.
- From the MiFi Liberate Manager:
 - » Check the Battery status icon displayed on the status bar at the top right side of any page.

Where can I find my IMEI number?

- From the MiFi Liberate touchscreen:
 - » Tap the **About** icon (6), then tap **Device Info** > to display the IMEI number.
- From the MiFi Liberate Manager:
 - » Select **About > Diagnostics** to display the Modem Status section which includes the IMEI number.

How do I check the available space on the microSD card?

- From the MiFi Liberate touchscreen:
 - » Tap the **File Sharing** icon **3**. The microSD storage information displays above the counter at the bottom of the page.
- From the MiFi Liberate Manager:
 - » Select File Sharing > Settings. The microSD storage information displays under the microSD Card Status section.

How do I turn off my MiFi device?

- 1. Press and hold the **Power** button until the **Shut Down** message displays.
- 2. Tap **Yes**.

What is the default Admin Login?

The default Admin Login is attadmin.

How do I access information on the Wi-Fi network and Wi-Fi clients?

- From the MiFi Liberate touchscreen:
 - 1. Tap the **Connected Devices** icon **to** display the Connected Devices page showing all devices currently connected to or blocked from your MiFi Liberate.
 - 2. Tap the name of a specific connected device to display the device type, time connected, MAC address, and IP address for that device.
- From the MiFi Liberate Manager:
 - » Select Connected Devices from the MiFi Liberate Manager Navigation panel to display all devices currently connected to or blocked from your MiFi Liberate, including IP and MAC address details.

I am having trouble connecting to my office VPN.

- From the MiFi Liberate Manager:
 - 1. Select Settings > Advanced Settings > Firewall.
 - 2. Slide the VPN Passthrough ON/OFF button to ON.

My MiFi device keeps going to sleep after a period of time when I'm idle.

This is a customizable setting which allows you to adjust the period of inactivity before the device turns off in order to conserve battery life.

- From the MiFi Liberate Manager:
 - 1. Select Settings > Device Settings > Preferences > Automatic Shutdown.
 - 2. Select **Never** from the drop down menu to disable Automatic Shutdown.

Using the Master Reset Button

Your MiFi Liberate comes with a master reset button that allows you to return it to its factory default state.

The master reset button is recessed in a hole on the back of the device. You need a paperclip or similar object to push the button.

- Make sure your MiFi Liberate is powered on.
- 2 Locate the master reset button on the back of the device directly below the raised SIM card section.



- 3 Insert a paper clip into the hole and hold the button down for five (5) seconds.

 Your list of wireless networks now shows the original default network when you first configured your device.
- **Gonnect** to your MiFi Liberate again and re-configure it. Your pre-configured profile information stays the same, but for any custom profiles you have to enter your APN and other information again.

Technical Support

Customer Service

For AT&T Customer Care while in the U.S. or Canada, call 800-331-0500.

When calling, enter the wireless number of your MiFi Liberate found on the device by tapping **About > Device Info**, or on the MiFi Liberate Manager by going to **About > Customer Care**. Entering the wireless number of the device will route your call to specialty customer care teams trained to assist with the MiFi Liberate devices.

More Information

For more information, visit <u>www.att.com/devicesupport</u>. For education content, visit <u>www.att.com/tutorials</u>.

Product Specifications and Regulatory Information

Product Specifications
Regulatory
Safety Hazards
Proper Battery Use and Disposal
Limited Warranty and Liability

Product Specifications

General

Name:	AT&T Mobile Hotspot MiFi Liberate
Model:	MiFi 5792
Approvals:	FCC, PTCRB, DLNA, RoHS, WEEE
Weight:	120 g (4.26 oz)
Dimensions:	102.9 x 73.1 x 8.6 mm (4.05 x 2.88 x 0.34 in)
Wireless Network:	LTE, UMTS, HSPA/HSPA+, EDGE, GPRS
Wireless Network - Wi-Fi Mode:	802.11b/g/n
Default SSID:	MIFI-LIBERATE-XXXX
Battery:	Rechargeable, lithium ion battery
- Size:	2900 mAh
- Time Required to Full Charge:	4 hrs
- Life:	Up to 12 hrs
Chipset:	QUALCOMM 9215
Interface Type:	USB
microSD/SDHC:	Up to 32 GB

Display

Touch screen:	TFT color display	
roach screen.	ii i coloi dispidy	

Technology/Bands

4G LTE:	700/850/AWS/1900 MHz
3G UMTS/HSPA/HSPA+:	850/900/AWS/2100 MHz
2G EDGE/GPRS:	850/900/1800/1900 MHz

Environmental

Operating Temperature:	-20° C to 60° C (-4° F to 140° F)
Storage Temperature:	-20° C to 60° C (-4° F to 140° F)
Drop:	1 meter (3.28 feet) drop, no damage – fully operational
Vibration Stability:	5 Hz to 500 Hz, 0.1 octave/second

Regulatory

Federal Communications Commission Notice (FCC – United States)



Electronic devices, including computers and wireless modems, generate RF energy incidental to their intended function and are therefore subject to FCC rules and regulations.

This equipment has been tested to, and found to be within the acceptable limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment.

This equipment generates radio frequency energy and is designed for use in accordance with the manufacturer's user manual. However, there is no guarantee that interference will not occur in any particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

This device complies with Part 15 of the Federal Communications Commission (FCC) Rules and Industry Canada ICES-003 for EMI compliance. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

WARNING: DO NOT ATTEMPT TO SERVICE THE WIRELESS COMMUNICATION DEVICE YOURSELF. SUCH ACTION MAY VOID THE WARRANTY. THE MIFI 5792 MODEM IS FACTORY TUNED. NO CUSTOMER CALIBRATION OR TUNING IS REQUIRED. CONTACT NOVATEL WIRELESS TECHNICAL SUPPORT FOR INFORMATION ABOUT SERVICING YOUR WIRELESS COMMUNICATION DEVICE.

FCC CAUTION: Any changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

MODIFICATIONS: The FCC requires that you be notified that any changes or modifications made to this device that are not expressly approved by Novatel Wireless, Inc. may void your authority to operate the equipment.

NOTE: The Radio Frequency (RF) emitter installed in your modem must not be located or operated in conjunction with any other antenna or transmitter, unless specifically authorized by Novatel Wireless Technologies.

RF CONTENT

FCC EQUIPMENT AUTHORIZATION ID: PKRNVWMIFI5792

This device is authorized for use in mobile and portable applications. At least 10 mm (0.4 inches) of separation between the MiFi device and the user's body must be maintained at all times.

This product has been evaluated for SAR and meets the FCC Guidelines for exposure to radio waves.

Safety Hazards

Do not operate your MiFi Liberate device in an environment that may be susceptible to radio interference resulting in danger, specifically:

Areas where prohibited by the law

Follow any special rules and regulations and obey all signs and notices. Always turn off your MiFi Liberate device (or the host device and remove the modem from the USB port) when instructed to do so, or when you suspect that it may cause interference or danger.

Where explosive atmospheres may be present

Do not operate your modem in any area where a potentially explosive atmosphere may exist. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Be aware and comply with all signs and instructions.

Users are advised not to operate the modem while at a refueling point or service station. Users are reminded to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. Potential locations can include gas stations, below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

Near medical and life support equipment

Do not operate your device around medical equipment, life support equipment, or near any equipment that may be susceptible to any form of radio interference. In such areas, the host communications device must be turned off. The device may transmit signals that could interfere with this equipment.

On an aircraft, either on the ground or airborne

In addition to FAA requirements, many airline regulations state that you must suspend wireless operations before boarding an airplane. Please ensure that your MiFi Liberate device (or the host device) is turned off and if in USB Mode, your modem is removed from the USB port prior to boarding aircraft in order to comply with these regulations. The modem can transmit signals that could interfere with various onboard systems and controls.

While operating a vehicle

The driver or operator of any vehicle should not operate a wireless data device while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some countries, operating such communications devices while in control of a vehicle is an offense.

Electrostatic discharge (ESD)

Electrical and electronic devices are sensitive to electrostatic discharge (ESD). Macintosh native connection software might attempt to reinitialize the device should a substantial electrostatic discharge reset the device. If the software is not operational after an ESD occurrence, then restart your computer.

Proper Battery Use and Disposal

CAUTION! Never dispose of batteries in a fire because they might explode:

WARNING! In the event of a battery leak:

- Do not allow the liquid to come in contact with the skin or the eyes. If contact has been made, wash the affected area with large amounts of water and seek medical advice.
- Seek medical advice immediately if a battery has been swallowed.

Contact your local recycling center for proper battery disposal.

Guidelines for Safe and Responsible Battery Use

- Do not disassemble or open, crush, bend or deform, puncture, or shred.
- Do not modify or remanufacture, attempt to insert foreign object into the battery, immerse or expose to water or other liquids, or expose to fire, explosion, or other hazard.
- Only use the battery for the system for which it was specified.
- Only use the battery with a charging system that has been qualified with the system per this standard. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic or conductive object to contact the battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard. Use of an unqualified battery may present a risk of fire, explosion, leakage, or other hazard.
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the device or battery. If the device or the battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion, or other hazard.

Limited Warranty and Liability

Novatel Wireless, Inc. warrants for the 12 month period immediately following receipt of the Product by Purchaser that the Product will be free from defects in material and workmanship under normal use. THESE WARRANTIES ARE EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The exclusive remedy for a claim under this warranty shall be limited to the repair or replacement, at Novatel Wireless' option, of defective or non-conforming materials, parts or components. The foregoing warranties do not extend to (I) non conformities, defects or errors in the Products due to accident, abuse, misuse or negligent use of the Products or use in other than a normal and customary manner, environmental conditions not conforming to Novatel Wireless' specification, of failure to follow prescribed installation, operating and maintenance procedures, (II) defects, errors or nonconformity's in the Product due to modifications, alterations, additions or changes not made in accordance with Novatel Wireless' specifications or authorized by Novatel Wireless, (III) normal wear and tear, (IV) damage caused by force of nature or act of any third person, (V) shipping damage, (VI) service or repair of Product by the purchaser without prior written consent from Novatel Wireless, (VII) products designated by Novatel Wireless as beta site test samples, experimental, developmental, reproduction, sample, incomplete or out of specification Products, or (VIII) returned products if the original identification marks have been removed or altered.

Glossary

Glossary

Glossary

- **802.11 (b, g, n)** A set of WLAN communication standards in the 2.4, 3.6 and 5 GHz frequency bands.
- Access Point A device that allows wireless communication devices to connect to a wireless network using a standard such as Wi-Fi.
- **APN** Access Point Name. The APN is an alphanumeric string that identifies the particular network service that is being accessed. These are used by GPRS and UMTS networks.
- **bps** bits per second. The rate of data flow.
- Broadband High-capacity high-speed, transmission channel with a wider bandwidth than conventional modem lines. Broadband channels can carry video, voice, and data simultaneously.
- **DHCP** Dynamic Host Configuration Protocol. Software found in servers and routers that automatically assigns temporary IP addresses to clients logging into an IP network.
- **DHCP Server** A server or service with a server that assigns IP addresses.
- **DNS** Domain Name System. A system for converting host names and domain names into IP addresses on the Internet or on local networks that use the TCP/IP protocol.
- **ESN** Electronic Serial Number. A unique 32-bit number embedded in a wireless device that identifies the device.
- **Firewall** A hardware or software boundary that protects a network or single computer from unwanted outside traffic.
- **Firmware** A computer program embedded in an electronic device. Firmware usually contains operating code for the device.
- **FTP** File Transfer Protocol. A network protocol for exchanging files over a TCP network.
- **Gateway** A network point that acts as an entrance to another network that uses a different protocol.
- **GSM** Global System for Mobile communication. A digital mobile telephony system widely used in Europe and other parts of the world. GSM was first launched in 1991 and is the most widely used of the three digital wireless telephony technologies (TDMA, GSM, and CDMA). GSM uses a variation of TDMA.
- **GPS** Global Positioning System. A radio-based navigation system that allows users to determine their location. The device uses satellite data to calculate its position. Commonly used in mapping and navigation systems.
- Host Name The unique name by which a network-attached device is known on a network.
- **Hotspot** A Wi-Fi (802.11) access point or the area covered by an access point. Used for connecting to the Internet.
- **Hot-Swappable** The ability to safely remove and replace a component (for example, a memory card or USB device) from a device or computer while it is powered on.
- HTTP Hypertext Transfer Protocol. An application-level protocol for accessing the World Wide Web

- **ICCID** Integrated Circuit Card Identification. A serial number stored in and engraved or printed on a SIM card that internationally identifies the card.
- **IMEI** International Mobile Equipment Identity. Used in GSM networks to identify the device. It is usually printed on the device and can often be retrieved using a USSD code.
- **IMSI** International Mobile Subscriber Identity. Used in GSM networks to identify the subscriber Usually embedded in the SIM.
- **IP** Internet Protocol. The mechanism by which packets are routed between computers on a network.
- **IP Type** The type of service provided over a network.
- **IP address** Internet Protocol address. The address of a device attached to an IP network (TCP/IP network).
- **ISP** Internet Service Provider. Also referred to as the service carrier, an ISP provides Internet connection service. (See Network Operator)
- **Kbps** Kilobits per second. The rate of data flow.
- LAN Local Area Network. A type of network that lets a group of computers, all in close proximity (such as inside an office building), communicate with one another. It does not use common carrier circuits though it can have gateways or bridges to other public or private networks.
- MAC Address Media Access Control. A number that uniquely identifies each network hardware device. MAC addresses are 12-digit hexadecimal numbers.
- **MEID** Mobile Equipment Identifier. A globally unique number for a physical piece of mobile station equipment.
- Mbps Megabits per second.
- microSD / microSDHC A small, removable flash memory card available in various storage sizes. Some products have a slot that allows them to utilize this external memory.
- **MSID** Mobile Station Identifier. A number for a mobile phone that identifies that phone to the network. These numbers are carrier specific.
- MSL Master Subsidy Lock. A numeric code for accessing certain phone settings.
- NAI Network Access Identifier. A standard way of identifying users who request access to a network.
- **NDIS** Network Driver Interface Specification. NDIS is a Windows specification for how communication protocol programs (such as TCP/IP) and network device drivers should communicate with each other.
- **Network Mask** A number that allows IP networks to be subdivided for security and performance.
- **Network Operator** The vendor who provides your wireless access. Known by different names in different regions, some examples are: wireless provider, network operator, and service provider.
- Network Technology The technology on which a particular network operator's system is built; such as GSM, HSPA, CDMA, EDGE, and EVDO.

- NNTP Network News Transfer Protocol. An Internet application protocol for reading and posting Usenet (newsgroup) articles.
- **Port** A virtual data connection used by programs to exchange data. It is the endpoint in a logical connection. The port is specified by the port number.
- Port Forwarding A process that allows remote devices to connect to a specific computer within a
 private LAN.
- **Port Number** A 16-bit number used by the TCP and UDP protocols to direct traffic on a TCP/IP host. Certain port numbers are standard for common applications.
- Protocol A standard that enables connection, communication, and data transfer between computing endpoints.
- **PRL** Preferred Roaming List. A list that your wireless phone or device uses to determine which networks to connect with when you are roaming. (Network operator specific)
- **Protocol** A standard that enables connection, communication, and data transfer between computing endpoints.
- Proxy A firewall mechanism that replaces the IP address of a host on the internal (protected) network with its own IP address for all traffic passing through it.
- **Router** A device that directs traffic from one network to another.
- **RTP** Real-time Transport Protocol. A packet format for streaming multimedia over the Internet.
- **SIM** Subscriber Identification Module. Found in GSM network technology, the SIM is a card containing identification information for the subscriber and their account. The SIM card can be moved to different devices.
- **SMS** Short Message Service. A service for sending short messages of up to 160 (224 in 5-bit mode) characters to mobile devices. SMS is also known as text messaging.
- **SSID** Service Set Identifier. The name assigned to a Wi-Fi network.
- **TCP** Transmission Control Protocol. A core protocol for transmitting and receiving information over the Internet.
- **TCP/IP** Transmission Control Protocol/Internet Protocol. The set of communications protocols used for the Internet and other similar networks.
- UI User Interface. The part of a software application or hardware device that a user sees and interacts with.
- USB Universal Serial Bus. A connection type for computing device peripherals such as a printer, mobile modem, etc. USB connectors may be used for data transfer or charging.
- **USB Port Types** The USB ports on computers and hubs have a rectangular Type A socket, and peripheral devices have a cable with a Type A plug. Peripherals that do not have an attached cable have a square Type B socket on the device and a separate cable with a Type A and Type B plug. Ports and connectors are available in different sizes (for example, standard, mini, and micro).
- USSD Unstructured Supplementary Service Data. A service found in HSPA/GSM networks that allows the user to retrieve information or implement certain types of call services.

- **VPN** Virtual Private Network. A secure private network that runs over the public Internet. Commonly used to connect to an office network from elsewhere.
- **VPN Passthrough** A feature that allows a client to connect to a VPN server.
- WAN Wide Area Network. A public network that extends beyond architectural, geographical, or political boundaries (unlike a LAN, which is usually a private network located within a room, building, or other limited area).
- **WEP** Wired Equivalent Privacy. An IEEE standard security protocol for 802.11 networks. Superseded by WPA and WPA2.
- **Wi-Fi (R)** Wireless Fidelity. Any system that uses the 802.11 wireless standard developed and released in 1997 by the IEEE.
- Wi-Fi Client A wireless device that connects to the Internet via Wi-Fi.
- **WLAN** Wireless Local Area Network. A typically low-power network that transmits a wireless signal over a span of a few hundred feet and usually only to stationary devices. Wi-Fi is the most common WLAN.
- **WPA/WPA2** Wi-Fi Protected Access. A security protocol for wireless 802.11 networks from the Wi-Fi Alliance.
- **WWAN** Wireless Wide Area Network. Wireless network technologies deployed over a large geographical area to a large number of users (see WLAN). This service is usually provided through cellular network operators. WWAN connectivity allows a user with a laptop and a WWAN device to surf the Internet, check e-mail, or connect to a virtual private network (VPN) from anywhere within the coverage area of the network operator.