Altivar Machine ATV320

Variable Speed Drives for Asynchronous and Synchronous Motors

Installation Manual

NVE41289.09
04/2025

www.se.com

Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

Table of Contents

About the document 5
- Validity Note 6
- Document Scope 7
- Safety Information 8
  - Qualification of Personnel 9
  - Intended Use 9
  - Product Related Information 10
- Related Documents 14
- Electronic product data sheet 16
- Terminology used in this document 17
- Contact us 18

Introduction 19
- Verifying the Absence of Voltage 20
- Drive Overview 22
  - Accessories and Options 29
  - Environmental Data Program 32
  - Altivar Efficiency Calculator 32
- Steps for setting up the drive 33
- Preliminary Instructions 34

Technical Data 35
- Environmental Conditions 36
- Dimensions and Weights 38
- Electrical Data - Drive Ratings 53

Electrical Data - Upstream Protective Device 57
- Upstream Protective Device – Introduction 58
- Prospective Short-Circuit Current 60
- IEC Type Circuit-Breaker — with enclosure 63
- IEC Type Circuit-Breaker — wall mounted 67
- IEC Fuses — with enclosure 70
- IEC Fuses — wall mounted 74
- UL Circuit-Breakers and Fuses 78

Drive Mounting 81
- Mounting Conditions 82
- Power Dissipated For Enclosed Drives and Required Air Flow 88
- Derating Curves 91
  - Derating Curves — Format Book 92
  - Derating Curves — Format Compact M2C 93
  - Derating Curves — Format Compact M3C 94
  - Derating Curves — Format Compact N4C 97
  - Derating Curves — Format Compact S6C 103
  - Derating Curves — M2W(S) 105
  - Derating Curves — Format Compact N4W(S) 106
- Checking mechanical installation before wiring 108

Drive wiring 109
- Wiring Instructions 110
- Cable Length Instructions 114
- General Wiring Diagrams 116