## **Encoding instructions FAIRWY**

## **General Discussions**

gertM

Apr 10

In the encoding instructions of I.1.4 Fairway point D tells us that the attribute DRVAL1 of the FAIRWY object class should not be used. As far as I can see, the feature FAIRWY has no DRVAL1 attribute defined (see feature catalogue).

I suppose that the instruction wants to point out that DEPARE has to be used in addition with FAIRWY (see C) and that DRVAL1 can be used in combination with DEPARE?

## johannes.nemeth

Apr 12

Yes, seems to be correct. When a FAIRWY is defined and encoded and no detailed bathymetry availbale than the geometry of the FAIRWY has to be encoded with I.1.5 Fairway Depth/Project Depth -> DEPARE (with attributes DRVAL 1 and DRVAL 2), see also instructions E at I.1.4. BR, Johannes