brsatoi()

Converts a character string into a DINT value

This function block can only be used conditionally for **redundancy**. The applicable limitations are described in the following sections:

Hidden pointer usage

Additional information can be found in the "Redundancy" section.

Parameters

I/O	Parameter	Data type	Description
IN	pString	UDINT (given as a pointer to STRING)	Address of character string to be converted
OUT	Z	DINT	Numerical value of character string

Call syntax (Automation Basic)

z = brsatoi(adr(Str))

Note

The brsatoi function converts a character string into a DINT value.

Examples

Automation Basic ANSI C Structured Text