

Dasan Zhone Commands

System and Hardware Management

slots

Displays the chassis slots, installed card types, and their current operating status.

list card-profile

Lists all configured card profiles and their identifiers.

get card-profile <profile_id>

Retrieves detailed configuration information for a specific card profile, including software file names, administrative status, and upgrade settings.

card stats all

Shows CPU and memory utilization, uptime, and the running software version for all installed cards.

audit

Audits various configuration profiles (such as alarm, analog, ATM, and bridge interfaces) to check for records and configuration issues.

GPON OLT and ONU Operations

gponolt show port

Displays hardware metrics for OLT ports across all slots, including temperature, voltage, Tx bias current, Tx power, and end-of-life status.

gpononu show

Displays the available ONUs and the discovered serial numbers for OLTs.

gpononu show <slot/port/onu>

Verifies that the specified ONT is associated with the OMCI file.

gpononu showall

Displays ONUs along with their serial number data and other related information.

gpononu status

Displays the operating status and GPON ONU line status for selected ONUs.

gpononu gemparts <slot/port/onu>

Displays the names and bandwidth of GEM ports for selected ONUs.

gpononu clear

Disables an ONU and clears the serial number to default.

onu show <slot/port/onu>

Displays the serial number, ONU name, enabled status, model number, and assigned OMCI files or profiles for a specific ONU.

onu clear <slot/port/onu>

Disables a specific ONT and clears the serial number for that ONT.

onu image show <slot/port/onu>

Displays software partition details for a specific ONU, including the software version, active status, commit status, and download status.

onu recover <slot/port/onu>

Initiates a recovery process for the specified ONU.

onu resync <slot/port/onu>

Forces a resynchronization of the specified ONU configuration.

Networking and Bridging

bridge show

Displays the bridge type and verifies the bridge is created.

bridge show vlan <vlan_id>

Displays bridge interfaces and MAC address tables assigned to a specific VLAN.

bridge stats vlan <vlan_id>

Displays packet counters (unicast, multicast, broadcast), storm detect packets, and error statistics for bridge interfaces on a specific VLAN.

bridge show <interface_string>

Shows specific bridge details for a targeted interface string.

interface show

Displays IP interfaces, their operational status, IP addresses, subnet masks, and associated MAC addresses.

ifxlate <ifIndex_number>

Translates an SNMP interface index (ifIndex) into physical hardware location data, identifying the specific shelf, slot, port, and subport.

linkagg show

Displays Link Aggregation groups, active links, priorities, partner MAC addresses, and overall status for bundled interfaces.

File System Operations

dir

Lists the files and directories in the current file system path, displaying permissions, size, and modification dates.

cd <directory_name>

Changes the current working directory in the file system.

copy <source_file> <destination_file>

Copies a file to a new destination name within the file system.