1. Printer Does Not Turn On

- Verify the power cord is securely connected to both the printer and a working wall outlet.
- Press the Power button and wait a few seconds.
- Try a different power outlet if the printer does not respond.
- Disconnect the power cable for 60 seconds, reconnect it, and turn the printer on again.

2. Printer Is Offline

- Ensure the printer is powered on and connected to the computer or network.
- Restart the printer and computer.
- Check the USB cable or Wi-Fi connection.
- Set the printer as the default printer in your operating system.
- Remove any paused or stuck print jobs.

3. Printer Not Printing

- Confirm there is paper loaded correctly in the input tray.
- Check ink or toner levels and replace low or empty cartridges.
- Verify the correct printer is selected when printing.
- Cancel pending print jobs and resend the document.
- Restart the printer after completing these checks.

4. Paper Jam

Clear the Paper Jam

1. Turn off the printer and unplug the power cord.
2. Remove any jammed paper carefully using both hands.
3. Check the input tray, output tray, and rear access door for torn paper.
4. Remove all paper fragments and foreign objects.
5. Reload paper properly and restart the printer.

5. Poor Print Quality

Improve Print Quality

1. Check ink or toner levels.
2. Clean the printhead or cartridges using the printer's maintenance menu.
3. Use the correct paper type and quality.
4. Align the printhead if alignment is available.
5. Print a test page to verify improvements.

6. Wireless Connection Issues

- Ensure Wi-Fi is enabled on the printer.
- Verify the printer is connected to the correct wireless network.
- Restart the router and printer.
- Move the printer closer to the router if the signal is weak.
- Reconnect the printer using the printer setup software.

7. Print Jobs Stuck in Queue

Windows

1. Open the Print Queue.
2. Cancel all pending print jobs.
3. Restart the Print Spooler service.
4. Restart the printer and computer.
5. Print a test page.

macOS

1. Open **Printers & Scanners**.
2. Open the printer queue.
3. Delete any stuck print jobs.
4. Restart the printer.
5. Print a test page.

8. Ink or Toner Not Detected

- Remove and reinstall the cartridge.
- Ensure the protective tape has been removed from new cartridges.
- Clean the cartridge contacts if recommended by the manufacturer.
- Install genuine, compatible cartridges.
- Restart the printer after reinstalling the cartridge.

9. Scanner Not Working (All-in-One Printers)

- Verify the scanner cable or wireless connection.
- Open the scanner software and check that the correct device is selected.
- Restart the printer and computer.
- Update or reinstall the printer drivers.
- Try scanning using another application.

10. Reset the Printer

1. Turn off the printer.
2. Disconnect the power cord.
3. Wait for 60 seconds.
4. Reconnect the power cord directly to a wall outlet.
5. Turn the printer on and check whether the issue is resolved.

Additional Tips

- Keep printer firmware and drivers up to date.
- Use the recommended paper type and size.
- Store ink cartridges properly when not in use.
- Clean the printer regularly to prevent dust buildup.
- Print a diagnostic or test page if problems continue.