Troubleshooting: Audio

Step 1: Check the volume

- Make sure the device is not muted.
- Increase the system volume.
- Check the volume in the application you're using.

Step 2: Verify the audio output device

- Ensure the correct speakers or headphones are selected.
- Disconnect and reconnect external audio devices.
- If using Bluetooth, make sure the device is connected.

Step 3: Restart the device

- Restart your computer, phone, or tablet.
- Test the audio again after restarting.

Step 4: Check physical connections

- Ensure speaker and headphone cables are securely connected.
- Try another USB port or audio jack if applicable.
- Verify that external speakers are powered on.

Step 5: Run the audio troubleshooter

Windows

1. Open **Settings** > **System** > **Troubleshoot**.
2. Select **Other troubleshooters**.
3. Run the **Playing Audio** troubleshooter.
4. Follow the on-screen instructions.

macOS

1. Open **System Settings** > **Sound**.
2. Verify the correct output device is selected.

3. Adjust the output volume.
4. Restart the Mac if necessary.

Step 6: Update or reinstall the audio driver (Windows)

1. Open **Device Manager**.
2. Expand **Sound, video and game controllers**.
3. Right-click the audio device.
4. Select **Update driver**.
5. If the issue continues, uninstall the driver and restart the computer to reinstall it automatically.

Step 7: Check application settings

- Ensure the application is not muted.
- Verify the correct input/output device is selected within the app.
- Restart the application.

Step 8: Test with another device

- Try different headphones or speakers.
- Test the current speakers or headphones on another device.
- This helps determine whether the issue is with the computer or the audio device.

Step 9: Install operating system updates

- Install the latest Windows, macOS, Android, or iOS updates.
- Restart the device after updates are installed.

Step 10: Reset audio settings (if needed)

- Restore audio settings to their default values.
- Restart the device and test the sound again.

If the issue persists

The problem may be caused by:

- Corrupted audio drivers

- Faulty speakers or headphones
- Hardware failure of the sound card
- Operating system issues

If possible, test the device with another audio output or contact the device manufacturer's support for further diagnosis.