Troubleshooting: Display Issues on Laptop and PC

Step 1: Check if the Device Is Powered On

- Make sure the laptop or PC is turned on.
- Verify that the power LED is lit.
- Listen for fan noise or hard drive activity.

Step 2: Check the Monitor or Laptop Screen

- Ensure the monitor is powered on.
- Increase the screen brightness on the laptop.
- Verify that the monitor's power cable is securely connected.
- Make sure the correct input source (HDMI, DisplayPort, VGA, etc.) is selected.

Step 3: Check Display Cables

- Disconnect and reconnect the display cable.
- Inspect the cable for damage.
- Try a different cable if available.
- Connect the monitor to another computer to verify it works.

Step 4: Restart the Computer

- Shut down the computer completely.
- Wait 30–60 seconds.
- Turn it back on and check if the display appears.

Step 5: Test with an External Monitor (Laptop)

- Connect the laptop to an external monitor or TV.
- Press **Windows + P** to switch display modes.
- If the external display works, the laptop screen or display cable may be faulty.

Step 6: Check Display Mode

- Press **Windows + P**.

- Select one of the following:
    - PC screen only
    - Duplicate
    - Extend
    - Second screen only

Step 7: Boot into Safe Mode

If the display issue started after a driver or software update:

1. Boot into Windows Recovery Environment.
2. Select **Troubleshoot > Advanced options > Startup Settings**.
3. Restart and choose **Safe Mode**.
4. Update or uninstall the display driver.

Step 8: Update or Reinstall Graphics Driver

1. Press **Windows + X** and select **Device Manager**.
2. Expand **Display adapters**.
3. Right-click the graphics adapter.
4. Select **Update driver**.
5. If necessary, uninstall the driver and restart the computer.

Step 9: Check for Physical Damage

- Look for cracks or liquid damage on the screen.
- Check for loose hinges or damaged display cables.
- Inspect the monitor for signs of hardware failure.

Step 10: Perform a Hard Reset (Laptop)

1. Turn off the laptop.
2. Disconnect the power adapter.
3. Remove the battery (if removable).

4. Hold the power button for **15–20 seconds**.
5. Reconnect the battery and power adapter.
6. Turn the laptop back on.

Step 11: Check BIOS/UEFI Display

- Restart the computer and enter the BIOS/UEFI setup (usually by pressing **F2**, **F10**, **Delete**, or **Esc** during startup).
- If the display works in BIOS but not in Windows, the issue is likely related to Windows or the graphics driver.

Step 12: Run Hardware Diagnostics

- Use the built-in hardware diagnostics provided by the computer manufacturer.
- Test the display, graphics adapter, and memory.

Step 13: When to Seek Hardware Repair

If the display still does not work after completing the above steps:

- The LCD panel may have failed.
- The graphics card or integrated GPU may be defective.
- The motherboard or display cable may require repair or replacement.
- Contact the device manufacturer's support or an authorized service center for further diagnosis