

OVP Guide to Using Processor Models Model Specific Information for variant powerpc_UISA

Imperas Software Limited

Împeras Buildings, North Weston Thame, Oxfordshire, OX9 2HA, UK docs@imperas.com



Author	nperas Software Limited				
Version	0.4				
Filename	OVP_Model_Specific_Information_powerpc32_UISA.pdf				
Created	25 August 2015				

Copyright Notice

Copyright © 2015 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Table of Contents

1.0 Overview	4
1.1 Description	4
1.2 Licensing	4
1.3 Limitations	4
1.4 Verification	4
1.5 Features	4
2.0 Configuration	4
2.1 Location	4
2.2 GDB Path	4
2.3 Semi-Host Library	4
2.4 Processor Endian-ness	5
2.5 QuantumLeap Support	5
2.6 Processor ELF Code	5
3.0 Other Variants in this Model	5
4.0 Bus Ports	5
5.0 Net Ports	5
6.0 FIFO Ports	5
7.0 Parameters	5
8.0 Execution Modes	6
9.0 Exceptions	
10.0 Hierarchy of the model	7
10.1 Level 1:	7
11.0 Model Commands	8
11.1 Level 1:	8
12.0 Registers	8
12.1 Level 1:	8
12.1.1 User	.8
12.1.2 FloatingPoint	.9
12.1.3 System	10

1.0 Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms.

The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance.

Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners.

There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

1.1 Description

PPC32 Family Processor Model.

1.2 Licensing

Open Source Apache 2.0

1.3 Limitations

This model is currently under development. The FPU is incomplete.

1.4 Verification

Basic verification of ISA against reference has been performed.

1.5 Features

2.0 Configuration

2.1 Location

The model source and object file is found in the VLNV tree at: power.ovpworld.org/processor/powerpc32/1.0

2.2 GDB Path

The default GDB for this model is found at: \$IMPERAS_HOME/lib/\$IMPERAS_ARCH/gdb/powerpc-elf-gdb

2.3 Semi-Host Library

The default semi-host library file is found in the VLNV tree at:

power.ovpworld.org/semihosting/powerpc32Newlib/1.0

2.4 Processor Endian-ness

This model can be set to either endian-ness (normally by a pin, or the ELF code).

2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

2.6 Processor ELF Code

The ELF code supported by this model is: 0x14

3.0 Other Variants in this Model

Table 1.

Variant	
mpc82x	
UISA	

4.0 Bus Ports

Table 2.

Туре	Name	Bits
master (initiator)	INSTRUCTION	32
master (initiator)	DATA	32

5.0 Net Ports

Table 3.

Name	Туре
reset	input

6.0 FIFO Ports

No FIFO Ports in this model.

7.0 Parameters

Table 4.

Name	Туре	Description
verbose	Boolean	Specify verbose output messages

	-in-	
UISA_I_B	Boolean	UISA Feature UISA_I_B
UISA_I_BCDA	Boolean	UISA Feature UISA_I_BCDA
UISA_I_S	Boolean	UISA Feature UISA_I_S
UISA_I_E	Boolean	UISA Feature UISA_I_E
UISA_I_E_PC	Boolean	UISA Feature UISA_I_E_PC
UISA_I_E_PD	Boolean	UISA Feature UISA_I_E_PD
UISA_I_EC	Boolean	UISA Feature UISA_I_EC
UISA_I_FP	Boolean	UISA Feature UISA_I_FP
UISA_I_DFP	Boolean	UISA Feature UISA_I_DFP
UISA_I_MA	Boolean	UISA Feature UISA_I_MA
UISA_I_SP	Boolean	UISA Feature UISA_I_SP
UISA_I_V	Boolean	UISA Feature UISA_I_V
UISA_I_LMA	Boolean	UISA Feature UISA_I_LMA
UISA_I_WT	Boolean	UISA Feature UISA_I_WT
UISA_I_VLE	Boolean	UISA Feature UISA_I_VLE
ENABLE_FPU	Uns32	Enable FPU At Startup
UNIMP_TO_NOP	Boolean	Map Unimplemented Instructions to NOP
WARN_NOP	Boolean	Warn when executing nop-mapped instructions

8.0 Execution Modes

No execution modes.

9.0 Exceptions

Table 5.

Name	Code
Reset	0
Undefined	1
Arith	2
RdAlign	3
WrAlign	4
RdAbort	5
WrAbort	6
RdPriv	7
WrPriv	8
Fetch	9

10.0 Hierarchy of the model

A CPU core may allow the user to configure it to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy.

Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

10.1 Level 1:

This level in the model hierarchy has 2 commands.

This level in the model hierarchy has 3 register groups:

Table 6.

Group name	Registers
User	32
FloatingPoint	32
System	7

This level in the model hierarchy has no children.

11.0 Model Commands

11.1 Level 1:

Table 7.

Name	Arguments		
isync	specify instruction address range for synchronous execution		
itrace	enable or disable instruction tracing		

12.0 Registers

12.1 Level 1:

12.1.1 User

Table 8.

Name	Bits	Initial		Description
		value (Hex)		
GPR0	32	0	rw	
GPR1	32	0	rw	
GPR2	32	0	rw	
GPR3	32	0	rw	
GPR4	32	0	rw	
GPR5	32	0	rw	
GPR6	32	0	rw	
GPR7	32	0	rw	
GPR8	32	0	rw	
GPR9	32	0	rw	
GPR10	32	0	rw	
GPR11	32	0	rw	
GPR12	32	0	rw	
GPR13	32	0	rw	
GPR14	32	0	rw	
GPR15	32	0	rw	
GPR16	32	0	rw	
GPR17	32	0	rw	
GPR18	32	0	rw	
GPR19	32	0	rw	
GPR20	32	0	rw	
GPR21	32	0	rw	
GPR22	32	0	rw	
GPR23	32	0	rw	

GPR24	32	0	rw	
GPR25	32	0	rw	
GPR26	32	0	rw	
GPR27	32	0	rw	
GPR28	32	0	rw	
GPR29	32	0	rw	
GPR30	32	0	rw	
GPR31	32	0	rw	

12.1.2 FloatingPoint

Table 9.

Name	Bits	Initial value (Hex)		Description
FPR0	64	0	rw	
FPR1	64	0	rw	
FPR2	64	0	rw	
FPR3	64	0	rw	
FPR4	64	0	rw	
FPR5	64	0	rw	
FPR6	64	0	rw	
FPR7	64	0	rw	
FPR8	64	0	rw	
FPR9	64	0	rw	
FPR10	64	0	rw	
FPR11	64	0	rw	
FPR12	64	0	rw	
FPR13	64	0	rw	
FPR14	64	0	rw	
FPR15	64	0	rw	
FPR16	64	0	rw	
FPR17	64	0	rw	
FPR18	64	0	rw	
FPR19	64	0	rw	
FPR20	64	0	rw	
FPR21	64	0	rw	
FPR22	64	0	rw	
FPR23	64	0	rw	
FPR24	64	0	rw	
FPR25	64	0	rw	
FPR26	64	0	rw	
FPR27	64	0	rw	
FPR28	64	0	rw	

FPR29	64	0	rw	
FPR30	64	0	rw	
FPR31	64	0	rw	

12.1.3 System

Table 10.

Name	Bits	Initial value (Hex)		Description
PC	32	0	rw	program counter
MSR	32	0	rw	
CR	32	0	rw	
LR	32	0	rw	
CTR	32	0	rw	
XER	32	0	rw	
FPSCR	32	0	rw	

#