/tb_decoder4to16/enable																		
/tb_decoder4to16/dec_in 0000		0001	0010	0011	0100	0101	0110	0111	1000	1001	1010	1011	1100	1101	1110	1111	0000	
/tb_decoder4to16/dec_out (ffff	fffe	fffd	fffb	fff7	ffef	ffdf	ffbf	ff7f	feff	fdff	fbff	f7ff	efff	dfff	bfff	7fff	fffe	ffff
/tb_decoder4to16/count —	00000	00001	00010	00011	00100	00101	00110	00111	01000	01001	01010	01011	01100	01101	01110	01111	10000	
0 ps	Ттт	50000 ps		1000		ilii	150000 p	s s	2000	000 ps	1111	250000 p	s s	3000			 350000 ps	