RAKT | GLO Live

FM-1 PERFORMANCE CHEAT SHEET

RAKT 0.1.4

Open and mix

PLAY starts or stops the band

Press GLO to open. Turn ALGORITHM for Map or State. Turn SELECT for tempo.
Press GLO or HOME to return. Press SAVE for Settings.

K1 Chords **K2** Bass **K3** Drums **K4** Layer

Level percentages appear in both views. SEL toggles solo and EDIT toggles mute for the focused part.

Keyboard map

Left to right on the FM-1

Hold F3 / G3 / A3 / B3 to solo Chords / Bass / Drums / Layer.
Tap CH / BA / DR / LY to mute those parts. Tap K / S / H / P to mute kick / snare / hats / perc.
Tap C4 to pause or resume, D4 to restart, E4 to unmute all, or F4 in time to set tempo.

Performance effects

Hold the key. Release to return to the mix.

C5 Riser

Filtered noise gets brighter and louder over four quarter-note beats. Release it on a fill or a drop for a quick fade.

D5 Beat Repeat

Loops a slice and defaults to 1/16.
Turn PRESETS right for faster, left for slower.
The screen shows the rate (1/8 to 1/64).
Slow tempos limit the longest loops.

E5 Echo Out

Cuts the mix into a fading 1/16-note echo or a shorter echo at slow tempos.
Open GLO a moment early so the effect can capture the mix.

F5 High-pass Sweep

Sweeps the low end out over two quarter-note beats. Release to bring the bass back smoothly.

Fills and drops

While the band plays, hold G4 for a fill now or tap A4 for a one-bar fill next bar.
Tap B4 to drop or bring back drums on the next downbeat.
With D5 released, turn PRESETS left to queue a fill or right to drop or return the drums.

Try it live Drop the drums with B4. Hold C5 for a buildup, then queue B4 again. Release C5 when the drums come back.

MIDI clock input controls pause, restart and tempo when enabled.
The song keeps running during the effects. USB inputs 1/2 capture the full mix.