

What's new in 3.1.1

Everything new since 3.0, in one guide. Catch a beat, shape the window, and print your performance.

01 Beat repeat

Start with a loaded loop playing in normal track mode. Keep PLAY held while you work the repeat.

Catch & resize

Hold PLAY + click rocker UP.

UP starts with the last beat; DOWN with two on an even-beat grid. More UP clicks halve; DOWN doubles. Hold to keep stepping.

Stay inside the chop

The repeat uses only the chopped audio.

If a beat would fill the chop, UP starts with a quarter of it; DOWN with half, down to the minimum size.

Move & shape

VOL- / VOL+ = earlier / later.

Add FN + all four faders to shape it.

FN + rocker jumps an octave. The same four-fader window controls work while PLAY stays held.

Release: hold the tape

Release PLAY with FN released.

On a gridded song, playback resumes from the repeat with the tape shift rounded to the nearest bar. Short stutters may leave position unchanged.

No grid: UP = 1/8 loop; DOWN = 1/4, limited by the chop. No grid or during a bounce: release returns to the running tape position. Full controls: sheet 5.

02 One window, four faders

Start with what you hear

Hold FN and move a fader.

Edits begin from the audible window, including a live chop or repeat.

Set the edges & position

F1 = start. F2 = end. F3 = position.

F3 slides the window with its width kept. Outside a repeat, cross F1 past F2 to reverse the window.

Zoom in, then back out

F4 = size. Down tightens; top restores.

Zoom centres on the region set by F1-F3. Re-gripping FN preserves that region, so it can widen back out.

Chop within your region

Hold FN + rocker: UP halves; DOWN doubles.

FN + VOL- / VOL+ steps the chop through the region. The fader-set region stays in place.

Reset the window

FN + PLAY + VOL- = whole loop, forwards.

Use outside a repeat. Clears window/chop reverse; per-track reverse stays. VOL+ moves home, keeping chop size and direction.

The filter is on Page 1. Fader 1 controls it; tap T1 to bypass. FN + fader 4 now controls window size.

03 Print it. Layer it.

Speed moves now print

During a bounce, release PLAY and use the rocker.

Tape copy records speed moves relative to its starting speed. Sampler print bakes the performance for playback at 1x.

Print the stutter

Hold PLAY, catch a repeat, then tap a spare destination TN.

Release PLAY to return to the running tape while the copy continues. Tap TN again to stop. A loaded destination is replaced.

Inside a held sampler print

Keep TN held: PLAY up = speed; PLAY down = repeat.

FN + PLAY + rocker = octave. Release TN to end the print. See sheets 2 and 5.

Echo + reverb together

Layer repeats with a reverb tail.

Echo feeds reverb. Both can run at once.

Input monitor mute

PLAY + both VOL toggles monitoring.

Downward LED sweep = muted; upward = live. Ordinary recording still captures input. Works on any page.

Sound & timing refinements: smoother loop joins, improved pop handling and more processing headroom. Chopped tracks align more closely, deep chops round more accurately, and mono chop limits are corrected.