Tape Looper 4.0

Full guide

SP-1 reference: recording, unlimited takes, effects, tape controls and your library.

Read the controls

T1-T4 = TRACK buttons / F1-F4 = faders

PLAY controls playback. FN is the function button. VOL- / VOL+ are the volume buttons. ROCKER UP / ROCKER DOWN are the side rocker.

A plus sign combines controls. Follow the words tap and hold; press order matters. Start in normal track mode unless a page or mode is named.

Setup

tapelooper.club/#setup

Connect SP-1 and follow Setup to install firmware and prepare the filesystem and Bluetooth. Verified steps are skipped.

Solderless is also available from Setup. Keep USB connected; follow the backup and storage choices shown there.

Your library

4 banks x 4 songs / 4 tracks per song

Each track has unlimited takes, limited by available storage. One take per track is selected for playback.

Each take can hold approximately eight minutes. The Library converts compatible audio and lets you choose a shorter clip from a long file.

USB Library

Stop/save > hold T2 + T3 for 3 seconds > release

Wait for SP1 MUSIC to appear. T2 + T3 stay lit when the drive is ready. Open it in Finder / File Explorer, or choose it in the site's Library.

Preparation can take time with a large library. In the browser, choose the top-level SP1 MUSIC drive, not a song folder.

Finish importing

Eject SP1 MUSIC; keep USB connected

After eject: T1 checks, T2 plans, T3 imports, T4 saves. Large files or batches can take several minutes. Wait for Tape Looper to return.

A completed file copy can still need device import processing. Repeated alarm lights indicate an error; collect diagnostics before reflashing.

Find a control

Six chapters

01 Start & record
02 Shape the tape
03 Effects
04 Place & time
05 Repeat & bounce
06 Rocker modes

Use PDF bookmarks to jump between chapters. Interactive help: tapelooper.club/#guide. Live Companion: tapelooper.club/#live.

01 / Start & record

CONNECT & WAKE

Audio inputs

USB-C or Bluetooth audio in

Select SP-1 as your computer or phone's USB audio output, or pair it over Bluetooth. Both inputs can play together.

The headphone jack is an output. Bluetooth audio input is separate from the companion's Bluetooth control connection.

Power

Hold FN / 1.5 s / 2.5 s

Hold FN about 1.5 seconds to wake. To power off, stop playback and hold FN about 2.5 seconds.

USB power can keep the charging gauge active.

Bluetooth Support

Triple-tap FN and hold the last press until all four track lights start fading in and out, then release

Triple-tap FN and hold the last press until all four track lights start fading in and out, then release to enable Bluetooth audio discovery. Pair SP-1 from your phone or computer, select it as the audio output, then record normally.

The gesture also works during playback and USB audio. USB and Bluetooth input mix together. This release focuses on Bluetooth input; outgoing audio to speakers or keyboards is deferred.

YOUR FIRST LOOP

Recording

Arm > send sound > tap to finish

Tap an empty track to arm it. Start your audio to begin recording. Tap the same track again to finish the loop, then raise its fader.

Without a grid, input sound starts recording; with a grid, recording follows its punch-in. Tap PLAY while armed to cancel and pause.

EVERYDAY CONTROLS

Playback controls

Tap PLAY / hold to restart

Tap PLAY to pause or resume. Hold PLAY for about half a second, then release to restart.

Track levels

F1-F4 = track levels

In track mode, raise a fader to bring its track forward; lower it to turn that track down.

Master volume

VOL- / VOL+

Use the two round buttons on the top edge to change master volume.

Track mute

Tap a loaded track

Tap a loaded track to mute it. Tap again to restore it.

Several track buttons can toggle their mutes together. Muting keeps the recorded audio.

Unlimited takes

TRACK + ROCKER DOWN = saved takes / TRACK + ROCKER UP = New

Hold a track and click ROCKER DOWN to cycle its recorded takes. ROCKER UP selects an empty New lane. Record normally there; your earlier takes stay saved. Each song and track has its own lane. Takes are limited by available storage.

Close control pages and leave four-head mode before switching takes. Switch while playing or stopped. A New lane breathes when saved takes exist. Hold FN during playback to count takes.

Overdub

Hold TRACK / release / tap TRACK

Hold a loaded track for 0.6 seconds to prepare overdub. Release, then tap it within 10 seconds to arm. Tap again to finish.

The earlier take stays saved in this track's lane. TRACK + ROCKER DOWN finds it after the new recording is saved. Tap FN to cancel preparation.

Take deletion

Double-tap; hold the second press

Double-tap the track, holding the second press until deletion is acknowledged. This removes the selected take; other takes remain.

If the track is still saving, wait for saving to finish and try again. TRACK + ROCKER DOWN finds the remaining takes.

Track lights

Dark / dim / blinking / solid

Dark means empty; dim means muted. Recording is solid. Playback pulses with the grid, or when each loop wraps.

Stopped, loaded/unmuted tracks stay solid. A refusal flash can mean saving is busy; wait before recording or deleting. Alternating T1+T3 / T2+T4 indicates a fault; keep USB connected and collect diagnostics before reflashing.

Escape hatch

Hold FN + T1 + T2 / 2 seconds

Reset performance controls without deleting recordings. Hold all three until the four track lights glow solid, then release.

Resets FX, speed, trim, timing and rocker settings; unmutes tracks and input. A waiting recording is cancelled; an active recording is saved.

SONGS & SETTINGS

Banks & songs

Hold FN + tap T1-T4

Choose a bank with T1-T4. Repeat the same button to step through that bank's four songs.

Use this from normal track mode. A longer FN + track hold opens a page instead.

Fixed & variable loops

Hold FN + PLAY / about 0.5 s, then release

Hold FN + PLAY for about half a second, then release both to switch Fixed / Variable.

Fixed rounds each take to a whole multiple of the base loop, keeping tracks aligned. Variable preserves each recorded length, so tracks can cycle independently. The side lights confirm your choice.

LED brightness

Hold FN + PLAY / 5 s

Keep FN + PLAY held through five seconds. The lights change while you hold.

This longer hold leaves loop length mode unchanged.

Side lights

Playing: level / FN held: song

During playback, the meter fills from the bottom. Hold FN to see the song: solid = bank, blinking = position.

If bank and position share a light, that light blinks. With a running grid the song blink follows the beat.

TAP A BEAT GRID

Beat grid

Tap FN 4+ times

From normal track mode, tap FN at least four times in time. Start on the downbeat.

Fresh taps align recording to beats. The saved grid follows the loop; tape speed changes its tempo.

Beat grid reset

Tap FN > press again and hold / ~1 s

Tap FN, then quickly press it again and hold about one second to clear the beat grid.

Solid track lights confirm. Recordings and the song's beats-per-bar setting stay unchanged.

Whole-BPM rounding

Tap FN 4+ times > hold FN / ~1 s

Tap FN at least four times in time, then press and hold FN about one second to round the tapped tempo to the nearest whole BPM. For example: 119.8 to 120 BPM.

Near-whole tempos round within 0.4 BPM, from 50-200 BPM. A sweep confirms rounding; all-four flashes mean no change.

02 / Shape the tape

SPEED & PITCH

Octave jumps

Hold FN + PLAY + rocker

With FN and PLAY held, click down for an octave lower or up for an octave higher.

No jump outside 0.25x-2x. Speed changes are locked during input recording; bounces allow them.

CHOP & WINDOW

Loop window length

Hold FN + rocker

Up halves the window. Down doubles it. Hold to keep stepping.

The chop stays inside your fader-set region.

Loop window position

Hold FN + VOL- / VOL+

Step the chop earlier or later through your region.

To move the window home without changing its size or direction, hold FN + PLAY and press VOL+. With a page open, FN + VOL- / VOL+ moves between pages.

Loop window controls

FN + F1 / F2 / F3 / F4

F1 = start. F2 = end. F3 = position. F4 = size / zoom.

Edits start from the audible window. F4 down tightens; top restores the region set by F1-F3. Re-gripping FN preserves that region.

Loop window reverse

FN + cross F1 past F2

Hold FN and move F1 (the start) past the end set by F2 to reverse the window.

Crossing edges during a beat repeat does not reverse it.

Reset loop controls

Hold FN + PLAY / press VOL-

Hold FN + PLAY and press VOL- to restore full loops and default timing.

Clears loop-window edits, song/track trims and timing offsets. Take length returns to OFF; beats per bar to 4. Recordings, FX and per-track reverse stay unchanged.

REVERSE OR ISOLATE

Track reverse

FN + track first > tap PLAY

With control pages closed, hold FN + the track button first, then tap PLAY before its page opens. Repeat to reverse back.

Press order matters. FN + PLAY first, then the track, isolates instead.

Track isolation

FN + PLAY first > track

With control pages closed, hold FN + PLAY first, then press the track to hear alone. Release the track to restore the mix.

Release the track to restore the previous mutes.

FOUR HEADS, ONE LOOP

Four-head mode

Hold FN + triple-tap PLAY

Hold FN and triple-tap PLAY while a loop plays. Hold FN and move a fader to position its head; release FN to mix head levels.

Faders set head levels, track taps mute, and FN + faders set head positions.

Head positions & source

FN + faders / hold a loaded track

In heads mode, FN + faders positions the heads. Hold another loaded track to make it the source.

TAPE RESET

Tape reset

Hold FN + double-tap PLAY

Return to normal (1x) speed and clear temporary tape transformations, including Scissors cuts and Magnet gaps.

Solid track lights confirm. Recordings, FX settings and the selected rocker mode stay unchanged.

TRACK TRIM

Track trim

Hold FN + PLAY / move that track's fader

Hold FN and PLAY, then move F1-F4 to shorten or lengthen the matching track. Lower the fader to shorten; raise it to lengthen. Release both to keep the trim.

The first small move catches the current length without jumping. With a grid, lengths step through straight and dotted musical values. Other tracks keep playing; the original recording stays intact.

Trim position

Hold PLAY / move the trimmed track's fader

Choose which part of a trimmed recording plays, without changing its length. Hold PLAY and move the track's fader: raise it toward the recording's start; lower it toward the end.

The first small move catches the current position. With a grid, movement follows sixteenth-note steps. Release PLAY to keep the position; moving the fader spends the PLAY press, so it does not pause or restart playback.

03 / Effects

PAGES & PICKUP

FX pages

Hold FN + a track button

Hold FN with a track button. Release both after the page opens. The page stays open.

T1-T4 opens Pages 1-4. Tap FN to close.

FX page navigation

Page open / VOL- / VOL+

With any page open, press VOL- or VOL+ to move between Pages 1-8. Tap FN to close.

The same controls move between rocker modes when the rocker page is open.

Fader pickup

Cross its stored value

Pickup prevents a parameter jump when you enter, leave or reset a page. Move through the stored value to take control.

Move through the stored value before a fader takes control. FN window edits respond to deliberate movement instead.

FX tap tempo

On the FX page: hold FN + tap TRACK 2+ times

Open the effect's page. Hold FN and tap its TRACK button at least twice in time to set its rate.

To clear the tapped rate, hold FN + PLAY and tap its TRACK button. Rate controls: P1 T2/T4; P2 T4; P3 T1/T2/T3; P4 T4.

PAGE 1 / FX 1

Filter

F1 / T1 bypass + reset damping

Move F1 for the filter. Center is neutral. Tap T1 to turn it off.

Hold T1 and move F1 for filter damping.

Chorus / Flanger

F2 / T2 type

Move F2 for depth. Tap T2 to switch Chorus / Flanger. Lower F2 to turn it off.

Hold T2 and move F2 for span. Hold FN and tap T2 at least twice in time to set its rate.

Distortion

F3 / T3 type

Tap T3 to cycle soft > hard > fold. F3 sets the amount. Lower F3 fully to turn it off.

Fader down gives clean audio; raising it restores the selected drive type.

Gate

F4 / T4 pattern

Move F4 for depth. Tap T4 to cycle Gallop / Halves / Slow gear. Slow gear fades into incoming notes. Lower F4 to turn it off.

Hold FN and tap T4 at least twice in time to set its rate.

PAGE 2 / FX 2

Crush / Lo-fi / Radio

F1 / T1 type

Move F1 for depth. Tap T1 to cycle Crush / Lo-fi / Radio. Lower F1 to turn it off.

Ring mod

F2 / T2 off

Move F2 for ring modulation. Tap T2 to turn it off.

Auto-wah

F3 / T3 off + reset damping

Move F3 for auto-wah. Tap T3 to turn it off.

Hold T3 and move F3 for wah damping.

Echo

F4 / T4 division

Tap T4 to cycle 1/16 > dotted 1/16 > 1/8. F4 sets the amount; lower it fully to turn echo off.

Hold T4 and move F4 for echo feedback. Hold FN and tap T4 at least twice in time to set its rate. A plain track tap clears its tapped rate.

PAGE 3 / FX 3

Phaser

F1 / T1 division

Tap T1 to cycle beat > half > quarter. F1 sets the amount. Lower F1 fully to turn it off.

Hold T1 and move F1 for phaser feedback. Hold FN and tap T1 at least twice in time to set its rate. A plain track tap clears its tapped rate.

Sweep

F2 / T2 division

Tap T2 to cycle beat > half > quarter. F2 sets the amount. Lower F2 fully to turn it off.

Hold FN and tap T2 at least twice in time to set its rate. A plain track tap clears its tapped rate.

Tremolo

F3 / T3 division

Tap T3 to cycle beat > half > quarter. F3 sets the amount. Lower F3 fully to turn it off.

Hold T3 and move F3 for tremolo shape. Hold T3 and move F4 for stereo spread. Hold FN and tap T3 at least twice in time to set its rate. A plain track tap clears its tapped rate.

Reverb / Freeze

F4 / T4 type

Move F4 for reverb. Tap T4 to freeze the current tail; tap again for Reverb. Lower F4 to turn it off.

Hold T4 and move F4 for reverb damping.

PAGE 4 / TAPE

Tape drive

F1 / T1 off

Move F1 for tape drive. Tap T1 to turn it off.

Tone / Compression

F2 / T2 Tone / Compression

Tap T2 to switch Tone / Compression. Move F2 through its saved value, then adjust. Center Tone for flat; lower Compression fully to turn it off. Both settings stay applied.

Both settings stay applied when you switch. Move F2 through its saved value to take control.

Noise

F3 / T3 source

Move F3 for noise level. Tap T3 to cycle Cassette / Vinyl / Pink / Minidisc. Lower F3 to turn it off.

Wobble

F4 / T4 type

Move F4 for depth. Tap T4 to cycle Wow + flutter / Wow / Flutter. Lower F4 to turn it off.

Hold FN and tap T4 at least twice in time to set its rate. A plain track tap clears its tapped rate.

SECONDARY CONTROLS

Secondary FX controls

Hold track + move fader

Hold a lane's TRACK button and move its fader: P1 filter damping / chorus span; P2 wah damping / echo feedback; P3 phaser feedback / tremolo shape / reverb damping. For tremolo stereo spread, hold T3 and move F4.

Move before releasing the track button to avoid its tap action. After release, cross the main value again before changing it.

Wah resonance

Page 2: hold T3 and move F3

While holding T3, move F3 down for a sharper peak or up for a softer peak.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Echo feedback

Page 2: hold T4 and move F4

Change the amount fed back into the echo.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Tremolo shape

Page 3: hold T3 and move F3

Move from softer to harder tremolo shapes.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Tremolo stereo spread

Page 3: hold T3 and move F4

Change the spread between the two channels. F4 does not change reverb while T3 is held.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Reverb damping

Page 3: hold T4 and move F4

Down is darker; up is brighter.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

PAGE 5 / GLOBAL EQ

Master EQ

F1 100 Hz / F2 350 Hz / F3 1.6 kHz / F4 4 kHz

Down cuts; up boosts. Center or a track-button tap returns that band to flat.

F1 and F4 are low/high shelves. EQ always affects the whole mix; lights show cut/boost amount.

FX ROUTING & RESET

FX routing

PLAY + VOL- / VOL+ / double-click

Hold PLAY and press VOL- for INPUT or VOL+ for TRACKS. Hold PLAY and double-click either volume button for BOTH.

INPUT prints input FX into ordinary takes. TRACKS leaves input dry. BOTH affects the heard mix; ordinary takes stay dry. EQ always affects the whole mix. During a repeat, VOL- / VOL+ move its window.

Input monitoring

Hold PLAY + VOL- + VOL+

Hold PLAY and press both volume buttons to mute or restore live input. Works on any page.

Muted input is also silent in recordings and cannot arm a new input take. Unmute before recording.

FX reset

On an FX page: FN + T1 + T4

Hold FN and tap T1 + T4 together to reset all FX, flatten EQ and set routing to BOTH.

The four TRACK lights briefly turn solid. Effects, EQ, rates, types and routing return to defaults. Monitor mute stays as set.

PAGE 1 / SECONDARY CONTROLS

Filter damping

Page 1: hold T1 and move F1

Hold T1 and move F1 to adjust filter damping without changing the main level.

Move the fader before releasing TRACK to avoid its tap action. After release, cross the main value to regain control.

Chorus / flanger span

Page 1: hold T2 and move F2

Hold T2 and move F2 to adjust chorus / flanger span without changing the main level.

Move the fader before releasing TRACK to avoid its tap action. After release, cross the main value to regain control.

PAGE 3 / SECONDARY CONTROLS

Phaser feedback

Page 3: hold T1 and move F1

Hold T1 and move F1 to adjust phaser feedback without changing the main level.

Move the fader before releasing TRACK to avoid its tap action. After release, cross the main value to regain control.

04 / Place & time

PAGE 6 / STEREO PLACEMENT

Stereo track placement

Page 6 / F1-F4 = track placement

Lower a fader to move left; raise it to move right. Return it to center, or tap its TRACK button for exact center.

A mono take pans; a stereo take leans. Center restores the original balance and its light goes dark. Cross the saved position to take control.

PAGE 7 / TAKE & TIMING

Grid offset

F1 = grid offset

On Page 7, move F1 up for later or down for earlier, by up to about half a beat. Return F1 to center for zero offset.

Beat lights and future grid-aligned punches follow the offset.

Take length & beats per bar

F2 = OFF / 1 / 2 / 4 / 8

On Page 7, F2 selects the take length. F3 selects 3, 4, 5 or 7 beats per bar, from bottom to top. Move through the saved value to take control.

Beats per bar is saved per song; the default is 4. Variable mode counts bars and needs a grid. Fixed mode counts base loops and needs a first take.

Preset recording length

Leave Page 7 > arm a track

On Page 7, choose a take length with F2. Tap FN to close the page, tap an empty track and let recording finish automatically.

The take stops automatically. Tap the recording track to finish earlier. Bounces do not use the preset.

Recording countdown

Open Page 7 during a preset take

Up to four track lights show the units remaining. The last unit blinks.

Fixed mode counts base loops; Variable counts grid bars. Up to four lights show the units left.

Grid recording indicators

Two flashes per beat

An armed track flashes twice per beat while waiting for punch-in. The same pulse marks a recording finishing its beat.

Recording continues until its aligned stop.

Beats per bar

Page 7 / F3 = 3 / 4 / 5 / 7

Sets the bar length for the beat grid. Hold FN + T4, then release. Press VOL+ three times for Page 7. Move F3 through its saved position, then select 3, 4, 5 or 7 beats per bar, bottom to top. Tap FN to close.

Saved per song; default 4. T3 flashes the selected number of beats.

PAGE 7 / NUDGE A LOOP

Track timing offset

Hold a track button + move its fader

On Page 7, hold a track button and move its fader. Up moves the track later; down moves it earlier. The edit is relative to the fader position when you held the button.

Nudge is relative; centering the fader alone does not reset it. On Page 7, TRACK taps clear its trim, then nudge, then its page setting; already-clear settings are skipped. Works without a grid; recording tracks cannot be nudged.

Timing offset lights

Amount while held / dim glow after

While a track is held, its light shows the nudge amount. After release, nudged tracks glow dim between beats.

The 1-2-3-4 chase shows the grid. Settings save per song after about two seconds.

PAGE 8 / NEXT TAKE FORMAT

Mono & stereo recording

Tap a track button on Page 8

Before recording, tap a track button to choose the format of its next take.

Solid light = mono. Blinking = stereo. Existing audio stays unchanged. Faders still control track levels.

05 / Repeat & bounce

CATCH & RESIZE

Beat repeat length

Hold PLAY > click ROCKER UP > resize

Hold PLAY and click the rocker up to catch a beat. ROCKER UP halves the repeat; ROCKER DOWN doubles it. Hold the rocker to keep stepping. Release PLAY to return to the song.

Release the rocker but keep PLAY held to repeat at the same length.

Beat repeat within a chop

PLAY + rocker inside your chop

The repeat only uses your chopped audio. It cannot reach outside the audible cycle.

If a requested beat would fill the chop: ROCKER UP starts with a quarter of it; ROCKER DOWN with half, down to the minimum size.

Beat repeat release

Release PLAY with FN released

On a gridded song, playback resumes from the repeat, with the tape shift rounded to the nearest bar.

A short stutter may leave the position unchanged. Without a grid, or during a bounce, release returns to the running tape position.

Beat repeat without a grid

Hold PLAY + rocker: ROCKER UP = 1/8 / ROCKER DOWN = 1/4

Without a grid, hold PLAY and click the rocker up for one eighth of the loop, or down for one quarter. Chop limits still apply.

On release, return to the running tape position. There is no bar-based tape hold.

SHAPE THE REPEAT

Beat repeat position

Keep PLAY held + VOL- / VOL+

VOL- moves earlier. VOL+ moves later. Each press shifts by one current window length inside the audible cycle.

During a repeat these controls move its window, not FX routing. Set routing before catching the repeat.

Beat repeat octave jumps

Keep PLAY held + FN + rocker

Add FN and click the rocker. Down is an octave lower; up is an octave higher.

BOUNCE WHAT YOU HEAR

Tape copy / bounce

Hold PLAY > briefly tap destination

Record the playing mix onto a spare track. Hold PLAY and tap the destination; tap it again to finish. This is a tape copy.

A loaded destination keeps its earlier take saved. Tape copy follows tape speed; grid, Fixed mode or chop can delay the stop to a cycle boundary.

Beat repeat bounce

Hold PLAY > click ROCKER UP > tap destination

Hold PLAY and click the rocker up to catch a repeat. Keep PLAY held and tap a spare track to start the bounce. Release PLAY to let the song flow back in; tap the destination again to finish.

Keep PLAY held to resize while recording. The destination's earlier takes stay saved.

Sampler print

Hold PLAY > hold destination

Hold PLAY, then hold the destination track to record a sampler print. Release the track to finish.

Speed is baked for playback at 1x. The destination's earlier takes stay saved.

Bounce controls in FX pages

PLAY + destination track

Use PLAY + the destination track again to stop a bounce while a page is open.

Bounce after beat repeat

After starting the copy, release PLAY

The repeat ends and the tape copy continues from the running tape position. Tap the destination again to stop.

Recorded speed changes

During a bounce: release PLAY > rocker

Use the rocker while a tape copy or sampler print is recording. Your speed moves become part of the performance.

Tape copy records speed moves relative to starting speed. Sampler print bakes the performance for playback at 1x.

Sampler print controls

Keep the destination held / PLAY changes the rocker

Keep the destination held. With PLAY released, the rocker changes speed. With PLAY held, it controls beat repeat. Add FN for octave jumps.

Release the destination to end the print. Release PLAY too to end the repeat.

06 / Rocker modes

Hold FN + both VOL to open. Release FN; VOL- / VOL+ select a mode. Tap FN to close; the mode stays selected.

1 / Pitch / speed

Change the whole tape's speed and pitch.

ROCKER UP: Click to increase speed. Double-click for the next semitone; hold to keep stepping.
ROCKER DOWN: Click to decrease speed. Double-click for the previous semitone; hold to keep stepping.

The new speed stays set. Whole tape.
FN + double-tap PLAY returns to normal speed.
The normal range is 0.25x-2x. FN + PLAY + rocker makes octave jumps. Input recording locks speed; bounces allow speed changes.

2 / FF / RW

Fast-forward or rewind through the tape.

ROCKER UP: Hold to wind forward.
ROCKER DOWN: Hold to rewind.

Speed settles back and the previous playback directions return. Whole tape.
Release the rocker. FN + double-tap PLAY restores the tape.
Page open: hold T1/T2/T3/T4 + rocker for 0.5x/1.5x/3x/4x.
Double-tap TRACK to latch its speed for bare-rocker winding, also after closing the page. Release rocker returns to playback speed.

3 / Tape bending

Drag the tape or pull it in uneven surges.

ROCKER UP: Hold for repeated pulling surges.
ROCKER DOWN: Hold to drag and stretch the tape; longer holds stretch further.

The tape springs back toward the set speed. Whole tape.
Release the rocker, or FN + double-tap PLAY to restore the tape.
Unlike Pitch, a bend is temporary. Your recordings stay unchanged.

4 / Battery drain

Make the motor sag, wobble and stall.

ROCKER UP: Hold to recover toward normal.
ROCKER DOWN: Hold to increase battery-drain wear.

The amount of wear stays. Whole tape.
Hold ROCKER UP to recover gradually. FN + double-tap PLAY restores the tape.
Release leaves the tired-battery sound in place so you can keep performing.

5 / Sandpaper

Roughen the tape with breakup and drag.

ROCKER UP: Hold to reduce the wear.
ROCKER DOWN: Hold to add roughness and breakup.

The amount of wear stays. Whole tape.
Hold ROCKER UP to clean it up gradually. FN + double-tap PLAY restores the tape.
Battery changes the motor's behavior; Sandpaper adds a rougher, damaged-tape texture.

6 / Magnet erase

Erase a passing section from playback without shortening the loop.

ROCKER UP: Tap to undo the latest matching erase.
ROCKER DOWN: Hold while the section passes, then release to leave a silent gap.

The gap stays; the rest of the loop keeps its timing. Bare rocker targets loaded tracks. With the rocker page open, hold TRACK to target only that track.
ROCKER UP undoes a recent erase. FN + double-tap PLAY clears all Magnet gaps.
The original audio is unchanged. A Magnet gap keeps its place in time.

7 / Cut / glue

Cut out a section and join the remaining tape.

ROCKER UP: Tap to cancel the first mark, or undo the last cut.
ROCKER DOWN: Tap at the start, then tap again at the end of the section.

Each completed cut stays, including after leaving the rocker page or slot. Bare taps target loaded tracks. Keep the rocker page open and hold the same TRACK for both marks to cut only that track.
ROCKER UP undoes; FN + double-tap PLAY restores all cuts.
Up to eight cuts. Use a full forward loop with playback running, without trim, repeat, Heads or recording. Song/take changes, recording or reboot clear the cuts.

8 / Manual heads

Touch the moving tape with one contact or four heads.

ROCKER UP: Hold to hear the tape under ordinary contact.
ROCKER DOWN: Hold for four-head contact. Move F1-F4 to position the heads.

Contact lifts and the tape becomes silent; transport keeps moving.
The active tape source; ROCKER DOWN exposes four playback heads.
Leave this slot to return to ordinary playback.
PLAY starts or stops the tape. This contact mode is separate from latching Heads with FN + triple-tap PLAY.