Connect & resets

Bluetooth Support

Triple-tap FN; hold the last press until the four track lights start fading, then release.

Choose SP-1 in Bluetooth settings and as audio output. USB and Bluetooth input can mix.

USB Library

Stop/save. Hold T2 + T3 for 3 seconds; release.

Wait for SP1 MUSIC; T2 + T3 stay lit when ready. Eject after copying. Preparation/import can take minutes; keep USB connected until Tape Looper returns.

Escape hatch

Hold FN + T1 + T2 for 2 seconds.

Solid track lights confirm. Performance controls reset; recordings stay saved.

Tape reset

Hold FN and double-tap PLAY.

Restores 1x and clears tape transformations. FX and the selected rocker mode stay set.

FX reset

On an FX page: hold FN; tap T1 + T4 together.

Resets FX, EQ and routing to BOTH. Input mute stays set.

Print at 100% on A4, landscape, double-sided. Flip on the short edge; fold in three. This is the back panel.

FX & control pages

Open a page

Hold FN + T1-T4; release both.

VOL- / VOL+ move through Pages 1-8. Tap FN to close. Cross the saved fader value to take control.

1 / Color

Filter; Chorus / Flanger; Distortion; Gate / Slow gear.

2 / Texture

Crush / Lo-fi / Radio; Ring mod; Auto-wah; Echo.

3 / Motion & space

Phaser; Sweep; Tremolo; Reverb / Freeze.

4 / Tape

Drive; Tone / Compression; Noise; Wobble. Tap T2 to select Tone / Compression; F2 adjusts.

5 / EQ

Center a fader, or tap its TRACK, for flat.

6 / Placement

F1-F4 place tracks. Center the fader, or tap TRACK for exact center.

7 / Timing

F1 grid offset; F2 take length; F3 beats per bar: 3 / 4 / 5 / 7. Hold TRACK + move its fader to nudge; the move is relative.

8 / Next take

Tap TRACK: solid = mono; blinking = stereo.

FX tempo / clear

Page open: hold FN; tap the timed FX TRACK 2+ times in time.

Clear: hold FN + PLAY; tap that TRACK. Rate lanes: P1 T2/T4; P2 T4; P3 T1-T3; P4 T4.

4.0 | Revised 12 Nov 2026 | tapelooper.club

SP-1

Tape Looper 4.0

Pocket guide

T1-T4 = TRACK buttons. F1-F4 = faders. + combines controls; follow tap/hold and press order. Start in track mode unless a page or mode is named.

Recording

Tap an empty TRACK to arm; tap again to finish.

Sound starts recording without a grid; a grid uses its punch-in. PLAY cancels a waiting arm and pauses. Input recording locks tape speed.

Playback controls

Tap PLAY to pause/resume.

Hold PLAY about 0.5 seconds, then release to restart.

Mix / mute

F1-F4: levels. Tap a loaded TRACK: mute/unmute.

VOL- / VOL+ set listening level.

Power

Hold FN 1.5 seconds to wake.

Stop playback; hold FN 2.5 seconds to power off.

Setup / help

tapelooper.club/#setup

Field Guide: tapelooper.club/#guide

4.0 | Revised 12 Nov 2026 | tapelooper.club

Record & takes

Banks & songs

Hold FN; tap T1-T4.

Select a bank; repeat that button to cycle its four songs. A longer hold opens a page.

Unlimited takes per track

Hold TRACK + ROCKER UP: New. TRACK + ROCKER DOWN: cycle takes.

Close pages and leave Heads first. Earlier takes stay saved. Hold FN during playback to count takes.

Overdub

Hold loaded TRACK 0.6 seconds, release, then tap within 10 seconds.

Tap again to finish. Earlier take stays saved. FN cancels preparation.

Take deletion

Double-tap TRACK; hold the second press.

Deletes the selected take; other takes stay saved. Wait for saving to finish first.

Beat grid

Tap FN 4+ times in time; start on the downbeat.

Round BPM: tap 4+ times, then hold FN about 1 second. Clear grid: tap FN, quickly press again and hold about 1 second.

Fixed / Variable

Hold FN + PLAY about 0.5 seconds; release both.

Fixed uses base-loop multiples. Variable preserves independent lengths.

Rocker modes

Open / select

Hold FN + both VOL; release FN. VOL- / VOL+ select.

Tap FN to close; the mode stays selected.

1 / Pitch / speed

Click: speed step. Double-click: semitone. Hold: sweep. Range 0.25x-2x. FN + PLAY + rocker: octave jumps.

2 / FF / RW

Hold ROCKER UP forward / ROCKER DOWN rewind; release to return. Page open: T1-T4 + rocker = 0.5x / 1.5x / 3x / 4x. Double-tap TRACK to latch.

3 / Tape bending

ROCKER DOWN stretches; ROCKER UP surges. Release springs back.

4 / Battery drain

ROCKER DOWN adds sag; ROCKER UP recovers. Wear stays on release.

5 / Sandpaper

ROCKER DOWN roughens; ROCKER UP reduces wear. Release keeps the wear.

6 / Magnet erase

Hold ROCKER DOWN to leave a gap; tap ROCKER UP to undo. Loop length stays.

7 / Cut / glue

Tap ROCKER DOWN at start and end; ROCKER UP cancels/undoes. Up to eight cuts.

8 / Manual heads

Hold ROCKER UP for tape contact. Hold ROCKER DOWN + move F1-F4 for four heads. Release is silent.

Magnet / Cut: with the rocker page open, hold TRACK to target one track; bare rocker targets loaded tracks. Cut needs full forward loops: no trim, Heads, repeat or recording.

4.0 | Revised 12 Nov 2026 | tapelooper.club

Shape & perform

Loop window

Hold FN: F1 start / F2 end / F3 position / F4 size.

FN + rocker: ROCKER UP halves / ROCKER DOWN doubles. FN + VOL- / VOL+ moves it.

Track trim / position

FN + PLAY + fader: lower to shorten; raise to lengthen.

PLAY + fader: lower to move the section later; raise to move earlier.

Reset loop controls

Hold FN + PLAY; press VOL-.

Clears window, trim and timing edits; take length OFF, 4 beats per bar. Recordings and FX stay unchanged.

Reverse / isolate

Reverse: FN + TRACK first, then tap PLAY.

Isolate: FN + PLAY first, then hold TRACK. Release TRACK to restore the mix.

Four-head mode

While playing: hold FN; triple-tap PLAY.

Repeat to exit. Hold a loaded TRACK to choose source; FN + faders position heads.

Beat repeat

Hold PLAY; click ROCKER UP.

ROCKER UP halves / ROCKER DOWN doubles. Release PLAY to return. Add FN for octave jumps; VOL- / VOL+ moves the repeat.

Bounce / sampler print

Hold PLAY; tap destination TRACK to bounce.

Tap destination to finish. Hold it instead for sampler print; release to finish. Earlier takes stay saved.

FX routing / input mute

Hold PLAY: VOL- = INPUT; VOL+ = TRACKS; double-tap either = BOTH.

PLAY + both VOL mutes input, including its recording. Unmute before arming.

4.0 | Revised 12 Nov 2026 | tapelooper.club