Connect & reset

Bluetooth

Tap FN twice; hold the third press for 1 second.

All four TRACK lights slowly fade together while pairing. Choose SP-1 on your phone/computer. Record normally. USB and Bluetooth inputs can mix.

USB Library

Stop/save. Hold T2 + T3 for 3 seconds; release.

Choose the SP1 MUSIC drive in Finder or the site's Library. Eject in Finder to finish importing; keep USB connected until Tape Looper returns.

Reset the tape

FN + double-tap PLAY

Restores normal speed and rocker transforms, including Magnet gaps and Scissors cuts. FX remain set.

Reset FX

On an FX page: FN + T1 + T4

Resets effects, EQ, rates, types and routing. Monitor mute is unchanged. Reset confirmation: all four TRACK lights solid briefly.

Print at 100% on A4, landscape, double-sided; flip on the short edge. Fold in three. This panel is the back.

FX & control pages

Effects, EQ, placement & timing

Hold FN + T1-T4 to open pages 1-4.

Release both. VOL- / VOL+ move through all eight pages; tap FN to close. Move a fader through its saved value to take control.

1 / Color

Filter; Chorus / Flanger; Distortion; Gate / Slow gear.

2 / Texture

Crush / Lo-fi / Radio; Ring mod; Auto-wah; Echo.

3 / Motion & space

Phaser; Sweep; Tremolo; Reverb / Freeze.

4 / Tape

Drive; Tone / Compression (tap T2 to select; F2 adjusts); Noise; Wobble.

5 / EQ

Four bands; tap T1-T4 to flatten a band.

6 / Placement

F1-F4 pan tracks; tap TRACK to center.

7 / Timing

F1 grid offset; F2 take length; F3 beats per bar: 3 / 4 / 5 / 7 (saved per song). TRACK + fader nudges that track.

8 / Next take

Tap TRACK: solid = mono; blinking = stereo.

SP-1

Tape Looper 4.0

Pocket guide

T1-T4: TRACK buttons. F1-F4: faders. A plus sign means hold together. Start in normal track mode unless a page is named.

Record

Tap an empty TRACK; sound starts recording.

Tap that TRACK again to finish. PLAY cancels an armed take and pauses; finish an active recording with TRACK.

Play / stop

Tap PLAY. Hold and release PLAY to restart.

Mix / mute

F1-F4: levels. Tap a loaded TRACK: mute/unmute.

VOL- / VOL+ set listening level.

Power

Hold FN 1.5 seconds to wake.

Stop playback, then hold FN 2.5 seconds to power off.

Record & takes

Banks & songs

Hold FN + tap T1-T4.

Choose a bank; repeat the same button to step through its four songs. A longer hold opens a control page.

Takes

TRACK + ROCKER DOWN: cycle saved takes.

TRACK + ROCKER UP: New lane. An empty lane breathes when other takes exist. Hold FN during playback to count all takes.

Overdub

Hold loaded TRACK 0.6 seconds, release, then tap within 10 seconds.

Tap again to finish. The earlier take remains saved. FN cancels preparation.

Delete selected take

Double-tap TRACK; hold the second press.

Wait for saving to finish. This deletes the selected take, not every take.

Beat grid

Tap FN at least four times, starting on the downbeat.

Round BPM: after tapping, press and hold FN about 1 second. Clear grid: tap FN, then quickly press and hold about 1 second.

Fixed / variable

Briefly hold FN + PLAY; release both.

Fixed uses multiples of the first loop; variable allows independent lengths.

Rocker modes

Open / select

FN + both VOL; release FN. VOL- / VOL+ select.

Tap FN to close. Selected mode stays active.

1 Pitch

ROCKER UP / ROCKER DOWN changes speed. Double-click: semitone; hold: sweep.

2 Wind

Hold ROCKER UP forward / ROCKER DOWN rewind. Release restores playback. On page, TRACK 1-4 + rocker: 0.5x / 1.5x / 3x / 4x. Double-tap TRACK to latch winding speed.

3 Bender

ROCKER DOWN drags; ROCKER UP surges. Release springs back.

4 Battery

ROCKER DOWN adds sag; ROCKER UP heals. Wear persists.

5 Sandpaper

ROCKER DOWN adds damage; ROCKER UP heals. Wear persists.

6 Magnet

Hold ROCKER DOWN to erase a passing gap; ROCKER UP undoes. Length stays the same.

7 Scissors / glue

ROCKER DOWN marks start, then end; ROCKER UP cancels / undoes. Up to eight cuts.

8 Manual tape head

Hold ROCKER UP for normal contact; hold ROCKER DOWN and use F1-F4 to scrub. Release is silent; PLAY still starts/stops.

Magnet / Scissors: bare rocker affects loaded tracks. Keep the rocker page open and hold TRACK to target one track. Scissors needs a full forward loop: no trim, Heads, repeat or recording.

Shape & perform

Window

FN + F1 start / F2 end / F3 position / F4 size.

FN + ROCKER UP halves; ROCKER DOWN doubles. FN + VOL- / VOL+ moves it. F4 fully up restores the F1-F3 region.

Track trim / slide

FN + PLAY + fader trims that track.

PLAY + fader slides the trimmed section. Raise the trim fader fully to restore length.

Whole loop / home

FN + PLAY + VOL-: whole forward loop and timing reset.

FN + PLAY + VOL+: home, keeping chop and direction.

Four heads

While playing: FN + triple-tap PLAY.

Repeat to exit. Hold a loaded TRACK to choose source; FN + faders moves heads.

Beat repeat

Hold PLAY + ROCKER UP.

ROCKER UP halves / ROCKER DOWN doubles. Release PLAY to return. Add FN for octave jumps. VOL- / VOL+ moves the repeat.

Bounce / print

Hold PLAY + tap destination TRACK: bounce.

Tap destination to finish. PLAY + hold destination: sampler print; release TRACK to finish. A loaded destination is replaced.

FX routing / input

PLAY + VOL-: INPUT; + VOL+: TRACKS. Double either: BOTH.

PLAY + both VOL toggles input monitoring. Muted input blocks ordinary recording.