Tape Looper 4.0

Full guide

A playable reference for the SP-1. Gestures, takes, eight rocker modes, eight control pages, Bluetooth and USB Library access.

Read the controls

T1-T4 = TRACK buttons / F1-F4 = faders

PLAY is the transport button. FN is the function button. VOL- and VOL+ are the two volume buttons. ROCKER UP and ROCKER DOWN refer to the side rocker.

A plus sign means hold controls together. "Tap" and "hold" are different gestures. Start from normal track mode unless a page or mode is named.

Start here

Flash > Setup v4 > make music

Flash the current Tape Looper BIN with Solderless. Use Setup v4 on the Tape Looper site to check the filesystem and Bluetooth. Setup skips work already verified.

Keep USB connected during setup. If your computer selects SP-1 as its sound output, switch to your usual speakers while setting up.

Your library

16 songs / 4 tracks per song

Four banks each contain four songs. With the v4 filesystem, each track can keep multiple takes; one lane is selected at a time.

Recording and file imports are limited to approximately eight minutes per take. The Library can prepare compatible audio and offers a clip selection for longer sources.

USB Library

Stop/save > hold T2 + T3 for 3 seconds

Release the buttons. Open the mounted SP1 MUSIC drive in Finder or select that drive in the site's Library. Add audio to the intended song/track; use takes to retain alternatives.

SP1 MUSIC is the mounted drive. Select its top-level folder when the browser asks for access. Do not select an individual song folder.

Finish importing

Eject SP1 MUSIC in Finder

Keep USB connected while the device validates and imports audio, then returns to Tape Looper. T3 pulses during audio import. Large files or batches take longer.

Copy completion is not import completion. Avoid powering off or pressing mode gestures while it is saving. Keep an external copy of recordings you need.

Find a control

Five chapters + rocker reference

01 Start & record 02 Shape the tape 03 Effects 04 Place & time 05 Repeat & bounce 06 Rocker modes

PDF bookmarks jump to each chapter. The pocket guide is a separate six-panel reference.

01 / Start & record

CONNECT & WAKE

Connect your sound

USB-C or Bluetooth audio in

Select SP-1 as your computer or phone's USB audio output, or pair it over Bluetooth. Both inputs can play together.

The headphone jack is an output. Bluetooth audio input is separate from the companion's Bluetooth control connection.

Wake. Power off.

Hold FN · 1.5 s / 2.5 s

Hold FN about 1.5 seconds to wake. To power off, stop playback and hold FN about 2.5 seconds.

USB power can keep the charging gauge active.

YOUR FIRST LOOP

Make your first loop

Arm > send sound > tap to finish

Tap an empty track to arm it. Start your audio to begin recording. Tap the same track again to finish the loop, then raise its fader.

While armed, tap PLAY to cancel and pause. Once recording starts, tap its track to finish.

EVERYDAY CONTROLS

Play. Stop. Restart.

Tap PLAY · hold to restart

Tap PLAY to start or stop. Hold PLAY, then release to restart.

Mix four tracks

F1-F4 = track levels

Raise a fader to bring its track forward. Lower it to pull that track back.

Set the listening level

VOL- / VOL+

Use the two round buttons on the top edge to change master volume.

Mute. Restore.

Tap a loaded track

Tap a loaded track to mute it. Tap again to restore it.

Several track buttons can toggle their mutes together. Muting keeps the recorded audio.

Keep more than one take

TRACK + ROCKER DOWN = saved takes · TRACK + ROCKER UP = New

Hold a track and click ROCKER DOWN to cycle its recorded takes. ROCKER UP selects an empty New lane. Record normally there; your earlier takes stay saved. Each song and track has its own lane.

Switch while playing or stopped. A New lane breathes when it has saved takes. Hold FN during playback to count the total takes on each track; the counts repeat together.

Overdub the current take

Hold TRACK · release · tap TRACK

Hold a loaded track for 0.6 seconds to prepare overdub. Release, then tap it within 10 seconds to arm. Tap again to finish.

The earlier take stays saved in this track's lane. TRACK + ROCKER DOWN finds it after the new recording is saved. Tap FN to cancel preparation.

Delete a take

Double-tap; hold the second press

Double-tap the track, holding the second press until deletion is acknowledged. This removes the selected take; other takes remain.

If the track is still saving, wait for saving to finish and try again. TRACK + ROCKER DOWN finds the remaining takes.

SONGS & SETTINGS

Find a song

Hold FN + tap T1-T4

Choose a bank with T1-T4. Repeat the same button to step through that bank's four songs.

Use this from normal track mode. A longer FN + track hold opens a page instead.

Fixed or variable loops

Briefly hold FN + PLAY; release

Briefly hold FN + PLAY, then release both to switch loop length mode.

Fixed rounds each take to a whole multiple of the base loop, keeping tracks aligned. Variable preserves each recorded length, so tracks can cycle independently. The side lights confirm your choice.

Adjust LED brightness

Hold FN + PLAY · 5 s

Keep FN + PLAY held through five seconds. The lights change while you hold.

This longer hold leaves loop length mode unchanged.

TAP A BEAT GRID

Tap a beat grid

Tap FN 4+ times

From normal track mode, tap FN at least four times in time. Start on the downbeat.

Fresh taps align recording to beats. The saved grid follows the loop; tape speed changes its tempo.

Clear the beat grid

Tap FN > press again and hold · ~1 s

Tap FN, then quickly press it again and hold about one second to clear the beat grid.

The four TRACK lights briefly turn solid. Your recorded audio stays in place.

Round to the nearest whole BPM

Tap FN 4+ times > hold FN · ~1 s

Tap FN at least four times in time, then press and hold FN about one second to round the tapped tempo to the nearest whole BPM. For example: 119.8 to 120 BPM.

Sweep = rounding succeeded. Shrug = no rounding applied; the tempo stays unchanged.

EVERYDAY CONTROLS

Read the track lights

Dark · dim · blinking · solid

Dark means empty; dim means muted. Recording is solid. Playback pulses with the grid, or when each loop wraps.

When stopped, an unmuted loaded track stays solid. Examples use 120 BPM and selected loop lengths. A refusal shrug can mean saving is still busy: wait for completion before deleting or recording again. Alternating T1+T3 / T2+T4 indicates a fault; stop testing and keep the device connected for diagnostics.

SONGS & SETTINGS

Read the side lights

Playing: level · FN held: song

During playback, the meter fills from the bottom. Hold FN to see the song: solid = bank, blinking = position.

If bank and position share a light, that light blinks. With a running grid the song blink follows the beat.

CONNECT & WAKE

Record from Bluetooth

Tap FN twice, then hold the third press

Tap FN twice, then hold FN on the third press for about one second to enable Bluetooth audio discovery. Pair SP-1 from your phone or computer, select it as the audio output, then record normally.

The gesture also works during playback and USB audio. USB and Bluetooth input mix together. This release focuses on Bluetooth input; outgoing audio to speakers or keyboards is deferred.

02 / Shape the tape

SPEED & PITCH

Return to 1x

Hold FN + double-tap PLAY

Hold FN and tap PLAY twice. The tape returns to its normal speed.

Also restores rocker tape transformations, including Magnet and Scissors. Recordings and effect-page settings stay intact.

Jump an octave

Hold FN + PLAY + rocker

With FN and PLAY held, click down for an octave lower or up for an octave higher.

A step outside the tape-speed range does nothing.

CHOP & WINDOW

Shorten the loop window

Hold FN + rocker

Up halves the window. Down doubles it. Hold to keep stepping.

The chop stays inside your fader-set region.

Move the window

Hold FN + VOL- / VOL+

Step the chop earlier or later through your region.

With a page open, this same chord walks pages instead.

One window. Four faders.

FN + F1 / F2 / F3 / F4

F1 = start. F2 = end. F3 = position. F4 = size / zoom.

Edits start from the audible window. F4 down tightens; top restores the region set by F1-F3. Re-gripping FN preserves that region.

Reverse the window

FN + cross F1 past F2

Hold FN and move F1 - the start - past the end set by F2 to reverse the window.

Crossing edges during a beat repeat does not reverse it.

Whole loop or home

FN + PLAY + VOL- / VOL+

VOL- resets to the whole loop, forwards. VOL+ returns home while keeping chop size and direction.

Use outside a repeat. Reset clears window reverse; per-track reverse stays. During repeat, the volume buttons move its window.

REVERSE OR ISOLATE

Reverse one track

FN + track first > tap PLAY

Hold FN + the track button first, then tap PLAY before its page opens. Repeat to reverse back.

Press order matters. FN + PLAY first, then the track, isolates instead.

Momentarily isolate

FN + PLAY first > track

Hold FN + PLAY first. Then press the track you want to hear alone.

Release the track to restore the previous mutes.

FOUR HEADS, ONE LOOP

Enter four-head mode

Hold FN + triple-tap PLAY

Start with a loop playing in normal track mode. Hold FN and triple-tap PLAY. Repeat to exit.

Faders set head levels, track taps mute, and FN + faders set head positions.

Move heads. Change source.

FN + faders · hold a loaded track

In heads mode, FN + faders positions the heads. Hold another loaded track to make it the source.

TAPE RESET

Restore the tape

Hold FN + double-tap PLAY

Restore normal rocker tape behavior: clear Scissors cuts and Magnet changes, release wind and reset speed.

The four TRACK lights briefly turn solid. Recordings and effect-page settings stay intact.

TRACK TRIM

Trim a track's length

Hold FN + PLAY · move that track's fader

Hold FN and PLAY, then move F1-F4 to shorten or lengthen the matching track. Lower the fader to shorten; raise it to lengthen. Release both to keep the trim.

The first small move catches the current length without jumping. With a grid, lengths step through straight and dotted musical values. Other tracks keep playing; the original recording stays intact.

Slide the kept section

Hold PLAY · move the trimmed track's fader

After trimming a track, hold PLAY and move its fader to slide the kept section through the recording. Its length stays the same. Raise the fader toward the start; lower it toward the end.

The first small move catches the current position. With a grid, movement follows sixteenth-note steps. Release PLAY to keep the position; moving the fader spends the PLAY press, so it does not pause or restart playback.

03 / Effects

PAGES & PICKUP

Open an effects page

Hold FN + a track button

Hold FN with a track button. Release both after the page opens. The page stays open.

T1-T4 opens Pages 1-4. Tap FN to close.

Move between pages

Page open · VOL- / VOL+

With any page open, press VOL- or VOL+ to move between Pages 1-8. Tap FN to close.

The same controls move between rocker modes when the rocker page is open.

Make the fader respond

Cross its stored value

Pickup prevents a parameter jump when you enter, leave or reset a page. Move through the stored value to take control.

Move through the stored value before a fader takes control. FN window edits respond to deliberate movement instead.

PAGE 1 / FX 1

Filter

F1 · T1 bypass + reset damping

Move F1 for the filter. Center is neutral. Tap T1 to turn it off.

Hold T1 and move F1 for filter damping.

Chorus / Flanger

F2 · T2 type

Move F2 for depth. Tap T2 to switch Chorus / Flanger. Lower F2 to turn it off.

Hold T2 and move F2 for span. Tap a rate with FN + T2, at least twice.

Distortion

F3 · T3 type

Tap T3 to cycle soft > hard > fold. F3 sets the amount. Lower F3 fully to turn it off.

Fader down gives clean audio; raising it restores the selected drive type.

Gate

F4 · T4 pattern

Move F4 for depth. Tap T4 to cycle Gallop / Halves / Slow gear. Slow gear fades into incoming notes. Lower F4 to turn it off.

Tap a rate with FN + T4, at least twice.

PAGE 2 / FX 2

Crush / Lo-fi / Radio

F1 · T1 type

Move F1 for depth. Tap T1 to cycle Crush / Lo-fi / Radio. Lower F1 to turn it off.

Ring mod

F2 · T2 off

Move F2 for ring modulation. Tap T2 to turn it off.

Auto-wah

F3 · T3 off + reset damping

Move F3 for auto-wah. Tap T3 to turn it off.

Hold T3 and move F3 for wah damping.

Echo

F4 · T4 division

Tap T4 to cycle 1/16 > dotted > 1/8. F4 sets the amount. Lower F4 fully to turn it off.

Hold T4 and move F4 for echo feedback. Tap a rate with FN + T4, at least twice.

PAGE 3 / FX 3

Phaser

F1 · T1 division

Tap T1 to cycle beat > half > quarter. F1 sets the amount. Lower F1 fully to turn it off.

Hold T1 and move F1 for phaser feedback. Tap a rate with FN + T1, at least twice.

Sweep

F2 · T2 division

Tap T2 to cycle beat > half > quarter. F2 sets the amount. Lower F2 fully to turn it off.

Tap a rate with FN + T2, at least twice.

Tremolo

F3 · T3 division

Tap T3 to cycle beat > half > quarter. F3 sets the amount. Lower F3 fully to turn it off.

Hold T3 and move F3 for tremolo shape. Hold T3 and move F4 for stereo spread. Tap a rate with FN + T3, at least twice.

Reverb / Freeze

F4 · T4 type

Move F4 for reverb. Tap T4 to freeze the current tail; tap again for Reverb. Lower F4 to turn it off.

Hold T4 and move F4 for reverb damping.

PAGE 4 / TAPE

Tape drive

F1 · T1 off

Move F1 for tape drive. Tap T1 to turn it off.

Tone / Compression

F2 · T2 Tone / Compression

Tap T2 to switch Tone / Compression. Move F2 through its saved value, then adjust. Center Tone for flat; lower Compression fully to turn it off. Both settings stay applied.

Both settings stay applied when you switch. Move F2 through its saved value to take control.

Noise

F3 · T3 source

Move F3 for noise level. Tap T3 to cycle Cassette / Vinyl / Pink / Minidisc. Lower F3 to turn it off.

Wobble

F4 · T4 type

Move F4 for depth. Tap T4 to cycle Wow + flutter / Wow / Flutter. Lower F4 to turn it off.

Tap a rate with FN + T4, at least twice.

PAGES & PICKUP

Tap or clear an FX rate

Hold FN + tap the lane 2+ times

On its page, hold FN and tap the rate-enabled lane at least twice.

Clear a tapped rate on its page with FN + PLAY + that track. Supported lanes: P1 T2/T4; P2 T4; P3 T1/T2/T3; P4 T4.

SECONDARY CONTROLS

Hold a lane. Shape it.

Hold track + move fader

Hold a lane's TRACK button and move its fader: P1 filter damping / chorus span; P2 wah damping / echo feedback; P3 phaser feedback / tremolo shape / reverb damping. For tremolo stereo spread, hold T3 and move F4.

Move before releasing the track button to avoid its tap action. After release, cross the main value again before changing it.

PAGE 5 / GLOBAL EQ

Shape the whole mix

F1 100 Hz · F2 350 Hz · F3 1.6 kHz · F4 4 kHz

Down cuts; up boosts. Center or a track-button tap returns that band to flat.

F1 and F4 are low/high shelves. EQ always affects the whole mix; lights show cut/boost amount.

FX ROUTING & RESET

Choose what gets FX

PLAY + VOL- / VOL+ / double-click

VOL- = INPUT. VOL+ = TRACKS. Double-click either volume button with PLAY held = BOTH.

INPUT records FX into ordinary takes. TRACKS leaves live input dry. BOTH processes the heard mix; ordinary takes stay dry. Set routing before a repeat.

Mute the input monitor

Hold PLAY + both VOL

Toggle monitoring with PLAY and both volume buttons. Works on any page.

Muted monitoring blocks ordinary recording. Unmute input before arming. On Pages 1-4, a blinking page number also marks muted monitoring.

Reset the effects

On an FX page: FN + T1 + T4

Restore the effects to their defaults, flatten EQ and set routing to BOTH.

The four TRACK lights briefly turn solid. Effects, EQ, rates, types and routing return to defaults. Monitor mute stays as set.

SECONDARY CONTROLS

Wah resonance

Page 2: hold T3 and move F3

While holding T3, move F3 down for a sharper peak or up for a softer peak.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Echo feedback

Page 2: hold T4 and move F4

Change the amount fed back into the echo.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Tremolo shape

Page 3: hold T3 and move F3

Move from softer to harder tremolo shapes.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Tremolo stereo spread

Page 3: hold T3 and move F4

Change the spread between the two channels. F4 does not change reverb while T3 is held.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

Reverb damping

Page 3: hold T4 and move F4

Down is darker; up is brighter.

Move before releasing the track button; releasing without movement triggers its usual tap action. Then cross the main value to regain control.

PAGE 1 / SECONDARY CONTROLS

Filter damping

Page 1: hold T1 and move F1

Hold T1 and move F1 to adjust filter damping without changing the main level.

Release TRACK to return to the primary control; pick up its saved level.

Chorus / flanger span

Page 1: hold T2 and move F2

Hold T2 and move F2 to adjust chorus / flanger span without changing the main level.

Release TRACK to return to the primary control; pick up its saved level.

PAGE 3 / SECONDARY CONTROLS

Phaser feedback

Page 3: hold T1 and move F1

Hold T1 and move F1 to adjust phaser feedback without changing the main level.

Release TRACK to return to the primary control; pick up its saved level.

04 / Place & time

PAGE 6 / STEREO PLACEMENT

Stereo track placement

Faders 1-4 = tracks 1-4

Down moves left. Up moves right. Center keeps the original balance.

A mono take pans; a stereo take leans. Lights are dark at center and brighter farther to either side.

Center one or all tracks

Tap a track button · FN + T1 + T4

With no take recording, tap a track to center its placement. FN + T1 + T4 centers all four on Page 6.

The all-track shortcut also resets FX.

PAGE 7 / TAKE & TIMING

Move the downbeat

F1 = grid offset

Center is no offset. Up moves later; down moves earlier, by up to about half a beat.

Beat lights and future grid-aligned punches follow the offset.

Choose a take length

F2 = OFF / 1 / 2 / 4 / 8

On Page 7, F2 selects the take length. F3 selects 3, 4, 5 or 7 beats per bar, from bottom to top. Move through the saved value to take control.

Beats per bar is saved per song; the default is 4. Variable mode counts bars and needs a grid. Fixed mode counts base loops and needs a first take.

Choose a length. Record a take.

Leave Page 7 > arm a track

On Page 7, choose a take length with F2. Tap FN to close the page, tap an empty track and let recording finish automatically.

The take stops automatically. Tap the recording track to finish earlier. Bounces do not use the preset.

Read the take countdown

Open Page 7 during a preset take

Up to four track lights show the units remaining. The last unit blinks.

The countdown is capped at four lights; an eight-unit take stays at four until only three units remain.

PAGE 7 / NUDGE A LOOP

Slide one track in time

Hold a track button + move its fader

On Page 7, hold a track button and move its fader. Up moves the track later; down moves it earlier. The edit is relative to the fader position when you held the button.

Nudge works without a grid. A recording track cannot be nudged. In heads mode, nudging the source moves all its heads.

Read the nudge lights

Amount while held · dim glow after

While a track is held, its light shows the nudge amount. After release, nudged tracks glow dim between beats.

The 1-2-3-4 chase shows the grid. Settings save per song after about two seconds.

Reset timing controls

Hold FN + PLAY · press VOL-

Reset the window, timing offsets and track trims. Take length returns to Off.

FN + T1 + T4 resets FX; it does not reset the timing page.

PAGE 8 / NEXT TAKE FORMAT

Choose mono or stereo

Tap a track button on Page 8

Before recording, tap a track button to choose the format of its next take.

Solid light = mono. Blinking = stereo. Existing audio stays unchanged. Faders still control track levels.

PAGE 7 / TAKE & TIMING

Waiting or finishing on the grid

Half-beat flashes

An armed track flashes at half-beat rate while waiting for punch-in. The same quicker pulse marks a recording finishing its beat.

The recording continues until its aligned stop; it is not stuck.

05 / Repeat & bounce

CATCH & RESIZE

Catch, reshape, release

Hold PLAY + ROCKER UP

Hold PLAY and click the rocker up to catch a beat. Use the rocker to resize it, then release PLAY to return to the song.

Make it shorter or longer

Hold PLAY > click ROCKER UP > resize

Hold PLAY and click the rocker up to catch a beat. ROCKER UP halves the repeat; ROCKER DOWN doubles it. Hold the rocker to keep stepping. Release PLAY to return to the song.

Release the rocker but keep PLAY held to repeat at the same length.

Repeat inside a chop

PLAY + rocker inside your chop

The repeat only uses your chopped audio. It cannot reach outside the audible cycle.

If a requested beat would fill the chop: ROCKER UP starts with a quarter of it; ROCKER DOWN with half, down to the minimum size.

Release: hold the tape

Release PLAY with FN released

On a gridded song, playback resumes from the repeat, with the tape shift rounded to the nearest bar.

A short stutter may leave the position unchanged. Without a grid, or during a bounce, release returns to the running tape position.

Repeat without a grid

Hold PLAY + rocker: ROCKER UP = 1/8 · ROCKER DOWN = 1/4

Without a grid, hold PLAY and click the rocker up for one eighth of the loop, or down for one quarter. Chop limits still apply.

On release, return to the running tape position. There is no bar-based tape hold.

SHAPE THE REPEAT

Move the repeating window

Keep PLAY held + VOL- / VOL+

VOL- moves earlier. VOL+ moves later. Each press shifts by one current window length inside the audible cycle.

During a repeat these controls move its window, not FX routing. Set routing before catching the repeat.

Jump an octave in the repeat

Keep PLAY held + FN + rocker

Add FN and click the rocker. Down is an octave lower; up is an octave higher.

Shape the repeat with faders

Keep PLAY held + FN + F1-F4

F1 = start. F2 = end. F3 = position. F4 = size / zoom. Move deliberately to engage a fader.

F3 keeps width. F4 tightens around the center; top restores the region set by F1-F3. Re-gripping FN preserves that region.

BOUNCE WHAT YOU HEAR

Bounce what you hear

Hold PLAY > briefly tap destination

Record the playing mix onto a spare track. Hold PLAY and tap the destination; tap it again to finish. This is a tape copy.

A loaded destination is replaced. Tape copy follows tape speed with its source. A grid may add count-out; fixed mode and chop can extend the stop to a full cycle.

Bounce a beat-repeat performance

Hold PLAY > click ROCKER UP > tap destination

Hold PLAY and click the rocker up to catch a repeat. Keep PLAY held and tap a spare track to start the bounce. Release PLAY to let the song flow back in; tap the destination again to finish.

Keep PLAY held to resize while recording. A loaded destination is replaced.

Make a sampler print

Hold PLAY > hold destination

Hold PLAY, then hold the destination track to record a sampler print. Release the track to finish.

The heard speed is baked for playback at 1x. Use a spare destination: a loaded track is replaced.

Stop a bounce from a page

PLAY + destination track

Use PLAY + the destination track again to stop a bounce while a page is open.

Let the song flow back in

After starting the copy, release PLAY

The repeat ends and the tape copy continues from the running tape position. Tap the destination again to stop.

Sweep speed into a take

During a bounce: release PLAY > rocker

Use the rocker while a tape copy or sampler print is recording. Your speed moves become part of the performance.

Tape copy records speed moves relative to starting speed. Sampler print bakes the performance for playback at 1x.

Perform inside a sampler print

Keep the destination held · PLAY changes the rocker

Keep the destination held. With PLAY released, the rocker changes speed. With PLAY held, it controls beat repeat. Add FN for octave jumps.

Release the destination to end the print. Release PLAY too to end the repeat.

06 / Rocker modes

Open with FN + both VOL. Release FN; VOL- / VOL+ choose a slot. Tap FN to close. The selected mode remains active. Keep the page open for TRACK modifiers. Holding TRACK previews the normal track lights.

1 / Pitch

Change the whole tape's speed and pitch.

ROCKER UP: Click to increase speed. Double-click for the next semitone; hold to keep stepping. ROCKER DOWN: Click to decrease speed. Double-click for the previous semitone; hold to keep stepping.

The new speed stays set. Whole tape.

FN + double-tap PLAY returns to normal speed.

The normal range is 0.25x-2x. FN + PLAY + rocker makes octave jumps.

2 / Wind

Fast-forward or rewind through the tape.

ROCKER UP: Hold to wind forward. ROCKER DOWN: Hold to rewind.

Speed settles back and the previous playback directions return. Whole tape.

Release the rocker. FN + double-tap PLAY restores the tape.

Page open: hold T1/T2/T3/T4 + rocker for 0.5x/1.5x/3x/4x. Double-tap TRACK to latch its speed for bare-rocker winding, also after closing the page. Release rocker returns to playback speed.

3 / Bender

Drag the tape or pull it in uneven surges.

ROCKER UP: Hold for repeated pulling surges. ROCKER DOWN: Hold to drag and stretch the tape; longer holds stretch further.

The tape springs back toward the set speed. Whole tape.

Release the rocker, or FN + double-tap PLAY to restore the tape.

Unlike Pitch, a bend is temporary. Your recordings stay unchanged.

4 / Battery

Make the motor sag, wobble and stall.

ROCKER UP: Hold to recover toward normal. ROCKER DOWN: Hold to increase battery-drain wear.

The amount of wear stays. Whole tape.

Hold ROCKER UP to recover gradually. FN + double-tap PLAY restores the tape.

Release leaves the tired-battery sound in place so you can keep performing.

5 / Sandpaper

Roughen the tape with breakup and drag.

ROCKER UP: Hold to reduce the wear. ROCKER DOWN: Hold to add roughness and breakup.

The amount of wear stays. Whole tape.

Hold ROCKER UP to clean it up gradually. FN + double-tap PLAY restores the tape.

Battery changes the motor's behavior; Sandpaper adds a rougher, damaged-tape texture.

6 / Magnet

Erase a passing section from playback without shortening the loop.

ROCKER UP: Tap to undo the latest matching erase. ROCKER DOWN: Hold while the section passes, then release to leave a silent gap.

The gap stays; the rest of the loop keeps its timing. Bare rocker targets loaded tracks. With the rocker page open, hold TRACK to target only that track.

ROCKER UP undoes a recent erase. FN + double-tap PLAY clears all Magnet gaps.

The original audio is unchanged. A Magnet gap keeps its place in time.

7 / Scissors / glue

Cut out a section and join the remaining tape.

ROCKER UP: Tap to cancel the first mark, or undo the last cut. ROCKER DOWN: Tap at the start, then tap again at the end of the section.

Each completed cut stays, including after leaving the rocker page or slot. Bare taps target loaded tracks. Keep the rocker page open and hold the same TRACK for both marks to cut only that track.

ROCKER UP undoes; FN + double-tap PLAY restores all cuts.

Up to eight cuts. Use a full forward loop with playback running, without trim, repeat, Heads or recording. Song/take changes, recording or reboot clear the cuts.

8 / Manual tape head

Touch the moving tape with one contact or four heads.

ROCKER UP: Hold to hear the tape under ordinary contact. ROCKER DOWN: Hold for four-head contact. Move F1-F4 to position the heads.

Contact lifts and the tape becomes silent; transport keeps moving. The active tape source; ROCKER DOWN exposes four playback heads.

Leave this slot to return to ordinary playback.

PLAY starts or stops the tape. This contact mode is separate from latching Heads with FN + triple-tap PLAY.