

OPERATING MANUAL - MODEL 42

Section 1: Safety

Always disconnect power before servicing.

Section 2: Maintenance

Inspect belts monthly. Replace filter every 90 days.

Figure 1: Control panel layout.