ZEBRA RFID MOBILE APP & SATO PRINTER GRAPHICAL USER INTERFACE

Installation and Usage Guide

Table of Contents

<u>ZEI</u>	BRA RFID MOBILE APP INSTALLATION	<u>2</u>
INS	STALLATION REQUIREMENTS	2
	IPPORTED OPERATING SYSTEMS:	
DOWNLOAD		
		_
ZEI	BRA RFID MOBILE APP USAGE GUIDE	2
FE/	ATURES	2
	LOCATE A TAG	
	VIEW HISTORY	
c.	CLEAR HISTORY	3
Tro	OUBLESHOOTING	3
Α.	READER CONNECTED, BUT SCAN NOT WORKING (I.E. DECODE LED NOT EMITTING GREEN LIGHT)	3
SA.	TO PRINTER GRAPHICAL USER INTERFACE INSTALLATION	5
<u> </u>		
	STALLATION REQUIREMENTS	-
	PPORTED OPERATING SYSTEMS:	
DΟ	DWNLOAD	5
SA'	TO PRINTER GRAPHICAL USER INTERFACE USAGE GUIDE	5
FE4	ATURES	5
	PRINTING RFID TAG	
	CLEAR WORK ID INSERT TEXT FIELD	

Zebra RFID Mobile App Installation

Installation Requirements

Supported Operating Systems:

• Android 10 and later for RFD40XX

Download

- Download the app-release-apk file under app/release folder.
- Locate the apk file in the Files app on your device.
- Launch the apk file and follow these steps:
 - o Allow installations from unknown sources in your device settings.
 - o Press Install once installation prompt appears.

Zebra RFID Mobile App Usage Guide

Features

- a. Locate a Tag
- 1. Insert a work id into the work id text box.
- 2. Click on 'FIND' button.
- 3. Press on the handlheld trigger (Figure 1) to initiate the scan.
- 4. Once a tag that contains the work id is detected, the RSSI (Received Signal Strength Indicator) will appear on the screen.
- 5. If not detected in the vicinity, a red cross icon will show and a "Tag not detected" message will appear.



Figure 1: Handheld trigger of the RFD40 sensor

- b. View History
- 1. Click on the history icon on the top navigation bar.
- c. Clear History
- 1. Click on the history icon on the top navigation bar.
- 2. Click on "Clear History" button to clear data.

Troubleshooting

a. Reader connected, but scan not working (i.e. Decode LED not emitting green light)



Figure 2: Zebra RFD40 Scanner Decode LED

- Check the battery status of the RFID scanner by checking the battery status LED.
 - o Green indicates sufficient battery.
 - o Orange indicates a moderate amount of battery.
 - Red indicates low battery.
 - o Blank indicates no battery.



Figure 3: Zebra RFD40 Scanner Battery Status LED

• When the battery is green, but it is still not working.

Solution 1: Exit the application and re-enter.

Solution 2: Reinsert the battery of the sensor.

SATO Printer Graphical User Interface Installation

Installation Requirements

Supported Operating Systems:

- Windows 7
- Windows 8 and 8.1
- Windows 10

Download

- Launch the SATONETGUISetup.msi file under SATONETGUISetup/Release folder to initiate the installation process.
- Press "Install" once installation prompt appears.

SATO Printer Graphical User Interface Usage Guide

Features

- a. Printing RFID Tag
- 1. Ensure that the SATO Printer USB cable is connected to the computer.
- 2. Insert the work id into the work id textbox and press the enter key on the keyboard.
- b. Clear Work ID Insert text field
- 1. Click on the "Clear" button to clear the text on the work id text input field.