2.12 DVP 系列 PLC 装置通讯地址
以十六进制地址为准,将十六进制转换成十进制即可

	以十六进制地址为准,将十六进制转换成十进制即可						
裝				DVP	Modbus		
置	範	圍	類別	通訊位址	通訊位址		
				(Hex)	(Dec)		
S	000~255		Bit	0000~00FF	000001~000256		
S	246~511	246~511		0100~01FF	000247~000512		
S	512~767		Bit	0200~02FF	000513~000768		
S	768~1023		Bit	0300~03FF	000769~001024		
Χ	000~377 (Octal)		Bit	0400~04FF	101025~101280		
Υ	000~377 (Octal)		Bit	0500~05FF	001281~001536		
Т	000~255		Bit	0600~06FF	001537~001792		
			Word	0600~06FF	401537~401792		
М	000~255		Bit	0800~08FF	002049~002304		
М	256~511		Bit	0900~09FF	002305~002560		
М	512~767		Bit	0A00~0AFF	002561~002816		
М	768~1023		Bit	0B00~0BFF	002817~003072		
М	1024~1279		Bit	0C00~0CFF	003073~003328		
М	1280~1535		Bit	0D00~0DFF	003329~003584		
М	1536~1791		Bit	B000~B0FF	045057~045312		
М	1792~2047		Bit	B100~B1FF	045313~045568		
М	2048~2303		Bit	B200~B2FF	045569~045824		
М	2304~2559		Bit	B300~B3FF	045825~046080		
М	2560~2815		Bit	B400~B4FF	046081~046336		
М	2816~3071		Bit	B500~B5FF	046337~046592		
М	3072~3327		Bit	B600~B6FF	046593~046848		
М	3328~3583		Bit	B700~B7FF	046849~047104		
М	3584~3839		Bit	B800~B8FF	047105~047360		
М	3840~409	5	Bit	B900~B9FF	047361~047616		
	0~199	16-bit	Bit	0E00~0EC7	003585~003784		
			Word	0E00~0EC7	403585~403784		
С	000 5	5 32-bit	Bit	0EC8~0EFF	003785~003840		
	200~255		Dword	0700~076F	403785~403840		
D	000~256		Word	1000~10FF	404097~404352		
D	256~511		Word	1100~11FF	404353~404608		
D	512~767		Word	1200~12FF	404609~404864		
D	768~1023		Word	1300~13FF	404865~405120		
D	1024~1279		Word	1400~14FF	405121~405376		
D	1280~1535		Word	1500~15FF	405377~405632		
D	1536~1791		Word	1600~16FF	405633~405888		
L	L				<u>i</u>		

			DVP	Modbus
装	範 圍	類別	 通訊位址	通訊位址
置			(Hex)	(Dec)
D	1792~2047	Word	1700~17FF	405889~406144
D	2048~2303	Word	1800~18FF	406145~406400
D	2304~2559	Word	1900~19FF	406401~406656
D	2560~2815	Word	1A00~1AFF	406657~406912
D	2816~3071	Word	1B00~1BFF	406913~407168
D	3072~3327	Word	1C00~1CFF	407169~407424
D	3328~3583	Word	1D00~1DFF	407425~407680
D	3584~3839	Word	1E00~1EFF	407681~407936
D	3840~4095	Word	1F00~1FFF	407937~408192
D	4096~4351	Word	9000~90FF	436865~437120
D	4352~4607	Word	9100~91FF	437121~437376
D	4608~4863	Word	9200~92FF	437377~437632
D	4864~5119	Word	9300~93FF	437633~437888
D	5120~5375	Word	9400~94FF	437889~438144
D	5376~5631	Word	9500~95FF	438145~438400
D	5632~5887	Word	9600~96FF	438401~438656
D	5888~6143	Word	9700~97FF	438657~438912
D	6144~6399	Word	9800~98FF	438913~439168
D	6400~6655	Word	9900~99FF	439169~439424
D	6656~6911	Word	9A00~9AFF	439425~439680
D	6912~7167	Word	9B00~9BFF	439681~439936
D	7168~7423	Word	9C00~9CFF	439937~440192
D	7424~7679	Word	9D00~9DFF	440193~440448
D	7680~7935	Word	9E00~9EFF	440449~440704
D	7936~8191	Word	9F00~9FFF	440705~440960
D	8192~8447	Word	A000~A0FF	440961~441216
D	8448~8703	Word	A100~A1FF	441217~441472
D	8704~8959	Word	A200~A2FF	441473~441728
D	8960~9215	Word	A300~A3FF	441729~441984
D	9216~9471	Word	A400~A4FF	441985~442240
D	9472~9727	Word	A500~A5FF	442241~442496
D	9728~9983	Word	A600~A6FF	442497~442752
D	9984~10239	word	A700~A7FF	442753~443008
D	10234~10495	word	A800~A8FF	443009~443246
D	10496~10751	word	A900~A9FF	443247~443502
D	10752~11007	word	AA00~AAFF	443503~443758

DVP-PLC 应用技术手册 2-151

2 DVP-PLC 各种装置功能

装置	範圍	類別	DVP 通訊位址 (Hex)	Modbus 通訊位址 (Dec)
D	11008~11263	word	AB00~ABFF	443759~444014
D	11264~11519	word	AC00~ACFF	444015~444270
D	11520~11775	word	AD00~ADFF	444271~444526
D	11776~11999	word	AE00~AEDF	444527~444750

DVP-PLC 应用技术手册