
CRR 40PS & CRR 40PS+

TK 50961-4.27



Printed (February 7, 2006)

Copyright @ 2001 - Thermo King Corp. - Minneapolis, MN U.S.A. Electronically printed in U.S.A.

General Information

Tables of Contents

This Parts Manual contains a numerical table of contents listing each assembly name, its associated Grid number and page number. The numerical table of contents is arranged numerically by Grid number. There are references in a parts list referring to other Grid numbers, the numerical table of contents is arranged to facilitate finding the referenced illustrations. At the rear of this parts manual are two indexes, a numerical and alphabetical. The indexes contain all of the part numbers and descriptions which appear in this manual.

Assemblies and Subassemblies

When parts are indented in the description list, they are preceded with a bullet (•). This indicates that the part(s) is available separately or included in an assembly.

GRID NO. 67D6 SWITCH PANEL ASSEMBLY

REF	PART# DESCRIPTION		QTY
	45-1239	PANEL - assy, switch	1
1	99-1960	• PANEL	1
	99-6280	• • NAMEPLATE - panel	1
2	33-743	• GASKET	1


For example: the switch panel nameplate (99-6280) is available separately, available as part of the switch panel (99-1960) and with the panel assembly (45-1239).

ABBREVIATIONS The following abbreviations appear in parts manuals

В	AC	current as required accumulator adjusting aluminum alternator ampere assembly board bearing breaker	F	(continued) evap. evaporator exch exchanger exp expansion ext external F. Farenheit fill fillister fi fuel injection fl flare fpt female pipe thread tt ft feet ftg fitting	O P	os oversized od outside diameter pcb printed circuit
D	C	clockwise counter- clockwise camshaft compressor condenser connecting, connector cylinder defrost degree dehydrator	H I	hex	S	req required rpm revolutions per minute sec second sld solder soc hd solder solder soc hd solenoid spl special sq square ss stainless steel std standard stl steel suct suction sw switch
E	DC	direct current discharge differential Extended Maintenance Interval European Economic Community	N	lg long mm milimeter mpt male pipe thread mod modulating neg negative No number NS not supplied NSS not sold separately	U V	term terminal temp temperature thk thick us undersize vib vibrasorber W watt w/ with w/o without

CRR 40PS & CRR 40PS+ Contents

Name	Grid	Page
CRR 40PS & PS+ REFERENCE SHEET	.6U33	3
AIR VENT (40 FT CONTAINERS)		
DEFROST DRAIN	.143D10	95
HIGH VOLTAGE TRAY	.146D7	61
SOLENOID VALVE		
RECORDING THERMOMETER (OPTION 098025)		
RECORDING THERMOMETER - 31 DAY FAHRENHEIT		
RECORDING THERMOMETER (OPTION 098026)		
THERMOMETER BOX ASSEMBLY		
THERMOMETER - 7 DAY FAHRENHEIT	.147G13	79
TRANSFORMER GROUP (098024, 098040, 098041, 098043,		
098071, 098123, 098128)	.148G2	85
HUMIDITY COMPONENTS (OPTION 098100)		
KVQ VALVE		
EVAPORATOR GROUP (TWO FANS)		
WATER COOLED CONDENSER		
CONDENSER FAN		
CONTROL BOX DOOR (mPC 3000 w/RMM)		
COMPRESSOR GROUP (UNITS w/o SUCTION VALVE)		
HUMIDITY CONTROL (OPTIONS 098104, 098137 & 098188)		
USDA RECEPTACLES	.157H2	65
REMOTE MONITOR OPTION (098182 CSR; 098144 CRR; 098182		
CSR)		
NAMEPLATES		
AFAM MP3000 (OPTION 098166)		
REFRIGERATION COMPONENTS (w/ALCO VALVES		
USDA DOWNLOAD PANEL (DEUTSCH CONNECTORS)		
EVAPORATOR FAN (VARIABLE SPEED)		
EVAPORATOR FAN (POWER SAVER & GAS SENSOR)		
ELECTRICAL COMPONENTS		
CONTROL BOX (HEATER WIRING INSIDE BOX)		
EVAPORATOR PANELS		
USDA DOWNLOAD PANEL		
CONDENSER COMPONENTS (3 FANS)		
REFRIGERATION COMPONENTS (MAERSK)		
LIQUID INJECTION VALVE		
COMPRESSOR GROUP (UNITS w/o SUCTION VALVE)		
DEFROST DRAIN		
CONTROL BOX (HEATER WIRING INSIDE BOX)		
USDA RECEPTACLES		
COMPRESSOR GROUP (UNITS W/o SUCTION VALVE, 098640)		
REFRIGERATION COMPONENTS (CRR40)	.185E4	25



CRR 40PS & PS+ REFERENCE SHEET



B/M	DESCRIPTION	Date
916167	CRR40PS-167	6/00
916168	CRR40PS-168	6/00
916169	CRR40PS-169	6/00
916170	CRR40PS-170	6/00
916174	CRR40PS-174	6/00
916178	CRR40PS-178	6/00
916175	CRR40PS+-175	6/00
916176	CRR40PS+-176	6/00
916177	CRR40PS+-177	6/00
916179	CRR40PS+-179	6/00
916180	CRR40PS+-180	6/00
916185	CRR40S-185	11/00
916188	CRR40PS-188	11/00
916189	CRR40PS+-189	11/00
916190	CRR40PS-190	11/00
916191	CRR40PS-191	3/01
916192	CRR40PS-192	3/01
916193	CRR40PS-193	3/01
916194	CRR40PS-194	3/01
916195	CRR40PS-195	3/01
916196	CRR40PS-196	3/01
916197	CRR40PS-197	3/01
098302	CRR40PS-302	9/01
098303	CRR40PS-303	9/01
098940	CRR40PS	6/00
098942	CRR40	3/03
098950	CRR40PS+	6/00
OPTIONS		
098025	Recording Thermostat	6/00
098026	Recording Thermostat	6/00
098041	Transformer	6/00
098075	Nameplate - Korean	3/00
098106	USDA Sensor	6/00
098125	AFAM MP3000	6/00
098144	Remote Monitor	6/00




CRR 40PS & PS+ REFERENCE SHEET

B/M	DESCRIPTION	Date
098150	Transfresh	6/00
098151	Dehumidity	6/00
098156	USDA Cannon Bayonet	6/00
098158	RMN	11/00
098162	Water Cooled Condenser	6/00
098166	AFAM+	11/00
098171	Dehumidity	6/00
098175	Dehumidity	6/00
098188	Dehumidity	11/00
098190	Dehumidity	11/00
098195	Modem	6/00
098196	Sensor - PT100	6/00











REF	PART#	DESCRIPTION	QTY
1	91-9912	ORIFICE - condenser fan	1
	55-7035	SCREW - orifice	4
	55-3045	WASHER - dome	7
	55-6997	NUT - captive	4
2	78-1173	FAN - condenser (clockwise)	1
	78-1197	FAN - condenser (counter clockwise)	1
	55-8137	SCREW - fan to hub	2
	55-6988	FLATWASHER	2
	55-7066	LOCKWASHER	2
3	104-689	MOTOR - condenser fan	1
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	55-8559	SCREW - motor	4
	55-6988	FLATWASHER	8
	55-7342	LOCKWASHER	4
	55-7339	NUT	4
4	55-5900	GRIP - cable	1
	55-8908	LOCKNUT	1
5	33-367	GROMMET	1
6	41-2953	HARNESS - condenser fan	1
	44-8340	TERMINAL - splice	9
7	33-3044	STRIP - sealing	A/R



EVAPORATOR GROUP (TWO FANS)




REF	PART#	DESCRIPTION	QTY
1	98-5475	HOUSING - evaporator (CRR 119)	1
	98-5918	HOUSING - evaporator (800 & 800A)	1
	98-5919	HOUSING - evaporator (800B)	1
	98-5768	HOUSING - evaporator (CRR 40-300)	1
	98-6213	HOUSING - evaporator (CRR 40-303 & 800D)	1
	98-6657	HOUSING - evaporator (800E & CRR40)	1
2	92-2331	BRACKET - left	2
	92-2779	• BRACKET - left (800E & CRR40)	2
3	92-2332	BRACKET - right	2
	55-9162	RIVET - shroud	10
4	33-3215	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-5900	CONNECTOR - harness & sensor	3
7	78-1117	FAN - evaporator (14 in, 355 mm dia)	2
8	67-1558	COIL - evaporator	1
	67-1923	COIL - evaporator (800E & CRR40)	1
	55-8891	SCREW - coil	9
	55-9217	CAP - tube	3
9	91-9328	BLOCK - coil	2
10	41-3277	HARNESS - fan & heater (800 & 800A)	1
	41-3685	HARNESS - fan (CRR 40-300, units w/o heater door)	1
	41-4018	HARNESS - evap fan (800B & CRR40)	1
11	104-691	MOTOR - fan	2
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	55-6993	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
12	99-4931	NAMEPLATE - arrow	1
13	91-8466	BRACKET - motor	2
	55-8903	SCREW - bracket	8
	55-8904	FLATWASHER	16
	55-7342	LOCKWASHER	8
	55-7339	NUT	8
14	33-2946	GROMMET (37 mm)	5
15	33-3838	GROMMET (22 mm)	2
16	92-2775	COVER - tube	1
	55-7172	SCREW - cover	3
	55-7075	FLATWASHER	3
17	33-367	GROMMET (0.625 id)	3



EVAPORATOR FAN (VARIABLE SPEED)




REF	PART#	DESCRIPTION	QTY
1	98-5768	HOUSING - evaporator	1
2	92-2331	BRACKET - left	2
3	92-2332	BRACKET - right	2
	55-9162	RIVET - shroud	10
4	33-2947	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-8907	CONNECTOR - harness & sensor	3
	55-8908	NUT	3
7	78-1117	FAN - evaporator	2
8	67-1673	COIL - evaporator	1
	55-8891	SCREW - coil	9
	55-9217	CAP - screw	3
9	91-9328	BLOCK - coil	2
10	41-3693	HARNESS - fan	1
11	104-691	MOTOR - fan	2
	55-6993	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
	92-425	NUTSTRIP - motor	4
12	99-4931	NAMEPLATE - arrow	1
13	91-8466	BRACKET - motor	2
	55-8903	SCREW - bracket	8
	55-8904	FLATWASHER	16
	55-7342	LOCKWASHER	8
	55-7339	NUT	8
14	41-3694	HARNESS - pilot, VFD	1
15	41-3695	HARNESS - evap motor, VFD	1
16	41-3696	HARNESS - evap motor, VFD	1
17	45-1931	MODULE - variable fan drive	1
	55-7366	SCREW - module	4
	55-9444	WASHER - insulator	8
	55-7089	FLATWASHER	8
	55-7034	NUT	4
18	33-2946	GROMMET (37 mm)	6
19	33-3838	GROMMET (22 mm)	1





REF	PART#	DESCRIPTION	QTY
1	98-5768	HOUSING - evaporator	1
2	92-2331	BRACKET - left	2
3	92-2332	BRACKET - right	2
	55-9162	RIVET - shroud	10
4	33-3215	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-8907	CONNECTOR - harness & sensor	3
	55-8908	NUT	3
7	78-1117	FAN - evaporator	2
8	67-1673	COIL - evaporator	1
	55-8891	SCREW - coil	9
	55-9217	CAP - screw	3
9	91-9328	BLOCK - coil	2
10	41-3693	HARNESS - fan	1
11	104-691	MOTOR - fan	2
	55-6993	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
12	99-4931	NAMEPLATE - arrow	1
13	91-8466	BRACKET - motor	2
	55-8903	SCREW - bracket	8
	55-8904	FLATWASHER	16
	55-7342	LOCKWASHER	8
	55-7339	NUT	8
14	41-3694	HARNESS - pilot, VFD	1
15	41-3695	HARNESS - evap motor, VFD	1
16	41-3696	HARNESS - evap motor, VFD	1
17	45-1931	MODULE - variable fan drive	1
	55-7366	SCREW - module	4
	55-9444	WASHER - insulator	8
	55-7089	FLATWASHER	8
	55-7034	NUT	4
18	92-456	BRACKET - sensor	1
	55-7035	SCREW - sensor	2
	55-7075	FLATWASHER	2
	55-8877	WASHER - insulating	2
19	41-3409	SENSOR - gas	1
20	11-4367	HOSE - sensor (1/4 od x 35 ft lg)	A/R
21	92-457	VENT	1
22	92-458	FILTER - gas sensor	1
23	33-2946	GROMMET (37 mm)	6




 $^{Revised}_{5/29/02}$ EVAPORATOR FAN (POWER SAVER & GAS SENSOR)



REF	PART#	DESCRIPTION	QTY
24	33-3838	GROMMET (22 mm)	1






Revised 4/16/03

REFRIGERATION COMPONENTS (w/ALCO VALVES



REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (CRR 40, see 157G4)	1
2	60-285	COIL - condenser	1
	33-2949	GASKET - coil	A/R
	55-8910	SCREW - coil	7
	55-6995	FLATWASHER	7
	55-9054	WASHER (nylon)	7
3	67-1651	TANK - receiver	1
4	66-9893	TUBE - condenser to receiver	1
5	66-9894	TUBE - receiver to condenser	1
6	506-364	PLUG - fusible	1
7	66-8811	SIGHT GLASS	1
8	33-3007	GASKET	5
9	61-152	TUBE - condenser to indicator	1
10	61-151	VALVE - shutoff	1
	509-1635	BRACKET - valve	1
	55-7843	SCREW - valve	2
	505-603	WASHER	2
11	61-153	TUBE - valve to dehydrator	1
12	66-9307	DEHYDRATOR	1
	55-4390	HANGER - dehydrator	1
	91-8620	LABEL - dehydrator	1
13	55-8938	CLAMP - dehydrator	1
	55-8891	SCREW - bracket	2
14	506-369	TUBE - discharge	1
15	66-8467	VALVE - check	1
16	506-370	TUBE - discharge	1
17	61-292	TUBE - transition	1
18	61-291	TUBE - transition	1
19	66-9163	KVQ - actuator (see 151A5)	1
20	61-145	TUBE - heat exchanger to dehydrator	1
	55-8951	SHOULDER - seal	1
	55-8950	NUT - shoulder	1
21	66-9071	TUBE - KVQ to compressor	1
22	61-726	TUBE - exchanger to KVQ	1
23	67-1650	HEAT EXCHANGER	1
24	61-293	TUBE - evaporator to exchanger	1
25	61-144	TUBE - solenoid to KVQ	1
26	66-9866	VALVE - solenoid (less coil pulse, Alco, see 166F6)	1
27	61-150	TUBE - valve to tee	1
28	55-6218	TEE	1
29	61-149	VALVE - solenoid (less coil, Alco)	1
30	61-296	TUBE - valve to exchanger	1






Revised 4/16/03


REFRIGERATION COMPONENTS (W/ALCO VALVES



REF	PART#	DESCRIPTION	QTY
31	66-9900	VALVE - expansion (or use kit 60-253)	1
32	66-9035	TUBE - valve to tee	1
33	55-2296	TEE	1
34	66-9868	TUBE - tee to valve	1
35	41-3303	VALVE - solenoid (dehumidifier, option 098151, Alco)	1
	41-3301	COIL - valve	1
36	61-146	TUBE - valve to coil	1
37	61-147	TUBE - tee to coil	1
38	67-1673	COIL - evaporator (see 160F8 or 160F9)	1
39	66-9062	TUBE - valve replacement	1
40	66-9075	TUBE - equalizer	1
41	66-9164	TUBE - tee to valve	1
42	66-9210	TUBE - valve to tee	1




REFRIGERATION COMPONENTS (MAERSK)



REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (see 157G4, before 1/01)	1
2	67-1632	COIL - condenser (800, 800A/B/C)	1
	60-285	COIL - condenser (800D)	1
	99-5966	STRIP - gasket (15 x 15 mm)	A/R
	33-2950	GASKET (10 x 15 mm)	A/R
	55-8910	SCREW - coil	7
	55-6995	FLATWASHER	7
	55-9054	WASHER (nylon)	7
3	66-9875	TUBE - top (800, 800A/B/C)	1
	61-1305	TUBE - top (800D)	1
4	66-9874	TUBE - bottom (800, 800A/B/C/D)	1
5	67-1575	TANK - condenser (800, 800A/B/C/D, see 154E13)	1
6	506-375	TUBE - condenser to indicator	1
7	66-9125	VALVE - shutoff	1
8	61-698	TUBE - dehydrator to valve (119, 800, 800A)	1
	61-695	TUBE - dehydrator to valve (800B/C/D)	1
9	66-9015	DEHYDRATOR	1
10	55-4390	HANGER - dehydrator	2
	55-8891	SCREW - bracket	2
11	506-369	TUBE - discharge	1
12	66-8467	VALVE - check	1
13	506-370	TUBE - discharge	1
14	504-1418	TUBE - temperature sensor to compressor (800, 800A/B/C)	1
15	66-9163	KVQ - valve (see 146E6)	1
16	61-696	TUBE - exchanger to dehydrator	1
17	61-697	TUBE - KVQ to compressor (800B/C/D)	1
18	61-726	TUBE - exchanger to KVQ	1
19	67-1650	HEAT EXCHANGER (800B/C/D)	1
20	61-293	TUBE - evaporator to exchanger	1
21	61-727	TUBE - solenoid to KVQ	1
22	66-9168	VALVE - solenoid (pulse, Danfass valve, see 166F6)	1
23	66-9214	TUBE - valve to tee	1
24	55-6218	TEE	1
25	66-9167	VALVE - solenoid (liquid, normally closed, see 146E5, Danfass valve)	
26	66-9085	TUBE - valve to exchanger (119, 800, 800A)	1
	61-1316	TUBE - valve to exchanger (800C/D)	1
	61-725	TUBE - valve to exchanger (800B)	1
27	66-9900	VALVE - expansion (or use Kit 60-253 for replacement of brass valves)	1
	61-2990	VALVE - cpr	1
	61-2237	VALVE - pressure regulator	1






REFRIGERATION COMPONENTS (MAERSK)




REF	PART#	DESCRIPTION	QTY
	61-2285	• COUPLING (1-1/8)	1
28	66-9164	TUBE - valve to tee	1
29	55-2296	TEE	1
30	66-9868	TUBE - tee to valve	1
31	66-9032	VALVE - solenoid (humidity control, normally open, Danfass valve)	1
32	61-295	TUBE - valve to coil (800B)	1
	61-724	TUBE - valve to coil (800C/D)	1
33	61-294	TUBE - tee to coil (800B)	1
	61-723	TUBE - tee to coil (800C/D)	
34	67-1532	COIL - evaporator (units w/ 3 evap fans, see 150G3)	1
	67-1806	COIL - evaporator (8/01 & after, 800, 800A/C/D)	1
	67-1673	COIL - evaporator (800B)	1
	67-1558	COIL - evaporator (before 7/01, units w/ 2 evap fans, 800A/C/D, see 152C1)	1
35	55-2299	BUSHING (5/8-1/2)	1
37	66-9075	TUBE - equalizer (119, 800, 800A/B)	1
	61-1307	TUBE - equalizer (800C/D)	1
38	66-9035	TUBE - solenoid to tee	1



REFRIGERATION COMPONENTS (CRR40)




REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (see 185E3)	1
	55-8911	SCREW - compressor	4
	55-137	FLATWASHER	4
	55-7360	FLATWASHER	4
	55-8992	NUT - hexagon	4
2	60-285	COIL - condenser	1
	33-2950	GASKET (10 x 15 mm)	A/R
	55-7035	SCREW - coil	6
	51-167	FLATWASHER	6
	55-9054	WASHER - insulator	6
3	67-1945	RECEIVER - tank compressor	1
4	506-388	INDICATOR - liquid	1
	33-3007	GASKET - o-ring	1
5	506-364	PLUG - fusible	1
6	66-6610	FITTING - high side	4
	55-9027	WASHER - insulating	4
	55-7075	FLATWASHER	2
	55-7347	LOCKWASHER	2
	51-273	NUT	2
7	61-2219	TUBE - discharge to compressor	1
8	61-2220	TUBE - discharge valve to compressor	1
9	61-2221	TUBE - KVQ to compressor	1
10	504-980	VALVE - KVQ (see 151A5)	1
	55-2331	BANDWRAP - valve	7
11	61-2222	TUBE - heat exchanger to KVQ	1
	51-627	CLAMP - tube	2
	55-9759	SCREW - clamp	2
	51-167	FLATWASHER - insulating	2
12	61-2223	VALVE - solenoid liquid injection	1
	41-5460	COIL - valve	1
13	67-1943	HEAT - exchanger	1
14	61-2224	TUBE - drier to heat exchanger	1
15	61-786	DEHYDRATOR (w/o-rings)	1
16	55-4390	HANGER - dehydrator	1
	55-7035	SCREW - hanger	2
	55-9054	WASHER - insulating	2
	51-167	FLATWASHER	2
	55-8316	SCREW - dehydrator	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
17	66-9125	VALVE - shutoff	1
18	61-2225	TUBE - check valve to dehydrator	1



REFRIGERATION COMPONENTS (CRR40)




REF	PART#	DESCRIPTION	QTY
19	61-2226	TUBE - suction to evaporator	1
20	61-2227	TUBE - liquid injection	1
21	61-2228	VALVE - solenoid	1
22	41-5460	COIL - valve	1
23	55-6218	TEE (1/2 x 3/8 x 3/8)	1
24	61-2229	TUBE - liquid to evaporator	1
25	55-2296	TEE (1/2)	1
26	61-2051	TUBE - tee to distributor	2
27	61-1626	VALVE - expansion	1
28	61-2048	TUBE - equalizer	1
29	61-2049	TUBE - expansion valve to tee	1
30	61-2050	TUBE - expansion valve to inlet	1
31	67-1923	COIL - evaporator	1
32	61-2238	TUBE - condenser coil to receiver	1
33	61-2239	TUBE - receiver tank to valve	1
34	66-8467	VALVE - check	1



COMPRESSOR GROUP (UNITS w/o SUCTION VALVE)



REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (CRR 40)	1
2	22-1051	KIT - valve plate	1
3	33-2510	•• GASKET - valve plate	1
4	502-240	•• KIT - reed suction	1
5	503-278	•• GASKET - cylinder head	1
6	22-1051	KIT - valve plate	1
	203-516	OIL - compressor	A/R
7	22-1186	ADAPTER - discharge	1
	55-2747	SCREW - adapter	2
	55-2159	LOCKWASHER	2
	55-2173	FLATWASHER	2
8	33-2548	GASKET - adapter/suction	1
9	33-981	GASKET - valve	1
10	66-9377	VALVE - discharge	1
11	66-6610	ADAPTER - service (highside)	1
	66-7182	CAP - adapter (red)	1
12	506-161	CAP - discharge valve	1
13	22-1099	FLANGE - suction	1
14	55-2976	SCREW - flange	2
15	55-2173	FLATWASHER	2
16	66-8054	ADAPTER (lowside)	1
17	66-6607	FITTING - service (lowside)	1
18	66-7183	CAP - fitting	1
19	41-2447	SENSOR - head temperature	1
20	509-1153	LABEL - compressor oil	1
21	22-398	SIGHT GLASS - oil	1
	33-2222	GASKET - sight glass	1
22	44-6360	SWITCH - hpco	1
22	41-3302	SWITCH - hpco	1
23	55-459	COUPLING - switch	1
24	41-3701	CABLE - compressor	1
25	55-5257	FITTING - harness	1
26	55-8911	SCREW - compressor (50 mm)	4
	55-8912	FLATWASHER	4
	55-8992	NUT	4
27	91-6435	ANGLE - lifting	1
	55-2505	ELBOW	1
28	33-3175	GASKET - discharge (rubberized)	1
29	92-1682	BOX - junction (plastic)	1
30	02-7043	KIT - spacer	1




$^{Revised}_{12/10/03}$ COMPRESSOR GROUP (UNITS w/o SUCTION VALVE)



REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (3DS 460V)	1
	203-516	OIL - compressor	A/R
2	22-1186	ADAPTER - discharge	1
	55-2747	SCREW - adapter	2
	55-2159	LOCKWASHER	2
	55-2173	FLATWASHER	2
3	33-2548	GASKET - suction adapter	2
4	33-981	GASKET - valve	1
5	66-9377	VALVE - discharge	1
6	66-6610	ADAPTER - service (highside)	1
	66-7182	CAP - adapter (red)	1
7	506-161	CAP - discharge valve	1
8	22-1099	FLANGE - suction	1
9	55-2976	SCREW - flange	2
10	55-2173	FLATWASHER	2
11	66-8054	ADAPTER (lowside)	1
12	66-6607	FITTING - service (lowside)	1
13	66-7183	CAP - fitting	1
14	41-2447	SENSOR - head temperature	1
15	509-1153	LABEL - compressor oil	1
16	22-398	SIGHT GLASS - oil	1
	33-2222	GASKET - sight glass	1
17	44-6360	SWITCH - hpco	1
	41-3302	SWITCH - hpco	1
18	55-459	COUPLING - switch	1
19	41-3701	CABLE - compressor	1
20	55-5257	FITTING - harness	1
21	55-8911	SCREW - compressor (50 mm)	4
	55-8912	FLATWASHER	4
	55-8992	NUT	4
22	91-6435	ANGLE - lifting	1
	55-2505	ELBOW	1






COMPRESSOR GROUP (UNITS w/o SUCTION VALVE, 098640)




REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (CRR 40)	1
2	22-1051	KIT - valve plate	1
3	33-2510	•• GASKET - valve plate	1
4	502-240	•• KIT - reed suction	1
5	503-278	•• GASKET - cylinder head	1
6	22-1051	• KIT - valve plate	1
	203-516	OIL - compressor	A/R
7	22-1186	ADAPTER - discharge	1
•	55-2747	SCREW - adapter	2
	55-2159	LOCKWASHER	2
	55-2173	FLATWASHER	2
8	33-3175	GASKET - adapter/suction	1
9	33-981	GASKET - valve	1
10	66-9377	VALVE - discharge	1
11	66-6610	ADAPTER - service (highside)	1
	66-7182	• CAP - adapter (red)	1
12	506-161	CAP - discharge valve	1
13	22-1187	FLANGE - suction	1
14	55-2747	SCREW - flange	2
	55-2159	LOCKWASHER	2
15	55-2173	FLATWASHER	2
16	66-8054	ADAPTER (lowside)	1
17	66-6607	FITTING - service (lowside)	1
18	66-7183	• CAP - fitting	1
19	41-4300	SENSOR - head temperature	1
20	509-1153	LABEL - compressor oil	1
21	22-398	SIGHT GLASS - oil	1
	33-2222	GASKET - sight glass	1
22	44-6360	SWITCH - hpco	1
	41-3302	SWITCH - hpco	1
23	55-459	COUPLING - switch	1
24	41-4015	CABLE - compressor	1
25	55-5257	FITTING - harness	1
26	51-137	SCREW - compressor (50 mm)	4
	55-7360	FLATWASHER	4
	55-8992	NUT	4
27	91-6435	ANGLE - lifting	1
	55-2505	ELBOW	1
28	22-1161	POCKET - sensor	1
29	92-1682	BOX - junction (plastic, Maersk only)	1
30	33-3175	GASKET - discharge (rubberized)	1

Revised 9/2/03


DANFOSS





REF	PART#	DESCRIPTION	QTY
1	66-9167	VALVE - liquid line (less coil, normally closed, Danfoss)	1
2	41-5460	COIL - valve	1
	41-2399	COIL - valve (2 pin connector, gray, Danfoss)	1
3	504-977	KIT - repair (normally closed)	1
4	66-9032	VALVE - dehumidifier (less coil, normally open, Danfoss)	1
5	504-922	KIT - repair (normally open)	1
6	41-3303	VALVE - dehumidifier (less coil, normally open, Alco)	1
	66-9867	VALVE - liquid line (less coil, normally closed, Alco)	1
7	61-149	VALVE - liquid line (less coil, normally closed, Alco)	1
8	41-3301	COIL - valve (2.2 meter leads)	1
	41-3301	COIL - valve (2.2 meter leads w/ pin terminals)	1
9	41-3592	COIL - valve (200 mm leads w/ pin connector, white band)	1
	40-782	COIL - valve (200 mm leads w/ pin connectors, green band)	1







WATER COOLED CONDENSER




REF	PART#	DESCRIPTION	QTY
1	67-1575	TANK - water cooled condenser	1
2	66-8811	INDICATOR	1
3	33-3007	O-RING	1
4	66-6610	FITTING - high side	1
5	66-7182	CAP - fitting	1
6	506-364	PLUG - fusible	1
	203-393	SEALER - locking	A/R
	51-1467	SCREW - tank	4
	51-1429	LOCKWASHER	4
	51-1430	FLATWASHER	4
7	66-4788	COUPLING - outlet	1
	203-385	SEALER - removable	A/R
8	91-6627	CAP - dust cover	1
9	55-1827	PLUG - outlet	1
10	91-6628	CAP - dust cover	1
11	61-3504	TUBE - condenser to filter	1
12	61-3525	VALVE - ball	1
13	61-3542	TUBE - valve to dehydrator	1
14	61-1305	TUBE - condenser to condenser	1
15	91-759	CLAMP - tube	2
	51-1462	SCREW - clamp	1
16	55-6730	CLAMP - tube	6
	55-7035	SCREW - clamp	2
	51-167	FLATWASHER	4
17	66-7543	TUBE - stub (1.88 lg)	1
18	66-9447	TUBE - stub (2.25 lg)	1



REF	PART#	DESCRIPTION	QTY
1	66-9163	VALVE - KVQ	1
2	504-980	• ACTUATOR	1
3	41-2603	HARNESS (before 10/02)	1
	41-5420	HARNESS (after 9/02)	1
4	503-291	GASKET	1






LIQUID INJECTION VALVE



REF	PART#	DESCRIPTION	QTY
1	66-8367	VALVE - liquid injection (w/ coil, 24V, 0.034 orifice, Alco, use on mP-D units only)	1
	66-9866	VALVE - liquid injection (w/o coil, .034 orifice, Alco)	1
2	66-8721	VALVE - liquid injection (w/ coil, 24V, 0.075 orifice, Alco)	1
	66-9195	VALVE - liquid injection (w/ coil, 24V, 0.110 orifice, Alco)	1
	66-9953	VALVE - bypass (w/o coil, 0.110 orifice, Alco used on units w/ modulation valves)	1
	61-681	VALVE - bypass (w/o coil, 0.075 orifice, Alco used on units w/ stepper & modulation valves)	1
3	41-3301	COIL - valve (24V, 2.2 m leads, ALCO)	1
	41-3301	COIL - valve (24V, 2.2 m leads w/ pin terminals, ALCO)	1
4	41-3592	COIL - valve (24V, 200 mm leads w/ 2 pin connector, white, ALCO)	
	40-782	COIL - valve (24V, 200 mm leads w/ 2 pin connector, green, ALCO)	
5	66-9168	VALVE - liquid injection (w/o coil, Danfoss)	1
6	61-2351	VALVE - warm gas bypass (w/o coil, Danfoss)	1
7	61-2223	VALVE - liquid injection (CRR, w/o coil, Danfoss)	1
8	41-2399	COIL - liquid line valve (24V, w/ 2 pin connector, gray, Danfoss)	1
9	41-5460	COIL (24V, 2.2 meter leads, Danfoss)	1






Revised 12/12/05

HUMIDITY CONTROL (OPTIONS 098104, 098137 & 098188)




REF	PART#	DESCRIPTION	QTY
1	41-3303	VALVE - solenoid (humidity control)	1
	41-3301	• COIL	1
2	66-9159	TUBE (replaces valve)	1
3	41-5635	SENSOR - humidity	1
	41-2838	HARNESS - sensor	1
4	55-1203	CLAMP - sensor	2
	55-8991	SPACER - clamp	2
	55-9173	SCREW - clamp	2



HUMIDITY COMPONENTS (OPTION 098100)




REF	PART#	DESCRIPTION	QTY
1	11-9085	COMPRESSOR - humidity	1
2	91-9002	PLATE - compressor	1
3	55-7339	NUT - compressor	4
	55-7085	FLATWASHER	4
4	55-2561	NIPPLE - compressor to nozzle	1
5	11-9084	NOZZLE - liquid spray	1
6	11-4860	ELBOW - hose (1/4)	2
7	10-243	KIT - sleeve & eyelet (1/4)	2
8	11-4841	NUT - hose (1/4)	2
9	11-4367	HOSE - supply & over flow (1/4 od x 35 ft lg)	A/R
10	41-3117	HARNESS - humidity compressor	2
11	41-5635	SENSOR - humidity	1
12	91-9003	FILTER	1
	91-6236	SCREEN	1
	91-6237	ADAPTER - outlet	1
13	55-6905	FITTING - barb (1/2 mpt, poly)	1
14	11-8983	HOSE - drain	2
15	55-9208	CONNECTOR - T-hose	1
16	11-9082	TANK - humidity	1
17	11-9083	CAP - tank	1
18	41-2691	HARNESS - tank heater	1
19	55-9149	SPACER - tank	4
20	55-4359	NIPPLE	1
21	55-7151	DRAIN COCK	1



ELECTRICAL COMPONENTS



77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 61-2223 VALVE - solenoid, liquid injection (800E) 1	REF	PART#	DESCRIPTION	QTY
2 41-4300 SENSOR - compressor 1 3 41-5635 SENSOR - humidity (800E) 1 4 41-5635 SENSOR - humidity (800E) 1 4 41-2838 HARNESS - sensor (humidity, see 147G12) 1 5 91-9754 POCKET - sensor 1 6 NSS BOX - control (see 16062 & 14607) 1 7 NSS PANEL - USDA receptacle (see 157H2, 185D6 & 158E2) 1 8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 200 mm leads) 6 45-1927 HEATER (680W, 200 mm leads) 6 45-1927 HEATER (680W, 200 mm leads) 6 10 91-8142 BRACKET - heater 2 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1	1	40-791	KIT - sensor (universal)	A/R
3 41-5635 SENSOR - humidity (see 147G12) 1 4 41-5635 SENSOR - humidity (800E) 1 4 41-2838 HARNESS - sensor (humidity, see 147G12) 1 5 91-9754 POCKET - sensor 1 6 NSS BOX - control (see 160G2 & 146D7) 1 7 NSS PANEL - USDA receptacle (see 157H2, 185D6 & 158E2) 1 8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1499 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 2 12 91-8142 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 41-3685 HARNESS - evaporator (800 & 800A) 1 41-3695 HARNESS - evaporator (980 & 800A) 1 </td <td></td> <td>51-270</td> <td>CONNECTOR - liquid tite</td> <td>1</td>		51-270	CONNECTOR - liquid tite	1
41-5635 SENSOR - humidity (800E) 1 4 41-2838 HARNESS - sensor (humidity, see 147G12) 1 5 91-9754 POCKET - sensor 1 6 NSS BOX - control (see 160G2 & 146D7) 1 7 NSS PANEL - USDA receptacle (see 157H2, 185D6 & 158E2) 1 8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 20 meter leads) 6 10 91-8140 SPRING - heater 2 11 91-8142 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 14 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator (GRA 40-300) 1 15 66-9167 VALVE - solenoid (800E) 1 16 66-9168 VALVE - solenoid (800E) 1 17 66-9032 VALVE - solenoid (1ess coil, see 145E5) 1 18 66-9163 VALVE - solenoid (1ess coil, see 147G12) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 22 41-4015 CABLE - power (19.2 meters, 73 ft) 1 24 45-1942 CABLE - power (12.2 meters, 73 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable	2	41-4300	SENSOR - compressor	1
4 41-2838 HARNESS - sensor (humidity, see 147G12) 1 5 91-9754 POCKET - sensor 1 6 NSS BOX - control (see 160G2 & 146D7) 1 7 NSS BOX - control (see 160G2 & 146D7) 1 8 104-691 MOTOR - fan 2 8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1491 • BEARING - shaft end 1 9 45-1921 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 10 91-8142 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-4018 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator (700 & 800A) 1 41-4018 HARNESS - evaporator (700 & 800A) 1 <t< td=""><td>3</td><td>41-5635</td><td>SENSOR - humidity (see 147G12)</td><td>1</td></t<>	3	41-5635	SENSOR - humidity (see 147G12)	1
5 91-9754 POCKET - sensor 1 6 NSS BOX - control (see 160G2 & 146D7) 1 7 NSS PANEL - USDA receptacle (see 157H2, 185D6 & 158E2) 1 8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 600 mm leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 41 41-3227 HARNESS - evaporator (800 & 800A) 1 41-4018 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator (600 & 800 & 800A) 1 41-4018 HARNESS - evaporator (for R4 0-300) 1		41-5635	SENSOR - humidity (800E)	1
6 NSS BOX - control (see 160G2 & 146D7) 1 7 NSS PANEL - USDA receptacle (see 157H2, 185D6 & 158E2) 1 8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1491 • BEARING - spopsite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (7CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800 & CRR40) 800 & CRR40) 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (less coil, see 166F6) 1 16 66-9168 <	4	41-2838	HARNESS - sensor (humidity, see 147G12)	1
7 NSS PANEL - USDA receptacle (see 157H2, 185D6 & 158E2) 1 8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (700 & 800A) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800 & CR40) 800 & CR40) 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (less coil, see 166F6) 1 16 66-9168 VALVE - solenoid, liquid injection (800E) 1 17 66-9032	5	91-9754	POCKET - sensor	1
8 104-691 MOTOR - fan 2 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (280 & 800A) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - solenoid, liquid injection (800E) 1 17 66-9032 VALVE - solenoid, liquid injection (800E) 1 18 66-9163 VALVE - solenoid, liquid injection (800E) 1 18 66-9163	6	NSS	BOX - control (see 160G2 & 146D7)	1
77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800 &	7	NSS	PANEL - USDA receptacle (see 157H2, 185D6 & 158E2)	1
77-1401 • BEARING - opposite end 1 9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800 & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 16 66-9168 VALVE - solenoid (less coil, see 145E5) 1 16 66-9168 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) <t< td=""><td>8</td><td>104-691</td><td>MOTOR - fan</td><td>2</td></t<>	8	104-691	MOTOR - fan	2
9 45-1791 HEATER (680W, 600 mm leads) 6 45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 15 41-3685 HARNESS - evaporator (700 RR 40-300) 1 16 41-4018 HARNESS - evaporator (100 RR 40-300) 1 17 41-4018 HARNESS - evaporator (100 RR 40-300) 1 18 66-9167 VALVE - solenoid (less coil, see 145E5) 1 19 61-2228 VALVE - solenoid (800E) 1 10 66-9168 VALVE - solenoid (800E) 1 11 66-9032 VALVE - solenoid (less coil, see 166F6) 1 18 66-9163 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 25 41-1976 PLUG - power 1 26 92-270 BRACKET - cable restraint 1 27 55-9164 SCREW - cable 1		77-1498	BEARING - shaft end	1
45-1927 HEATER (680W, 2 meter leads) 6 10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-4018 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (less coil, see 145E5) 1 16 66-9168 VALVE - solenoid (less coil, see 166F6) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 19 8102-743 COMPRESSOR (see 155C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 <td< td=""><td></td><td>77-1401</td><td>BEARING - opposite end</td><td>1</td></td<>		77-1401	BEARING - opposite end	1
10 91-8140 SPRING - heater 6 11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (less coil, see 145E5) 1 16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - kVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1	9	45-1791	HEATER (680W, 600 mm leads)	6
11 91-8467 BRACKET - heater 2 12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 8008 & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (less coil, see 145E5) 1 16 66-9168 VALVE - solenoid (less coil, see 166F6) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - kVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 <t< td=""><td></td><td>45-1927</td><td>HEATER (680W, 2 meter leads)</td><td>6</td></t<>		45-1927	HEATER (680W, 2 meter leads)	6
12 91-8142 BRACKET - heater 1 13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - solenoid (less coil, see 166F6) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 19 8102-743 COMPRESSOR (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan	10	91-8140	SPRING - heater	6
13 41-3401 THERMOSTAT - defrost termination 1 14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - solenoid (less coil, see 166F6) 1 17 66-9032 VALVE - solenoid, liquid injection (800E) 1 18 66-9163 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - kVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1	11	91-8467	BRACKET - heater	2
14 41-3277 HARNESS - evaporator (800 & 800A) 1 41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 17 66-9168 VALVE - solenoid, liquid injection (800E) 1 17 66-9163 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1	12	91-8142	BRACKET - heater	1
41-3685 HARNESS - evaporator (CRR 40-300) 1 41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 61-2223 VALVE - solenoid, liquid injection (800E) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 25 41-1976 • PLUG - power 1 26	13	41-3401	THERMOSTAT - defrost termination	1
41-4018 HARNESS - evaporator fan (2 fan units w/o heater doors, 800B & CRR40) 1 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 61-2223 VALVE - solenoid, liquid injection (800E) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 <td< td=""><td>14</td><td>41-3277</td><td>HARNESS - evaporator (800 & 800A)</td><td>1</td></td<>	14	41-3277	HARNESS - evaporator (800 & 800A)	1
800B & CRR40) 15 66-9167 VALVE - solenoid (less coil, see 145E5) 1 61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 61-2223 VALVE - solenoid, liquid injection (800E) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 26 92-277 BRACKET - power cable (800E & CRR40) 1 </td <td></td> <td>41-3685</td> <td>HARNESS - evaporator (CRR 40-300)</td> <td>1</td>		41-3685	HARNESS - evaporator (CRR 40-300)	1
61-2228 VALVE - solenoid (800E) 1 16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 61-2223 VALVE - solenoid, liquid injection (800E) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1 </td <td></td> <td>41-4018</td> <td></td> <td>1</td>		41-4018		1
16 66-9168 VALVE - liquid injection (less coil, see 166F6) 1 61-2223 VALVE - solenoid, liquid injection (800E) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	15	66-9167	VALVE - solenoid (less coil, see 145E5)	1
61-2223 VALVE - solenoid, liquid injection (800E) 1 17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 25 41-1976 • PLUG - power 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1		61-2228	VALVE - solenoid (800E)	1
17 66-9032 VALVE - solenoid (less coil, dehumidity, see 147G12) 1 18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	16	66-9168	VALVE - liquid injection (less coil, see 166F6)	1
18 66-9163 VALVE - KVQ (see 151A5) 1 19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1		61-2223	VALVE - solenoid, liquid injection (800E)	1
19 8102-743 COMPRESSOR (see 165C9 & 185E3) 1 20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	17	66-9032	VALVE - solenoid (less coil, dehumidity, see 147G12)	1
20 41-3302 SWITCH - hpco 1 21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	18	66-9163	VALVE - KVQ (see 151A5)	1
21 104-689 MOTOR - condenser (see 155D4) 1 77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	19	8102-743	COMPRESSOR (see 165C9 & 185E3)	1
77-1498 • BEARING - shaft end 1 77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	20	41-3302	SWITCH - hpco	1
77-1401 • BEARING - opposite end 1 22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	21	104-689	MOTOR - condenser (see 155D4)	1
22 41-4015 CABLE - compressor 1 23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1		77-1498	BEARING - shaft end	1
23 41-2953 HARNESS - condenser fan 1 24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1		77-1401	BEARING - opposite end	1
24 45-1942 CABLE - power (22.3 meters, 73 ft) 1 45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	22	41-4015	CABLE - compressor	1
45-1992 CABLE - power (19.2 meters, 63 ft) 1 25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	23	41-2953	HARNESS - condenser fan	1
25 41-1976 • PLUG - power 1 26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	24	45-1942	CABLE - power (22.3 meters, 73 ft)	1
26 92-270 BRACKET - cable restraint 1 92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1		45-1992	CABLE - power (19.2 meters, 63 ft)	1
92-2777 BRACKET - power cable (800E & CRR40) 1 55-9164 SCREW - cable 1	25	41-1976	• PLUG - power	1
55-9164 SCREW - cable 1	26	92-270	BRACKET - cable restraint	1
		92-2777	BRACKET - power cable (800E & CRR40)	1
55-7357 FLATWASHER 1		55-9164	SCREW - cable	1
		55-7357	FLATWASHER	1




ELECTRICAL COMPONENTS



REF	PART#	DESCRIPTION	QTY
	55-7344	NUT	1
	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4


NOTE: Use Universal Sensor Kit 40-791 to repair all sensors except 41-3594, 41-4156 & 41-4300.





REF	PART#	DESCRIPTION	QTY
1	92-236	BRACKET - diagram	1
	55-3272	RIVET - bracket	4
2	92-237	BRACKET (w/ receptacle)	2
	55-2074	NUT - speed	1
	55-9166	SCREW - bracket	4
	55-9444	WASHER - insulating (nylon)	4
3	845-2834	BOARD - relay (MP3000)	1
	55-9166	SCREW - relay board	6
4	504-514	RELAY - power	6
	92-860	CLIP - relay	6
5	504-970	FUSE (20 amp)	3
6	41-3430	HOLDER - fuse	1
7	41-3402	CABLE - retriever plug	1
	55-3272	RIVET - plug	4
	505-416	CAP - plug	1
8	92-238	HINGE - cover	2
	55-7172	SCREW - hinge	4
	55-8877	WASHER (nylon)	4
	509-955	INSULATOR	2
	55-6995	WASHER	2
	505-566	LOCKWASHER	2
	55-7042	NUT	4
9	505-408	PLUG - seal	3
10	91-9833	NAMEPLATE - Caution	1
11	92-244	NAMEPLATE - on/off	1
12	55-5885	CONNECTOR - liquid tite	1
13	55-8907	FITTING - harness	5
14	55-5257	FITTING - harness	2
15	41-3595	SWITCH - unit on/off	1
	92-239	BOOT - switch	1
16	41-3276	BREAKER - circuit	1
	44-8688	BOOT - circuit breaker	1
	41-2832	CONNECTOR - plug (2 pin)	1
17	41-3596	BLOCK - terminal (4 pole)	1
	41-3597	BLOCK - terminal (5 pole)	1
	41-3598	BLOCK - terminal (8 pole)	1
	41-3851	BLOCK - terminal (12 pole)	1
	41-3599	BLOCK - terminal (14 pole)	1
	41-3608	BLOCK - terminal (18 pole)	1
18	NSS	DOOR - controller (see 158D7)	1
19	203-509	BATTERY (12V, 1.9 AH)	1
20	33-3043	GASKET - cover	1






Revised 12/2/03



REF	PART#	DESCRIPTION	QTY
21	33-3838	GROMMET	1
22	55-9401	PLUG - seal	3
23	98-5454	BOX - control	1
	55-6994	SCREW - control box	4
	55-7075	FLATWASHER	4
	55-9054	WASHER - insulator	4
24	33-3215	GROMMET	3
25	NSS	TRAY - high voltage (see 158A1 or 146D7)	1
26	309-3066	RAIL - terminal block	1
	55-7169	SCREW - rail	2
	55-7033	FLATWASHER	2
	55-9445	WASHER - insulator	2
	55-7034	NUT	2
27	41-3687	TERMINAL - stop clip	2
28	41-3702	PLATE - end terminal	1
29	41-3688	BLOCK - terminal (UK, heaters)	6
30	41-3703	CONNECTOR - cross	1
31	41-3335	CABLE - battery	1








REF	PART#	DESCRIPTION	QTY
1	92-236	BRACKET - diagram	1
	55-3272	RIVET - bracket	4
2	92-237	BRACKET (w/receptacle)	2
	55-2074	• NUT - speed	4
	55-9166	SCREW - bracket	4
	55-9444	WASHER - insulating (nylon)	4
3	45-2010	BOARD - relay (MP3000)	1
	51-336	SCREW - relay board	6
4	504-514	RELAY - power	6
	92-860	CLIP - relay	6
5	504-970	FUSE (20A)	3
6	41-3430	HOLDER - fuse	3
7	41-3402	CABLE - retriever plug	1
	55-9322	RIVET - plug	4
	41-2406	CAP - plug	1
	99-3685	CHAIN - cap	1
8	92-238	HINGE - cover	2
	55-7172	SCREW - hinge	4
	55-8877	WASHER (nylon)	4
	51-618	INSULATOR	2
	55-7075	WASHER	2
	55-7378	LOCKWASHER	2
	55-7042	NUT	2
9	41-2833	PLUG - seal	2
10	91-9833	NAMEPLATE - Caution	1
11	92-244	NAMEPLATE - On/Off	1
12	41-3686	CONNECTOR - liquid tite	1
13	55-5900	FITTING - harness	5
14	55-5257	FITTING - harness	2
15	41-3595	SWITCH - unit on/off	1
	92-239	BOOT - switch	1
16	51-629	PLUG - seal	3
17	41-2832	CONNECTOR - plug (2 pin, short circuit)	1
	504-327	PLUG (2 pole)	1
	41-3596	BLOCK - terminal (4 pole)	1
	41-3597	BLOCK - terminal (5 pole)	1
	41-3598	BLOCK - terminal (8 pole)	1
	41-3851	BLOCK - terminal (12 pole)	1
	41-3599	BLOCK - terminal (14 pole)	1
	41-3608	BLOCK - terminal (18 pole)	1
18	NSS	DOOR - controller (see 157D7)	1
19	203-509	BATTERY (12V, 1.9 AH)	1






Revised 4/15/03



REF	PART#	DESCRIPTION	QTY
	55-9759	SCREW - battery	1
	55-6995	FLATWASHER	2
	55-7042	NUT	1
20	33-3837	GASKET - cover	1
21	33-3838	GROMMET	1
22	98-5454	BOX - control	1
	55-6994	SCREW - control box	4
	51-167	FLATWASHER	4
	55-9054	WASHER - insulator	4
23	33-3215	GROMMET	3
24	NSS	TRAY - high voltage (see 146D7)	1
25	41-3335	CABLE - battery	1
	41-4527	CONNECTOR (7 pin)	1
	44-6381	• CONNECTOR (2 pin)	2
26	309-3066	RAIL - terminal block	1
	55-7169	SCREW - rail	2
	55-7033	FLATWASHER	2
	55-9445	WASHER - insulator	2
	55-7034	NUT	2
27	41-3687	TERMINAL - stop clip	2
28	41-5105	PLATE - end terminal	1
29	41-3688	BLOCK - terminal	6
30	41-3703	CONNECTOR - cross	1
31	44-9359	FUSE (7.5 amp)	1






CONTROL BOX DOOR (mPC 3000 w/RMM)




REF	PART#	DESCRIPTION	QTY
1	91-9380	DOOR - control box	1
2	41-4142	KEYPAD (MP3000)	1
3	91-9381	HINGE - door	2
	55-7407	SCREW - hinge	4
	55-9444	WASHER (nylon)	4
	55-7033	WASHER	8
	55-7034	NUT	4
4	55-9392	INSULATOR - hinge	2
5	55-9393	SCREW - door	2
6	55-8919	RETAINER - screw	2
7	845-1909	CONTROLLER (MP3000)	1
	55-7034	NUT - controller	4
	55-8919	LOCKWASHER	2
	55-9444	WASHER - insulating (nylon)	4
8	845-1898	MODEM - RMM (option 098158, 098159)	1
9	41-3335	CONNECTOR (7 pin)	1
10	41-3602	CABLE - connecting (25 pin, No. 1 & 3)	2
11	91-9976	NAMEPLATE - Relay Board	1
12	41-3603	CABLE - connecting (RMM, option 098158, 098159)	1
13	55-9395	ADAPTER - push-on	1
	505-511	NUT	1
14	91-9382	NAMEPLATE - Controller Warning	1
15	91-9383	NAMEPLATE - Phase Select	1
16	41-2835	CABLE - connecting (No. 2)	1





REF	PART#	DESCRIPTION	QTY
1	91-9913	PLATE - bottom	1
	55-7372	SCREW - plate to box	4
	51-619	WASHER - insulator	4
	55-7075	FLATWASHER	4
	55-7378	LOCKWASHER (internal tooth)	4
	55-7042	NUT	4
2	41-5104	BREAKER - circuit (25 amp)	1
3	41-3605	CONTACTOR (CI 25)	1
4	41-3317	TRANSFORMER	1
	55-9396	SCREW - transformer	4
5	91-9273	RAIL - din	1
	55-7404	LOCKWASHER	6
6	55-9166	SCREW (pan hd)	9




Revised 2/25/04

REMOTE MONITOR OPTION (098182 CSR; 098144 CRR; 098182 CSR)



REF	PART#	DESCRIPTION	QTY
1	41-3606	HARNESS - remote monitor	1
2	41-3607	• RECEPTACLE (4 pin)	1
	55-9322	RIVET - receptacle	4
3	92-206	CAP - plug	1
	55-9323	RIVET - cap	1
4	41-5309	CONTACTOR - auxiliary (CSR units)	2








REF	PART#	DESCRIPTION	QTY
	41-3336	PANEL - USDA, assembly	1
1	91-9834	PANEL - USDA receptacle	1
2	41-3585	CONNECTOR (12 pin)	1
3	41-3586	RECEPTACLE (5 pin, cannon, bayonet)	1
4	41-3587	RECEPTACLE (4 pin, cannon, bayonet)	3
	55-9322	RIVET - receptacle	16
5	41-3588	CAP - receptacle	4
	55-3272	• RIVET - cap	4
6	92-206	• CAP - plug	1
	55-9211	RIVET - panel	4
7	41-5405	SENSOR - PT100 (4 pin, cannon, bayonet)	4
8	41-2853	CABLE & PLUG - retriever (cannon threaded)	1






USDA DOWNLOAD PANEL (DEUTSCH CONNECTORS)




REF	PART#	DESCRIPTION	QTY
1	91-9834	PANEL - USDA receptacle (before 4/00)	1
	92-428	PANEL - USDA receptacle (4/00 & after)	1
	55-3272	RIVET - panel	4
2	41-2406	CAP - dust	1
3	99-3685	CHAIN - cap	1
4	41-3588	CAP - dust	3
	55-9322	RIVET - cap	4
5	304-2772	RECEPTACLE (3 pin, Deutsch)	3
	55-9322	RIVET - connector	16
6	41-2405	RECEPTACLE (5 pin, Deutsch)	1
7	55-9402	PLUG - spare hole	1
8	41-3585	CONNECTOR - plug (12 pin)	1
9	92-243	NAMEPLATE - data download USDA	1
10	41-3107	SENSOR (3 pin, Deutsch, 14 m)	4
11	41-3402	CABLE & PLUG - retreiver (Deutsch)	1



USDA DOWNLOAD PANEL




REF	PART#	DESCRIPTION	QTY
1	91-8645	PANEL - USDA receptacle	1
	55-7713	RIVET - panel	4
2	41-2406	CAP - dust	1
3	99-3685	CHAIN - cap	5
4	41-890	CAP - dust	4
	55-9323	RIVET - cap	4
5	41-4016	RECEPTACLE (4 pin)	4
	55-2270	RIVET - receptacle	16
	55-8410	FLATWASHER	16
6	41-2405	CONNECTOR - receptacle (5 pin)	1
	55-2265	RIVET - receptacle	5
	55-7697	FLATWASHER	5
8	41-3585	CONNECTOR - plug (12 pin)	1
9	92-243	NAMEPLATE - data download USDA	1
10	41-3107	SENSOR - thermistor (USDA)	4




REF	PART#	DESCRIPTION	QTY
1	92-428	PANEL - USDA receptacle	1
	51-620	RIVET - panel	4
2	41-5416	CONNECTOR (16 pin)	1
3	41-2405	CONNECTOR - receptacle (5 pin, cannon bayonet)	1
4	41-3587	RECEPTACLE (4 pin, cannon bayonet)	4
	55-3272	RIVET - receptacle	20
5	41-3588	CAP - receptacle	5
	55-9323	RIVET - cap	5
6	41-3107	SENSOR (PT 100, 15 m)	1
7	41-3402	CABLE & PLUG - retreiver	1
8	92-243	NAMEPLATE - USDA data download	1






RECORDING THERMOMETER (OPTION 098025)



REF	PART#	DESCRIPTION	QTY
1	45-1830	THERMOMETER - recording (31 day, see 147B2)	1
	45-1834	THERMOMETER - 7 day (recording, see 147G13)	1
	55-7172	SCREW - recorder	4
	55-6996	LOCKWASHER	4
	55-6995	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	4
3	91-4218	PLATE - box (bottom)	1
	55-7340	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
4	33-451	GROMMET	1
5	99-7230	GUIDE - latch	1
6	55-7169	SCREW - guide (12 mm)	1
7	55-8720	SCREW - guide (25 mm)	1
8	55-7033	FLATWASHER	4
9	55-7404	LOCKWASHER	1
10	55-9444	WASHER - insulating (nylon)	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	91-5006	BRACKET - latch	1
	55-7340	SCREW - bracket	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
14	98-7209	COVER - recorder (incl items 15, 16 & 17)	1
15	91-5007	PLATE - keeper	1
	55-2988	RIVET - plate	2
16	91-8707	• WINDOW	1
17	33-3008	GASKET - cover	4
	91-4219	HINGE SET - left	1
18	91-8708	• HINGE - right (w/ pin)	1
19	91-8725	HINGE - right (w/o pin)	1
	55-7169	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
	91-4220	HINGE SET - right	1






Revised 8/30/05

RECORDING THERMOMETER (OPTION 098025)



REF	PART#	DESCRIPTION	QTY
20	91-8709	HINGE - left (w/ pin)	1
21	91-8726	HINGE - left (w/o pin)	1




Revised 2/2/06

RECORDING THERMOMETER - 31 DAY FAHRENHEIT



REF	PART#	DESCRIPTION	QTY
	45-1830	THERMOMETER (31 day, F)	1
1	44-5644	• ELEMENT - thermo (1/2 od, 7.5 in lg bulb, 10 ft capillary)	1
	44-2339	• ELEMENT - thermo (3/8 od, 14 in lg bulb, 10 ft capillary)	1
2	91-8217	• ROD - push	1
3	33-2962	• O-RING	1
4	41-2216	• MECHANISM	1
5	44-2966	DRIVE - chart (31 day)	1
6	55-5099	• NUT, CLIP & CORD	1
7	41-2218	• PLATEN	1
8	55-8955	• KEY - winding	1
9	91-2205	• KIT - stylus	1
10	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1






THERMOMETER - 7 DAY FAHRENHEIT



REF	PART#	DESCRIPTION	QTY
	45-1834	THERMOMETER - 7 day (F)	1
1	41-2219	• ELEMENT - thermo (3/8 od, 14 lg bulb, 10 ft capillary)	1
3	33-2962	• O-RING	1
4	41-2216	• MECHANISM	1
5	41-2224	DRIVE - chart (7 day)	1
6	55-5099	• NUT, CLIP & CORD	1
7	41-2218	• PLATEN	1
8	55-8955	• KEY - winding	1
9	91-2205	• KIT - stylus	1
10	203-179	CHART (7 day, -20 to +85 Fahrenheit, box of 50)	1






THERMOMETER BOX ASSEMBLY



REF	PART#	DESCRIPTION	QTY
	55-7341	SCREW - box	4
1	91-8770	BOX - recorder	1
	55-8904	WASHER	2
	55-8953	WASHER (nylon)	2
2	33-3043	GASKET - door	A/R
3	91-8106	PIN - hinge (w/ snap)	1
4	91-8771	LATCH - door	1
	505-559	RIVET - latch	2
5	91-8774	BRACKET - door support	1
6	55-7367	NUT	1
7	55-7034	NUT	2
8	55-7033	WASHER	1
9	55-9444	WASHER (nylon)	1
10	91-8772	COVER - recorder box	1
11	91-8775	SPRING - latch	1
	55-9083	RIVET - latch	2
12	45-1831	THERMOMETER - recording (see 147B9)	1
	55-8910	SCREW - thermometer	4
	55-6995	WASHER	8
	55-8877	WASHER (nylon)	8
	55-7042	NUT	4
13	33-3010	GASKET - capillary tube	1
14	33-3011	GASKET - bulkhead	1
15	55-8935	ANCHOR	1
	55-2260	RIVET - anchor	1
16	55-8942	CLAMP - bulb	2
	55-9062	SCREW - clamp	2
	55-7034	NUT	2




Revised 9/3/04

RECORDING THERMOMETER (OPTION 098026)



REF	PART#	DESCRIPTION	QTY
	45-1831	THERMOMETER - recording (Saginomiya, 31 day battery)	1
	45-1832	THERMOMETER - recording (Saginomiya, 31 day, AC power)	1
1	44-9780	• ELEMENT	1
2	44-9781	INDICATOR - volt	1
3	44-7782	• TIMER	1
4	509-911	PLATE - recorder	1
5	505-390	NUT - chart	1
6	509-912	• STYLUS - pen	1
7	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1






Revised 12/3/03

TRANSFORMER GROUP (098024, 098040, 098041, 098043, 098071, 098123, 098128)



148G2


REF	PART#	DESCRIPTION	QTY
1	45-1859	TRANSFORMER	1
2	41-1977	RECEPTACLE - power (32 amp, 440V)	1
	55-2995	SCREW - receptacle	4
	55-2964	• LOCKWASHER	2
	55-2001	• FLATWASHER	2
3	55-5919	CONNECTOR - grip	1
	55-2636	NUT - connector	1
4	41-3083	CABLE - power (69 ft)	1
5	91-9508	INSULATOR	2
6	55-7341	SCREW - transformer	2
	55-8891	SCREW - transformer	4
	55-7085	FLATWASHER	6
	55-7342	LOCKWASHER	6
7	91-6988	BRACKET - cable restraint (current units)	1
8	55-9164	SCREW - cable	1
	55-7357	FLATWASHER	1
	55-7344	NUT	1
9	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4
10	91-3238	BRACKET - cable (early units)	1
	55-7172	SCREW - bracket	3
	55-6995	FLATWASHER	6
	55-7042	NUT	3
11	44-3828	PLUG - power (50 amp)	1
	44-5133	PLUG - power (60 amp, orange)	1
	41-3429	PLUG - power (50 amp, blue)	1
	33-2482	BUSHING - plug	1



CONDENSER COMPONENTS (3 FANS)




REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	2
	55-9312	SCREW - keeper (TIR seal)	4
	55-6995	FLATWASHER	4
	55-9054	WASHER (nylon)	4
	505-2582	WASHER (nylon)	4
2	91-8108	BRACKET - frame	1
	55-7341	SCREW - bracket	3
	55-6988	WASHER	6
	55-9541	WASHER (nylon)	6
	55-7339	NUT	3
3	98-6236	PLATE - cable storage (front, 800B/C/D)	1
	91-9504	PLATE - cable storage (CRR40)	1
	55-9168	NUT	2
	55-9054	WASHER (nylon)	6
	55-6994	SCREW - plate	2
	51-167	FLATWASHER	6
	55-8933	WASHER (nylon)	6
4	91-9912	ORIFICE - condenser	1
	55-7035	SCREW - orifice	4
	55-7075	FLATWASHER	4
	55-3045	WASHER - dome	4
	55-8849	NUT - captive	4
5	98-5925	GRILLE - condenser (800B/C/D/E)	1
	33-3043	EXTRUSION (6.25 ft)	1
	55-6994	SCREW - grille	4
	51-167	FLATWASHER	4
	55-9054	WASHER (nylon)	4
6	98-6518	DOOR - evaporator	1
	92-2995	HINGE - evap door	2
	51-620	• RIVET - hinge	8
7	91-9040	• KNOB	2
8	55-7035	• SCREW - door	2
9	91-8199	• SPRING	2
10	55-7354	• NUT	2
11	55-9054	WASHER (nylon)	2
12	91-9041	• LATCH - door	2
	55-2864	• RIVET - latch	4
13	91-8134	INSULATOR - latch	2
14	509-1654	• HINGE	2
	55-9313	• SCREW - hinge (TIR seal)	4
	55-9541	• WASHER (nylon)	4



CONDENSER COMPONENTS (3 FANS)



REF	PART#	DESCRIPTION	QTY
	55-7085	• FLATWASHER	4
15	91-8256	PIN - hinge (w/ snap)	2
16	92-891	BRACKET - safety hook (800B/C/D)	1
	55-9541	SCREW - bracket	4
	55-7085	FLATWASHER	4
	55-9541	WASHER	8
17	98-5932	FRAME - condenser (CRR 40-300)	1
	98-5921	FRAME - condenser (800B)	1
	98-6238	FRAME - condenser (800C)	1
	98-6239	FRAME - condenser (800D)	1
	98-6663	FRAME - condenser (CRR40)	1
18	33-3969	GASKET - evaporator door	1
19	91-8475	NAMEPLATE - TK	1
20	33-2983	GASKET - unit	1
21	91-8728	COVER (instead of thermometer)	1
	55-7391	SCREW - cover	3
	55-6988	FLATWASHER	3
22	91-8664	PLATE - guard	1
	55-7341	SCREW - plate (20 mm)	2
	55-6993	SCREW - plate (25 mm)	1
	55-8953	WASHER (nylon)	3
23	91-9039	HOOK - strap	1
	55-3065	CLAMP - hook	1
	55-9166	SCREW - clamp	1
24	509-937	STRAP - door	1
	55-9173	SCREW - strap	1
	55-7089	FLATWASHER	2




AIR VENT (40 FT CONTAINERS)



REF	PART#	DESCRIPTION	QTY
	91-8252	VENT - air (complete)	1
1	91-9048	BRACKET - air vent handle	1
2	51-1426	SCREW - handle	1
	51-1474	• SCREW (M8 x 1.25 x 65, ss)	1
	55-9541	WASHER (nylon)	4
	51-1427	• NUT	1
3	91-8100	• SPRING	1
4	92-440	NAMEPLATE - Do Not Open Below 0 C	1
5	91-8102	HANDLE - air vent	1
6	77-2467	BEARING - slide	1
7	91-8104	BRACKET - handle	1
8	51-1428	• NUT	2
	51-1429	• LOCKWASHER	1
	51-1430	• FLATWASHER	1
9	51-1431	• NUT - wing	1
10	91-8103	DISK - air vent	1
11	33-4255	GASKET - air vent	1
12	91-8105	PLATE - air vent	1
	55-7172	SCREW - plate	4
	55-7075	• FLATWASHER	4
	55-9541	WASHER (nylon)	4
13	33-2944	GASKET - air vent	1
14	91-8663	PROTECTOR - edge	1
15	91-8106	• PIN - hinge	1
16	91-8107	NAMEPLATE - Do Not Open Below 0 C	1
17	55-9168	ADAPTER - hose	1
18	92-411	HINGE - air vent	1
	51-619	SCREW - mtg vent	8
	55-8933	WASHER - insulator (6.4 id)	4
	55-7075	FLATWASHER	4
	55-9054	WASHER - insulator (8.4 id)	6
	51-167	FLATWASHER	6
	55-7339	NUT	6






AFAM MP3000 (OPTION 098166)




REF	PART#	DESCRIPTION	QTY
1	92-412	BRACKET - motor box	1
	55-7172	SCREW - bracket	2
	51-167	WASHER	2
	51-619	WASHER - insulator	2
2	92-415	GRILLE - fresh air	1
	55-7172	SCREW - grille	3
	51-167	WASHER	3
	51-619	WASHER - insulator	3
3	92-416	BRACKET - receptacle	1
	55-7172	SCREW - bracket	2
4	33-3264	GASKET - receptacle (10 x 10)	1
5	92-414	HOUSING - motor	1
	55-7404	LOCKWASHER	4
	55-7033	FLATWASHER	4
	55-7367	NUT	4
6	33-314	GROMMET	1
7	92-413	BRACKET - mechanical stop	1
	55-7862	SCREW - bracket	4
	203-393	SEALER - thread	A/R
8	41-3674	MOTOR - damper (24VDC)	1
9	41-2832	CONNECTOR - plug (2 pin)	1
10	92-418	LINKAGE	1
11	92-417	LINKAGE	1
	55-7027	SCREW - linkage	2
	55-8893	WASHER	4
	55-7042	NUT	2
12	55-3537	PIN - cotter	2
13	55-9338	WASHER - shoulder	1
14	92-419	ROD - linkage	1
15	11-4929	BALL JOINT	1
	92-5521	BALL JOINT	1
16	55-9437	RETAINER - pin	1
17	92-420	VENT - air	1
18	33-3265	GASKET - air vent	1
19	92-411	HINGE - plate	1
20	91-8106	PIN - hinge (w/ snap)	1
21	41-3583	BOARD - interface (AFAM+)	1
22	41-3584	CABLE - AFAM/AFAM+	1









REF	PART#	DESCRIPTION	QTY
1	91-8244	BRACKET - hose	1
2	99-3281	MOUNT - cable tie	5
	55-2260	RIVET - anchor	5
3	55-2686	CLAMP - hose	2
4	55-8891	SCREW - bracket	2
5	55-9208	CONNECTOR - T-hose	1
6	55-2330	BANDWRAP	6
7	11-8983	HOSE - flex	1





REF	PART#	DESCRIPTION	QTY
1	91-8244	BRACKET - hose	1
2	99-3281	MOUNT - cable tie	5
	55-2260	RIVET - mount	5
3	55-2686	CLAMP - hose	2
4	55-8891	SCREW - bracket	2
5	55-9208	CONNECTOR - T (hose)	1
6	55-2330	BANDWRAP	6
7	11-8983	HOSE - flex	1
8	11-9575	T-DRAIN	1
	11-9735	T-DRAIN (after 9/03)	1
9	11-9576	HOSE - flex (11/01 & after)	A/R



EVAPORATOR PANELS



REF	PART#	DESCRIPTION	QTY
1	98-5773	PLATE - rear (bottom)	1
2	98-5772	PLATE - rear (top)	1
	51-336	SCREW - plate	23
	55-9444	WASHER - insulating	23
	55-3136	RIVET - plate	29
3	98-5774	GRILLE - evaporator (MAGNUM)	1
	98-5923	GRILLE - evaporator (MAGNUM 924)	1
	98-6556	GRILLE - evaporator (MAGNUM 40-SL)	1
	98-6565	GRILLE - evaporator (MAGNUM 20)	1
	55-3136	RIVET - grille	17
4	92-427	CHANNEL - Z (MAGNUM & MAGNUM 924)	5
	92-2774	CHANNEL - Z (MAGNUM SL-40)	5
	91-9922	CHANNEL - Z (MAGNUM 20)	5
	51-621	RIVET - channel	39
5	NSS	PANEL - USDA receptacle (see 157H2 & 189D7)	1
6	92-2773	CHANNEL - air (MAGNUM)	1
	91-9923	CHANNEL - air (MAGNUM SL 40 & 20)	1
	203-389	SEALER - polyurethane	A/R
	55-8891	SCREW - channel	6
7	91-9330	INLET - fresh air (MAGNUM)	1
	91-9924	INLET - fresh air (MAGNUM SL 40 & 20)	1
	55-9323	RIVET - inlet	10
	203-389	SEALER - polyurethane	A/R
8	91-9331	CHANNEL - fresh air	1
	55-9323	RIVET - channel	8
9	98-5775	PLATE - cover (Transfresh)	1
	55-7713	RIVET - plate	4
10	41-2554	CABLE - Transfresh (option 098150)	1
11	41-2555	CABLE - Transfresh (option 098150)	1
12	41-5405	SENSOR - PT100 (option 098106)	2
13	92-722	PLATE - cover	1
	55-2262	RIVET - plate	6





INGERSOLL RAND

THERMO KING

Compressor discharge may be hot!



MANUAL CONTROL

13

2.

1. COOL 1

2. COOL 2 3. NOT IN USE



3

WARNING!

TURN POWER OFF BEFORE DISCONNECTING DATALOGGER OR CONTROLLER.

11


5.

6.

4. NOT IN USE

5. DEFROST 6. HEAT

16





Ingersoll Rand


CAUTION COMPRESSOR MAY SOFT START

REFERENCE SERVICE MANUAL

19

3 ON / OFF CYCLES

18



REF	PART#	DESCRIPTION	QTY
1	91-9511	NAMEPLATE - TK	1
2	91-8746	NAMEPLATE - Ingersoll Rand	1
3	92-723	NAMEPLATE - Power Saver	1
4	91-9778	NAMEPLATE - Thermo King	1
5	91-5882	NAMEPLATE - R404A	1
6	91-8694	NAMEPLATE - Warning, Fan Start	1
7	91-8695	NAMEPLATE - Warning, Hot Components	1
8	91-8154	NAMEPLATE - R404A	1
9	92-243	NAMEPLATE - data download USDA	1
10	91-9833	NAMEPLATE - Caution	1
11	91-9382	NAMEPLATE - Warning	1
12	91-9383	NAMEPLATE - Main Relay Board	1
13	91-9384	NAMEPLATE - Main Relay Board	1
14	91-8107	NAMEPLATE - Air Exchanger	1
15	91-9441	NAMEPLATE - Air Exchanger	1
16	91-5459	NAMEPLATE - R134a	1
17	92-863	NAMEPLATE - IR/Ingersoll Rand	1
18	92-1218	NAMEPLATE - Weld	1
19	91-7475	NAMEPLATE - Caution, Compressor	1

00 7040		00.004		44.0000	
02-7043	30	33-981	30, 32, 34	41-3686	56
10-243	46	40-782	36, 42	41-3687	54, 58
104-689	8, 48	40-791	48	41-3688	54, 58
104-691	10, 12, 14, 48	41-1976	48	41-3693	12, 14
11-4367	14, 46	41-1977	86	41-3694	12, 14
11-4841	46	41-2216	78, 80	41-3695	12, 14
11-4860	46	41-2218	78, 80	41-3696	12, 14
11-4929	94	41-2219	80	41-3701	30, 32
11-8983	46, 96, 98	41-2224	80	41-3702	54
11-9082	46	41-2399	36, 42	41-3703	54, 58
11-9083	46	41-2405	68, 70, 72	41-3851	52, 56
11-9084	46	41-2406	56, 68, 70	41-4015	34, 48
11-9085	46	41-2447	30, 32	41-4016	70
11-9575	98	41-2554	100	41-4018	10, 48
11-9576	98	41-2555	100	41-4142	60
11-9735	98	41-2603	40	41-4300	34, 48
203-179	80	41-2691	46	41-4527	58 [°]
203-180	78, 84	41-2832	52, 56, 94	41-5104	62
203-385	38	41-2833	56	41-5105	58
203-389	100	41-2835	60	41-5309	64
203-393	38, 94	41-2838	44, 48	41-5405	66, 100
203-509	52, 56	41-2853	66	41-5416	72
203-516	30, 32, 34	41-2953	8, 48	41-5420	40
22-1051	30, 34	41-3083	86	41-5460	26, 28, 36, 42
22-1031	30, 32	41-3003	68, 70, 72	41-5635	
	30, 32 34				44, 46, 48
22-1161		41-3117	46	41-890	70 70
22-1186	30, 32, 34	41-3276	52	44-2339	78 70
22-1187	34	41-3277	10, 48	44-2966	78
22-398	30, 32, 34	41-3301	20, 36, 42, 44	44-3828	86
304-2772	68	41-3302	30, 32, 34, 48	44-5133	86
309-3066	54, 58	41-3303	20, 36, 44	44-5644	78
33-2222	30, 32, 34	41-3317	62	44-6360	30, 32, 34
33-2482	86	41-3335	54, 58, 60	44-6381	58
33-2510	30, 34	41-3336	66	44-7782	84
33-2548	30, 32	41-3401	48	44-8340	8
33-2944	92	41-3402	52, 56, 68, 72	44-8688	52
33-2946	10, 12, 14	41-3409	14	44-9359	58
33-2947	12	41-3429	86	44-9780	84
33-2949	18	41-3430	52, 56	44-9781	84
33-2950	22, 26	41-3583	94	45-1791	48
33-2962	78, 80	41-3584	94	45-1830	74, 78
33-2983	90	41-3585	66, 68, 70	45-1831	82, 84
33-3007	18, 26, 38	41-3586	66	45-1832	84
33-3008	74	41-3587	66, 72	45-1834	74, 80
33-3010	82	41-3588	66, 68, 72	45-1859	86
33-3011	82	41-3592	36, 42	45-1927	48
33-3043	52, 82, 88	41-3595	52, 56	45-1931	12, 14
33-3044	8, 10, 12, 14	41-3596	52, 56	45-1942	48
33-314	94	41-3597	52, 56	45-1992	48
33-3175	30, 34	41-3598	52, 56	45-2010	56
33-3215	10, 14, 54, 58	41-3599	52, 56	502-240	30, 34
33-3264	94	41-3602	60	503-278	30, 34
33-3265	94	41-3603	60	503-291	40
33-367	8, 10	41-3605	62	504-1418	22
33-3837	58	41-3606	64	504-327	56
33-3838	10, 12, 16, 54, 58	41-3607	64	504-514	52, 56
33-3969	90	41-3608	52, 56	504-922	36
33-4255	92	41-3674	94	504-970	52, 5 6
33-451	74	41-3685	10, 48	504-977	36
55 .51		5000	. 0, . 0	551 077	

504-980	26, 40	55-2636	86	55-7378	56, 62
505-2582	88	55-2686	96, 98	55-7391	90
505-390	84	55-2747	30, 32, 34	55-7404	62, 74, 94
505-408	52	55-2864	88	55-7407	60
505-416	52	55-2964	86	55-7697	70
505-511	60	55-2976	30, 32	55-7713	70, 100
505-559	82	55-2988	74	55-7843	18
505-566	52	55-2995	86	55-7862	94
505-603	18	55-3045	8, 88	55-8137	8
506-161	30, 32, 34	55-3065	90	55-8316	26
506-364	18, 26, 38	55-3136	100	55-8410	70
		55-3272			
506-369	18, 22		52, 56, 66, 68, 72	55-8559 55-8559	8
506-370	18, 22	55-3537	94	55-8720	74
506-375	22	55-4359	46	55-8849	88
506-388	26	55-4390	18, 22, 26	55-8877	14, 52, 56, 82
509-1153	30, 32, 34	55-459	30, 32, 34	55-8891	10, 12, 14, 18, 22, 86,
509-1635	18	55-5099	78, 80		96, 98, 100
509-1654	88	55-5257	30, 32, 34, 52, 56	55-8893	94
509-911	84	55-5885	52	55-8903	10, 12, 14
509-912	84	55-5900	8, 10, 56	55-8904	10, 12, 14, 82
509-937	90	55-5919	86	55-8907	12, 14, 52
509-955	52	55-6218	18, 22, 28	55-8908	8, 12, 14
51-137	34	55-6730	38	55-8910	18, 22, 82
51-1426	92	55-6905	46	55-8911	26, 30, 32
51-1427	92	55-6988	8, 74, 88, 90	55-8912	30, 32
51-1428	92	55-6993	10, 12, 14, 90	55-8919	60
51-1429	38, 92	55-6994	54, 58, 88	55-8933	88, 92
51-1430	38, 92	55-6995	18, 22, 52, 58, 74, 82,		82
51-1431	92	33-0993		55-8938	18
		EE 6006	86, 88 74		82
51-1462	38	55-6996 55-6007		55-8942	
51-1467	38	55-6997	8	55-8950	18
51-1474	92	55-7027	94	55-8951	18
51-167	26, 38, 58, 88, 92, 94	55-7033	54, 58, 60, 74, 82, 94	55-8953	74, 82, 90
51-270	48	55-7034	12, 14, 54, 58, 60, 74, 82		78, 80
51-273	26	55-7035	8, 14, 26, 38, 88	55-8991	44
51-336	56, 100	55-7042	26, 52, 56, 58, 62, 82,		26, 30, 32, 34
51-618	56		86, 94	55-9027	26
51-619	62, 92, 94	55-7066	8, 10, 12, 14	55-9054	18, 22, 26, 54, 58, 88, 92
51-620	72, 88	55-7075	10, 14, 26, 50, 54, 56,		82
51-621	100		62, 86, 88, 92	55-9083	82
51-627	26	55-7085	10, 12, 14, 46, 86, 90	55-9149	46
51-629	56	55-7089	12, 14, 90	55-9162	10, 12, 14
55-1203	44	55-7151	46	55-9164	48, 86
55-137	26	55-7169	54, 58, 74	55-9166	52, 56, 62, 90
55-1827	38	55-7170	50, 86	55-9168	88, 92
55-2001	86	55-7172	10, 50, 52, 56, 74, 86,		44, 90
55-2074	52, 56		92, 94	55-9208	46, 96, 98
55-2159	30, 32, 34	55-7339	8, 10, 12, 14, 46, 88, 92	55-9211	66
55-2173	30, 32, 34	55-7340	74	55-9217	10, 12, 14
55-2260	82, 96, 98	55-7341	74, 82, 86, 88, 90	55-9312	88
55-2262	100	55-7342	8, 10, 12, 14, 86	55-9313	88
55-2265	70	55-7344	50, 86	55-9322	56, 64, 66, 68
	70		26		
55-2270 55-2206		55-7347		55-9323	64, 70, 72, 100 04
55-2296	20, 24, 28	55-7354 55-7357	74, 88	55-9338	94
55-2299	24	55-7357 55-7360	48, 86	55-9392	60
55-2330	96, 98	55-7360	26, 34	55-9393	60
55-2331	26	55-7366	12, 14	55-9395	60
55-2505	30, 32, 34	55-7367	82, 94	55-9396	62
55-2561	46	55-7372	62	55-9401	54

55-9402	68	61-726	18, 22	8102-743	18, 22, 26, 30, 32, 34, 48
55-9437	94	61-727	22	845-1898	60
55-9444	12, 14, 52, 56, 60, 74,		26	845-1909	60
	82, 100	66-4788	38	845-2834	52
55-9445	54, 58	66-6607	30, 32, 34	91-2205	78, 80
55-9541	88, 90, 92	66-6610	26, 30, 32, 34, 38	91-3238	86
55-9759	26, 58	66-7182	30, 32, 34, 38	91-4218	74
60-285	18, 22, 26	66-7183	30, 32, 34	91-4219	74
61-1305	22, 38	66-7543	38	91-4220	74
61-1307	24	66-8054	30, 32, 34	91-5005	74
61-1316	22	66-8367	42	91-5006	74
61-144	18	66-8467	18, 22, 28	91-5007	74
61-145	18	66-8721	42	91-5459	102
61-146	20	66-8811	18, 38	91-5882	102
61-147	20	66-9015	22	91-6236	46
61-149	18, 36	66-9032	24, 36, 48	91-6237	46
61-150	18	66-9035	20, 24	91-6435	30, 32, 34
61-151	18	66-9062	20	91-6627	38
61-152	18	66-9071	18	91-6628	38
61-153	18	66-9075	20, 24	91-6988	86
61-1626	28	66-9085	22	91-7475	102
61-2048	28	66-9125	22, 26	91-759	38
61-2049	28	66-9159	44	91-8100	92
61-2050	28	66-9163	18, 22, 40, 48	91-8102	92
61-2051	28	66-9164	20, 24	91-8103	92
61-2219	26	66-9167	22, 36, 48	91-8104	92
61-2220	26	66-9168	22, 42, 48	91-8105	92
61-2221	26	66-9195	42	91-8106	82, 92, 94
61-2222	26	66-9210	20	91-8107	92, 102
61-2223	26, 42, 48	66-9214	22	91-8108	88
61-2224	26	66-9307	18	91-8134	88
61-2225	26	66-9377	30, 32, 34	91-8140	48
61-2226	28	66-9447	38	91-8142	48
61-2227	28	66-9866	18, 42	91-8154	102
61-2228	28, 48	66-9867	36	91-8195	88
61-2229	28	66-9868	20, 24	91-8199	88
61-2237	22	66-9874	22	91-8217	78
61-2238	28	66-9875	22	91-8244	96, 98
61-2239	28	66-9893	18	91-8252	92
61-2285	24	66-9894	18	91-8256	90
61-2351	42	66-9900	20, 22	91-8466	10, 12, 14
61-291	18	66-9953	42	91-8467	48
61-292	18	67-1532	24	91-8475	90
61-293	18, 22	67-1558	10, 24	91-8620	18
61-294	24	67-1575	22, 38	91-8645	70
61-295	24	67-1632	22	91-8663	92
61-296	18	67-1650	18, 22	91-8664	90
61-2990	22	67-1651	18	91-8694	102
61-3504	38	67-1673	12, 14, 20, 24	91-8695	102
61-3525	38	67-1806	24	91-8705	74
61-3542	38	67-1923	10, 28	91-8707	74
61-681	42	67-1943	26	91-8708	74
61-695	22	67-1945	26	91-8709	76
61-696	22	77-1401	8, 10, 48	91-8725	74
61-697	22	77-1498	8, 10, 48	91-8726	76
61-698	22	77-2467	92	91-8728	90
61-723	24	78-1117	10, 12, 14	91-8746	102
61-724	24	78-1173	8	91-8770	82
61-725	22	78-1197	8	91-8771	82

```
91-8772
            82
                                     92-420
                                                  94
91-8774
            82
                                     92-425
                                                  12
                                                  100
91-8775
            82
                                     92-427
                                                  68, 72
91-9002
            46
                                     92-428
                                                  92
91-9003
            46
                                     92-440
91-9039
            90
                                     92-456
                                                  14
91-9040
            88
                                     92-457
                                                  14
91-9041
            88
                                                  14
                                     92-458
91-9048
            92
                                     92-5521
                                                  94
91-9273
            62
                                                  100
                                     92-722
91-9328
            10, 12, 14
                                                  102
                                     92-723
91-9330
            100
                                     92-860
                                                  52, 56
91-9331
            100
                                     92-863
                                                  102
91-9380
            60
                                                  90
                                     92-891
91-9381
            60
                                     98-5454
                                                  54, 58
            60, 102
                                                  10
91-9382
                                     98-5475
            60, 102
                                                  10, 12, 14
91-9383
                                     98-5768
91-9384
            102
                                     98-5772
                                                  100
91-9441
            102
                                     98-5773
                                                  100
91-9504
            88
                                                  100
                                     98-5774
91-9508
            86
                                                  100
                                     98-5775
            102
                                                  10
91-9511
                                     98-5918
91-9754
            48
                                     98-5919
                                                  10
91-9778
            102
                                     98-5921
                                                  90
91-9833
            52, 56, 102
                                     98-5923
                                                  100
91-9834
            66,68
                                     98-5925
                                                  88
91-9912
            8,88
                                     98-5932
                                                  90
91-9913
            62
                                     98-6213
                                                  10
91-9922
            100
                                     98-6236
                                                  88
91-9923
            100
                                     98-6238
                                                  90
91-9924
            100
                                     98-6239
                                                  90
91-9976
            60
                                                  88
                                     98-6518
92-1218
            102
                                                  100
                                     98-6556
            30, 34
                                                  100
92-1682
                                     98-6565
            64,66
92-206
                                                  10
                                     98-6657
                                                  90
92-2331
            10, 12, 14
                                     98-6663
92-2332
            10, 12, 14
                                     98-7209
                                                  74
            52, 56
                                                  96, 98
92-236
                                     99-3281
92-237
            52, 56
                                     99-3685
                                                  56, 68, 70
92-238
            52, 56
                                                  10, 12, 14
                                     99-4931
92-239
            52, 56
                                     99-5966
                                                  22
92-243
            68, 70, 72, 102
                                     99-7230
                                                  74
92-244
            52, 56
92-270
            48
92-2773
            100
            100
92-2774
92-2775
            10
92-2777
            48
92-2779
            10
92-2995
            88
92-411
            92, 94
92-412
            94
92-413
            94
92-414
            94
92-415
            94
92-416
            94
92-417
            94
            94
92-418
            94
92-419
```

A	CABLE - retriever plug 32, 36	DOOR - CONTROL DOX 60
ACTUATOR 40	CABLE - Transfresh 100	DOOR - controller 52 , 56
ADAPTER 30, 32, 34	CABLE & PLUG - retreiver 68, 72	DOOR - evaporator 88
ADAPTER - discharge 30, 32, 34	CABLE & PLUG - retriever 66	DRAIN COCK 46
ADAPTER - hose 92	CAP - adapter 30, 32, 34	DRIVE - chart 78, 80
ADAPTER - outlet 46	CAP - discharge valve 30, 32, 34	
ADAPTER - push-on 60	CAP - dust 68, 70	E
ADAPTER - service 30, 32, 34	CAP - dust cover 38	ELBOW 30 , 32 , 34
	CAP - fitting 30 , 32 , 34 , 38	ELBOW - hose 46
ANCHOR 82	CAP - plug 52 , 56 , 64 , 66	ELEMENT 84
ANGLE - lifting 30, 32, 34	CAP - receptacle 66, 72	ELEMENT - thermo 78, 80
В	CAP - screw 12 , 14	EXTRUSION 88
В	•	EXTROSION 66
BALL JOINT 94	CAP - tube 46	F
BANDWRAP 96, 98	CAP - tube 10	
BANDWRAP - valve 26	CHAIN - cap 56 , 68 , 70	FAN - condenser 8
BATTERY 52, 56	CHANNEL - air 100	FAN - evaporator 10, 12, 14
BEARING - opposite end 8, 10, 48	CHANNEL - fresh air 100	FILTER 46
BEARING - shaft end 8, 10, 48	CHANNEL - Z 100	FILTER - gas sensor 14
BEARING - slide 92	CHART 78, 80, 84	FITTING - barb 46
BLOCK - coil 10, 12, 14	CLAMP - bulb 82	FITTING - harness 30 , 32 , 34 , 52 , 56
BLOCK - terminal 52 , 54 , 56 , 58	CLAMP - dehydrator 18	FITTING - high side 26, 38
BOARD - interface 94	CLAMP - hook 90	FITTING - service 30, 32, 34
BOARD - relay 52, 56	CLAMP - hose 96, 98	FLANGE - suction 30, 32, 34
BOOT - circuit breaker 52	CLAMP - sensor 44	FLATWASHER 8, 10, 12, 14, 18, 22
BOOT - switch 52 , 56	CLAMP - tube 26, 38	26, 30, 32, 34, 38, 46,
BOX - control 48 , 54 , 58	CLIP - relay 52, 56	48, 50, 54, 58, 62, 70,
	COIL 42 , 44	74, 86, 88, 90, 92, 94
BOX - junction 30, 34	COIL - condenser 18 , 22 , 26	FLATWASHER - insulating 26
BOX - recorder 74 , 82	COIL - evaporator 10 , 12 , 14 , 20 , 24 ,	FRAME - condenser 90
BRACKET 52 , 56	28	FUSE 52 , 56 , 58
BRACKET - air vent handle 92	-	1 002 02, 00, 00
BRACKET - cable 86	COIL - liquid line valve 42	
BRACKET - cable 86 BRACKET - cable restraint 48, 86	COIL - liquid line valve 42 COIL - valve 20 , 26 , 28 , 36 , 42	G
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56	COIL - liquid line valve 42 COIL - valve 20 , 26 , 28 , 36 , 42 COMPRESSOR 18 , 22 , 26 , 30 , 32 , 34 ,	G GASKET 18, 22, 26, 40
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48	G GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46	G GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10,	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - 0-ring 26
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - o-ring 26 GASKET - receptacle 94
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - receptacle 94 GASKET - sight glass 30, 32, 34
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor 10, 12, 14 BRACKET - receptacle 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - right 10, 12, 14 BRACKET - safety hook 90	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - receptacle 94 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor 10, 12, 14 BRACKET - receptacle 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - sensor 14	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - receptacle 94 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - sensor 14 BRACKET - valve 18	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60 COUPLING 24	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - receptacle 94 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - right 10, 12, 14 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - sensor 14 BRACKET - valve 18 BREAKER - circuit 52, 62	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T - hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60 COUPLING 24 COUPLING - outlet 38	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - receptacle 94 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - sensor 14 BRACKET - valve 18 BREAKER - circuit 52, 62 BUSHING 24	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - receptacle 94 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34 GRILLE - condenser 88
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - right 10, 12, 14 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - sensor 14 BRACKET - valve 18 BREAKER - circuit 52, 62	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34 COVER 90	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - receptacle 94 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34 GRILLE - condenser 88 GRILLE - evaporator 100
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - safety hook 90 BRACKET - valve 18 BREAKER - circuit 52, 62 BUSHING 24 BUSHING - plug 86	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34 COVER 90 COVER - recorder 74	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34 GRILLE - condenser 88 GRILLE - evaporator 100 GRILLE - fresh air 94
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - safety hook 90 BRACKET - valve 18 BREAKER - circuit 52, 62 BUSHING 24 BUSHING - plug 86	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR 62 CONTACTOR - auxiliary 64 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34 COVER 90 COVER - recorder 74 COVER - recorder box 82	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - door 82 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve 91ate 30, 34 GRILLE - condenser 88 GRILLE - evaporator 100 GRILLE - fresh air 94 GRIP - cable 8
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - safety hook 90 BRACKET - valve 18 BREAKER - circuit 52, 62 BUSHING 24 BUSHING - plug 86	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34 COVER 90 COVER - recorder 74	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - discharge 30, 34 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34 GRILLE - condenser 88 GRILLE - evaporator 100 GRILLE - fresh air 94 GRIP - cable 8 GROMMET 8, 10, 12, 14, 16, 54, 58
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - right 10, 12, 14 BRACKET - safety hook 90 BRACKET - safety hook 90 BRACKET - valve 18 BREAKER - circuit 52, 62 BUSHING 24 BUSHING - plug 86	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T - hose 46, 96 CONTACTOR 62 CONTACTOR 62 CONTACTOR - auxiliary 64 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34 COVER 90 COVER - recorder 74 COVER - recorder box 82 COVER - tube 10	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - discharge 30, 34 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34 GRILLE - condenser 88 GRILLE - evaporator 100 GRILLE - fresh air 94 GRIP - cable 8 GROMMET 8, 10, 12, 14, 16, 54, 58 74, 94
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - receptacle 94 BRACKET - safety hook 90 BRACKET - safety hook 90 BRACKET - valve 18 BREAKER - circuit 52, 62 BUSHING 24 BUSHING - plug 86 C CABLE - AFAM/AFAM+ 94	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T 98 CONNECTOR - T-hose 46, 96 CONTACTOR 62 CONTACTOR - auxiliary 64 CONTROLLER 60 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34 COVER 90 COVER - recorder 74 COVER - recorder box 82 COVER - tube 10	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - discharge 30, 34 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34 GRILLE - condenser 88 GRILLE - evaporator 100 GRILLE - fresh air 94 GRIP - cable 8 GROMMET 8, 10, 12, 14, 16, 54, 58
BRACKET - cable 86 BRACKET - cable restraint 48, 86 BRACKET - diagram 52, 56 BRACKET - door support 82 BRACKET - frame 88 BRACKET - handle 92 BRACKET - heater 48 BRACKET - hose 96, 98 BRACKET - latch 74 BRACKET - left 10, 12, 14 BRACKET - mechanical stop 94 BRACKET - motor 10, 12, 14 BRACKET - motor box 94 BRACKET - power cable 48 BRACKET - receptacle 94 BRACKET - receptacle 94 BRACKET - safety hook 90 BRACKET - safety hook 90 BRACKET - valve 18 BREAKER - circuit 52, 62 BUSHING 24 BUSHING - plug 86 C CABLE - AFAM/AFAM+ 94 CABLE - battery 54, 58	COIL - liquid line valve 42 COIL - valve 20, 26, 28, 36, 42 COMPRESSOR 18, 22, 26, 30, 32, 34, 48 COMPRESSOR - humidity 46 CONNECTOR 58, 60, 66, 72 CONNECTOR - cross 54, 58 CONNECTOR - grip 86 CONNECTOR - harness & sensor 10, 12, 14 CONNECTOR - liquid tite 48, 52, 56 CONNECTOR - plug 52, 56, 68, 70, 94 CONNECTOR - receptacle 70, 72 CONNECTOR - T 98 CONNECTOR - T - hose 46, 96 CONTACTOR 62 CONTACTOR 62 CONTACTOR - auxiliary 64 COUPLING 24 COUPLING - outlet 38 COUPLING - switch 30, 32, 34 COVER 90 COVER - recorder 74 COVER - recorder box 82 COVER - tube 10	GASKET 18, 22, 26, 40 GASKET - adapter/suction 30, 34 GASKET - air vent 92, 94 GASKET - bulkhead 82 GASKET - capillary tube 82 GASKET - coil 18 GASKET - coil 18 GASKET - cover 52, 58, 74 GASKET - cylinder head 30, 34 GASKET - discharge 30, 34 GASKET - discharge 30, 34 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - evaporator door 90 GASKET - sight glass 30, 32, 34 GASKET - suction adapter 32 GASKET - unit 90 GASKET - valve 30, 32, 34 GASKET - valve plate 30, 34 GRILLE - condenser 88 GRILLE - evaporator 100 GRILLE - fresh air 94 GRIP - cable 8 GROMMET 8, 10, 12, 14, 16, 54, 58 74, 94

CABLE - power 48, 86

П	KVQ - actuator 18	74, 82, 86, 88, 92, 94
HANDLE - air vent 92	KVQ - valve 22	NUT - captive 8, 88
HANGER - dehydrator 18, 22, 26	_	NUT - chart 84
HARNESS 40	L	NUT - compressor 46
HARNESS - condenser fan 8, 48	LABEL - compressor oil 30, 32, 34	NUT - connector 86
	LABEL - dehydrator 18	NUT - controller 60
HARNESS - evap fan 10	LATCH - cover 74	NUT - hexagon 26
HARNESS - evap motor, VFD 12, 14	LATCH - door 82 , 88	NUT - hose 46
HARNESS - evaporator 48	LINKAGE 94	NUT - shoulder 18
HARNESS - evaporator fan 48		
HARNESS - fan 10, 12, 14	LOCKNUT 8	NUT - speed 52 , 56
HARNESS - fan & heater 10	LOCKWASHER 8, 10, 12, 14, 26, 30,	NUT - wing 92
HARNESS - humidity compressor 46	32, 34, 38, 50, 52, 56,	NUTSTRIP - motor 12
HARNESS - pilot, VFD 12, 14	60, 62, 74, 86, 92, 94	NUT, CLIP & CORD 78, 80
HARNESS - remote monitor 64	5.4	
HARNESS - sensor 44, 48	M	0
HARNESS - tank heater 46	MECHANISM 78, 80	OIL - compressor 30, 32, 34
HEAT - exchanger 26	MODEM - RMM 60	ORIFICE - condenser 88
HEAT EXCHANGER 18, 22	MODULE - variable fan drive 12, 14	ORIFICE - condenser fan 8
	MOTOR - condenser 48	O-RING 38, 78, 80
HEATER 48	MOTOR - condenser fan 8	
HINGE 88	MOTOR - damper 94	P
HINGE - air vent 92	MOTOR - fan 10 , 12 , 14 , 48	PANEL - USDA receptacle 48, 66, 68,
HINGE - cover 52 , 56		• • • • • • • • • • • • • • • • • • • •
HINGE - door 60	MOUNT - cable tie 96, 98	70, 72, 100
HINGE - evap door 88	N	PANEL - USDA, assembly 66
HINGE - left 76		PIN - cotter 94
HINGE - plate 94	NAMEPLATE - Air Exchanger 102	PIN - hinge 82 , 90 , 92 , 94
HINGE - right 74	NAMEPLATE - arrow 10 , 12 , 14	PLATE - air vent 92
HINGE SET - left 74	NAMEPLATE - Caution 52 , 56 , 102	PLATE - bottom 62
HINGE SET - right 74	NAMEPLATE - Caution, Compressor	PLATE - box 74
HOLDER - fuse 52, 56	102	PLATE - cable storage 88
HOOK - strap 90	NAMEPLATE - Controller Warning 60	PLATE - compressor 46
HOSE - drain 46	NAMEPLATE - data download USDA	PLATE - cover 100
HOSE - flex 96 , 98	68, 70, 102	PLATE - end terminal 54, 58
HOSE - sensor 14	NAMEPLATE - Do Not Open Below 0 C	PLATE - guard 90
HOSE - supply & over flow 46	92	PLATE - keeper 74
	NAMEPLATE - Ingersoll Rand 102	PLATE - rear 100
HOUSING - evaporator 10, 12, 14	NAMEPLATE - IR/Ingersoll Rand 102	PLATE - recorder 84
HOUSING - motor 94	NAMEPLATE - Main Relay Board 102	PLATEN 78, 80
1	NAMEPLATE - On/Off 56	PLUG 56
I		
INDICATOR 38	NAMEPLATE - on/off 52	PLUG - fusible 18 , 26 , 38
INDICATOR - liquid 26	NAMEPLATE - Phase Select 60	PLUG - outlet 38
INDICATOR - volt 84	NAMEPLATE - Power Saver 102	PLUG - power 48 , 86
INLET - fresh air 100	NAMEPLATE - R134a 102	PLUG - seal 52 , 54 , 56
INSULATOR 52 , 56 , 86	NAMEPLATE - R404A 102	PLUG - spare hole 68
INSULATOR - hinge 60	NAMEPLATE - Relay Board 60	POCKET - sensor 34, 48
INSULATOR - latch 88	NAMEPLATE - Thermo King 102	PROTECTOR - edge 92
	NAMEPLATE - TK 90, 102	
K	NAMEPLATE - USDA data download	R
KEEPER - door latch 88	72	RAIL - din 62
	NAMEPLATE - Warning 102	RAIL - terminal block 54, 58
KEY - winding 78 , 80	NAMEPLATE - Warning, Fan Start 102	
KEYPAD 60	NAMEPLATE - Warning, Hot	RECEPTACLE 64 , 66 , 68 , 70 , 72
KIT - reed suction 30, 34	——————————————————————————————————————	RECEPTACLE - power 86
KIT - repair 36	Components 102	·
KIT - sensor 48	NAMEPLATE - Weld 102	RELAY - power 52 , 56
KIT - sleeve & eyelet 46	NIPPLE 46	RETAINER - pin 94
KIT - spacer 30	NIPPLE - compressor to nozzle 46	RETAINER - screw 60
KIT - stylus 78, 80	NOZZLE - liquid spray 46	RIVET - anchor 82, 96
KIT - valve plate 30, 34	NUT 8 , 10 , 12 , 14 , 26 , 30 , 32 , 34 , 50 ,	RIVET - bracket 52, 56
KNOB 88	52, 54, 56, 58, 60, 62,	RIVET - cap 64, 66, 68, 70, 72

INDEX ALPHABETICAL BY DESCRIPTION

RIVET - channel 100	SEALER - polyurethane 100	TUBE - equalizer 20, 24, 28
RIVET - connector 68	SEALER - removable 38	TUBE - evaporator to exchanger 18, 22
RIVET - grille 100	SEALER - thread 94	TUBE - exchanger to dehydrator 22
RIVET - hinge 88	SENSOR 68, 72	TUBE - exchanger to KVQ 18, 22
RIVET - inlet 100	SENSOR - compressor 48	TUBE - expansion valve to inlet 28
RIVET - latch 74, 82, 88	SENSOR - gas 14	TUBE - expansion valve to tee 28
RIVET - mount 98	SENSOR - head temperature 30, 32,	TUBE - heat exchanger to dehydrator
RIVET - panel 66, 68, 70, 72	34	18
RIVET - plate 74, 100	SENSOR - humidity 44, 46, 48	TUBE - heat exchanger to KVQ 26
RIVET - plug 52, 56	SENSOR - PT100 66, 100	TUBE - KVQ to compressor 18, 22, 26
RIVET - receptacle 64 , 66 , 70 , 72	SENSOR - thermistor 70	TUBE - liquid injection 28
RIVET - shroud 10, 12, 14	SHOULDER - seal 18	TUBE - liquid to evaporator 28
ROD - linkage 94	SIGHT GLASS 18	TUBE - receiver tank to valve 28
ROD - push 78	SIGHT GLASS - oil 30, 32, 34	TUBE - receiver to condenser 18
	SPACER - clamp 44	TUBE - solenoid to KVQ 18, 22
S	SPACER - tank 46	TUBE - solenoid to tee 24
SCREEN 46	SPRING 88, 92	TUBE - stub 38
SCREW 62, 92	SPRING - heater 48	TUBE - suction to evaporator 28
SCREW - adapter 30, 32, 34	SPRING - latch 82	TUBE - tee to coil 20, 24
SCREW - battery 58	STRAP - door 90	TUBE - tee to distributor 28
SCREW - box 74, 82	STRIP - gasket 22	TUBE - tee to valve 20, 24
SCREW - bracket 10, 12, 14, 18, 22,	STRIP - sealing 8	TUBE - temperature sensor to
50, 52, 56, 74, 86, 88,	STYLUS - pen 84	compressor 22
90, 94, 96, 98	SWITCH - hpco 30, 32, 34, 48	TUBE - top 22
SCREW - cable 48, 86	SWITCH - unit on/off 52, 56	TUBE - transition 18
SCREW - channel 100	_	TUBE - valve replacement 20
SCREW - clamp 26, 38, 44, 82, 90	Т	TUBE - valve to coil 20, 24
SCREW - coil 10, 12, 14, 18, 22, 26	TANK - condenser 22	TUBE - valve to dehydrator 18, 38
SCREW - compressor 26, 30, 32, 34	TANK - humidity 46	TUBE - valve to exchanger 18, 22
SCREW - control box 54, 58	TANK - receiver 18	TUBE - valve to tee 18, 20, 22, 24
SCREW - cover 10, 90	TANK - water cooled condenser 38	
SCREW - dehydrator 26	T-DRAIN 98	V
SCREW - door 60, 88	TEE 18, 20, 22, 24, 28	VALVE - ball 38
SCREW - fan to hub 8	TERMINAL - splice 8	VALVE - bypass 42
SCREW - flange 30, 32, 34	TERMINAL - stop clip 54, 58	VALVE - check 18, 22, 28
SCREW - grille 88, 94	THERMOMETER 78	VALVE - cpr 22
SCREW - guide 74	THERMOMETER - 7 day 74, 80	VALVE - dehumidifier 36
SCREW - handle 92	THERMOMETER - recording 74, 82,	VALVE - discharge 30, 32, 34
SCREW - hanger 26	84	VALVE - expansion 20, 22, 28
SCREW - hinge 52, 56, 60, 74, 88	THERMOSTAT - defrost termination	VALVE - KVQ 26, 40, 48
SCREW - keeper 88	48	VALVE - liquid injection 42, 48
SCREW - linkage 94	TIMER 84	VALVE - liquid line 36
SCREW - module 12, 14	TRANSFORMER 62 , 86	VALVE - pressure regulator 22
SCREW - motor 8, 10, 12, 14	TRAY - high voltage 54, 58	VALVE - shutoff 18, 22, 26
SCREW - mtg vent 92	TRIM - edge guard 10, 12, 14	VALVE - solenoid 18, 20, 22, 24, 28,
SCREW - orifice 8, 88	TUBE 44	44, 48
SCREW - plate 74 , 88 , 90 , 92 , 100	TUBE - bottom 22	VALVE - solenoid liquid injection 26
SCREW - plate to box 62	TUBE - check valve to dehydrator 26	VALVE - solenoid, liquid injection 48
SCREW - rail 54, 58	TUBE - condenser coil to receiver 28	VALVE - warm gas bypass 42
SCREW - receptacle 86	TUBE - condenser to condenser 38	VENT 14
SCREW - recorder 74	TUBE - condenser to filter 38	VENT - air 92, 94
SCREW - relay board 52, 56	TUBE - condenser to indicator 18, 22	144
SCREW - sensor 14	TUBE - condenser to receiver 18	W
SCREW - strap 90	TUBE - dehydrator to valve 22	WASHER 18, 22, 52, 56, 60, 74, 82,
SCREW - tank 38	TUBE - discharge 18, 22	88, 90, 92, 94
SCREW - thermometer 82	TUBE - discharge to compressor 26	WASHER - dome 8, 88
SCREW - transformer 62, 86	TUBE - discharge valve to compressor	WASHER - insulating 14, 26, 52, 56,
SCREW - valve 18	26	60, 74, 100
SEALER - locking 38	TUBE - drier to heat exchanger 26	WASHER - insulator 12, 14, 26, 54,

INDEX ALPHABETICAL BY DESCRIPTION

58, 62, 92, 94 WASHER - shoulder 94 WINDOW 74