

Mobility Axiom — Quick Guide

What you need on this PC

Item	Required?	Notes
Windows 10/11 (64-bit)	Yes	Administrator rights for Docker
Node.js	No	Included in <code>Mobility-Axiom\tools\node\</code>
Docker Desktop	Yes (VC only)	Download
Internet	First install only	Docker image pull; map tiles are offline

Install (once)

1. **Unzip** the full **CN Trial Mobility** folder (e.g. `C:\CN-Trial\`).
2. **Install Docker Desktop** — start it (whale icon steady).
3. Double-click `Install-Mobility.bat` in the pack root.
4. Double-click `Start Mobility.bat` each time you use Mobility.

Do not run `npm install` — libraries are pre-built in the pack.

First login

Field	Value
URL	<code>http://:3888</code>
Username	<code>global</code>
Password	<code>global123</code>

Language: **English** or **中文（简体）** on login page.

Map

This pack includes **offline map tiles** (Beijing area). No internet needed for the basemap.

BWC online (short)

1. **Settings** → **Server Config** → **Network** — set server IPv4.
2. **Settings** → **Server Config** → **BWCs** — add Device ID + officer name.
3. On BWC SIP screen — use **Type on BWC** values (IPv4 only).

Video Conference

Install **MobilityConference-1.5.6.apk** on Android. Docker must be running.