

Mobility Axiom — User Manual (Operator Guide)

Audience: Dispatchers, supervisors, evidence staff, control-room operators.

Related docs: **Quick Guide** (install) · **Configuration Manual** (server/BWC setup) · **README.txt** (pack layout)

This guide walks through **every tab**, **every major button**, and **step-by-step workflows** in the dashboard. UI labels match your selected language; this manual uses English names as they appear in the English UI.

Table of contents

1. [What the system does](#)
 2. [Sign in, language, sign out](#)
 3. [Header bar \(top of every screen\)](#)
 4. [Main layout — Operations tab](#)
 5. [Device Summary \(fleet table\) — detailed](#)
 6. [SOS — banner, log, incident report](#)
 7. [PTT groups and Messages](#)
 8. [Map — pins, panels, toolbar](#)
 9. [Geofencing — step by step](#)
 10. [Video wall \(6 panels\) — detailed](#)
 11. [Evidence & Docking — all sub-tabs](#)
 12. [Command Wall — Live wall & Display room](#)
 13. [Centre Summary](#)
 14. [Video Conference — Live, Lobby, Recordings, Settings](#)
 15. [Settings hub & Audit Trail](#)
 16. [User roles and permissions](#)
 17. [Workflow cookbook \(shift scenarios\)](#)
 18. [Troubleshooting](#)
-

1. What the system does

Capability	Where in UI	What you can do
Live GPS map	Operations → map	See officer location, SOS, recording status
Live BWC video	Map pin panel, video wall, Command Wall	Watch up to many streams; 6 on Operations by default
Voice / PTT	Fleet table, map pin, PTT groups	One-to-one or group push-to-talk
SOS handling	Header banner, SOS log, map	Alarm, report, folder export
Text to BWC	Operations → Messages	Send text to online cameras
Evidence library	Evidence tab	Search dock uploads, server recordings, case files
Video conference	Video Conference tab	Room with phones, PCs, live BWC share
Administration	Settings → Server Config	Network, BWC list, operators (super admin)

2. Sign in, language, sign out

2.1 First login

1. Open browser (Chrome or Edge recommended).
2. Go to `http://<server-ip>:3888` (trial on same PC: `http://localhost:3888`).
3. Enter **Username** and **Password** (trial default: `global` / `global123`).
4. Click **Sign in**.

2.2 Change language

- **At login:** use the language dropdown before signing in.
- **After login:** top-right **Language** dropdown in the header.
- APAC trial: English, Korean, Thai, Indonesian, Filipino.

All menus, buttons, and hints switch immediately.

2.3 Change your password (super admin)

1. **Settings** tab → **Server Config**.
2. Open **Dashboard Auth** (left nav inside Server Config).

3. Find your user row → set new password → **Save** on that row.

2.4 Sign out

1. **Settings** tab.
2. Left panel → **Sign out**.
3. Browser returns to login page. Always sign out on shared PCs.

3. Header bar

Visible on every tab.

Control	Location	What it does
Mobility Axiom logo	Top left	Brand; no action
Voice mute 	Top right	Mute/unmute spoken SOS and alert voice prompts
Repeat	Top right	Replay last voice alert (useful if dispatcher missed it)
Language	Top right	Change UI language
SOS banner	Below header (when active)	Red strip: device name, time, acknowledge actions — appears only during open SOS

Tip: If you hear no voice alerts, check voice mute is off (icon not struck through).

4. Main layout — Operations tab

Operations is the **default home screen** after login.

4.1 Three columns

Area	Contents
Left sidebar	Device Summary, SOS log, PTT groups, Messages, Storage shortcuts
Centre	Interactive map + map toolbar

Area	Contents
Right	Six live video wall panels

4.2 Collapse sidebar

Click ◀ on the narrow gutter between sidebar and map to hide the fleet panel and gain map space. Click again to show.

4.3 Top nav (only on Operations)

When **Operations** tab is active, extra controls appear in the top bar:

Control	Action
Auto-rotate	Checkbox — cycles cameras across the 6 wall panels automatically
Popout Matrix	Opens full-screen video matrix on another monitor
Config	Opens video wall assignment dialog

4.4 Command Wall awareness strip

If Command Wall is open elsewhere, a thin bar may appear above the map: **Open Command Wall** → — click to jump to that tab.

5. Device Summary (fleet table)

Location: Operations → left sidebar → **Device Summary**.

Summary line: e.g. 3 online • 5 devices — quick fleet health.

5.1 Search and filter

1. **Search** box — type officer name or device ID; table filters live.
2. **Filter** dropdown:
 - **All** — every registered BWC
 - **Online only** — units currently connected
 - **Offline only** — registered but not connected

5.2 Table columns — what to click

Column	How to use	Notes
Pin	Click once	Toggles map pin + floating live video panel. Click again to remove pin.
PTT	Press and hold	Talk to this BWC only. Release to stop. No video on PTT.
Call	Click	Starts voice call session to BWC (no video).
GPS	Click	Opens route / GPS track view for historical path.
<i>(checkbox)</i>	Tick	Used with PTT groups — select 2+ online units.
Device	—	Shows officer nickname and device ID.
Status	—	Online (green) or Offline (grey).

5.3 Bulk pin actions

Button	When enabled	Action
Open All (Up to 6)	At least one online	Pins up to six online devices on map simultaneously
Clear map pins	Pins open	Removes all floating pin panels from map

5.4 Workflow — monitor one officer

1. Find officer in table (search if needed).
2. Confirm **Online**.
3. Click **Pin** → map zooms; floating video opens.
4. To talk: hold **PTT** on row OR on map pin panel.
5. To stop video on map: click **Pin** again or close pin panel.

5.5 Workflow — call without video

1. Click **Call** on fleet row.
2. Wait for BWC to answer (device-dependent).
3. End call from BWC or dashboard when done.

5.6 Empty table

No devices yet — no BWCs registered. Super admin must add devices under **Settings** → **Server Config** → **BWCs** (see Configuration Manual).

6. SOS

6.1 Active SOS — header banner

When a BWC triggers SOS:

1. **Red banner** appears under header with device identity and time.
2. Map typically **zooms** to SOS location.
3. Pin shows **SOS** status chip.
4. Voice alert may play (unless muted).

Dispatcher actions:

1. Set **response radius** (200–1000 m) if needed — red circle on map shows nearby units.
2. Click **Pin** if not already open — confirm live video on the alarm officer.
3. **Acknowledge** — see §6.1b (forms PTT team from checked nearby units), **or** click **PTT team** on the banner first.
4. **Press and hold PTT** on wall panel or map pin to talk to the **whole team** when **PTT TEAM · ON** is shown.
5. Open **SOS log** row for full report (below).

6.1b Response radius and SOS PTT team

Banner control	Action
Radius chips	200 / 300 / 400 / 500 / 1000 m — who counts as “nearby” on the map
Summary line	Nearby unit names and distances
PTT team	Push one PTT group now (alarm officer + online units in radius); alarm stays open
Acknowledge	Close alarm in the log; see steps below

Recommended — Acknowledge with auto PTT team:

1. Click **Acknowledge** on the banner.
2. In the dialog, **nearby units are checked by default** — uncheck any you do not want on the team.
3. Optional note → **Submit / close**.
4. Wait for toast **PTT team ON — ...** (needs at least one checked online helper besides the alarm officer).
5. **Press and hold PTT** on the alarm officer’s wall panel or map pin — all checked units hear you (audio only, not a phone call).

Manual PTT team (alarm still open): Click **PTT team** on the banner instead of step 1–3 above, then hold PTT as in step 5.

Notes:

- Helpers must be **online** and inside the radius (GPS on map).
- Uncheck **all** helpers in Acknowledge if you only want to log the alarm without forming a team.
- Server must have PTT enabled (see Configuration Manual).

6.2 SOS log panel

Location: Operations → left sidebar → **SOS log**.

Element	Action
Chart	Visual count of recent SOS events
Event rows	Click row → incident detail dialog + map focus
Open incident files	Opens Windows folder with SOS packages on server
Download CSV	Export log for compliance
Clear list	Clears on-screen list only (not server files)
Reload list	Refresh from server

6.3 SOS incident detail dialog

After clicking a log row:

Button	Action
Open in new tab	Full HTML report in browser tab
Close	Dismiss dialog
Server folder (admin)	Open raw incident folder on server

Some incidents require **PIN unlock** before viewing sensitive report content — enter agency PIN → **Unlock**.

6.4 Create case file from SOS

From **Evidence** → **Case Files** → **Create from SOS** links evidence workflow to the alarm (see §11.4).

7. PTT groups and Messages

7.1 PTT groups

Location: Operations → **PTT groups** box.

Purpose: One push-to-talk channel for multiple BWCs (e.g. all units at a scene).

Steps:

1. **Option A — map group:** Select coloured group from dropdown (groups defined in Server Config → Map groups).
2. **Option B — manual pick:** Tick checkboxes on 2+ **online** rows in fleet table.
3. Review **Members** list — click **x** to exclude, **+** to include before joining.
4. Click **Join group PTT** — status line confirms.
5. Hold **PTT** on any grouped device to broadcast to all members.
6. Click **Ungroup all** when incident ends.

7.2 Messages

Location: Operations → **Messages**.

1. **Online BWCs** list shows who can receive text.
2. Click officer name → chat thread opens.
3. Type in text field → **Send**.
4. Multiple threads: tabs appear for each open chat.
5. **Clear thread** — removes messages from your view (server may retain per policy).

Retention: UI shows last 24 hours; server stores up to 30 days.

8. Map

8.1 Map basics

- Pan: click-drag map.
- Zoom: mouse wheel or +/- controls.
- **Pin colours** = map groups (legend appears bottom-left when pins visible).
- **Offline** devices do not show GPS pins.

8.2 Floating pin panel

Opened by clicking **Pin** on fleet row or clicking map pin.

Part	Use
Title bar	Officer name, device ID — drag to move panel
Live video	Real-time BWC camera
PTT button	Hold to talk
Minimize / Expand	Resize panel
Status badges	Online, SOS, REC (SD), SRV REC (server), Fall, Patrol
Close (×)	Closes panel — wall video may continue on right

Stacked panels: If multiple pins open, hint says **Stacked — drag panel headers apart**.

8.3 Map toolbar (below map)

Order of use for remote commands:

1. Select **online BWC** from dropdown (required for snapshot/record).
2. Use action buttons on the right.

Button	Steps	Result
Wall Map	Click	New window — map only for TV/monitor (display mirror; control stays here)
Snapshot	Select BWC → Snapshot	Still image captured on device
Start SD record	Select BWC → Start	Records to BWC SD card
Stop SD record	Select BWC → Stop	Ends SD recording
Record to server	Select BWC → Start	Server saves live stream to evidence path
Stop server record	Click Stop	Ends server recording
Set geofencing	See §9	

Button	Steps	Result
Clear geofencing	See §9	

Permission box: If remote control blocked on BWC, **Permission** button explains — officer may need to grant remote control on device.

9. Geofencing

9.1 Set geofence

1. Map toolbar → enter **radius** in metres (e.g.).
2. Click **Set geofencing**.
3. Dialog: choose target BWC (online).
4. On map: **drag orange centre** or **white edge** to position, or click map to place.
5. Click **Save geofence** on map bar.
6. Toast confirms when BWC enters/leaves zone.

9.2 Clear geofence

1. Click **Clear geofencing**.
 2. Select BWC in dialog.
 3. Confirm **Clear geofencing**.
-

10. Video wall

Location: Operations → right column (six panels).

10.1 Each panel

- Shows one live BWC stream when assigned.
- **Stop** on panel — stops that stream only.
- Empty panel — grey placeholder until device pinned or configured.

10.2 Auto-rotate

1. Top nav → tick **Auto-rotate**.

2. System cycles online cameras across panels every few seconds.
3. Untick to stop.

10.3 Popout Matrix

Opens dedicated full-screen grid on second monitor — useful for supervisor desk.

10.4 Config dialog (assign cameras)

1. Top nav → **Config**.
2. For **each of 6 panels**, choose source:
 - Fixed **device ID**
 - **Map group** (rotates within group)
 - **All online**
 - Custom ID list
3. **Download wall template (CSV)** — edit in Excel → **Import wall CSV**.
4. **Export wall CSV** — backup current layout.
5. **Save** — applies immediately.
6. **Cancel** — discard changes.

Note: BWCs must be registered under Server Config → BWCs before they appear in lists.

11. Evidence & Docking

Tab: Evidence & Docking (top nav).

Sub-tabs (horizontal nav inside Evidence):

Sub-tab	Purpose
Overview	Stats — how much evidence indexed, guidance
Docking Stations	Register physical docks, see bay status
Evidence Library	Searchable table of all files
Case Files	Investigation case folders linking evidence
Route & GPS	Replay GPS tracks (evidence context)
Storage	Super admin — folder paths, FTP, scan (hidden if no permission)

11.1 Evidence Library — daily use

1. Open **Evidence Library** sub-tab.
2. Click **Refresh** to load latest index.
3. Use search/filter toolbar (officer, date, source).
4. Click row **Detail** → preview player opens.
5. **Download** column — save file locally (if permitted).
6. **Secure export** — may prompt for extra confirmation (role-dependent).

Sources you may see: FTP dock upload, live capture, SOS auto-record, manual server record.

11.2 Docking Stations

1. **Docking Stations** sub-tab.
2. **Register dock** — add dock ID and name (admin).
3. Select dock in list → **bay grid** shows slots and upload status.
4. When officer places BWC in dock, files upload via FTP — appear in Library after scan.

11.3 Case Files

1. **Case Files** sub-tab.
2. **New case file** — enter title, officer, narrative.
3. **Create from SOS** — pre-fills from SOS incident.
4. Filter: search, period, open/closed status.
5. Open case → link evidence from Library → write report → close case when done.

11.4 Route & GPS

1. **Route & GPS** sub-tab.
2. Select device and time range.
3. Map replays path — use for incident reconstruction reports.

11.5 Storage (admin)

1. **Storage** sub-tab (super admin).
2. Set **FTP folder**, **live capture folder**, browse server paths.
3. **Save storage** → **Scan FTP for evidence** to index new files.

12. Command Wall

Tab: Command Wall.

Sub-tabs: Live wall | Display room

12.1 Live wall

Step	Action
1	Roster on left lists online devices — search if needed
2	Drag device chip onto empty panel in grid
3	Live video starts automatically
4	Choose layout : 1, 4, 9, 16, 32, or 1+7 focus
5	Rotate / Poll — auto-cycle feeds (set interval, pause/resume)
6	Click panel — spotlight (enlarge); click again for grid
7	PTT on wall toolbar — talk to devices on wall
8	Clear wall — remove all
9	Popout Matrix or ↗ — TV / second monitor

12.2 Display room

Pre-configured **multi-monitor** layouts for Windows extended desktop:

- **4-Monitor SOS Room** preset: Ops on monitor 1, live wall on 2, map mirror on 3, KPIs on 4.
- Follow on-screen **Open** buttons to launch each window to the correct display.

13. Centre Summary

Tab: Centre Summary (super admin / managers).

Section	What you see	Actions
KPI rings	Online, offline, open SOS, SOS week, storage, uptime	Hover for detail
Period selector	Daily / weekly / monthly / yearly	Change graph range

Section	What you see	Actions
SOS trend chart	Bar/line trend	Download chart PNG
Storage breakdown	Folder sizes	Identify disk pressure
System health	SIP, PTT, fleet link up/down	If red, see Configuration Manual
Recent activity	Who did what	Click row for detail
AI assistant	Chat box	Ask e.g. "How many devices online?" → Ask

Refresh button updates all widgets.

14. Video Conference

Tab: Video Conference. Requires **Docker Desktop** running.

Sub-tabs: **Live** | **Lobby** | **Recordings** | **Settings**

14.1 Join a room (Live)

1. **Live** sub-tab.
2. Enter room name or pick recent room.
3. Click **Join Room**.
4. Allow camera/microphone in browser prompt.
5. Video tiles appear — your self-view and others.

14.2 Layout controls (in room)

Layout	Best for
Gallery	Equal tiles — everyone visible
Speaker	Active speaker large
Focus	One speaker full screen
2-up	Two main feeds
Briefing	Shared content main stage

Layout	Best for
Side-by-side	Share left, people right
PiP	Picture-in-picture

14.3 Share content

- **Share screen** — show desktop/apps.
- **Share image** — upload still for briefing.

14.4 Add BWC live to room

1. In room, find **Body Cameras (BWC)** section.
2. Dropdown → select **online** BWC.
3. **Add to Room** — live body camera appears as participant tile.
4. **Remove BWC Share** when done.

14.5 Host tools (super admin / host)

- Mute all, grant/deny speak floor, **End Room**.

14.6 Lobby

Schedule or advertise rooms; waiting participants (if configured).

14.7 Recordings

List server-recorded conference files — play/download per policy.

14.8 Settings

Set **Phone / browser video URL** (WebSocket) if mobile users cannot connect outside LAN.

14.9 Android app

1. Install `MobilityConference-1.5.6.apk`.
2. Server URL = dashboard URL.
3. Sign in → join same room name → enable camera.

15. Settings & Audit Trail

15.1 Settings hub

Tab: Settings.

Health strip (top): Fleet count, FTP status, uptime, license.

Left panel:

Field / button	Meaning
BWC register IP	IPv4 for cameras — must match camera SIP screen
Operator login	URL for read-only operator accounts
Deployment	Lab / LAN / Cloud mode
Signed in	Your user + role badge
Server Config	Full admin (network, BWCs, users)
Tech admin	License tools (super admin)
Audit Trail	Compliance log
Sign out	End session

Device lifecycle cards:

Card	Click Manage to
Onboarding	Step-by-step first BWC setup wizard
Assets	Device inventory
Configuration	Jump to Server Config
Maintenance	Open storage folders
Faults & SOS	Centre Summary
Monitoring	Diagnostics
Firmware	OTA inventory

15.2 Audit Trail

Open: Settings → **Audit Trail**.

1. Set **From** / **To** dates.
 2. Filter **Category**, **Action**, **User**, free-text **Search**.
 3. **Apply** → table fills.
 4. Click row → **Event detail** side panel (JSON details).
 5. **Export CSV** (if permitted) for auditors.
 6. **Previous** / **Next** pages for long histories.
-

16. User roles

Role	Operations	Evidence	Command Wall	VC	Server Config
Super admin	Full	Full + storage	Full	Full + host	Edit all
Operator	Full	View/search	Full	Join	Read-only
Custom	Per toggle	Per toggle	Per toggle	Per toggle	Per toggle

Missing tabs or banners like "*access not granted*" = ask super admin to enable under **Dashboard Auth**.

17. Workflow cookbook

Shift start (dispatcher)

1. Confirm server running (`Start Mobility.bat`).
2. Login → Operations.
3. Check `N online · M devices` .
4. Settings → verify BWC register IP.
5. Test one **Pin** + **PTT** with field unit.

Active incident — single officer

1. Search officer → **Pin**.
2. **Record to server** if policy requires.
3. Hold **PTT** for instructions.
4. On close: stop server record.

Multi-unit scene

1. Tick 3+ online units OR select map group.
2. **Join group PTT.**
3. Optional: **Open All (Up to 6)** for map overview.

SOS response

1. Read header banner; set **radius** if needed.
2. Pin + live video on alarm officer.
3. **Acknowledge** — leave nearby helpers **checked** → PTT team forms automatically (\$6.1b), **or PTT team** on banner first.
4. **Press and hold PTT** on wall or pin to brief the team.
5. SOS log → open report.
6. Evidence → **Create from SOS** case file.

Evidence handover to investigations

1. Evidence → Library → filter by date/officer.
2. Download or secure export.
3. Case Files → link clips to case ID.

Control room TV

1. Command Wall → 16 layout.
2. Drag all online units.
3. Rotate 30s.
4. Popout to TV HDMI PC.

18. Troubleshooting

Symptom	Likely cause	Fix
All devices Offline	Wrong server IP on cameras	Configuration Manual → Network + Type on BWC
One device Offline	ID/password mismatch	Check BWCs tab vs camera SIP screen
Pin works, no video	Firewall 3889	Open port on server
PTT silent	Tapping not holding	Hold PTT; check group not conflicting

Symptom	Likely cause	Fix
SOS PTT reaches one unit only	No team formed	Ack with helpers checked or PTT team ; wait for PTT team ON toast
No nearby units in Ack list	GPS missing or offline	Wait for map positions; widen radius
No GPS pin	GPS off on BWC	Enable GPS; wait 30s
VC fails	Docker stopped	Start Docker; re-run Install-Mobility.bat
Evidence empty	FTP path wrong or not scanned	Storage tab → Scan FTP
Cannot edit server	Operator role	Login as super admin
Map blank grey	No tile internet (APAC)	Needs internet for OSM tiles; CN pack uses offline tiles

Document map

You need...	Read...
Install Docker, bats, first login	Quick Guide
SIP, firewall, BWC registration, operators	Configuration Manual
Day-to-day dashboard use	This User Manual