

Mobility Axiom — Manwal ng Configuration

Para sa: IT, super admin, installer.

Basahin kasama: [Quick Guide](#) · [User Manual](#)

Saklaw: server setup, BWC registration, operators, storage, firewall, video conference — may numbered steps.

Talaan ng nilalaman

1. [Bago magsimula](#)
 2. [Buksan ang Server Config](#)
 3. [Network & deployment](#)
 4. [Irehistro ang BWCs](#)
 5. [Map groups](#)
 6. [Dashboard Auth](#)
 7. [Evidence storage](#)
 8. [Video Conference](#)
 9. [Centre Summary AI](#)
 10. [Firewall at ports](#)
 11. [Trial license](#)
 12. [Password at audit](#)
 13. [Checklist pagkatapos i-setup](#)
-

1. Bago magsimula

Item	Kailangan
Server PC	Windows 10/11 64-bit, static LAN IP inirerekomenda
Pack	Na-unzip; <code>Install-Mobility.bat</code> isang beses
Docker Desktop	Naka-install at tumatakbo (VC lang)
BWC cameras	Naka-on, network OK, SIP screen accessible

Item	Kailangan
Network	Parehong LAN; IPv4 lang sa keypad ng camera

Huwag mag-install ng hiwalay na Node — kasama sa `Mobility-Axiom\tools\node\` .

2. Buksan ang Server Config

1. Mag-sign in bilang **super admin** (trial: `global`).
2. **Settings** tab → **Server Config**.
3. Kaliwang nav: **Network & deployment** | **BWCs** | **Map groups** | **Dashboard Auth**.

Operator accounts: **read-only** lang.

3. Network & deployment

3.1 Deployment

Piliin ang **LAN server** → **Save server settings**.

3.2 LAN network (mahalaga)

1. **BWC SIP server IP** = **IPv4** ng PC (hal. `192.168.1.10`) — hindi hostname.
2. Tandaan ang HTTP port `3888` at video WS `3889` .
3. **Save server settings**.

3.3 BWC camera register

Itakda ang Platform ID, Realm, Password → kopyahin ang **Type on BWC** sa bawat camera SIP screen.

4. Irehistro ang BWCs

Tab: BWCs

1. **Add row** → **Device ID** (eksaktong tulad sa camera) → **Officer** → **Map group** (opsyonal).

2. Save BWC list.

SIP screen ng camera:

Field	Ilagay
SIP server	IPv4 ng server
Port	5060
Platform ID / Realm / Password	Pareho sa Server Config
Device ID	Pareho sa row sa BWC list

Maghintay ~30s → **Operations** → **Online**.

Trial pack: `FM_SEED_BWC_ID=` walang laman — walang demo device.

5. Map groups

Gumawa ng grupo may pangalan at kulay → i-assign sa BWCs tab → para sa kulay ng pin, video wall, PTT.

6. Dashboard Auth

Operator: payagan ang Operations/Evidence/Command Wall/VC — huwag payagan ang edit ng Server Config → **Save** sa row.

Super admin: dagdag ng row → **Save**.

7. Evidence storage

FTP folder, live capture, evidence index → **Save storage** → **Scan FTP for evidence**.

NAS: i-mount muna sa Windows.

Opsyonal: **Auto-record server video on SOS alarm**.

8. Video Conference

1. Docker Desktop.
2. `Install-Mobility.bat` — LiveKit.
3. **Video Conference** → **Settings** — WebSocket URL para sa phone (hal. `ws://192.168.1.10:7880`).

I-distribute ang `MobilityConference-1.5.6.apk` .

9. Centre Summary AI

Model sa `Mobility-Axiom\vendor\llm\` (~2 GB). Walang download on-site. Unang **Ask** 1–2 minuto mag-load.

10. Firewall at ports

Port	Serbisyo
3888	Dashboard HTTP
3889	Live video WebSocket
5060	SIP
7880	LiveKit
40130+ UDP	RTP

11. Trial license

5 BWC · 10 dashboard users · 1 taon (ayon sa license file).

12. Password at audit

Dashboard Auth → bagong password → **Save**. **Audit Trail** → filter → **Export CSV**.

13. Checklist pagkatapos i-setup

Hakbang	OK?
Install-Mobility.bat walang error	☐
Docker tumatakbo	☐
<code>http://localhost:3888</code> bukas	☐
LAN IP = IPv4 ng PC	☐
BWC naka-save	☐
SIP camera tumutugma	☐
Online sa 60s	☐
Pin may live video	☐
PTT naririnig	☐
FTP scan OK	☐
VC Join Room OK	☐
Operator read-only test	☐

Kung may fail: User Manual §18 at `VIEW-LOG.bat` .