

Mobility Axiom — 빠른 시작 가이드

이 PC에 필요한 것

항목	필수?	설명
Windows 10/11 (64비트)	예	Docker 설치 시 관리자 권한
Node.js	아니오	패키지에 포함 (Mobility-Axiom\tools\node\)
Docker Desktop	예 (화상회의)	다운로드
인터넷	최초 설치 시	화상회의용 Docker 이미지 다운로드

설치 (한 번)

- 배송 폴더 전체를 압축 해제 (예: C:\Mobility-Trial\).
- 위 링크에서 **Docker Desktop** 설치 후 실행 — 고래 아이콘이 안정될 때까지 대기.
- Install-Mobility.bat** 더블클릭 (패키지 루트).
 - 번들 Node 및 라이브러리 확인
 - LAN IP로 .env 생성
 - LiveKit(화상회의) 시작
- 사용할 때마다 **Start Mobility.bat** 더블클릭.

npm install 을 실행하지 마세요 — 의존성은 패키지에 포함되어 있습니다.

첫 로그인

Field	Value
URL	http://<서버-IP>:3888
사용자명	global
비밀번호	global123

BWC 온라인 (요약)

- Settings** → **Server Config** → **Network** — set server IPv4 → **Save server settings**.
- Settings** → **Server Config** → **BWCs** — add Device ID + officer name → **Save BWC list**.

3. On each BWC SIP screen — enter values from **Type on BWC** (IPv4 only).
4. Wait ~30s — device shows **Online** in fleet list.

화상 회의 (휴대폰)

1. Install **MobilityConference-1.5.6.apk** on Android.
2. Server URL = same as dashboard (<http://:3888>).
3. Sign in → open room → Join with camera.

체험 라이선스

5 BWC · 10 dashboard users · 1 year.

Full steps: **Configuration Manual** in this folder.