

Mobility Axiom — คู่มือเริ่มต้นอย่างรวดเร็ว

สิ่งที่ต้องมีบน PC นี้

รายการ	จำเป็น?	หมายเหตุ
Windows 10/11 (64-bit)	ใช่	สิทธิ์ผู้ดูแลระบบสำหรับ Docker
Node.js	ไม่	รวมอยู่ในแพ็คเกจ (Mobility-Axiom\tools\node\)
Docker Desktop	ใช่ (VC)	ดาวน์โหลด
อินเทอร์เน็ต	ติดตั้งครั้งแรก	ดึง Docker image สำหรับ Video Conference

ติดตั้ง (ครั้งเดียว)

1. แยกไฟล์ โฟลเดอร์ทั้งหมด (เช่น C:\Mobility-Trial\).
2. ติดตั้ง **Docker Desktop** จากลิงก์ด้านบน เปิด Docker — รอจนไอคอนวาฟองที่.
3. ดับเบิลคลิก `Install-Mobility.bat` (โฟลเดอร์รากของแพ็คเกจ).
4. ทุกครั้งที่ใช้งาน ดับเบิลคลิก `** Start Mobility.bat**` .

อย่า รัน `npm install` — ไบเบรารีถูกสร้างไว้ในแพ็คเกจแล้ว.

เข้าสู่ระบบครั้งแรก

Field	Value
URL	http://:3888
ชื่อผู้ใช้	global
รหัสผ่าน	global123

BWC ออนไลน์ (สรุป)

1. **Settings** → **Server Config** → **Network** — set server IPv4 → **Save server settings**.
2. **Settings** → **Server Config** → **BWCs** — add Device ID + officer name → **Save BWC list**.
3. On each BWC SIP screen — enter values from **Type on BWC** (IPv4 only).
4. Wait ~30s — device shows **Online** in fleet list.

Video Conference (โทรศัพท์)

1. Install **MobilityConference-1.5.6.apk** on Android.
2. Server URL = same as dashboard (<http://:3888>).
3. Sign in → open room → Join with camera.

ใบอนุญาตทดลอง

5 BWC · 10 dashboard users · 1 year.

Full steps: **Configuration Manual** in this folder.