



Input: 5 V from the bike USB socket. F1 limits the current; D1 clamps over-voltage and, if the supply is reversed, conducts forward until F1 trips.
Switches: UP, DOWN, LEFT, RIGHT seen by the rider. Each switch uses a diagonal pad pair, so the result does not depend on which pads the part pairs internally. Pressing the stick straight in closes all four; the firmware reads that chord as the centre press.

Four C&K KSC2 switches under the stick disc, 5 V input protection

Sheet: /
File: joystick.kicad_sch

Title: Open Rally Remote — joystick PCB

Size: A4	Date: 2026-10-10	**Rev: V0.23**
KiCad E.D.A. 10.0.6		Id: 1/1