





DS30 - DS5x

(Hardware rev. 1.20

Firmware rev. 1.09)

Programmable stepper motor drives with integrated Modbus-RTU field bus

User's Manual

The information in this document replace any other material previously published.

LAM Technologies reserves the right to change technical specification and price to any product here at any time and without further notice.

This manual contains reserved and proprietary information. All rights are reserved. It may not be copied, disclosed or used for any purposes not expressly authorized by LAM Technologies.

LAM Technologies warrants the products herein against defects in materials and workmanship for a period of 12 months. This warranty does not apply to defects resulting from an improper use, inadequate installation or maintenance. This warranty also does not apply in case the products are received modified or integrated with other parts and/or products not expressly authorized or provided for by LAM Technologies. This warranty also does not apply in case the product's label has been removed or modified.

Any assistance request must be addressed to the product's purchase source. In case of direct purchase from LAM Technologies a returned material authorization number (RMA) must be obtained from support@lamtechnologies.com clearly specifying the product code, the serial number, the problem found and the assistance required. The RMA will have to be clearly stated on each shipping documents otherwise the parcel could be rejected.

The customer shall be responsible for the packaging and shipping of the defective product to LAM Technologies and the shipment must be made charges prepaid. The product inspected, repaired or substituted will be available to be collected at LAM Technologies'.

During and within the warranty period, LAM Technologies can, on its judgment, repair or substitute the product. The cost of material and labor will not be charged within the warranty period.

The above warranty also does not apply to the software. LAM Technologies shall not be liable for any direct or indirect damages such as, but not limited to, costs of removal and installation, lost profits, coming from the use or the impossibility to use the software.

This manual is intended for skilled technical staff. In case the arguments, the terms and the concepts should not be clear you can contact support@lamtechnologies.com. It is forbidden to use the products herein described without being sure to have understood characteristics, installation and use procedures.

Even though products described have been designed with extreme care, they are not intended or authorized for use as components in applications intended to support or sustain life and in application in which the failure of the product could create a situation where injury or death may occur to people or animals.

LAM Technologies shall not be liable for any direct or indirect damages coming from the use of its products.

The information in this manual have been carefully checked and are believed to be accurate, however any suggestion to improve it will be highly appreciated.

LAM Technologies is a registered trade mark.

Contacts:

General information: info@lamtechnologies.com
 Technical support: support@lamtechnologies.com
 Sales information: sales@lamtechnologies.com

1	N	OTES, TEI	RMS AND WARNINGS	7
2	R	ISKS AND	PRECAUTIONS	9
3	II.	NTRODUC	TION	11
	3.1	PRODUCT	DESCRIPTION	11
	_		vailable models	
	_		lain Features	
	-		RIES	
4			TON	
•	4.1		ON	
	4.2		ICAL INSTALLATION	
	4.3		ING	
	4.4			
			ower Supply: AC models	
			ower Supply: DC models	
	4.		lotor	
	4.	.4.4 Co	ontrol Signals	
		4.4.4.1	Fiedlbus (DS5x series)	35
		4.4.4.		
		4.4.4.		
		4.4.4.		
		4.4.4.2 4.4.4.3	Digital inputs Digital outputs	
		4.4.4.4	Analog inputs	
		4.4.4.5	Analog outputs	
		4.4.4.6	Connection examples (PNP, NPN and Line Driver)	
		4.4.4.	6.1 Inputs	46
		4.4.4.		
	4.	.4.5 Ch	nassis setting	48
5	F	UNCTION	ALITY AND CONFIGURATION	51
	- 1	6	DESCRIPTION	F.4
	5.1			
	5.2		JRRENT	
	5.3		TIC CURRENT REDUCTION	
	5.4 5.5		WAVEFORM MODIFICATIONAND PROTECTIONS CONDITIONING	
			EDS	
	5.6 5.7		IONS	
	•		eneral description	
	-		nder voltage	
	_		ver voltage	
	_		ver temperature	
	_		nase-to-phase short circuit	
			nase-to-ground short circuit	
	_		nase-to-Vp short circuit (Vac)	
	_		terrupted phase A, interrupted phase B	
6			MING	
ь				
	6.1		N	
	6.2		. HARDWARE SIGNALS	
	6.3		REGISTERS	
	6.	.3.1 De 6.3.1.1	escription of each single register	
		6.3.1.1	Velocity	
		6.3.1.3	TargetPos	
		6.3.1.4	Position	
		6.3.1.5	CPosition	72
		6.3.1.6	MaxVel	72

	6.3.1.	.7 Acceleration	72
	6.3.1.	.8 Deceleration	73
	6.3.1.	.9 ControlMode	73
	6.3.1.		
	6.3.1.	,	
	6.3.1.	.12 StByCurrent_Percentage	74
	6.3.1.	.13 TimerA	74
	6.3.1.		
	6.3.1.		
	6.3.1.		
	6.3.1.		
	6.3.1.		
	6.3.1.		
	6.3.1.		
	6.3.1.	•	
	6.3.1.		
	6.3.1.		
	6.3.1.		
	6.3.1.		
	6.3.1.	5 1	
	6.3.1. 6.3.1.		
	6.3.1. 6.3.1.	0	
	6.3.1.	0	
	6.3.1.		
		ABLES	
		STANTS	_
		RUCTION BLOCKS	
	6.6.1	Assignment	
	6.6.1.		
	6.6.1.	• • • • • •	
	6.6.2	Function	
	6.6.2.		
	6.6.2.		_
		Jump	
	6.6.3.	.1 Unconditional jump	84
	6.6.3.	.2 Conditional jump	85
	6.6.4	Wait until	86
	6.6.5	Delay	87
	6.6.6	Return	88
	6.6.7	Mathematics	89
	6.6.8	Logic operations	
		MON PROGRAMMING CONSTRUCT	
	6.7.1	Loop	
	-	·	
	6.7.2	Delay without suspend program execution	
	6.7.3	For Next cycle	
	6.7.4	IfThenElse	
	6.7.5	Hysteresis	95
	6.7.6	Constraint of a value	96
	6.7.7	CounterA extension on 32bits	97
_	FIEL DE:		
7	FIELDBU	US	98
	7.1 GENER	RAL DESCRIPTION	98
	7.2 Mode	BUS-RTU COMMUNICATION PROTOCOL	98
	7.2.1	Data structure (frame)	
	7.2.2	Data processing (frame)	
	7.2.3	Checksum computation (CRC)	
	_	Data organization	
	7.2.4	<u> </u>	
	7.2.4.		
	7.2.4. 7.2.4.	- 7	
	1.7.4.	.a wull	103

DS30 - DS5x

8	TECHN	ICAL DATA	115
	7.3.6	Serialivariiber	113
	7.3.6	Serial Number	
	7.3.5	SpecialVersion	113
	7.3.4	HardwareRev	113
	7.3.3	FirmwareVer	
	7.3.2	ProductCode	
	7.3.1	RegTableVer	112
7.		OF THE REGISTERS AND USER'S VARIABLE	
_	7.2.5	on to one of the order (mask trice neglecter)	
	7.2.5		
	7.2.5		
	7.2.5	Supported functions	
	7.2.4		
	7.2.4		103

1 Notes, Terms and Warnings

In this manual some symbols, whose meaning is listed below, are used to underline particular arguments.



There is a dangerous condition which must be accurately evaluated and avoided. The not-respect of indications marked with this symbol can cause serious damages and injury to people, animals and things.



The subject is very wide and could require a deeper examination with the technical support.



The non-observation of what described could damage the products.



Features and functionalities which cannot be easily found in other products. A shortcut to reach a target is shown.



A change or repairing intervention which can be made directly by the user.



An aspect connected to the temperature or longevity of the product.

The terms listed below are also used:

Product

The microstepping drive described herein.

User

Who selects and/or installs and/or uses the product.

Application

The machine, the equipment, the device, etc. on which the product is applied.



2 Risks and Precautions

ATTENTION

Following are listed the most important warnings to be fully comprehended and applied by the user who, in case of non-complete comprehension or impossibility to apply them correctly, must not use the product at all.



The DS30 – DS5x drives are components. It is the user's responsibility as the installer to be sure the product complies with the rules and regulations in force. The user must also be trained in the installation of the electronic equipment to fully comprehend the features, the calibration parameters and the indications contents of this guide.

The user must provide for the application of all the local safety laws and regulations in force in the Country and/or application in which the product is used.



The user must provide that the product is inaccessible while powered on. The user must also consider that, because of the capacitors inside the drive, it is necessary to wait at least for 30 seconds after the power off before acceding to the drive. According to the external capacitors eventually mounted on the power supply circuit, it is possible the user shall have to wait for a longer time.



While working the product generates heat which can raise the temperature of some parts (as the heat sink, for example) up to values that can cause burns. Such a conditions remains for a long time even after the product has been powered off. The user must provide for the appropriate protections and signals, must train the operator, the technical support and risk maintenance staff, and then must indicate it in the service manual of the finished product.



The high performance drive is able to generate rapid accelerations with high motor torque. Never touch any mechanical part while the drive is powered on. The user must prearrange the application in order this condition is always granted.



Risks and Precautions DS30 – DS5x



The power supply of the product must be isolated from the electrical net. The user must always place a protective fuse in series to the power supply circuit.



The control signals are isolated from the power supply during normal working; anyway, during the designing of the application, the eventuality that in case of breakdown these lines could reach the same potential as the power supply, must be considered to meet safety requirements.



The product could be permanently damaged by corrosive substances (such as gas, salts, etc.), liquids or conductive dusts. Even a long and constant exposure to strong vibrations could cause the damage.



During some damage conditions the drive could emit sparks and fire. The cabinet and the nearby components must be chosen to tolerate this eventuality and to avoid propagation of flames to the application.



The products cannot be used in life support applications or where the failure of the products could cause death or injury to people, animals or things, or economic losses. The user not able to assure this condition must not use the products herein described.



Do not dismantle the product, do not try and repair it and do not modify it without being expressly authorized by LAM Technologies.



If the product is used in any manner that does not comply with the instructions given in this manual, then the product could be permanently damaged. For example, the product could be permanently damaged if power supplied with voltage superior to the allowed one, if supply polarity is inverted, if the motor is connected or disconnected while the drive is operating, and so on.



DS30 – DS5x Introduction

3 Introduction

3.1 Product description

The DS30 – DS5x series drives integrate a built-in flexible programmable motion controller able to perform accurate motor control both in speed and in position.



The programming is quick and simple and it is made putting in sequence the various functional blocks available in the *UDP Commander* development software tool, such as assignment blocks, conditional jump blocks, etc. Particularly powerful are the mathematical blocks able to execute additions, subtractions, multiplications and divisions and which allow to realize even complex applications.

The connection with the external devices is through 4 inputs and 2 digital outputs each one optocoupled, independently PNP or NPN or line driver usable. Two +/-10V analog inputs and one 0-10Vdc analog output complete the available interface signals.

Suitable for the bi-polar mode driving of two phase stepper motors at 4, 6 or 8 wires), the DS30 – DS5x series drives feature an accurate current control which assures a correct and smoothness movement of the motor. The use of last generation power components, together with the development of an innovative current control technology, has made possible to reach high level of efficiency, to be compact sized and to reduce drive heating.



The high technology present in the product has also allowed to overcome the previous full step or fractioned limited step solutions, offering at the same price a product able to drive in microstepping mode with an high step frequency.



The DS30 – DS5x drives series is equipped with a special port called DUP, designed for the programming, the debug and diagnostics of the drive. Through this special device it is possible to download into the drive the application program, to visualize the content of registers, I/O signals, etc.

The bundled drive software simply and quickly guides the user in all the programming phases and assists him during the diagnostics and application debug. Before starting to operate on the product be sure to have the latest software version.

The use of last generation components and technologies, together with the computerized test made on each single unit, gives to the product high reliability and economic competitiveness.



Introduction DS30 – DS5x

3.1.1 Available models

The DS30 - DS5x family drives are available in a complete range of models diversified according to the power supply voltage and the phase current delivered to the motor. Some of them are also available in the AC supply version, identified by the letter A at the end of the code (for example DSxx44A).

All the models share the same functional features:

Model	AC postupole supply (Va	voltage		er supply e (Vdc)	Effect phase c (Arm	urrent	cur	phase rent pk)
	Min	Max	Min	Max	Min	Max	Min	Max
DS3041			18	50	0.3	1.4	0.42	2.0
DS3041A	16	36			0.3	1.4	0.42	2.0
DS3044			20	50	1	4	1.4	5.6
DS3044A	18	36			1	4	1.4	5.6
DS3048			20	50	3	8	4.2	11.3
DS3048A	18	36			3	8	4.2	11.3
DS3073			24	90	0.8	3	1.1	4.2
DS3073A	20	65			0.8	3	1.1	4.2
DS3076			24	90	2	6	2.8	8.5
DS3076A	20	65			2	6	2.8	8.5
DS3078			24	90	4	10	5.6	14.1
DS3078A	20	65			4	10	5.6	14.1
DS3084			45	160	2	4	2.8	5.6
DS3084A	35	115			2	4	2.8	5.6
DS3087			45	160	4	8.5	5.6	12.0
DS3087A	35	115			4	8.5	5.6	12.0
DS3098			45	240	4	10	5.6	14.1
DS5x41			18	50	0.3	1.4	0.42	2.0
DS5x41A	16	36			0.3	1.4	0.42	2.0
DS5x44			20	50	1	4	1.4	5.6
DS5x44A	18	36			1	4	1.4	5.6
DS5x48			20	50	3	8	4,2	11,3
DS5x48A	18	36			3	8	4,2	11,3
DS5x73			24	90	0,8	3	1,1	4,2
DS5x73A	20	65			0,8	3	1,1	4,2
DS5x76			24	90	2	6	2,8	8,5
DS5x76A	20	65			2	6	2,8	8,5
DS5x78			24	90	4	10	5,6	14,1
DS5x78A	20	65			4	10	5,6	14,1
DS5x84			45	160	2	4	2,8	5,6
DS5x84A	35	115			2	4	2,8	5,6
DS5x87			45	160	4	8,5	5,6	12,0
DS5x87A	35	115			4	8,5	5,6	12,0
DS5x98	45	240	45	240	4	10	5.6	14.1



DS30 – DS5x Introduction

3.1.2 Main Features

- ✓ Simple programming at blocks
- ✓ Mathematical functions at 32bit
- ✓ Speed or position control
- ✓ Independent acceleration and deceleration ramps
- ✓ Absolute or relative positioning
- ✓ Resolution up to 3000rpm at 1/128 step/rev
- ✓ Quote from -2,147,483,638 to +2,147,483,647
- ✓ Four digital inputs and two +/-10V analog inputs
- ✓ Two digital outputs and one 0-10V analog output
- ✓ Optocoupled and differential I/O, independently NPN or PNP usable
- ✓ Analog inputs at 11bit
- ✓ Digital inputs from 3Vdc up to 28Vdc with current regulator
- ✓ Line driving supported
- ✓ Protective diode for inductive loads on each digital output
- ✓ Automatic current reduction settable from 0% up to 100% with increments of 10%
- ✓ Wide range of power supply
- ✓ Single power supply voltage for the whole drive
- ✓ Current setting with increments of 0.1Arms
- ✓ Accurate current control
- ✓ Resonance damping
- ✓ High efficiency, low losses and contained heating
- Colored and numbered removable terminal blocks for easy and fast wiring
- Complete diagnostics
- ✓ Over/under voltage protections
- ✓ Phase to phase short circuit protection both direct and crossed
- ✓ Phase to ground short circuit protection
- ✓ Positive supply short circuit protection
- ✓ Thermal protection
- ✓ Interrupted phase alarm independent for each phase
- ✓ Univocal indication for each anomaly
- ✓ Malfunctioning status LED indicator
- ✓ Motor qualification LED indicator
- ✓ Power supply LED indicator
- ✓ Digital development
- ✓ PC based simple setting
- PC based diagnostics
- ✓ Compact size
- ✓ Simple and fast DIN rail mounting
- ✓ Low cost



Introduction DS30 – DS5x

3.2 Accessories

The UDP30 interface is an essential accessory for the setting and diagnostics of the product.

Each drive is sold complete of the removable terminal blocks, anyway in case of loss or breach it is possible to re-order them making reference to one of the following codes.

Code	Description						
UDP30	Setting and diagnostic interface						
LSP1004	DIN rail kit consisting of hook and spring						
LSP4002	Terminal blocks kit consisting of:						
	1pc. numbered removable terminal block, red color, 2 poles						
	1pc. numbered removable terminal block, grey color, 5 poles						
	1pc. numbered removable terminal block, grey color, 10 poles						
LSP4004	5pcs. numbered removable terminal block, red color, 2 poles						
LSP4006	5pcs. numbered removable terminal block, grey color, 5 poles						
LSP4007	5pcs. numbered removable terminal block, grey color, 6 poles						
LSP4008	5pcs. numbered removable terminal block, grey color, 10						
	poles						




4 Installation

4.1 Inspection

Verify that the drive is not damaged, the package is intact and all accessories are included. Furthermore, control that the drive code corresponds to the ordered one, eventual special and customized version included. In case of problems please address to the product's vendor.


4.2 Mechanical Installation

The drive is designed to be mounted vertically on a 35mm DIN rail. To block the drive on the DIN rail insert first the bracket on the top, on the back of the drive, over the top of the DIN rail, keeping the drive slightly inclined as shown in the picture, then push the drive downward to engage the lower section of the rail. To verify the correct engagement of the drive try and pull it slightly upward to control that it is still in position.




To remove the drive from the DIN rail insert a small flat bladed screwdriver into the red colored hook on the bottom, on the back of the drive. Push the hook downward and pull the drive upward slightly rotating it, releasing it from the DIN rail as shown in the picture.





Insert a small flat bladed screwdriver into the red colored hook




Push the screwdriver slightly downward and pull the drive upward, releasing it from the DIN rail



The heat generated by the drive while operating must be dissipated toward the surrounding air. To help cooling, the drive must be installed vertically in an area with a sufficient air gap of about 50mm above and below the drive itself, with no obstructions (wiring cables are anyway allowed). No space needs to be left on the sides and more drives can be put side by side taking a very compact space.

According to the drive calibration and to the running cycle, the space can be also substantially reduced without compromising the correct working of the drive.





4.3 Air cooling


The product you have purchased has an exceptional efficiency that often allows the use even in the absence of forced ventilation.




Whereas the drives is used with high calibration current or at high power supply voltage, whereas the working cycle is very heavy or the ambient temperature is high, it is possible to apply to forced ventilation to maintain the drive temperature whiting the functioning range values.



The fan can be positioned over or under the drive. A lateral position is not recommended. Thanks to the compact size of the drive, one only and economic fan of 120mm x 120mm can supply air circulation sufficient for 6 drives simultaneously (models of 18mm wide).



In case of a reduced fan size, it must be set in a rear position and at about 30mm high from the drive. A nearer or more distant position could reduce its effectiveness.






It is important to avoid the drive is covered with powder, dust or other. The buildup of such substances inside the drive could cause the malfunctioning or the breaking of the drive. Filters and necessary solutions must be got ready to avoid these damages to occur.

4.4 Wiring



The use of numbered and colored movable terminal blocks makes easier the wiring of the drive.


All the terminal blocks have 5mm pitch to allow an easy wiring of signal and power cables.



All the terminal blocks do not contain iron and are supplied with mobile truck. The clamping screw is slotted head, sized for screwdriver of 3x0.6mm.



We recommend to apply a tightening torque of about 0.8Nm.



All terminals can tighten correctly cables with section between 0.1mm^2 and 2.5mm^2 (24...14 AWG).

We recommend to skin off the cable for 7/8mm as shown in the figure below.



4.4.1 Power Supply: AC models

The AC supply drives are identified by the letter A placed at the end of the code (ex. DS3044A). They integrate a rectifier bridge and the filter condensers necessary to rectify and filter the AC power supply voltage.



Therefore, this series of drives does not need an external power supply and can be directly connected to the output of a transformer with adequate voltage.

These products can also be supplied in DC, however take present that the rectifier bridge inside does not allow to recover the energy produced by the motor during the deceleration.




When supplying in DC a drive provided for the AC input, make reference to the parameters of the corresponding DC version (for example for the DS3076A refer to the DS3076) considering that the rectifier bridge inside has a total drop of about 3Vdc. This means that, if for example a drive provided for AC input is supplied with 35Vdc voltage, this will act, for the purpose of the applied voltage, as the corresponding supplied at about 32Vdc.

The following table resumes the working and breaking effective voltage values considering a sinusoidal waveform.

Symbol	Des	scription		Value		Unit
		•	Min	Тур	Max	
		DSxx41A	16	28	36	
	Nominal AC supply	DSxx44A DSxx48A	18	32	36	
Vac	voltage	DSxx73A DSxx76A	20	55	65	
		DSxx78A				
		DSxx84A DSxx87A	35	110	115	
		DSxx41A			42	
	AC supply voltage	DSxx44A DSxx48A				
Vacbrk	causing the	DSxx73A DSxx76A			75	
	permanent damage	DSxx78A				Vac
		DSxx84A DSxx87A			142	Vac
		DSxx41A DSxx41A	36.5		39	
	Over voltage	DSxx44A DSxx48A	40		42	
Vach	protection	DSxx73A DSxx76A	69		73	
	intervention	DSxx78A				
	threshold	DSxx84A DSxx87A	120		126	
		DSxx41A DSxx41A	12.5		14.5	
	Under voltage	DSxx44A DSxx48A	14		15.6	
Vacl	protection	DSxx73A DSxx76A	16		18.6	
	intervention	DSxx78A				
	threshold	DSxx84A DSxx87A	31		33.6	

The power supply is connected by the grey colored two poles connector.





	CN1 - Signal set-up (AC models)				
Contact n.	Description				
1	Vac, AC power supply voltage input				
2	2 Vac, AC power supply voltage input				



The overcoming of the *Vacbrk* voltage limit damages permanently the drive.

Do not install the drive before the wiring is complete.

For the connection with the transformer it is necessary to use a conductor with section adequate to the drive's calibration (for safety's it is better to use the max current supplied by the drive).

The following table resumes the cable sections suggested for each drive:

Model	Cable section (mm²)
DSxx41A	1
DSxx44A	
DSxx48A	2.5
DSxx73A	1
DSxx76A	1.5
DSxx78A	2.5
DSxx84A	1.5
DSxx87A	2.5

The power supply cable can be installed together with the ones connecting the drive to the motor. It is recommended not to place the power supply cable nearby the signal ones.

While choosing the transformer secondary voltage it is important to take into account the maximum net fluctuation expected in the worst operative conditions, the maximum vacuum voltage and the minimum full load voltage and to ensure that the maximum and minimum values, result of the combination of these components, are within the maximum and minimum voltage values specified for the chosen drive model.




The power that the transformer must handle is given by the one absorbed by the load (depending from the torque required to the motor as well as from the rotation speed), and by the motor and drive efficiency.

The power lost on the drive for each model is indicated in the following table.

Model	Min	Тур	Max	Unit
DSxx41A			7	W
DSxx44A			12	W
DSxx48A			21	W
DSxx73A			10	W
DSxx76A			20	W
DSxx78A			24	W
DSxx84A			20	W
DSxx87A	·		36	W

The following is an example of base connection.



The above scheme includes a three-phase transformer (note the distribution of the drives on the three phases). If necessary it is also possible to use a mono-phase transformer.

Also note that the wiring must be star-like, where the earth connections of the various components ends in one only point electrically connected to the metal chassis and the earth of the plant.



Do not connect the transformer secondary to earth otherwise there is a risk of permanent damage to the drive due to the short circuit created between the transformer secondary and the ground of the drive (terminal 5 of connector CN2).

As shown in the scheme, it is necessary to put in series to the transformer primary winding a filter able to stop the emissions coming from the drive and/or present on the main supply. Furthermore, the filter must be able to support the maximum power required by the drive plus the transformers losses.

The reduction level the filter must guarantee can vary a lot according to the laws applied to the field to which the application and/or installation belongs.

The producers of filters SHAFFNER and CORCOM can represent a good reference to find the right filter.

It is obligatory to provide on each phase of the transformer primary winding a fuse able to intervene in case of short circuit or malfuctioning. It is also obligatory to use a fuse on each drives' power supply conductor.

The following table relates the suggested value for some components according to the number of drives present in the application.

The calculation considers also an oscillation of the main supply voltage included within +10/-20%.



Model	Fuses Fn (A rit.)	Number of drives	Secondary T1 (Vac)	Power T1 (VA)
		1		50
	2	2	32	100
DSxx41A	_	3	32	150
		45		250
		68		350
		1		125
	6.3	2	32	250
DSxx44A	0.0	3	32	375
		45		600
		68		900
		1		250
	12.5	2	32	500
DSxx48A		3		750
		45		1100
		68		1800
		1		150
	4	2	55	300
DSxx73A		3		450
		45		700
		68		1000
		1		300
	8	2	. 55	600
DSxx76A	Ü	3		900
		45		1400
		68		2100
		1		400
	16	2	55	800
DSxx78A		3		1200
		45		1800
		68		2800
		1		350
	6.3	2	110	700
DSxx84A		3		1050
		45		1600
		68		2500
		1		700
	12.5	2	110	1400
DSxx87A	0	3		2000
		45		2500
		68		5000

The working voltage of the T1 transformer primary winding must be chosen according to the main supply voltage available during the installation of the application. The transformer must have a shield between primary and secondary windings which must be connected to earth with a short and not inductive connection. The secondary winding voltage is



meant without the load, with the primary winding supplied at the nominal voltage.



In the configurations with more than a drive, if the drives are not all calibrated to the maximum current and/or if the working cycle is not simultaneous, the power of the transformer can be considerably reduced. In some cases this can also be made when the motors' speed is limited.

The set composed by the filter and the transformer must be used only to supply voltage to the drives. It is advised against deriving other supplies from any of these parts. On the contrary, it is suggested to get auxiliary supplies using directly the main supply upstream of the filter.


4.4.2 Power Supply: DC models

The DC supply drives need a *Vp* voltage as specified in the table below. In the highest absorption conditions the power supply must grant a ripple voltage inferior to *Vprp*.

Symbol	L	Description		Value		Unit
		-	Min	Тур	Max	
		DSxx41	18	45	50	
		DSxx44 DSxx48	20	45	50	
Vp	Nominal DC	DSxx73 DSxx76 DSxx78	24	80	90	Vdc
	supply voltage	DSxx84 DSxx87	45	140	160	
		DSxx98	45	200	240	
		DSxx41			8	
		DSxx44 DSxx48				
Vprp	Allowed ripple	DSxx73 DSxx76 DSxx78			15	Vpp
	voltage	DSxx84 DSxx87			25	
		DSxx98			30	
		DSxx41	-0.5		58	
	Voltage causing	DSxx44 DSxx48				
Vpbrk	permanent	DSxx73 DSxx76 DSxx78	-0.5		105	Vdc
	damage	DSxx84 DSxx87	-0.5		200	
		DSxx98	-0.5		260	
	Over voltage	DSxx41	50.2		51.5	
	protection	DSxx44 DSxx48	54		56	
Vph	intervention	DSxx73 DSxx76 DSxx78	96		102	Vdc
V PII	threshold	DSxx84 DSxx87	170		180	
		DSxx98	242		255	
	Under voltage	DSxx41	16		17.8	
	protection	DSxx44 DSxx48	18		19.5	
Vpl	intervention	DSxx73 DSxx76 DSxx78	21		23.5	Vdc
	threshold	DSxx84 DSxx87DSxx98	41		44	



The power supply is connected by the red colored 2 poles connector. The positive terminal must be connected to the terminal 1, while the negative terminal to the terminal 2.



CN1 - Signals set-up (DC models)				
Contact n.	Description			
1	+Vp, positive DC supply voltage			
2	-Vp (GND), negative DC supply voltage			



Reverse polarity connection damages permanently the drive, just as the overcoming of the *Vpbrk* voltage limit.

Do not install the drive before the wiring is complete.

Never connect the drive with the power supply turned on.

If the distance between the drive and the power supply is more than 3m, it is necessary to place near the drive (less than 10cm) an electrolytic capacitor whose characteristics are listed below:

Model	C2 Voltage (Vdc)	C2 Capacity (μF)
DSxx41	63	470
DSxx44	63	470
DSxx48	63	1000
DSxx73	100	220
DSxx76	100	470
DSxx78	100	1000
DSxx84	200	470
DSxx87	200	1000
DSxx98	250	1000

To connect together the power supply, the drive and the eventual local capacitor, it is necessary to use a conductor with section adequate to the drive's current calibration (anyway, for safety's reason, it is better to use the maximum current supplied by the drive).

The following table resumes the cable section suggested for each drive:



Model	Cable section (mm²)
DSxx41	1
DSxx44	
DSxx48	2.5
DSxx73	1
DSxx76	1.5
DSxx78	2.5
DSxx84	1.5
DSxx87	2.5
DSxx98	2.5

The power supply cable can be installed together with the ones connecting the drive to the motor. We recommend not to place the power supply cable nearby the signal ones.

There are two types of power supplies commonly used, regulated and unregulated.

The regulated power supply maintains a stable output voltage, immune to the net and load fluctuations, which allows to supply the drive even with voltage values near to the allowed maximum ones, with an immediate benefit in terms of torque supplied by the motor at high speed. The disadvantage of the regulated power supplies is their cost.

An unregulated power supply is cheaper, but it requires the consideration of safety's tolerance during its sizing so that, in presence of net and load fluctuations, voltage remains however within the acceptable working values.

A detailed description about the sizing of the power supply is outside of this manual. The user who decides to construct its own power supply must be technically qualified to size it, to assure its correct working and to fulfill each safety requirements. To determine the power supply output voltage it must be considered the maximum net fluctuation expected on worse operating conditions, the maximum vacuum voltage and the minimum voltage at full load, and to assure that the values result of these components combination are within the range of the maximum and minimum voltage values specified for the chosen drive model.


The power that the power supply must deliver is given by the one absorbed by the load (depending from the torque required to the motor as well as from the rotation speed), and by the motor and drive efficiency.



The power lost on the drive for each model is indicated in the following table.

Model	Min	Тур	Max	Unit
DSxx41			5	W
DSxx44			8	W
DSxx48			15	W
DSxx73			8	W
DSxx76			15	W
DSxx78			15	W
DSxx84			15	W
DSxx87			20	W
DSxx98			30	W

Because of the many variables in play it is clear the impossibility to prior indicate an only one kind of dimensioning valid for each application. Just for example, not to be considered exhaustive and correct for the application, see the following electric scheme of an unregulated power supply with a brief indication of the components value.



Also note that the wiring must be star-like, where the earth connection of the various components ends in one only point electrically connected to the metal chassis and the earth of the plant.

Also the wiring towards the drives must be star-like, with the center of the star on C1 capacitor poles.

As shown in the scheme, it is necessary to put in series to the transformer primary winding a filter able to stop the emissions coming from the drive and/or present on the main supply. Furthermore, the filter must be able to support the maximum power required by the drive plus the transformers losses.



It is obligatory to provide on each phase of the transformer primary winding a fuse able to intervene in case of short circuit at the supply output or a malfunctioning of its parts. It is also obligatory to use a fuse on each drives' power supply conductor.

The reduction level the filter must guarantee can vary a lot according to the laws applied to the field to which the application and/or installation belongs.

The producers of filters SHAFFNER and CORCOM can represent a good reference to find the right filter.

The following table relates the characteristic values of the main components in the transformer. The calculation considers also an oscillation of the main supply voltage included within +10/-20%.

You can also ask to your own vendor to evaluate if the following values are usable for your application.

Model	Fuses Fn (A rit.)	Number of drives	Secondary T1 (Vac)	Power T1 (VA)	Current D1 (Arms)	Voltage C1 (Vdc)	Capacity C1 (μF)
		1		50	25A		1000
DSxx41	2	2	32	100	25A	63	2200
DOXX-1	2	3	32	150	25A	03	3300
		45		250	25A		4700
		68		350	25A		5600
		1		125	25A		3300
DSxx44	6.3	2	32	250	25A	63	4700
DOXX : :	0.0	3	02	375	25A	00	5600
		45		600	25A		8200
		68		900	35A		10000
		1		250	25A		4700
DSxx48	12.5	2	32	500	25A	63	6800
DOXX 10	12.5	3	02	750	25A	00	8200
		45		1100	35A		10000
		68		1800	50A		15000
		1		150	25A		1800
DSxx73	4	2	55	300	25A	100	2200
DOXX, O	·	3		450	25A	100	3300
		45		700	25A		4700
		68		1000	35A		5600
		1		300	25A		2200
DSxx76	8	2	55	600	25A	100	3300
	O	3		900	25A	100	3900
		45		1400	35A		4700
		68		2100	50A		6800



		1		400	25A		3300
DSxx78	16	2	55	800	25A	100	4700
DSXX/G	10	3	35	1200	25A	100	5600
		45		1800	35A		8200
		68		2800	50A		10000
		1		350	25A		1000
DSxx84	6.3	2	110	700	25A	200	1500
DOXXOT	0.5	3	110	1050	25A	200	1800
		45		1600	25A		2200
		68		2500	35A		3300
		1		700	25A		1500
DSxx87	12.5	2	110	1400	25A	200	2200
DONNO		3	2000	25A	200	3300	
		45		2500	35A		4700
		68		5000	50A		6800
		1		1000	25A		1800
DSxx98	16	2	140	2000	25A	250	2200
ZOAKJO	10	3	. 40	3000	35A	230	3300
		45		4500	50A		4700
		68		7000	50A		6800

The values suggested for the capacitor C1 can also be obtained placing more capacitors in parallel amongst them. Eventual approximations must be made in excess. The user can add in parallel to the C1 capacitor a resistor, opportunely dimensioned, to discharge the capacitor more quickly. The working voltage of the T1 transformer primary winding must be chosen according to the main supply voltage available during the installation of the application. The transformer must have a shield between primary and secondary windings which must be connected to earth with a short and not inductive connection. The secondary winding voltage is meant without the load, with the primary winding supplied at the nominal voltage.

The rectifier, besides supporting the maximum current required by the drive, must be able to tolerate the current supplied during the C1 capacitor charge. Such current, as being essentially limited only by the internal resistor of the transformer secondary winding, usually very low, and by the wiring, can also be of elevated entity, even if of short length (it exhausts when the capacitor is charged).

Furthermore, the rectifier needs an heat sink able to maintain the temperature within the range defined by the manufacturer (usually 70°C). The working voltage of the D1 rectifier must be then chosen according to the T1 transformer secondary winding voltage multiplied at least by 2.

In the configurations with more than a drive, if the drives are not all calibrated to the maximum current and/or if the working cycle is not simultaneous, the power of the transformer can be considerably reduced. In some cases this can also be made when the motors' speed is limited.



The diagram and the components values refer to a three-phase power supply. Dimensioning in a different way the components it is possible to realize a mono-phase power supply, which is not recommended when the required power is greater than 500W.

The set composed by the filter, the transformer and the power supply must be used only to supply voltage to the drives. It is advised against deriving other supplies from any of these parts. On the contrary, it is suggested to get auxiliary supplies using directly the main supply upstream of the filter.


4.4.3 Motor

The connection between the drive and the motor must be made using shielded cable and connecting the screen to the drive's SHIELD terminal. The cable shield on the motor side must be connected to the motor body only if this one is electrically insulated from the structure where it is fastened. In case the motor is electrically earth connected (for example through a mechanical fastener) the motor side shield must not be connected.

Only if problems connected to electromagnetic emissions occur it is possible to try and connect the shield also from the motor side. Because of the possible ground loops which could start, it is advised to execute this wiring only when strictly necessary.



The drive regulates the current in the motor phases through the supply voltage modulation in chopper technique. The use of a good quality shielded cable and a correct wiring are essential to better reduce the electromagnetic emissions.



CN2 - Signals set-up				
Contact n.	Description			
1	FA-, negate output phase A			
2	FA+, positive output phase A			
3	FB+, positive output phase B			
4	FB-, negate output phase B			
5	SHIELD (internally connected with GND)			

Inverting the FA+ phase with the FA- phase, or the FB+ phase with the FB-phase, the motor rotation direction is inverted (making both inversions the rotation does not change).

The cable section can be dimensioned according to the drive current calibration, anyway it is suggested to choose a cable suitable for the maximum current deliverable from the chosen drive.

It is also advised to connect the motor to the drive with a cable with a length inferior to 10m. For cables with a greater length, the cable size must be increased to counterbalance the voltage drop.

The following table indicates the cable section suggested for each drive according to the cable length:

	Cable section (mm ²)			
Model	Cable length <= 10m	Cable length > 10m		
DSxx41	0.5	1		
DSxx44	1	1.5		
DSxx48	1.5	2		
DSxx73	1	1.5		
DSxx76	1.5	2		
DSxx78	2.5	3		
DSxx84	1	1.5		
DSxx87	1.5	2		
DSxx98	2.5	3		

The cable connecting the drive to the motor can be installed together with the power supply cable, but it must be kept separate from the signal ones.



If difficulties are met to pass compatibility tests, it is possible to place in series to each phase an inductor with a value included between 10uH and 100uH and with current adequate to the set phase current. The inductor must be placed directly at the drive output.



4.4.4 Control Signals

The cable used for the control signals wiring must be a shielded-type.

4.4.4.1 Fiedlbus (DS5x series)


The information contained in the following chapters apply only to the drives provided with fieldbus (DS50, DS52 and DS54 series).

When the drive is supplied only through the UDP30, the RS485 or the RS232 fieldbus communication ports are not working.

4.4.4.1.1 DS50 series (RS485 - Modbus RTU)

The DS50 series is equipped with a RS485 hardware interface, optoisolated from the power stage, and with a Modbus-RTU communication protocol.

The connection to the bus is through a 9 pin female D-sub connector as required by the Modbus specifications. In the following representation is shown the signals arrangement on the 9 pin connector.




	CN5 - Signals disposition				
Contact n.	Description				
1	signals common, it is the reference (0V) of the D0 and D1 signals				
2	+5V, voltage referred to the OV with max current of 10mA				
3	not connected				
4	not connected				
5	D0, data line also called A/A' or TxRx-				
6	not connected				
7	not connected				
8	not connected				
9	D1, data line also called B/B' or TxRx+				

For the connection it is suggested the use of a twisted pair cable.

The connections 1 and 2 can be used to connect the RS485 polarization resistors if needed. Keep in mind that the max source current from the pin 2 is 10mA. The value suggested for the polarization resistors is between 1Kohm and 4K7ohm.

If the length of the bus is high (usually more than 10m) it is sometimes necessary to insert the bus termination resistors. The suggested value for the termination resistors is between 120ohm and 330ohm. These resistors must be connected bewteen D0 and D1, to the extremes of the net.


In the following picure both termination and polarization resistors can be seen.



4.4.4.1.2 DS52 series (RS232 - Modbus RTU)

The DS52 series is equipped with a RS232 hardware interface, optoisolated from the power stage, and with a Modbus-RTU communication protocol.

The connection to the bus is through a 9 pin female D-sub connector as required by the Modbus specifications. In the following representation is shown the signals disposition on the 9 pin connector.



CN5 - Signals disposition				
Contact n.	Description			
1	not connected			
2	TXD, data transmitted by the drive			
3	RXD, data received by the drive			
4	not connected			
5	signals common, it is the reference (0V) of the TXD and RXD signals			
6	not connected			
7	not connected			
8	not connected			
9	not connected			

For the connection to the master it is suggested the use of a shielded cable with a length not superior to 20m.


Installation DS30 – DS5x

4.4.4.1.3 DS54 series (USB - Modbus RTU)

The DS54 series is equipped with an USB Full-Speed-type hardware interface, optoisolated from the power stage, and with a Modbus-RTU communication protocol.

The USB interface is particularly suitable to control the drive through a PC. The bundled drive software allows to emulate a standard system serial port. This solution helps to write the communication program with the drive, which will be able to make use of all the provided standard functions to communicate through a system serial port. The drives currently supplied are for operating systems such as Windows 98, 98SE, Me, 2K, XP, Vista and Windows 7 (32 or 64 bit).

The connection is through a standard female USB-B connector. In the following illustration is shown the signals disposition on the USB-B connector.



CN5 - Signals disposition			
Contact n.	Description		
1	Vbus, positive power supply coming from the PC		
2	D-, negate data line		
3	D+, data line		
4	Ground, 0V reference for the signals and for Vbus		

For the connection to the PC it is suggested to use a good quality shielded cable with a length not superior to 5m.




4.4.4.2 Digital inputs

The drive is provided with a total of 4 digital inputs referring to the CN3 10-poles connector (two poles are reserved to a digital output).

The cable used for the wiring must be shielded-type.

The shielding of the connecting cable must be connected only to the side of the numerical control device (PC, PLC or other), while on the side of the drive it must remain unconnected, as shown in the figure below.



CN3 - Signals			
Contact n.	Description		
1	DIO+ DigitalInput(0), positive 0 digital input		
2	DIO- DigitalInput(0), negative 0 digital input		
3	DI1+ DigitalInput(1), positive 1 digital input		
4	DI1- DigitalInput(1), negative 1 digital input		
5	DI2+ DigitalInput(2), positive 2 digital input		
6	DI2- DigitalInput(2), negative 2 digital input		
7	DI3+ DigitalInput(3), positive 3 digital input		
8	DI3- DigitalInput(3), negative 3 digital input		
9	DO0+ DigitalOutput(0), positive 0 digital output		
10	DO0- DigitalOutput(0), negative 0 digital output		

The section of the cable does not have much importance as the circulating currents are meager (in the order of few mA), therefore choose the section according to the wiring functionality.

The control signal cable must not be placed together with the power supply or the motor cables. If it happens there is the possibility that the high slew rate voltage and the high rate current could be coupled with the logic level signal and corrupt it.




Installation DS30 – DS5x



The digital inputs of the DS30 – DS5x drives can be independently connected in NPN or PNP logic or in line driving mode. Each input lays both the connections making possible mixed settings.

All inputs are optocoupled amongst them, towards the motor and towards the power supply.






The DS30 – DS5x drives have on each input a particular current limitation circuit which grants a constant absorption to the varying of the applied voltage. This device allows a wide input power supply range (from 3Vdc up to 28Vdc) without requiring excessive current to the control equipment or external limit resistor.

A good number of drives nowadays on the market, of the same category, uses to place in series to the input a simple current limitation resistor which reduces the input working voltage setting and causes, moreover, high current values when the input voltage is high. The DS30 – DS5x drives, on the contrary, maintain an almost constant absorption on the whole working range, as shown in the diagram below.







Each single input can be used on line driving mode independently from the others.

The following table resumes the electric characteristics of the control signals.

Symbol	Description	Value		Unit	
		Min	Тур	Max	
Vdi	Active input voltage	3		28	Vdc
Vdioff	Inactive input voltage	-30		1	Vdc
Vdibrk	Digital inputs breakdown voltage	-30		+30	Vdc
Idi	Current absorbed by the digital inputs (24Vdc)	4	6	8	mA



The overcoming of the *Vdibrk* voltage limit damages permanently the drive.



Sometimes the *Vdibrk* voltage limit can be accidentally overcome because of the currents driven by the inductive loads present in the application and out of the recycle diode in anti-parallel. If the installation includes electro valves, contactor (remote control switch), electromagnetic brakes, etc. it is advised to place on each one of them a recycle diode, or to adopt a similar solution, to avoid the extra voltage produced when the inductive load switched off.



If the same power supply is used to provide the power and the signal supply, for example a 24Vdc device, carefully verify that the energy produced by the motor during the braking does not increase the voltage at the ends of the power supply over the *Vdibrk* limit supported by the input.


Installation DS30 – DS5x

4.4.4.3 Digital outputs


The drive is provided with a total of two digital outputs. The DO0 output is available on the CN3 connector while the DO1 one on the CN4 connector, as shown in the representation below.

The cable used for the wiring must be shielded-type.

The shielding of the connecting cable must be connected only to the side of the numerical control device (PC, PLC or other), while on the side of the drive it must remain unconnected, as shown in the figure below.



CN3 - Signals			
Contact n.	Description		
1	DIO+ DigitalInput(0), positive 0 digital input		
2	DIO- DigitalInput(0), negative 0 digital input		
3	DI1+ DigitalInput(1), positive 1 digital input		
4	DI1- DigitalInput(1), negative 1 digital input		
5	DI2+ DigitalInput(2), positive 2 digital input		
6	DI2- DigitalInput(2), negative 2 digital input		
7	DI3+ DigitalInput(3), positive 3 digital input		
8	DI3- DigitalInput(3), negative 3 digital input		
9	DO0+ DigitalOutput(0), positive 0 digital ouput		
10	DO0- DigitalOutput(0), negative 0 digital ouput		






CN4 - Signals				
Contact n.	Description			
1	GND, analog signals ground (internally connected with power round)			
2	AIO, O analog input			
3	AIO, 1 analog input			
4	AO0, 0 analog output			
5	DO1+ DigitalOutput(1), positive 1 digital output			
6	DO1- DigitalOutput(1), negative 1 digital output			



The outputs have a zener diode placed in parallel which allows to connect the output with medium entity loads (for example signal relays) without having to use an external recirculating diode.



The following table resumes the electrical characteristics of the digital outputs.

Symbol	Description	Value		Unit	
		Min	Тур	Max	
Vdo	Digital outputs operating voltage	1		30	Vdc
Vdobrk	Digital outputs breakdown voltage			37	Vdc
Vdoz	Zener diode voltage placed in parallel to each output		39	42	Vdc
Ido	Digital outputs available current			60	mA
Idobrk	Idobrk Digital outputs breakdown current				mA
Pwdo	Digital outputs dissipable power	400		mW	



The outputs are protected against brief short circuits. An extended short circuit, or the overcome of the *Idobrk* current, can permanently damage the output.



Installation DS30 – DS5x


4.4.4.4 Analog inputs

The DS30 – DS5x series drives are provided with two analog inputs able to measure voltages inside the range of \pm 10V.



The breakdown voltage superior to 28Vdc allows to use the analog inputs as digital inputs as well.

The connection to the analog inputs must be made through a shielded cable, having care to connect the shield only to the drive side as shown in the following representation.



CN4 - Signals					
Contact n.	Description				
1	GND, analog signals ground (internally connected with power ground)				
2	AIO, O analog input				
3	AIO, 1 analog input				
4	AO0, 0 analog output				
5	DO1+ DigitalOutput(1), positive 1 digital output				
6	DO1- DigitalOutput(1), negative 1 digital output				

The following table resumes the electrical characteristics of the analog inputs and of the A/D converter inside the drive.

Symbol	Description	Value		Unit	
		Min Typ Max			
Vai	Analog inputs operating voltage	-10		+10	Vdc
Vaibrk	Analog input breakdown voltage	-45 +45			Vdc
Rai	Analog inputs impedance	47			ΚΩ
ADrai	A/D converter resolution	11		bit	
ADst	A/D converter conversion time	10			msec
ADsoff	A/D converter start offset	1 2		%fs	
ADdoff	A/D converter offset drift	0.3 0.5		%fs	
ADline	A/D converter linearity error	1 2			%fs


When the drive is supplied only through the UDP30 setting interface the analog inputs are not usable.



4.4.4.5 Analog outputs

On complation of the I/O signals set, the DS30 - DS5x series drives are also provided with an analog output able to supply a voltage between 0 e 10V.

The connection to the analog output must be made through a shielded cable, having care to connect the shield only to the drive side as shown in the following figure.



CN4 - Signals						
Contact n.	Description					
1	GND, analog signals ground (internally connected with power round)					
2	AIO, O analog input					
3	AIO, 1 analog input					
4	AOO, 0 analog output					
5	DO1+ DigitalOutput(1), positive 1 digital output					
6	DO1- DigitalOutput(1), negative 1 digital output					

The following table resumes the electrical characteristics of the analog output and the D/A converter inside the drive.

Symbol	Description	Value			Unit
		Min	Тур	Max	
Vao	Analog outputs operating voltage	0		+10	Vdc
Iao	Analog outputs operating current			10	mA
Iasc	Analog outputs short circuit current	20		mA	
Rao	Analog outputs output impedance	1		Ω	
DArai	D/A converter resolution	10		bit	
DAud	D/A converter update	10		msec	
DAsoff	D/A converter start offset 0.3 1		1	%fs	
DAdoff	D/A coverter offset drift	0.1 0.3		%fs	
DAline	D/A coverter linearity error	0.3 1.5			%fs

When the drive is supplied only through the UDP30 setting interface the analog output voltage is undetermined.




Installation DS30 – DS5x


4.4.4.6 Connection examples (PNP, NPN and Line Driver)

Below are some examples of valid connection to PLC equipped with PNP and NPN I/O type.

4.4.4.6.1 Inputs



4.4.4.6.2 Outputs



Installation DS30 – DS5x

4.4.5 Chassis setting

In order to contain the electromagnetic emissions and to better shield the drive, it is essential to give particular attention to the setting of the chassis. The drive must be placed inside a metal case, preferably iron made, capable to successfully shield the electromagnetic emissions. The case must be electrically placed to ground as better described further below.

Filter

The filter must be correctly placed in series to the main supply. The ideal position is on the chassis edge in order to have a short wiring coming out from the main supply. If, on the contrary, the main supply cables run inside the chassis, they can be invested by electromagnetic interferences making ineffective or much reducing the filter efficiency.

The filter output earth must be connected to the metallic body of the chassis. It is important the connection is of short length and made with a large section and low inductance conductor. The point of connection between ground coming from the filter and the chassis constitutes the star center to which all other components earth must be connected. Moreover, the filter metallic body must be electrically placed in contact with the case.

Transformer

The transformer must be placed close to the filter and must have a shield between the primary and the secondary windings. The shield must be ground connected in the star center obtained inside the case. Furthermore, the transformer metallic body must be electrically connected to the case.

Power Supply

It is best to install the power supply near the transformer. The power supply earth (usually the negate pole of the filter capacitor) must be connected to ground in the star center obtained inside the case.

Drive


The drive position must be chosen in order the motor cables can immediately come out from the case without running long distances inside the case itself.

Numerical Control

The numerical control device, PLC or other, which generates the driving signals of the drive must be as far as possible from the drives and from the power supply group. Moreover, the signals wiring must be remain distant from the power supply and motor cables. When the distance from the numerical control device and the drive and/or the power supply is reduced, there must be one or more shielding walls, electrically connected to the case.

The following figure shows a possible setting of the chassis.







Safety must never be compromised. Safety is always of first priority.

5 Functionality and Configuration

5.1 General description

The configuration of the drive working parameter is made setting the content of the system registers (for a more complete description see chapter 6.3 System registers). This can be made through the setting or, only for the DS5x drives, through the fieldbus.



The drive is equipped with a DUP port which allows to program the drive, to modify the configuration parameters, to read the status and the production information and, at the end, to update the firmware inside the drive.

This latest feature deserves particular attention as it allows to maintain the product updated with the last implemented functionalities.

To facilitate the drive setting it has been created a software, called *UDP Commander*, designed for Windows platform, particularly immediate and easy to use.

The software makes use of the UDP30 interface to communicate with the DUP port of the drive. The UDP30 interface is connected to the PC by the USB port.



To grant high noise immunity and to protect the equipment integrity, the connection between the PC and the drive must be of insulated-type.

The UDP30 interface makes use of the power supply on the USB port to feed the drive digital section, <u>making possible the setting and the reading</u> of information therein contained even without the power supply.

For a more detailed description of the features and installation of the UDP30 and of the *UDP Commander* software, see the dedicated user's manuals.



5.2 Phase current



It is necessary to pay close attention to the phase current setting as a wrong value can damage permanently the motor.

The phase current must be set in order to correspond to the stepper motor's plate current declared by the manufacturer.

In the following table are detailed the minimum and maximum current values which can be set according to the various models of drive.

Model	Current value (Arms)		
	Min	Max	
DSxx41(A)	0.3	1.4	
DSxx44(A)	1	4	
DSxx48(A)	3	8	
DSxx73(A)	0.8	3	
DSxx76(A)	2	6	
DSxx78(A)	4	10	
DSxx84(A)	2	4	
DSxx87(A)	4	8.5	
DSxx98	4	10	


It is important to note that the values listed above are expressed as effective current and not as peak current.


Some manufacturers indicate the Ipk peak current (or Imax maximum current). To obtain the effective current value it is sufficient to divide the peak current by 1.41 (this calculation is not applicable in case of full step or not sinusoid currents given to the motor).



The above explains why a 4Arms drive (4A effective current) is equivalent to a drive with peak current (or maximum current) equal to 5.6Apk (4 x 1.41). Do consider this while comparing the features of the DS30 – DS5x drives with other producers' devices.

The following figures show the phase current supplied by the DS3048 drive calibrated to 5Arms (right figure) and the current of a competitor's drive calibrated to 5Apeak (left figure).









It appears evident how the DS30 – DS5x drives (which characterize the current to the effective Arms value) supply greater current than those drives which characterize the phase current as peak value or maximum value.

As above explained, the current calibration must be executed according to the motor characteristics declared by the manufacturer, however in particular cases it is possible to use an higher current value than the declared nominal one. This could be useful to obtain more torque from the motor, but it is important to keep in mind that this method leads to an higher motor heating. If the motor temperature exceeds the maximum allowed values (usually 90°C) the motor could be permanently damaged. Usually, the motor is over supplied only if the working cycle is flat and therefore allows a medium working temperature within the maximum allowed values declared by the manufacturer.

Because of the saturation phenomena of the magnetic circuit inside the motor (which vary from model to model), there is not a direct correspondence between torque and phase current when the nominal value is exceeded. In other words, even doubling the current, a double torque is never obtained from a motor. For this reason it is usually superfluous to over supply the motor of more than 30% of the nominal current.

If the motor works in a very hot site or without a mechanic device capable to discharge the heat, it is possible it reaches high temperatures even if supplied by the nominal current. In this case it is necessary to introduce a forced ventilation on the motor or, if the torque margins allow it, to reduce the current calibration on the drive.



Remember that in this case the benefit obtained in terms of temperature will go at the expense of the torque supplied by the motor. Moreover, consider that when the drive calibration current does not correspond to the motor nominal current, the microstepping movement can lose regularity. In the same way, sometimes it is possible to improve the microstepping movement by slightly modifying the current calibration.



The DS30 – DS5x drives allow to optimize the microstepping movement of each motor by changing the waveform of the applied current, as better described further below.

Usually a two phase stepping motor disposes of four wires, two per each phase. In this case the drive current calibration must correspond to the motor plate current. If, for example, the motor relates 3A/phase also the drive shall have to be calibrated to 3Arms.

The 8-wires stepping motors have instead four phases which can be connected in series or in parallel amongst them, two by two. The current calibration between a connection in series and a connection in parallel is different, such as the motor performances, as specified further below.





The series configuration requires a lower phase current but it also exposes a superior anti-electromotive force and a phase inductance towards the drive (4 times the single phase one) which penalizes the motor torque at high speeds. Therefore, this kind of connection is used in applications where the motor speed is limited or the supply voltage is sufficiently high.

When a series configuration is used it is necessary to calibrate the drive to the motor phase current multiplied by the coefficient 0.71, if the manufacturer specifies the current value in unipolar mode, or multiplied by 0.5 if the current is specified in relation to a parallel bipolar connection.

If, for example, the motor used has a plate current of 3A in unipolar mode, with the windings connected in series, the drive shall have to be calibrated to a current of 2.1Arms (3 * 0.71).

Instead, if the motor to be used has a plate current of 10A, declared for a parallel bipolar use, the drive shall have to be calibrated to a current of 5Arms(10 * 0.5).



On the contrary, the parallel configuration requires an higher phase current but it has the advantage to maintain the torque supplied by the motor more constant to the increasing of the speed. It happens thanks to an inferior anti-electromotive force and inductance exposed towards the drive (in respect to a series connection).

The parallel connection is therefore preferable when the motor working speed is high or when then supply voltage is low.

When a parallel configuration is used it is necessary to calibrate the drive to the motor phase current multiplied by the coefficient 1.41, when the manufacturer specifies the current value in unipolar mode, or multiplied by 2 if the current is specified in relation to a series bipolar connection. If, for example, the motor used has a plate current of 3A/phase in unipolar mode, with the windings connected in parallel, the drive shall have to be calibrated to a current of 4.2Arms (3 * 1.41).

5.3 Automatic current reduction

Stepper motor drives work at impressed current, i.e. they always supply the motor at the set nominal current independently from the fact that motor gives torque to the load or not.

In other types of motor, as for example in DC or Brushless motors, the drive supplies to the motor the current strictly necessary to maintain the position or the rotation speed required. In these cases the drive obtains the information on the position or speed errors through transducers such as tachogenerator, encoder, resolver, etc. Therefore, such a system disposes of a feedback and it is classified as a reactioned system or at closed loop.



On the contrary, the stepper motors can be used without the help of any transducer, even granting constant speeds and precise and repeatable positioning. This is possible because the stepper motor is a synchronous actuator which follows without shifting the rotating magnetic field generated by the stator windings. Till when the load opposes a resistant torque inferior to the one supplied by the motor, the rotor remains "hooked" to the rotating magnetic field, while when the load exceeds the available torque the rotor loses the synchronism and the position and the speed are not more granted.

Therefore, it appears evident that for a correct use of the stepper motor it is of primary importance to take care of the sizing of the application, so that the request for the load torque remains inferior to the torque supplied by the motor (on the whole speed range required).

When the stepper motor is firm it is often necessary to grant a maintaining torque capable to keep the load in stable position (a suspended load for example), for this reason the drive supplies current to the motor even when it is motionless.

However, in many cases the current necessary to grant the load stability is inferior, even a lot, to the required operating value. This is mainly due to two reasons: when the motor is firm there are no inertial loads (which appear instead during speed changes), furthermore the torque / speed curve of the motor reaches its utmost just in proximity of zero speed (motionless motor).



In order to limit the motor and drive heating there is a function able to automatically reduce the supplied current after a defined time (settable) from the stop of the motor.



The DS30 – DS5x drives allow to define accurately both the current reduction percentage and the timing from the motor stop to the reduction intervention. The regulation dynamics is extraordinarily wide and allows to change the current between 0% and 100% of the nominal current. The reduction intervention time can be set in few milliseconds up to 10 seconds. Setting a value equal to 0% the current is completely set off when the motor is firm, while setting 100% the current is always maintained at the nominal value.


The current reduction percentage must be set considering the real torque required by the application when the motor is firm, while the second parameter (the time) must be set according to the time that the load takes to stable after the stop of the motor or to the application working cycle.



Observe that removing the current reduction with motor at rest (that is to say setting the 100% value) the motor and the drive heat more. It is therefore suggested to make this calibration only if the application requires an high static torque to the motor.

The following figure shows the relation between the motor cycle and the automatic current reduction.





After the stop of the motor the *Tir* time starts to pass, after which the automatic current reduction intervenes reducing the phase current (in the example to the 60% of the nominal value, i.e. of the set value).

5.4 Current waveform modification



The extraordinary flexibility offered by the DS30 – DS5x series drive allows to intervene on the current waveform supplied to the motor to better adapt it to the constructive characteristics of the motor itself and of the application.

This procedure grants the most rotation homogeneity and the maximum positioning precision.

The parameters on which it is possible to intervene through the *UDP Commander* are the *Shape* and the *Offset*.

Shape

The *Shape* parameter allows to modify the current profile changing the sine/cosine shape normally used.

Offset

The *Offset* parameter adds or deducts a DC component to the current waveform applied to the motor.

5.5 Alarms and Protections conditioning

In order to protect the drive and to make easier the identification of the most common functioning or setting anomalies, the DS30 – DS5x drives are equipped with many alarms and a complete diagnostics.





Furthermore, the extraordinary flexibility offered by the product allows to singularly configure the operative mode of each alarm choosing among *Automatic, Permanent, Enable* or *Disable*.

The configuration is made without the necessity to intervene on the drive's hardware, without jumper, dip-switch, etc.

Automatic

The drive constantly examines the alarm condition and when this disappears it provides autonomously to remove the signal and to turn back to the operative status.

Permanent

Each alarm condition remains in the drive's memory. To remove the signal the drive must be switched off and then switched on again.

Enable

The alarm condition signal remains till the drive is not disabled through the boolean ENABLE input.

Disable

The alarms are disabled and ignored by the drive. For security reasons some protections cannot be put in this status.

In the following table are resumed the various possible settings for each single alarm.

Alarm type / protection	Possible setting			
	Automatic	Permanent	Enable	Disable
Under voltage	Yes	Yes	Yes	No
Over voltage	Yes	Yes	Yes	No
Over temperature	Yes	Yes	Yes	No
Phase-to-phase short circuit	Yes	Yes	Yes	No
Phase-to-ground short circuit	Yes	Yes	Yes	No
(GND)				
Phase-Vp short circuit	Yes	Yes	Yes	No
Interrupted Phase A	Yes	Yes	Yes	Yes
Interrupted Phase B	Yes	Yes	Yes	Yes

For a complete description of protections and alarms see chapter 5.7 Protections.



5.6 Signal LEDs

The drive has three signal LEDs: the green one called On, the yellow LED called Enable / Run and the red one called Fault.

On

The LED called *On* lights up when the drive is supplied with a voltage sufficient to allow a correct functioning of the control electronics.

When the LED is on, the drive is able to elaborate the information but it is not necessarily in the working status (because, for examples, the supply voltage is beyond the working limits or the temperature is excessive).

Enable / Run

This LED gives contemporaneously various information about the status of the drive.

When the motor is enabled the LED is fixed lighted up, when the motor is disabled the LED is off.

When the motor is rotating the LED status is inverted for a little while. In other words, when the motor is enabled and rotating this LED is mainly lighted up with short power-offs.

Relation between the yellow LED and the status of the motor						
Rotation	Enable	Yellow LED status				
No	No	On Off				
No	Yes	On Off				
Yes	No	On Off				
Yes	Yes	On Off				

Fault

This LED lights up each time there is at least an alarm signaling.

When the LED is lighted up, the drive is not operative and the motor is without supply (observe that also in this condition the yellow LED continues its own activity as described in the previous chapter).



In presence of an alarm the red LED lights up and starts a sequence of flashing related to the kind of problem found.

The following table shows the association between the number of flashes and the error found.



	Codification of errors signaled by red LED				
Number of flashes	Problem description				
1	Under voltage, the supply voltage is inferior to Vpl value				
2	Over voltage, the supply voltage is superior to Vph value				
3	Over temperature, the heat sink temperature is superior to <i>Tchh</i>				
4	Phase-to-phase short circuit, one or two phases are in short circuit				
5	Phase-to-ground short circuit (GND), phase in short circuit with ground				
6	Phase-Vp short circuit, one phase is in short circuit with power supply				
7	Interrupted phase A, connection between drive and motor is missing				
8	Interrupted phase B, connection between drive and motor is missing				

If more than a problem occurs contemporaneously the lighting flashes sequences associated to each one of them are cyclically executed. If, for example, the over temperature condition occurs together with the over voltage one, the LED will flash twice and then three times alternatively till when the malfunction signaling will be removed.

The drive features grant at least a visualization cycle for each activated alarm. For this reason it is not possible to remove an alarm before the first visualization cycle is finished.

Observe that each error signals can be removed in different ways according to how the drive's configuration has been made (for a close examination see chapter 5.5 Alarms and Protections conditioning).

For a detailed description on the various alarms and protections see chapter 5.7 Protections.



When in the drive the *Loader* (an always resident small software necessary for the firmware update) is active, the *Fault* LED remains always on.

To restore the normal functioning it is sufficient to load a compatible firmware in the drive.



5.7 Protections

5.7.1 General description

The drive is equipped with efficient protections which protect its integrity whenever one of the most common problems occurs. Furthermore, some controls have been implemented which can detect positioning errors even before the motor starts to move.



In spite of the care and attention used in the development and manufacturing of the drive, an installation or an use not in compliance with the indications present in this manual, or out of stated maximum limits, can damage the drive permanently.



Through the configuration it is possible to define the drive behavior at the occurring of the various alarm conditions.

For example, it is possible to choose and make permanent an alarm or to set the drive so that it is automatically re-enabled as soon the alarm condition is ceased. For a detailed description about the various configuration options see chapter 5.5 Alarms and Protections conditioning.

When there is at least an alarm signal the drive is not active and the motor is not supplied, consequently the torque is null.

5.7.2 Under voltage

The under voltage alarm intervenes when the drive supply voltage is inferior to the *Vpl* value (*Vacl* for the AC models). Such value varies according to the drive model as per the following table.


Model	Vpl	Vpl value (Vacl)		
	Min	Тур	Max	
DSxx41		18		
DSxx44		20		
DSxx48		20		
DSxx73		24		_
DSxx76		24		Vdc
DSxx78		24		
DSxx84		45		
DSxx87		45		
DSxx98		45		
DSxx41A		13.5		
DSxx44A		15		
DSxx48A		15		
DSxx73A		18		
DSxx76A		18		Vac
DSxx78A		18		
DSxx84A		33		
DSxx87A		33		



The drive constantly verifies the supply voltage value; it is sufficient that it goes beyond the *Vpl* threshold (*Vacl* for the AC models) for few instants to generate the under voltage alarm. It does not have to be astonishing the fact that the protection intervenes despite the measured voltage is within the functioning limits, as it is possible that, because of the main supply fluctuations or cables length, the voltage that effectively reaches the drive becomes, in particular moments (for example during the motor acceleration phase), inferior to *Vpl* value (*Vacl* for AC models).



In order to make a correct measurement it is necessary to act directly on the drive supply terminal blocks, using a band-pass instrument of at least 10KHz (as an oscilloscope, for example) able to memorize the voltage transients minimum values.



If the supply voltage is very near to the drive functioning limit and sporadically the under voltage alarm intervenes, it is possible, in some cases, to solve the problem reducing the distance between the power supply and the drive, increasing the cables section or placing an electrolytic capacitor near the drive itself (valid only the DC models).



5.7.3 Over voltage

The over voltage protection intervenes when the supply voltage is superior to the *Vph* value (*Vach* for the AC models). In these conditions the drive protects the power stage turning it off. Such value varies according to the drive model, as per the following table.

Model	Vph	Vph value (Vach)		
	Min	Тур	Max	
DSxx41		50		
DSxx44		55		
DSxx48		55		
DSxx73		98		
DSxx76		98		Vdc
DSxx78		98		
DSxx84		175		
DSxx87		175		
DSxx98		248		
DSxx41A		37		
DSxx44A		40		
DSxx48A		40		
DSxx73A		71		Vac
DSxx76A		71		
DSxx78A		71		
DSxx84A		124		
DSxx87A		124		


The drive constantly controls the supply voltage and when it goes beyond the *Vph* value (*Vach* for AC models), even also for few instants, the over voltage protection intervenes.

It does not have to be astonishing the fact that the protection intervenes despite the measured voltage is within drive functioning limits. In fact it is possible that, in some occasions (sudden motor decelerations, sudden voltage changes, etc.) the voltage which supplies the drive goes beyond the *Vph* value (*Vach* for AC models) causing the protection intervention.



In order to make a correct measurement of the effective drive supply voltage it is necessary to act directly on the supply terminal blocks of the drive itself, using a band-pass instrument of at least 10KHz and able to capture the voltage transients peaks.





If the supply voltage is very near to the drive functioning limit and the over voltage alarm sporadically intervenes, it is possible in some cases to solve the problem reducing the distance between the power supply and the drive, increasing the cables section or placing an electrolytic capacitor near the drive (valid only for DC models).



ATTENTION, if the supply voltage increases a lot beyond the maximum functioning value, and in particular it goes beyond the *Vpbrk* breakdown voltage (*Vacbrk* for AC models), the drive will be irreversibly damaged.

When the over voltage protection intervenes because of the energy returned from the motor during the deceleration phase, which causes a bus voltage rise beyond the *Vph* value (*Vach* for AC models), it is possible to avoid such condition using a braking resistor calibrated to intervene before the bus voltage reaches the *Vph* value (*Vach* for AC models).

The power supplies of the DP1xx2 series integrate this functionality and represent a valid solution to solve this problem.




5.7.4 Over temperature

The over temperature protection intervenes when the drive power stage temperature goes beyond the *Tchh* value. In this condition the drive stops working.

This intervention ends when the temperature falls below *Tchl* value. When this occurs the alarm signal is removed or not according to the drive configuration (see chapter 5.5 Alarms and Protections conditioning).

Symbol	Description	Value		Unit	
		Min	Тур	Max	
Tchh	Intervention threshold of thermal protection	85	90	95	°C
Tchl	Restoration threshold of thermal protection	60	65	70	°C



5.7.5 Phase-to-phase short circuit

In case of a motor wirings short circuit, on the same phase or on different phases (cross phase short circuit), the drive stops working and activates the phase-to-phase short circuit protection.

This kind of protection requires a careful survey to find the cause of the short circuit. Consider that the short circuit can be, apart in the wiring, also inside the motor.

According to the drive configuration (see chapter 5.5 Alarms and Protections conditioning) the protection can be removed through a turning off and on cycle or disabling temporarily the drive through the ENABLE signal.



5.7.6 Phase-to-ground short circuit

The protection starts whenever one of the connections towards the motor creates a short circuit with the drive ground connection (GND). In these conditions the drive protects itself switching off the supply to the motor and putting itself in an inactive status.

This intervention of this protection requires a careful survey to find the cause of the short circuit. Consider that the short circuit can be, apart in the wiring, also inside the motor.

According to the drive configuration (see chapter 5.5 Alarms and Protections conditioning) the protection can be removed through a turning off and on cycle or disabling temporarily the drive through the ENABLE signal.

5.7.7 Phase-to-Vp short circuit (Vac)

Whenever one of the phase connections (motor connections) cause a short circuit with the supply voltage positive (+Vp or Vac for the AC models) the phase-to-Vp short circuit protection starts. When this condition occurs the drive protects itself switching off the supply to the motor and putting itself in an inactive status.

According to the drive configuration (see chapter 5.5 Alarms and Protections conditioning) the protection can be removed through a turning off and on cycle or disabling temporarily the drive through the ENABLE signal.

5.7.8 Interrupted phase A, interrupted phase B



If the connection between the drive and the motor is interrupted, even if of only a single phase, or an inner motor winding is damaged (interrupting itself), the drive activates the interrupted phase alarm. For a more accurate diagnostics the signal is distinguished for the phase A and phase B.

Take present that the drive executes the interrupted phase control only with the drive enabled and with the motor at rest or with rotation speed inferior to 15rpm.



DS30 – DS5x Programming

6 Programming

6.1 Overview

The DS30 – DS5x series drives allow to execute a program developed by the user driving the motor both in position and/or in speed mode.

The programming is made putting in sequence more instruction blocks. An instruction block performs a specific function, as for example the variable assignment, a conditional jump, etc. To each instruction block can be given a reference label to be used as jump destination.

At the beginning the drive executes in sequence the functional blocks, starting from the first one (block 001). The jump instruction blocks (*jump* or *call*) change the sequential program execution order.

All the drive parameters and functions are controlled by the value present in a series of variables called system registers. The instruction blocks can read all the registers while only some of them can be written. For example the *TargetPos* register, which represents the motor final position, can be both read and written; while the *bInPosition* status boolean register, which indicates when the motor is in position, can be only read.

Besides the system registers, the user can create one's program variables defining their name and their size. Variables can be created 1-byte, 2-bytes, 3-bytes or 4-bytes long.

The last types of available data are the constants or numbers. The constants can take any value included between -2,147,483,648 and 2,147,483,647.

The firmware inside the drive is multitasking. The application program and the motion control algorithm are executed in two different tasks, this means that the eventual stop of the application program does not strictly cause a stop to the motor and vice versa.

The application program is never suspended awaiting for the end of a movement; if the application has to wait for an event to continue, it is necessary to expressly insert a *conditional* jump or a *wait until* block.

The entire application development takes place inside the *UDP Commander* software which assists the programmer from the writing of the application program, to its compiling, to the download of the compiled program into the drive until its test and debug.



The drive connection is made through the DUP port. This connection allows to download the application program into the drive, to control its execution, to read the registers, the user variables, the I/O status, etc. Through the same port it is then possible to update the firmware inside the drive. This last feature deserves particular attention as it allows to maintain the product always updated.



Programming DS30 – DS5x

To connect the DUP port of the drive to the PC, it is necessary a little and cost-effective interface called UDP30. The UDP30 interface is connected to the PC through the USB port.



To grant high noise immunity and to safeguard the equipment integrity, the connection between the PC and the drive must be of insulated-type. In addition, the UDP30 interface is able to supply the drive digital section, making possible the programming and the reading of the information therein contained even without the power supply.

For a more detailed description on the features of the UDP30 interface please see the dedicate user's manual.

6.2 Control hardware signals

Through the control hardware signals the application program interacts with the external equipment.

The application program reads and/or changes the hardware signals through some specialized system registers. The I/O is updated in real time, therefore, writing 1 in the register associated to a digital output, the output itself is immediately activated.

In the following tables are detailed the main characteristics of each signal and the associated system register.

Digital inputs					
Number	Possible values				
0	328Vdc	DigitalInput(0)	01		
1	328Vdc	DigitalInput(1)	01		
2	328Vdc	DigitalInput(2)	01		
3	328Vdc	DigitalInput(3)	01		

A digital input is defined active when it is supplied. When the input is in the active status, the corresponding system register assumes value 1. When the input is not active the register value is 0.

Digital outputs					
Number	Allowed values				
0	130Vdc	DigitalOutput(0)	01		
1	130Vdc	DigitalOutput(1)	01		



DS30 – DS5x Programming

A digital output is active when it allows the current to flow. To activate an output the corresponding registers must be set to value 1. Setting a value equal to 0 the output is inactive.

The drive is equipped with two analog bipolar inputs converted with resolution 10bit plus sign.

Analog inputs						
Number	Voltage range	Input impedance	System register	Possible values		
0	-10+10Vdc	47K	AnalogInput(0)	-1024+1023		
1	-10+10Vdc	47K	AnalogInput(1)	-1024+1023		

The analog inputs have been designed to work also as digital inputs, in the need it is therefore possible to connect digital sources to the analog inputs.

The voltage threshold used to discriminate the logic 1 from the logic 0 is freely adjustable from 1V to 10V through the configuration of the drive (see the *UDP Commander* user's manual).

Analog inputs used as digital inputs						
Number	Voltage range	Active input treshold	System register	Possible values		
4	-2828Vdc	1.5V	DigitalInput(4)	01		
5	-2828Vdc	1.5V	DigitalInput(5)	01		



The analog output can also be used to supply little loads (as for example potenziometers, sensors, etc.) provided that the absorption is inferior to the current delivered by the output itself.

Analog outputs							
Number	Voltage range	Output current	System register	Possible values			
0	010Vdc	10mA	AnalogOutput(0)	01023			



Programming DS30 – DS5x

6.3 System registers

The drive functionalities are controlled through the system registers. Some of them can be only read (R), others can be both read and written (RW).



When trying to assign to a register a value out of the allowed range, the register is automatically clamped to the nearest maximum or minimum value. If trying to assign the value -35 to a register with range 0..100, then the register will assume the value 0; similarly trying to assign to the same register the value 122 the register will be set at a maximum value of 100.

The following table resumes the available registers.

Name	Description	Input /	Default	Possible /	Unit
	•	Size		Allowed values	
RefVel	Speed reference	RW, 2bytes	0	-32768+32767	0.25rpm
Velocity	Instantaneous speed	R, 2bytes	0	-32768+32767	0.25rpm
TargetPos	Target position	RW, 4bytes	0	-2147483648	1/128
0		J		+2147483647	step
Position	Motor instantanous position	RW, 4bytes	0	-2147483648	1/128
	•	_		+2147483647	step
CPosition	Seizing of the motor	RW, 4bytes	0	-2147483648	1/128
	instantaneous position			+2147483647	step
MaxVel	Maximum rotation speed	RW, 2bytes	2000	012000	0.25rpm
Acceleration	Allowed maximum acceleration	RW, 2bytes	1000	130000	1rpm/s
Deceleration	Allowed maximum deceleration	RW, 2bytes	1000	130000	1rpm/s
ControlMode	Movement control mode	RW, 1byte	1	01	
PhaseCurrent	Motor phase current	RW, 1byte	I min	Imin Imax	0.1Arms
StByCurrent_Time	Delay before current reduction	RW, 1byte	5	1100	100ms
StByCurrent_Percentage	Current reduction percentage	RW, 1byte	50	0100	%
TimerA	Timer	RW, 2bytes	0	032767	1ms
CounterA	Counter	RW, 2bytes	0	032767	
Status	Drive status	R, 1byte		-128+127	
ControlFlags	It contains various control bits	RW, 1byte	0	-128+127	
Fault	Drive faults	R, 1byte		-128+127	
Error	Drive errors	R, 1byte		-128+127	
bEnable	Drive enabling	RW, bool	0	01	
bInPosition	In position motor flag	R, bool	0	01	
bEnabled	Drive enabling status	R, bool	0	01	
bInStop	In stop motor flag	R, bool	0	01	
bUVarSaved	Variables stored in flash	R, bool	0	01	
bUVarLoaded	Variables loaded from flash	R, bool	0	01	
DigitalInput(0)	0 digital input image	R, bool		01	
DigitalInput(1)	1 digital input image	R, bool		01	
DigitalInput(2)	2 digital input image	R, bool		01	
DigitalInput(3)	3 digital input image	R, bool		01	
DigitalInput(4)	4 digital input image	R, bool		01	
DigitalInput(5)	5 digital input image	R, bool		01	
DigitalInputsA	Digital inputs image	R, 1byte		-128+127	
DigitalOutput(0)	0 digital output image	RW, bool	0	01	
DigitalOutput(1)	1 digital output image	RW, bool	0	01	
DigitalOutputsA	Digital outputs image	R, 1byte		-128+127	
AnalogInput(0)	0 analog input image	R, 2bytes		-1024+1023	9.77mV
AnalogInput(1)	1 analog input image	R, 2bytes		-1024+1023	9.77mV
AnalogOutput(0)	0 analog output image	RW, 2bytes	0	01023	9.77mV



The DS30 – DS5x series contains an advanced motor control algorithm able to recalculate in real time the motor movement. This allows to change in any time the value of the movement control registers, without waiting for the motor to stop.



DS30 – DS5x Programming

6.3.1 Description of each single register

The following is a detailed description of the various registers.

6.3.1.1 RefVel

It is the speed reference used in the *speed control* mode (see *ControlMode* register description). When the drive works in *position control* mode, the content of the *RefVel* register is ignored.

With the register set at 0 the motor stops, while at values different from 0 the motor rotates at a speed proportional to the absolute value of the register itself. The sign, positive or negative, of the value written in the *RefVel* register determines the rotation direction. In other words setting the *RefVel* register at the value -800 or +800, it is obtained an identical rotation speed, but in two different directions.

The motor movement variations always occur according to the acceleration, deceleration and maximum speed values present in the *Acceleration*, *Deceleration* e *MaxVel* registers respectively.

The *RefVel* register is accessible both in reading and in writing mode and can assume values between -32768 and +32767. Each unit corresponds to 0.25rpm, consequently setting for example the value 1000 in the *MaxVel* register, it is commanded a speed rotation of 250rpm.

6.3.1.2 Velocity

It is useful to know the instantaneous speed of the motor. The value is constantly updated, wheather the drive works in position or in speed control mode. The *Velocity* is accessible on in reading. Each unit corresponds to 0.25rpm, consequently if the motor is rotating at a speed of 700rpm the *Velocity* register will contain the 2800 value.

6.3.1.3 TargetPos

It represents the destination position of the motor, expressed in in 1/128 of full step, when the *position control* mode is selected (see *ControlMode* register description). When the drive works in *speed control* mode, the value of the *TargetPos* register is ignored.

To command a positioning it is sufficient to write the destination quote value in the register. The motor will reach the target quote according to the values of acceleration, deceleration and maximum speed present in the *Acceleration*, *Deceleration* and *MaxVel* registers respectively.

The *TargetPos* registers is accessible both in reading and in writing mode and can assume any value between -2,147,483,648 and +2,147,483,647.

6.3.1.4 Position

Through this register it is possible to know the real time motor position expressed in 1/128 of step. The value is constantly updated whether the drive works in position or in speed control mode.



Programming DS30 – DS5x

The *Position* register, besides in reading, it is also accessible in writing and this allows to force the motor quote to any value. A typical case is the zero procedure where there is the need to put to 0 the motor quote, usually when the home sensor is activate.

The *Position* register is accessible both in reading and in writing mode and can be set or assume values between -2,147,483,648 and +2,147,483,647.

6.3.1.5 CPosition

In this register it can be stored the instantaneous position of the motor (*Position* register), espressed in 1/128 of step, when a predetermined digitial input is activate. The save operation of the motor position (also called capture) is very fast and it ends in a time inferior to 100us. Between one save and the following one there must be at least 2ms, otherwise the second save could not happen. The uses of the *CPosition* register are many and go from the products orientation, to the labelling, to the cutting "on the fly", etc.

The digital input which activates the storage is defined in the *ControlFlags* register (see further below).

The *CPosition* register is accessibile both in reading and in writing and can be set or assume values bewten -2.147.483.648 and +2.147.483.647.

6.3.1.6 MaxVel

The *MaxVel* register is useful to set the maximum speed limit at which the motor can rotate. The maximum speed value is an absolute value and it is applied for the movements executed by the motor in both directions. The speed constrainment occurs when the drive works both in position and in speed control mode.

If the *MaxVel* register is dynamically modified with the motor in movement, the motor speed adjustment always occurs according to the acceleration and deceleration values present in the *Acceleration* and *Deceleration* registers respectively.

The *MaxVel* register is accessible both in reading and in writing mode and it can assume values between 0 and +12000. Each unit corresponds to 0.25rpm, consequently setting for example the value 2000 in the *MaxVel* register the maximum speed is set at 500rpm.

6.3.1.7 Acceleration

The motor acceleration is controlled by the *Acceleration* register and by the configuration of the drive (see the *UDP Commander* user's manual) which allows to apply a multiplication factor equal to 4.

It is possible to assign to the register values included between 1 and 30000 and it is allowed to change the value also with the motor in movement. The *Acceleration* register is accessible both in reading and in writing mode. Each unit corresponds to 1rpm/s, if in the configuration it is set a multiplication factor equal to 1, or 4rpm/s if it is set a multiplication factor equal to 4. For example, assigning the value 10000 to the *Acceleration*



register it is set an acceleration equal to 10000rpm/s, with a multiplication factor x1, or 40000rpm/s with multiplication factor x4.

6.3.1.8 Deceleration

The motor deceleration is controlled by the *Deceleration* register and by the configuration of the drive (see the *UDP Commander* user's manual), which allows to apply a multiplication factor equal to 4. It is possible to assign to the register values included between 1 and 30000 and it is allowed to change the value also with the motor in movement. The *Deceleration* register is accessible both in reading and in writing mode. Each unit corresponds to 1rpm/s, if in the configuration it is set a multiplication factor equal to 1, or 4rpm/s if it is set a multiplication factor equal to 4. For example, assigning the value 4000 to the *Deceleration* register it is set a deceleration equal to 4000rpm/s, with a multiplication factor x1, or 16000rpm/s with multiplication factor x4.

6.3.1.9 ControlMode

The *ControlMode* register allows to define the motor control mode. When the register value is 1 the drive works in speed control mode, while when the value is 0 the drive operates a position control. The register is accessible both in reading and in writing mode and it can be dynamically changed also during the movement. The following table resumes the possible values.

Value	Description
0	Position control
1	Speed control

6.3.1.10 PhaseCurrent

The contents of this register defines the effective current (Arms) supplied to the motor during the rotation. Each unit corresponds to 100mArms, therefore setting for example 35 in the *PhaseCurrent* register, the current supplied to the motor will be equal to 3.5Arms.

The value of the register can be dynamically changed by the application program and this makes possible to adapt the motor torque to the various working phases reducing the current when the motor nominal torque is not necessary, or boosting the motor current if a greater torque is required for short times.

The *PhaseCurrent* register is accessible both in reading and in writing mode. The minimum and maximum limit of the values writeable in the register is not fixed, but it varies according to the model of the drive.

In the following table are listed the limits according to the model of the drive:



Model	Minimum value	Maximum value
DSxx41(A)	3	14
DSxx44(A)	10	40
DSxx48(A)	30	80
DSxx73(A)	8	30
DSxx76(A)	20	60
DSxx78(A)	40	100
DSxx84(A)	20	40
DSxx87(A)	40	85
DSxx98	40	100

6.3.1.11 StByCurrent_Time

The *StByCurrent_Time* register allows to change the time expected, after the motor stop, before reducing the phase current. Each unit produces a delay of 100ms, therefore setting for example the register to the value 15, the motor phase current will be reduced after 1.5 seconds from stop.

The *StByCurrent_Time* register is accessible both in reading and in writing mode and it can assume the values included between 1 and 100.

6.3.1.12 StByCurrent_Percentage

It allows to define the phase current reduction percentage set through the *PhaseCurrent* register, passed the time from the motor stop defined in the *StByCurrent_Time* register.

The *StByCurrent_Percentage* register is accessible both in reading and in writing mode and it can assume values included between 0 and 100.

6.3.1.13 TimerA

The *TimerA* register has a particular characteristic. The value it contains is automatically decreased by the drive of one unit each msec until the 0 value is reached; such a value is maintained until the register is not written again. The register is normally used to realize delays or to measure the time between two events.

The *TimerA* register is accessible both in reading and in writing mode and it can assume values included between 0 and 32767.

6.3.1.14 CounterA

The 0 digital input (DigitalInput(0)) is associated to an hardware counter able to accept pulses up to a maximum frequency of 100KHz. The value of the counter is accessible through the *CounterA* register. The counter increase occurs during the active/inactive transition of the input, reached the value 32767 the count starts again from 0. To execute counts greater than 32767 it is possible to use the user variables and the programming tools to implement one exemption to the *CounterA* register.

The hardware counter allows to realize many application as for example:



 Closed loop systems. Counting the pulses received from an encoder or from a phonic wheel to verify the correct positioning of the motor.

- Execution of a positioning with ramp starting from a fixed frequency impulse train. Associating the counter value to the target position of the motor.
- Speed measurement of a master axis and consequent realization of an electrical axis. Verifying the number of pulses received within an unit of time.
- Electronic can. Using the counter value to assign the target position to the motor.
- Measurement of the wrapped/unwarapped film or tissue. Using an idler wheel moved by the film and connected to an encoder.
- Etc.

The *CounterA* register is accessibile both in reading and in writing mode and can assume values included between 0 and 32767.

6.3.1.15 Status

It is a read only register whose bits give various information about the status of the drive. The following table shows the correspondence between the bits and the given information.

Bit	Name	Description
		It becomes active (value = 1) when the motor
bit7	bInPosition	reaches the set position, i.e. when the Position
		register is equal to the TargetPos register
bit6	bInStop	It becomes active (value = 1) when the motor is in
		stop state
bit5	bEnabled	It becomes active (value = 1) when the motor is
		enabled
bit4	bFault	It becomes active (value = 1) where there is at least
		one fault in the drive (Fault register <> 0)
bit3	bUVarLoaded	Becomes active (value = 1) when the program
		variables are successfully loaded from flash memory
bit2	bUVarSaved	Becomes active (value = 1) when the program
		variables are successfully saved to flash memory
bit3bit0	Not used	

Some bits are accessible also as Boolean-type independent registers.



6.3.1.16 ControlFlags

It is a register that controls some functions of the drive. The following table shows the correspondence between the various bits and the function performed.

Bit	Name	Description
bit0	bEnable	It allows to enable (value = 1) or disable
		(value = 0) the motor.
bit1		They allow to enable and define the digitial
bit2		input used to store the motor quote (for more
bit3		details see <i>CPosition</i> register) according to the
		following correspondence:
		bit3=0 bit2=0 bit1=0 → disabled
		bit3=0 bit2=0 bit1=1 → DI0
		bit3=0 bit2=1 bit1=0 \rightarrow DI1
		bit3=0 bit2=1 bit1=1 → DI2
		bit3=1 bit2=0 bit1=0 → DI3
bit4bit7	Not used	

Some bits are accessible also as Boolean-type independent registers.

6.3.1.17 Fault

It is a read only register which assumes a value different from 0 each time the drive detects a fault condition. The fault cause (or causes) can be easily determined analyzing the status of the various bits composing the register. The correspondence is resumed in the following table:

Bit	Name	Description
bit7		It becomes active (value = 1) if the drive detects a
		break phase condition on A phase.
bit6		It becomes active (value = 1) if the drive detects a
		break phase condition on B phase
bit5		It becomes active (value = 1) when the drive detects a
		short circuit between a phase and the Vp supply
bit4		It becomes active (value = 1) when the drive detects a
		short circuit between a phase and the supply negative
		(GND)
bit3		It becomes active (value = 1) when the drive detects a
		short circuit among the motor phases
bit2		It becomes active (value = 1) when the heat sink
		temperature exceeds the maximum allowed value
bit1		It becomes active (value = 1) when the power supply
		voltage exceeds the maximum allowed value
bit0		It becomes active (value = 1) when the power supply
		voltage is inferior to the minimum allowed value



6.3.1.18 Error

It is a read only register which assumes values different from 0 each time an error occurs inside the drive.

In the following table are the possible values assumed by the register and their meaning:

Value	Description
0	No error
1	Wrong application program checksum

6.3.1.19 bEnable

It is a Boolean-type register useful to enable or disable the motor. When the value described in the register is 1 the motor is enabled, when the value is 0 the motor is disabled.

The *bEnable* register is accessible both in reading and in writing mode. In the following table are resumed the effects produced by the various values assignable to the register:

Value	Description
0	Disable the motor
1	Enable the motor

6.3.1.20 bInPosition

It is a Boolean-type read only register which becomes active (value equal to 1) when the motor is in position. In other words the *bInPosition* register is activated when the value of the *Position* register is equal to the one present in the *TargetPos* register.

This register is often used together with a conditional jump to suspend the application program execution until the motor has reached the position required.

The *bInPosition* register is updated only when the position control mode is active

In the following table is resumed the meaning expressed by the various values:

Value	Description
0	Motor not in position
1	Motor in position



6.3.1.21 **bInStop**

It is a Boolean-type read only register which becomes active (value equal to 1) when the motor is in stop.

In the following table is resumed the meaning expressed in the various values:

Value	Description
0	Motor in rotation
1	Motor in stop

6.3.1.22 bEnabled

It is a Boolean-type read only register useful to know if the motor is enabled or not.

In fact, the enable status does not depend only on the *bEnable* register, but also on the status of the drive. If, for example, there are fault conditions, the drive disables the motor independently from the value of the *bEnable* register.

The purpose of the *bEnabled* register is to give information about the real status of the motor.

Value	Description
0	Disabled motor
1	Enabled motor

6.3.1.23 bFault

It is a Boolean-type read only register which becomes active (value equal to 1) when there is at least one fault in the drive (Fault register <>0).

In the following table is resumed the meaning expressed in the various values:

Value	Description
0	Drive correctly working
1	Drive in fault

6.3.1.24 bUVarLoaded

It is a Boolean-type read only register which becomes active (value equal to 1) when the program variables are successfully loaded from flash memory.

Program variables are loaded from flash memory each time the program is reset and the flash memory contains a valid save, or whenever the variables are successfully saved to flash memory (see next section for details).

The following table resumes the meaning according to the values:



Value	Description
0	Variables are initialized to the default
	value 0
1	Variables are initialized with the values
	read from flash memory

6.3.1.25 bUVarSaved

It is a Boolean-type read only register which becomes active (value equal to 1) when the program variables are successfully stored in flash memory. If the save operation fails, the register is set as inactive (value is 0).

The saving of the variables can automatically occur at shutdown if the corresponding option is selected in the configuration (see the *UDP Commander* user's manual), or manually through the execution of a specific program block (for more information see par. 6.6.2.1 Save Variables in Flash).

Note that the flash memory cannot be written for more than 50,000 times, and it is therefore necessary to limit the number of saves to this value.

The following table resumes the meaning according to the values:

Value	Description
0	Variables save not executed
1	Variables successfully saved to flash
	memory

6.3.1.26 **DigitalInput(0)..(3)**

It is a boolean-type read only register which reflects the status of the corresponding digital input. When the register assumes value 1 it means that the input is supplied (active); when the value of the register is 0 the input is disabled (inactive).

Value	Description	
0	Not supplied input (inactive)	
1	Supplied input (active)	

6.3.1.27 DigitalInput(4)..(5)

It is a Boolean-type read only register which reflects the status of the analog input, when this is used to acquire digital signals.

When the register assumes a value equal to 1 it means that to the input it is applied a voltage higher than 1.5V; when the value of the register is equal to 0 the voltage is lower than 1.5V.



The *DigitalInput*(4) register corresponds to the 0 analog input, while the *DigitalInput*(5) register to the 1 analog input.

Value	Description	
0	Not supplied input (inactive)	
1	Supplied input (active)	

6.3.1.28 DigitalInputsA

It is a read only register which includes the status of all the digital inputs (from *DigitalInput(0)* to *DigitalInput(5)*).

The correspondence between the bits and the inputs is the following:

Bit	Name	Description
bit7bit6		Not used
bit5	DigitalInput(5)	1 analog input used as in digital
bit4	DigitalInput(4)	0 analog input used as in digital
bit3	DigitalInput(3)	3 digital input
bit2	DigitalInput(2)	2 digital input
bit1	DigitalInput(1)	1 digital input
bit0	DigitalInput(0)	0 digital input

When the bit assumes a value equal to 1, it means that the corresponding input is supplied (active); when the value of the register is equal to 0 the corresponding input is not supplied (inactive).

6.3.1.29 DigitalOutput(0)..(1)

It is a Boolean-type register accessible both in reading and in writing mode. Setting the register to 1, the corresponding output is activated and it allows the current flow; on the contrary, setting the register to 0 the output is deactivated preventing the current flow.

Value	Description	
0	Inactive output	
1	Active output	

6.3.1.30 DigitalOutputsA

It is a register that includes the status of all the digital outputs (DigitalOutput(0) and DigitalOutput(1)). Modifying the status of one bit the corresponding digital output is changed. Setting the bit to 1 the output is activated; on the contrary, setting the bit to 0 the output is deactivated.

The *DigitalOutputsA* register is accessibile both in reading and in writing mode.



The correspondence between the outputs and the bits of the register is the following:

Bit	Name	Description
bit7bit2		Not used
bit1	DigitalInput(1)	1 digital output
bit0	DigitalInput(0)	0 digital output

6.3.1.31 AnalogInput(0)..(1)

It is a read only register which reflects the status of the corresponding analog input. It can assume values included between -1024 and +1023 in correspondence with input voltage from -10V to +10V.

6.3.1.32 AnalogOutput(0)

It is the register to be used to set the analog output voltage. It can be assigned to any value included between 0 and 1023. The *AnalogOutput(0)* register is accessible both in reading and in writing mode.

6.4 Variables



Besides the registers, there are available program variables freely configurable by the user both as name and as size. The program variables are an essential resource to ensure the maximum flexibility and to allow to realize complex applications. The use of the variables allows to realize counters, *for.next* cycles, mathematic computations, etc.

The variables are always signed integer-type and can represent both positive and negative integer numbers. The maximum value storable in the variable depends on the size of the variable itself which can be defined as of 1 byte, 2 bytes, 3 bytes or 4 bytes.

In the following table are resumed the maximum and minimum values which can be stored in each variable size:

Size	Access	Allowed values
1 byte	RW	-128+127
2 bytes	RW	-32768+32767
3 bytes	RW	-8388608+8388607
4 bytes	RW	-2147483648+2147483647



If it is tried to assign a value greater than the maximum allowed one, the variable is automatically limited to the maximum or minimum allowed value.



Through the drive configuration (see the *UDP Commander* user's manual) you can set an autosave feature trigger at the drive shutdown able to make the variables retentive.



It is also possible to manually save the variables through the execution of a specific program block (for more information see par. 6.6.2.1 Save Variables in Flash).

6.5 Constants

The constants are represented by singed integer numbers. The constants can assume any value included between -2.147.483.648 and +2.147.483.647.

6.6 Instruction blocks

The instruction block is the basic unit of the application program. An application program is built putting in sequence more instruction blocks. The *UDP Commander* software is a convenient graphic interface which assists the user during the writing of the application program.

The following is a detailed description of the available instruction blocks:

6.6.1 Assignment

The assignment block allows to give a value to a register or to a variable. The assignment can be either unconditional or conditional on the occurrence of a particular condition.

6.6.1.1 Unconditional

The unconditional assignment is always performed and is composed of a left operand, that is the destination, and a right operand that is instead the source. Both of them can be registers and program variables, while only the operand on the right can also be a constant (a number) or a read only register. The following are some assignment examples:

	· · · · · · · · · · · · · · · · · · ·
Instruction block	Description
Assign:	Assign to the <i>TargetPos</i> register the
TargetPos = 1500	value 1500 and to the Position
Position = 0	register the value 0
Assign:	Put the 0 digital output in the same
DigitalOutput(0) =	status of the 1 digital input
DigitalInput(1)	
Assign:	Assign the value of the <i>Position</i>
myVar = Position	register to the <i>myVar</i> variable

Each block can contain up to 4 separate assignments. Assignments contained in the same block are processed without interruption and the value of the registers is guaranteed unchangeable throughout the execution of the block.



6.6.1.2 Conditioning

The conditioning assignment allows to assign a value to a register or to a variable only if the result of an expression is true. If the result is false the register or variable continue to maintain their value or take a second value declared as alternative (*else* case).

Instruction block	Description
Assign: Position = 12800 if	Assign the value 12800 to the
DigitalInput(3) = 1	Position register if the digital input 3
	is 1 (if the input is active)
Assign: RefVel = 1000 if	Assign the value 1000 to the RefVel
AnalogInput(0) < 750 else	register if the analog input 0 is less
RefVel = 300	than 750 otherwise RefVel = 300

The entire block is processed without interruption and the value of the registers is guaranteed unchangeable throughout the execution of the block.

6.6.2 Function

It is an instructions block that launches the execution of a specific function. Follows a detailed description of the available functions:

6.6.2.1 Save Variables in Flash

This feature is useful to store the value of program variables in flash memory. The flash memory is able to maintain the stored data even in absence of power, and this allows to make the user variables retentive.

Whenever variables are stored in flash memory the previous value is overwritten.

Flash memory can be rewritten up to 50,000 times, and it is therefore necessary to respect this limit.

The function is performed only when the motor is disabled (bit *bEnabled* equal to 0), otherwise the instruction block is ignored.

When saving is finished, the function checks the integrity of data stored and if the operation is successful, the *bUVarSaved* bit is set active (value equal to 1). In this case, the variables are initialized with the values read from the flash memory and also the bit *bUVarLoaded* is set active (value equal to 1). If instead the writing operation fails, the *bUVarSaved* bit is placed inactive (value equal to 0). The variables in any case maintain their original value.

Instruction block	Description
Function:	Save the program variables in the
Save Variables in Flash	flash memory (if bEnabled = 0)



6.6.2.2 Reset User Program

This feature is useful to reset the application program.

The execution of this instruction block generates an immediate reset of the registers to their default values and the initialization of program variables to 0, or to the last value stored in flash, if available. In addition, the program execution resumes from the first block, exactly as it happens at drive startup.

Instruction block	Description
Γ=	15
Function:	Reset the application program.
Reset User Program	

6.6.3 Jump

The jump instructions block allow to change the normal sequential execution flow of the application program. The jumps can be unconditional, which are always executed, or conditioned to the occurring of some particular condition.

The jump destination is identified by a label; inside the program there must be one only instruction block with the same label.

When the jump is executed, the application program execution changes instantaneously from the jump block to the block with the corresponding destination label.

If the jump is a *Call* (call to a subroutine) it is possible to return to the program execution, from the instruction block successive to the one which has generated the jump, by inserting a *Return* instruction block. It must be observed that the reference to the return block is overwritten each time a *Call* jump is executed, therefore the *Return* instruction is always referred to the last *Call* executed

6.6.3.1 Unconditional jump

An *unconditional jump* is simply coded by declaring the jump destination label.

The following are some examples of *unconditional jumps*:

Instruction block	Description
Jump to jumpHere always:	Jump always to the instruction block identified by the <i>jumpHere</i> label.
Call thisPlace always:	Jump always to the instruction block identified by the <i>thisPlace</i> label. If during the program execution it is met the <i>Return</i> instruction block, the program return to the instruction block successive to this one.



6.6.3.2 Conditional jump

The *conditional jumps* are characterized by two different operands and a comparison one. When the equation result is *true* the jump is executed, otherwise the drive executes the next instruction block.

Both the right operand and the left one can be a register, a variable or a constant. Instead, the comparison operand must be chosen among the ones in the following table:

Operand	Description	
=	The comparison is <i>true</i> when the operand value on the	
	left is equal to the one on the right	
<>	The comparison is <i>true</i> when the operand value on the	
	left is different from the one on the right	
>	The comparison is true when the operand value on the	
	left is greater than the one on the right	
>= The comparison is <i>true</i> when the operand value on th		
	left is greater or equal to the one on the right	
<	The comparison is <i>true</i> when the operand value on the	
	left is smaller than the one on the right	
<=	The comparison is true when the operand value on the	
	left is smaller or equal to the one on the right	

The following are some examples of *conditional jump*:

Instruction block	Description	
Jump to jumpHere if: Position > 12500	Jump to the instruction block identified by the <i>jumpHere</i> label if the value of the <i>Position</i> register is greater than 12500	
Jump to startMovement if:	Jump to the instruction block	
DigitalInput(0) = 1	identified by the <i>startMovement</i> label if the value of the 0 digital input is 1 (if the input is active)	
Call noElapse if: TimerA <> 0	Jump to the instruction block identified by the <i>noElapse</i> label if the value of the <i>TimerA</i> register is different to 0. If during the program execution it is met the <i>Return</i> instruction block, the program return to the instruction block successive to this one.	
[
Jump to doSomething if: myVar1 <= myVar2	Jump to the instruction block identified by the doSomething label if the value of the myVar1 variable is smaller or equal to the value contained in the myVar2 variable	



6.6.4 Wait until

The *Wait unitl* block has the purpose to suspend the execution of the applicative program until the specified condition becomes *true*.

To define the condition there are two different operands and a comparison one. Both the right operand and the left one can be a register, a variable or a constant. Instead, the comparison operand must be chosen among the ones in the following table:

Operand	Description	
=	The comparison is true when the numeric operand	
	value on the left is equal to the one on the right	
<>	The comparison is true when the numeric operand	
	value on the left is different to the one on the right	
>	The comparison is true when the numeric operand	
	value on the left is greater than the one on the right	
>=	The comparison is true when the numeric operand	
	value on the left is greater or equal to the one on the	
	right	
<	The comparison is true when the numeric operand	
	value on the left is smaller than the one on the right	
<=	The comparison is true when the numeri operand value	
	on the left is smaller than the one on the right	

The following are some examples of wait until:

Instruction block	Description
Wait Until: Position > 51200	Suspend the execution of the application program until the poistion of the motor (<i>Position</i> register) has exceeded the value 51200
Wait Until: DigitalInput(2) = 1	Suspend the execution of the application program until the 2 digital input becomes active
Wait Until: bInPosition = 1	Suspend the execution of the application program until the motor has reached the trarget position

Considering that the *Wait until* block indefinitely suspends the execution of the program, it is suggested to use it only for event that will surely occur, otherwise it could block the application program. If a event time-out is needed, the *TimerA* must be used with the conditional jump.



6.6.5 **Delay**

It is an instruction block which suspend the execution of the application program for a predetermined time.

The time is express in milliseconds and can be set as a numeric constant, a register or a variable. In these last two cases the delay will be equal to the value contained in the register or in the variable.

The range can vary from 0 to 32000ms (equal to 32s). Setting greater or smaller values the delay is in any case limited bewteen 0 and 32000ms.

The following are some examples of the *Delay* instruction block:

Instruction block	Description		
Wait for 1250 ms	Suspend the execution of the application program for 1250 ms (i.e. for 1.25 seconds)		
Wait for AnalogInput(0) ms	Suspend the execution of the application program for the milliseconds corresponding to the voltage applied to the 0 analog input		
Wait for myVar ms	Suspend the execution of the application program for the number of milliseconds contained in the <i>myVar</i> variable		



6.6.6 Return

The *Return* instruction block has the task to turn back the execution of the program to the instruction block subsequent to the last one which executed a *Call* jump.

If the *Return* instruction block is met in absence of a *Call* jump, the execution return to the first instruction block of the application program (block 001).

It must be observed that the refence to the return block is overwritten each time a *Call* jump is executed, therefore the *Return* instruction is always referred to the last *Call* executed.

The *Return* instruction block can also be used to "force" a return block specifying its label.

The following are some examples of the *Return* instruction block:

Instruction block	Description
	The execution of the application
Return	program returns to the bloch
	subsequent to the block which has
	executed the last Call
	Set the block identified by the here
Set return address to here	label as the instruction block which
	will be executed immediately after
	the execution of the Return block



6.6.7 Mathematics



The mathematic instruction block is a powerful instrument which is rarely present in drives belonging to this price range. The block resolves the following equation

The *result* operand on the left can be a variable or a register which has the writing access. The m1, m2 and c operands can be indifferently variables, registers or constants. The bd division coefficient can be chosen among the powers of 2 included between 2^0 and 2^3 . Thanks to the denominator it is possible to simulate computations with decimal coefficients. If, for example, it was necessary to multiply a value by 1.5, it is possible to obtain an identical result multiplying first by 3 and then dividing by 2 (2^1). Choosing the correct multiplier/divisor combination it is possible to approximate any decimal multiplication or division.

The following are some examples of mathematic instruction block:

	·	
Instruction block	Description	
Resolve: TargetPos = 10 * AnalogInput(0)	The <i>TargetPos</i> register is set to 10 times the value assumed by the 0 analog input	
Resolve:	The <i>counter</i> variable is increased by	
counter = counter + 1	one unit	
Resolve: MaxVel = (DigitalInput(2) * 1000) + 500	The MaxVel register assumes value 500 when the 2 digital input is inactive (value = 0) and 1500 when the 2 input is active (value = 1)	
Resolve: myVar = (3 * myVar) / 8	The value contained in the <i>myVar</i> variable is multiplied by a 0.375 (3/8) factor	

The mathematic block has an execution time longer than the other functional blocks, therefore when a fast reaction is required (less than 1ms) it is better to execute before the computations, storing the result in a temporary variable.



6.6.8 Logic operations



The logic operation block allows to handle bits of registers or variables. Besides the usual operations in AND, OR and XOR it is possible to execute the SHIFT to right or left. In the shift operation all the outgoing bits are lost while the new bits are put to 0.

$$result = (op1 fnc1 op2) fnc2 op3$$

The *result* operand on the left can be a variable or register which has the writing access. The *op1*, *op2* and *op3* operand can be indifferently variables, registers or constants. The *fnc1* and *fnc2* logic functions must be chosen among the following ones:

Operand	Description	
AND	Execute the AND bit by bit. The result is 1 if both bit	
	compared are 1, otherwise the result is 0.	
OR	Execute the OR bit by bit. The result is 1 if at least one	
	of the two bit compated is 1, otherwise the result is 0.	
XOR	Execute the XOR bit by bit. The result is 1 if one of the	
	two bits compared is 1 and the other 0, otherwise the	
	result is 0 if both bits are equal.	
SHIFT_R	Execute the shift to right of the operand on the left for	
	the number of bits specified in the operand in the right.	
	At any shift the less significant bit (lsb) is lost and the	
	more significant bit (msb) is put to 0.	
SHIFT_L	Execute the shift to left of the operand on the left for	
	the number of bits specified in the operand on the	
	right. At any shift the more significant bit (msb) is lost	
	and the less significant bit (Isb) is put to 0.	

The following are some example of the logic operations block:

Instruction block	Description
Resolve: DigitalOutputsA = DigitalOutputsA XOR 3	The DigitalOutput(0) and DigitalOutput(1) digital outputs are inverted (if the output was active it becomes inactive and vice versa).
Resolve: myVar = (myVar AND 0xF3) OR 128	The bit2 and bit3 of the <i>myVar</i> variable are put to 0 and the bit7 is put to 1. It must be observed that the numeric constants can be also written in hexadecimal format.
Resolve: myVar = DigitalInputsA SHIFT_R 3	The bit2, bit1 and bit0 of the <i>myVar</i> variable are assigned respectively to the <i>DigitalInput(5)</i> , <i>DigitalInput(4)</i> e <i>DigitalInput(3)</i> digital inputs.



6.7 Common programming construct

During the writing of an application program some recurrent instruction blocks combinations are often met. The following are the examples of the most common ones:

6.7.1 Loop

This construct is very frequently used. Each application program has at least an infinite loop cycle: the main loop. The main loop of the program is used to transfer the control from the last instruction block again to the first one for a successive processing. Without a main loop, the application program would end after the execution of the last instruction block.

Instruction block	Description
startLoop:	
	First block of the loop. The <i>startLoop</i> label is used as input reference to the block
:	Instruction blocks inside the loop
Jump to startLoop always:	Unconditional jump which returns the execution of the program to the beginning of the loop



6.7.2 Delay without suspend program execution

When there is the need to realize a wait and it is possible to suspend the execution of the program, it is possible to use the *Delay* block (for more information see par. 6.6.4 Wait until). If on the contrary during the wait the application program must continue to process the instruction blocks (for example to control an error condition or a wait cancellation) it is possible to use the *TimerA* to realize an untriggered wait.

Instruction block	Description	
Assign:	It is assigned to the <i>TimerA</i> register	
TimerA = 80	the time to be waited (80ms)	
waitHere:		
:	First block of the loop executed	
	during the wait	
:		
	Further instruction blocks inside the	
	wait loop	
Jump to waitHere if:	Jump to the waitHere label until the	
TimerA <> 0	value of the TimerA register	
	(automatically decreased) reaches the	
	0 value	



6.7.3 For .. Next cycle

The *For..Next* cycles are useful to execute one or more instruction blocks for a well defined number of times.

It is assumed that the *forNextCnt* variable is already declared with a length equal to 2 bytes. The following example is valid for cycles repeated at least one time.

Instruction block	Description	
· · · · · · · · · · · · · · · · · · ·		
Assign: forNextCnt = 1450	It is assigned to the variable used as	
TOTNEXICTIE = 1450	counter the number of cycles to be execute (1450)	
startFor:		
:	First fornext cycle block. The startFor label is used as block	
	reference	
:	Instruction blocks inside the fornext cycle	
Resolve: forNextCnt = forNextCnt - 1	The forNextCnt variable is decreased by one unit	
Jump to startFor if: forNextCnt <> 0	Jump to the instruction block identified by the <i>startFor</i> label (fornext cycle start) if the value of the <i>forNextCnt</i> variable is different from 0	
:	First block executed after the	
	fornext cycle is completed (forNextCnt variable = 0)	



6.7.4 If ...Then...Else

Whenever it is necessary to perform an operation conditioned to the occurring of determined conditions, it is used the If.. Then construct; if it is then necessary to execute a second operation, in the case the required condition is not satisfied, it is used the Else structure.

Instruction block	Description					
	·					
Jump to hereIfTrue if: Position > 18000	Jump to the instruction block identified by the <i>hereIfTrue</i> label if the value of the <i>Position</i> register is greater than 18000					
	First executed block if the condition is					
	false. This represents the first block of the Else case					
	Instruction blocks of the Else case					
Jump to nextOperation always:	Unconditional jump which terminates the blocks of the Else case and transfers the execution of the program to the first following block to the IfThenElse construct					
hereIfTrue:						
:	First block executed if the condition is true. This represents the first block of the Then case					
:	Instruction blocks of the Then case					
nextOperation:						
:	First block subsequent to the IfThenElse construct executed independently from the test result					



6.7.5 Hysteresis

When analog values are used it is often necessary to condition the signal with an hysteresis to avoid that continuous little signal fluctuations (often due to electric noise) produce on the application undesired effects.

To better comprehend this problem, it can be taken as an example the use of an analog input to command the motor position. Because of the electrical noise the A/D converted value oscillates of some units around the medium value; if the converted number is used directly as destination position, the motor will continuously move around the medium position. This may cause mechanical stress and noises and the not intervention of the current reduction function (which occurs only if the motor is in stop). To avoid this behavior it is sufficient to insert a simple algorithm which realizes an hysteresis on the analog input signal.

The following example realizes an hysteresis of +/-3 units in respect to the value read by the analog input.

It is assumed that the *myVar*, *hystHigh* and *hystLow* variables are already declared with a length equal to 2 bytes.

Instruction block	Description
readAgain:	· · · · · · · · · · · · · · · · · · ·
Assign: myVar = AnalogInput(0)	Assign the real time value of the 0 analog input to the myVar program variable
Jump to outOfHyst if: myVar > hystHigh	If the <i>myVar</i> variable is greater than the hysteresis higher limit (<i>hystHigh</i> variable) it is updated the hysteresis limits and carried out the required operations
Jump to readAgain if: myVar >= hystLow	This block is reached only if the <i>myVar</i> variable is smaller or equal to the hysteresis positive limit. Now it is controlled if the <i>myVar</i> variable is smaller than the hysteresis lower limit (<i>hystLow</i> variable), in this case it is updated the hysteresis limits and carried out the required operations. It must be noted that the test is negate to avoid the unconditional jump block that would be necessary to return to the <i>readAgain</i> label
outOfHyst:	
Resolve: hystLow = myVar - 3	It is updated the hysteresis negative limit with a value 3 units lower than the <i>myVar</i> variable (that corresponds to the reading of the analog input)
Resolve: hystHigh = myVar + 3	It is updated the hysteresis positive limit with a value 3 units higher than the <i>myVar</i> variable (that corresponds to the reading of the analog input)
	Other operations to execute



6.7.6 Constraint of a value

The shown algorithm is used to contain a value between a minimum and a maximum one. In the example it is assumed to associate the analog output of the drive to an analog input, with the constraint that the analog output reproduces input variations included only between 1Vdc and 5Vdc. It must be noted that these voltages are equivalent to a numeric value converted by the A/D of 102 and 512 respectively.

It is assumed that the *myVar* variable is already declared with a length equal to 2 bytes.

Instruction block	Description						
readAgain:							
Assign: myVar = AnalogInput(0)	Assign the real time value of the 0 analog input to the <i>myVar</i> program variable						
[-							
Jump to checkHigh if: myVar >= 102	If the <i>myVar</i> variable is higher or equal to the allowed minimum one, jump to the instruction block for the maximum limit control						
Assign: myVar = 102	This block is reached if the value of the <i>myVar</i> variable is lower than the allowed minimum one. In this case the minimum value is assigned						
Jump to upDateAO always:	Unconditional jump to the analog output update block						
checkHigh:							
Jump to upDateAO if: myVar <= 512	This block is reached only if the <i>myVar</i> variable is higher or equal to the allowed minimum one. Now it is controlled if the <i>myVar</i> variable is lower than the maximum limit, in this case jump to the analog output update block						
Assign: myVar = 512	This block is reached if the value of the <i>myVar</i> variable is higher than the allowed maximum one. In this case the maximum value is assigned						
upDateAO:							
Assign: AnalogOutput(0) = myVar	Update the analog output with the value clipped between 102 and 512						
Jump to readAgain always:	Unconditional jump that returns the program execution to the <i>readAgain</i> label						



6.7.7 CounterA extension on 32bits

The *CounterA* counts the pulses applied to the DI0 input, reached the maximum value of 32767 the counter starts again from 0.

In some application it could be necessary to have a wider counting capacity. The following example extends the *CounterA* register to 32bits to count up to 2147483647 pulses.

It is assumed that the *savedCounterA*, *oldCounterA* and *cntPulse* variables, are already declared with a length equal to 2 bytes and the *new32CounterA* variable with a length of 4 bytes.

Instruction block	Description						
	· · · · · · · · · · · · · · · · · · ·						
Assign: savedCounterA = CounterA	Store the value of the counter in the <i>saveCounterA</i> variable as the <i>CounterA</i> register can change during the successive processing (because of the pulses applied to the DIO input)						
Jump to calc if:	If the counter has not executed the rollover (i.e. it						
savedCounterA >= oldCounterA	has not reached 32767 and started again from 0) jump to the instruction block identified by the <i>calc</i> label						
Γ							
Resolve: cntPulse = (-1 * oldCounterA) + 32768	This block is reached if the counter has started again from 0 (rollover). Execute the difference between 32768 and the previous value of the counter to calculate how many counts are to arrive to 0						
	T						
Resolve: cntPulse = cntPulse + saveCounterA	Add the counts executed after the rollover						
Jump to acc always:	Unconditional jump to the block identified by the acc label						
calc:							
Resolve: cntPulse = (-1 * oldCounterA) + saveCounterA	Execute the difference between the currently value of the counter and the previous value saved to obtain the total number of pulses counted in the previous processing						
acc:							
Resolve: new32CounterA = new32CounterA + cntPulse	Add to the <i>new32CounterA</i> the pulses counted in the previous processing						
Assign: oldCounterA = savedCounterA	Update the <i>oldCounterA</i> variable for the successive processing						



Fieldbus DS30 – DS5x

7 Fieldbus

The information contained in the following chapters apply only to the drives provided with fieldbus, belonging to the DS5x series. The DS30 products are not supplied with fieldbus.

7.1 General description

Through the fieldbus it is possible to access to the drive registers and to the program variables to monitor or control the status of the motor.



The ability of the drive to execute an own internal program and to communicate contemporaneously with an external device (PC, PLC, CNC, etc.) offers a great flexibility and infinite applicative possibilities.

The machine cycle can, for example, be implemented inside the drive, to obtain execution rapidity, and parametrized by the control master (for example in the times, in the repetition numbers, in the quotes or speeds of the motor, etc.), also with the motor in rotation!

A further advantage offered by this kind of approach is to enormously limit the number of messages passing on the bus. Inside a structure with decentralized intelligence it is in fact sufficient to send only once the configuration parameters, to command the start and eventually to interrogate once in a while the drive to know its status.



The various I/O of the drive (both analog and digital) allow to locally control the sensors such as end-run, home, load cells, resistors, etc., as well as actuators like electromagnets, proportional valves, etc., furtherly relieving the control master of the working load and improving the real-time reply of the system.

7.2 Modbus-RTU communication protocol

The communication protocol implemented in the drives belonging to the DS5x series is the industrial standard Modbus-RTU.

The Modbus protocol, born in 1979, soon imposed itself as a standard in the industrial field. Appreciated for its simplicity and efficiency, it is a free protocol which does not require the payment of royalties to be implemented or used.

Despite the inferior communication speed in comparison to other protocols (such as Profibus and CAN), it vaunts a great number of installation, constantly increasing, as it represents a simple and economic solution to realize nets and undernets on the machine.

It must not be confused the communication protocol with the physical mean used for data conveyance (called also layer). The protocol (in our case the Modbus-RTU) is the "language" used by the devices to "speak" to each other while the communication mean can be different (RS485, optical fibre, current loop, etc.).



DS30 – DS5x Fieldbus

For example, it is possible to communicate in Spanish by phone, fax, email, etc. The phone, the fax, etc. are the physical mean (the layer) while the Spanish grammar is the protocol.



The DS5x series drives are available in 3 different physical layers as detailed in the following table:

Model	Physical Layer	Notes
DS50xx(A)	RS485	It allows to connect more devices to a same communication bus. Optimum noise immunity. Maximum distance 1000m
DS52xx(A)	RS232	Suitable for point-to-point connections. Maximum distance between the devices 20m
DS54xx(A)	USB	Through the Hub it is possible to connect more drives to a same PC. Maximum distance between the PC (or the Hub) and the drive 5m

The Modbus-RTU protocol strictly provides for a *master-slave* relation. In the net there is always one only *master* and one or more *slave* devices. Each communication is always generated by the *master*. The *slave* can send data only further to a command or an inquiry sent by the *master*. The *master* device (PC, PLC, etc) identifies the *slave* with which to communicate through an address which must be univocal inside the net. In other words each *slave* must have an address different from all the others. The possible addresses vary from 1 to 247. The special address 0 has the function of *broadcast address*, i.e. it allows to send a command which will be processed contemporaneously by all the devices in the net. The use of the address 0 does not provide any reply by the *slaves*.

The set of data which compose a Modbus-RTU command includes, besides the *slave* device address, also a function code, a group of data depending on the function invoked and at last a checksum useful to evaluate the integrity of the received data.

In the following description the number in hexadecimal notation are anticipated by the suffix "0x". The value 0x22 for example indicates the hexadecimal number 22 which corresponds to the value 34 in the decimal notation.

A detailed description of the Modbus-RTU communication goes beyond the purpose of the this manual. Following are detailed only some basic notions to help and better comprehend the functioning of the product. For an exhaustive description of the Modbus protocol see the official documentation on the site www.modbus.org.



Fieldbus DS30 – DS5x

7.2.1 Data structure (frame)

The set of data (called *frame*) which pass from the *master* control device (PC, PLC or else) towards the *slave* (the drive for example) and vice versa is always organized in the same way and satisfies the following structure:

Address	Function Code	Data	CRC

Address, it is the address of the *slave* receiver of the command when the data flow is from the *master* towards the *slave*, or the address of the *slave* which transmits when the data flow is from the *slave* to the *master* (reply).

Function Code, it identifies the function the *master* wants the *slave* to execute when the data flow is from the *master* towards the *slave*, or the function elaborated by the *slave* when the data flow is from the *slave* to the *master* (reply).

Data, specific information about the evoked function, transmitted to the *slave* or received by the same.

CRC, it is the checksum calculated by the sender using all the data of the *frame*. The receiver then calculates the CRC of the received data and compares it with the CRC received.

7.2.2 Data processing (frame)

The *slave* device processes the data which follow the *address* only if the address itself corresponds to its own or to the address 0 (*broadcast address*). In all the other cases the data which follow the address are ignored.

Once recognized the address, the *slave* memorizes all the remaining data until it receives the CRC and then calculates the CRC using the received data and compares it with the received CRC. If the two values are different, the *slave* ignores the *frame* and keeps listening again without sending any reply. The *master* device detects this condition as transmission *time-out* (lack of reply from the *slave*).

If the CRC is correct the *slave* tries to execute the command given by the *master* and if the operation successfully ends the *slave* sends the appropriate reply to the *master* (according to the *Function Code* or no reply if the address was 0, i.e. *broadcast address*).

In the case the *slave* cannot execute the command given by the *master*, it sends an error reply called *Exception Frame* composed as follows:

Address, it is the address of the *slave* which sends the reply.



DS30 – DS5x Fieldbus

Function Code OR 0x80, it is the code of the function which has generated the error with the bit7 (the most significant bit or MSB) set to 1 (it is equivalent to make the OR of the function code with the value 0x80).

Exception Code, it is a code which gives an indication about the type of problem detected by the *slave*.

CRC, it is the checksum calculated by the *slave*.

The possible transmitted *Exception Codes* are the following:

Exception Code	Description
0x01	It indicates that it is not possible to execute the required function.
	Possible causes are the not implementation of the same function,
	an attempt to write onto an only writing location, etc.
0x02	It indicates that the location to which there is an attempt to access
	does not exist.
0x03	It indicates that one or more values are beyond the allowed limits.

7.2.3 Checksum computation (CRC)

The checksum computation (CRC) examines the whole *frame* (with the exception of the CRC which is instead calculated). The CRC has the size of a word (2bytes) and is calculated applying the following algorithm to any byte of the *frame*.

- 1. The CRC is initialized to the value 0xFFFF.
- 2. It is executed the XOR (OR exclusive) of the byte with the low byte of the CRC, memorizing the result of the CRC.
- 3. It is executed the shift (rotation) of the CRC of a position (one bit) towards right and it is set to 0 the bit15 (MSB) of the CRC
- 4. If the bit0 (LSB) before the shift was 0 it return to the point 3, while if the bit0 (LSB) before the shift was at 1 it is executed the XOR of the CRC with the value 0xA001.
- 5. The points 3 and 4 must be repeated 8 times for each byte (8 shifts).
- 6. It is repeated from point 2 until all the *frame* bytes are processed.
- 7. The CRC value is the checksum.

It must be considered that the checksum is transmitted in reverse order in respect to the other words. The first byte transmitted is the less significant one and the second byte transmitted is the most significant byte. Inside the *frame* the CRC is therefore disposed as follows:

CRC	CRC
Lo	Hi



Fieldbus DS30 – DS5x

7.2.4 Data organization

Inside the drive there are 5 different types of data with different dimensions; *bit*, *byte*, *word* (2 bytes), *3byte*, and *dword* (double word i.e. 4 bytes).


Any register or program variable, read or written through the Modubus-RTU protocol must been formatted inside one or more words.

Following are detailed the rules with which the data in the various dimensions are or must be formatted and interpreted:

7.2.4.1 bit

The binary-type data corresponds to the bit0 of the word. The other bits, from bit1 to bit15, remain unused and have value 0.

Es. 1




Es. 2

7.2.4.2 byte


The byte-type data are present in the lowest 8 bits of the word (from bit7 to bit0), the higher 8 bits (from bit15 to bit8) are instead set to 1 or 0 following the rule of the extension of the sign; if the byte value is ≥ 0 the bits are set to 0, if instead it is ≤ 0 the are all set to 1.

Es. 1






DS30 – DS5x Fieldbus




7.2.4.3 word

The word-type data are represented in native mode, without any particular format.

Es. 1 word = 12384 (0x3060)



Es. 2 byte = -3172 (0xF39C)




7.2.4.4 3byte


The 3bytes data are represented using two words. The first word, the one with minor address, contains in the lowest 8 bits (from bit7 to bit0) the most significant byte of the data while the superior 8 bits (from bit15 to bit8) are set to 1 or 0 following the rule of the extension of the sign; if the byte value is \geq 0 the bits are set to 0, if instead it is \leq 0 they are all set to

Fieldbus DS30 – DS5x

1. The second word, with address + 1, contains the two remaining bytes of the data.


Es. 1 3byte = 1526317 (0x174A2D)






Rmaining 2 bytes (0x4A2D)

Es. 2 3byte = -1270301 (0xEC9DE3)






Remaining 2 bytes (0x9DE3)

DS30 – DS5x Fieldbus


7.2.4.5 dword

The dword-type data are represented using two words. The first word, the one with the minor ID (address), contains the two most significant bytes of the dword while the second word with address + 1, contains the two remaining bytes of the dword.

Es. 1 word = 898271058 (0x358A8752)




Value of the most significant bytes (0x358A)



Value of the two most significant bytes (0x8752)

Es. 2 word = -1026521534 (0xC2D08642)



Value of the two most significant bytes (0xC2D0)

Word 1															
bit15															bit0
1	0	0	0	0	1	1	0	0	1	0	0	0	0	1	0
															,

Value of the two most significant bytes (0x8642)

Fieldbus DS30 – DS5x

7.2.5 Supported functions

The manipulation of each register or program variable is executed using only three standard functions of the Modbus protocol. The function with code 0x03 is useful to read the registers or the variables and allows to contemporaneously read up to 2 words at the time. The function 0x10 instead is useful to write both registers and variables and allows to write up to 2 words at the time. Finally, the function with code 0x16 allows to change only some bits of a register or a variable leaving the remaining bits unchanged.

7.2.5.1 0x03, Reading of registers and variables (Read Holding Registers)

The command is useful to read the registers or the program variables.

Through the parameter *Word Number* it is possible to choose if reading one only word or two words contemporaneously. This last mode is useful to read registers or variables with a dimension of 3 or 4 bytes.

The following table shows the composition of the *frame* transmitted to the drive and the relative reply in case of command successfully concluded.

Function	0x03, Read Holding Registers									
Request (Master → Slave)										
Transmitted	Address	Function	Wor	rd ID	Word	CRC				
Frame structure		Code			Number					
Dimension (byte)	1	1		2	2	2				
Possible values	1247	0x03	063	5535 ¹	1 or 2	065535				
		Reply (Slav	ve → Maste	r)						
Received	Address	Function	Byte	Word0	[Word1	CRC				
Frame structure		Code	Counter Value		Value]					
Dimension (byte)	1	1	1	2	2	2				
Possible values	1247	0x03	2 or 4	065535	065535	065535				

Address, it is the address of the *slave* receiver of the command when the data flow is from the *master* towards the *slave* or the address of the *slave* which transmits when the data flow is from the *slave* to the *master* (reply).

Function code, it is the identification of the function for the reading of registers and program variables (0x03).

Word ID, it is the ID (also called address) of the first word to which to access.

¹ Only some addresses correspond to valid registers and variables (see further on). The access to non-existent registers or variables produces an error reply message from the drive.



DS30 – DS5x Fieldbus

Word number, it is the quantity of words on which to operate. At most it is possible to operate on 2 words at the time.

Byte counter, it contains the number of bytes which will follow excepted the CRC. Its value is the double of the *Word Number* parameter.

Word0 value, it is the value of the first read word corresponding to the Word ID.

Word1 Value, it is the value of the second read word relative to the *Word ID* + 1. The parameter is indicated between square brackets because it is present only when the command is sent with Word Number = 2. Differently the $Word1 \ Value$ is not received.

CRC, it is the checksum calculated by the sender using all the *frame* data. The receiver calculates the CRC of the received data and compares it with the CRC received.

Ex. 1, reading of the register 41226 (Acceleration) from the drive with address 1

Function	Function 0x03, Read Holding Registers									
Request (Master → Slave)										
Transmitted Address Function Word ID Word CRO										
frame structure		Code			Number					
Transmitted values	0x01	0x03	0xA	A109	0x0001	0x77F4				
		Replay (Sla	ve → Mast	er)						
Received frame	Address	Function	Byte	Word0	[Word1	CRC				
structure		Code	Counter Value		Value]					
Received values	0x01	0x03	0x02	$0x03E8^{2}$		0xB8FA				

² The value changes according to the real content of the register



_

Fieldbus DS30 – DS5x

7.2.5.2 0x10, Writing of registers and variables (Write Multiple Registers)

The command is useful to write the records or the program variables.

Through the *Word Number* parameter it is possible to choose to write one only word or two words contemporaneously. This last mode is useful to write registers or variables with a size of 3 or 4 bytes.

The following table shows the composition of the *frame* transmitted to the drive and of the relative reply in case of command successfully concluded.

Function	0x10, Write Multiple Registers							
Request (Master → Slave)								
Transmitted <i>frame</i> structure	Address	Function Code	Word ID	Word Number	Byte Counter	Word0 Value	[Word1 Value]	CRC
Dimension (byte)	1	1	2	2	1	2	2	2
Possible values	1247	0x10	065535	1 o 2	2 o 4	065535	065535	065535
Reply (Slave → Master)								
Received frame structure	Address	Function Code	Word ID	Word Number				CRC
Dimension (byte)	1	1	2	2				2
Possible values	1247	0x10	065535	1 or 2				065535

Address, it is the address of the *slave* receiver of the command when the data flow is from the *master* to the *slave* or the address of the *slave* which transmits when the data flow is from the *slave* to the *master* (reply).

Function code, it is the identification of the function for the writing of registers and program variables (0x10).

Word ID, it is the ID (also called address) of the first word to which to access.

Word number, it is the quantity of words on which to operate. At most it is possible to operate on 2 words at the time.

Byte Counter, it contains the number of bytes which will follow excepted the CRC. Its value is the double of the *Word Number* parameter.

Word0 Value, it is the value of the first written word corresponding to the Word ID.

Word1 Value, it is the value of the second written word corresponding to the *Word ID* + 1. The parameter is indicated between square brackets because it is present only when the command is sent with *Word Number* = 2. Differently the *Word1 Value* is not transmitted.

CRC, it is the checksum calculated by the transmitter using all the *frame* data. The receiver calculates the CRC of the received data and compares it with the CRC received.



DS30 – DS5x Fieldbus

$\mathbf{F}\mathbf{x}$ 1	writing of a	a dword valu	e in the i	register 41730	(TargetPos	of the drive	e with address 1
$L_{\Lambda,1}$	writing or a	i awora vara	c m mc	register +1/50	(Iuigen os) Of the diffy	o with address i

Function		0x10, Write Multiple Registers						
	Request (Master → Slave)							
Transmitted frame structure	Address	Function Code	Word ID	Word Number	Byte Counter	Word0 Value	Word1 Value	CRC
Possible values	1	0x10	0xA301	0x0002	0x04	0x0003	0xE800	0X6094
	Reply (Slave → Master)							
Received frame structure	Address	Function Code	Word ID	Word Number			CRC	
Possible values	1	0x10	0Xa301	0x0002 0x32			0x324C	

7.2.5.3 0x16, Changing of the bits of a register (Mask Write Registers)

The command is useful to change only some bits of a register or of a program variable, leaving the status of the remaining bits unchanged.

The following table shows the composition of the *frame* transmitted to the drive and the relative reply in case of command successfully concluded.

Function	0x16, Mask Write Registers							
Request (Master → Slave)								
Transmitted <i>frame</i> structure	Address	Function Code	Word ID	AND Mask	OR Mask	CRC		
Dimension (byte)	1	1	2	2	2	2		
Possible values	1247	0x16	065535	065535	065535	065535		
		Reply (Sl	ave → Master)					
Received frame structure	Address	Function Code	Word ID	AND Mask	OR Mask	CRC		
Dimension (byte)	1	1	2	2	2	2		
Possible values	1247	0x16	065535	065535	065535	065535		

Address, it is the address of the *slave* receiver of the command when the data flow is from the *master* to the *slave* or the address of the *slave* which transmits when the data flow is from the *slave* to the *master* (reply).

Function code, it is the identification of the function for the changing of registers and program variables (0x16).

Word ID, it is the ID (also called address) of the word on which to operate.

AND Mask, it is the mask of bit put in AND with the register or the program variable indicated by *Word ID*.

OR Mask, it is the mask of bit put in OR with the register or the program variable indicated by *Word ID*.



Fieldbus DS30 – DS5x

Ex. 1, setting to 0 of the bit0 and setting to 1 of the bit 1 of the register 41473 (DigitalOutputsA) of the drive with address 1

Function	0x16, Mask Write Registers							
	Request (Master → Slave)							
Transmitted <i>frame</i> structure	Address	Function Code	Word ID	AND Mask	OR Mask	CRC		
Possible values	1	0x16	0xA201	OxFFFE	0x0002	0x02A1		
	Risposta (Slave → Master)							
Received frame structure	Address	Function Code	Word ID	AND Mask	OR Mask	CRC		
Possible values	1	0x16	0xA201	OxFFFE	0x0002	0x02A1		

DS30 – DS5x Fieldbus

7.3 Map of the registers and user's variable

The following table shows the position of the registers inside the addressing space. For the program variables it is indicated only the address of start and end of the whole space available as the ID of each single variable depends on how the same variable is declared and positioned. The ID of each single variable is shown in the *Id.* column in the chart *Variables* of the *UDP Commander* software.

Map of the registers corresponding to RegTableVer=1						
ID ³ (a	address)	Access	Register	Description		
Dec	Hex	(byte)				
40193	0x9D01	R (2)	RegTableVer	Version of the registers table		
40194	0x9D02	R (2)	ProductCode	Code of the product		
40195	0x9D03	R (2)	FirmwareVer	Revision of the firmware		
40196	0x9D04	R (2)	HardwareRev	Revision of the hardware		
40197	0x9D05	R (2)	SpecialVersion	Special version		
40198	0x9D06	R (4)	SerialNumber	Serial number of the product		
40199	0x9D07			·		
40961	0xA001	RW()		Program variables		
40993	0xA021	RW()		Program variables		
41217	0xA101	R (1)	Fault	Faults present in the drive		
41218	0xA102	R (1)	Error	Errors present in the drive		
41219	0xA103	R (1)	Status	Status of the drive		
41220	0xA104	RW (1)	PhaseCurrent	Phase current of the motor		
41221	0xA105	RW (1)	ControlMode	Mode of movement control		
41222	0xA106	RW (1)	StByCurrent_Time	Time before the current reduction		
41223	0xA107	RW (1)	StByCurrent_Percentage	Percentage of current reduction		
41224	0xA108	RW (2)	MaxVel	Maximum rotation speed		
41225	0xA109	RW (2)		Do not use it		
41226	0xA10A	RW (2)	Acceleration	Maximum acceleration allowed		
41227	0xA10B	RW (2)	Deceleration	Maximum deceleration allowed		
41228	0xA10C	RW (4)	Position	Instant position assumed by the motor		
41229	0xA10D					
41230	0xA10E	RW (2)	TimerA	Timer with base 1ms		
41231	0xA10F	RW (1)	ControlFlags	It contains various control bits		
41232	0xA110	RW (2)	CounterA	Hardware counter associated to DIO		
41233	0xA111	RW (4)	CPosition	Capture of the instant position assumed by		
41234	0xA112			the motor		
41235	0xA113	R (2)	Velocity	Instant speed of the motor		
41473	0xA201	R (1)	DigitalInputsA	Image of the digital inputs		
41474	0xA202	RW (1)	DigitalOutputsA	Image of the digital outputs		
41475	0xA203	R (2)	AnalogInput(0)	Image of 0 analog input		
41476	0xA204	R (2)	AnalogInput(1)	Image of 1 analog input		
41477	0xA205	RW (2)	AnalogOutput(0)	Image of 0 analog output		
41729	0xA301	RW (2)	RefVel	Speed reference		
41730	0xA302	RW (4)	TargetPos	Position of destination		
41731	0xA303					

³ It must considered that according to the Modbus specification the registers are allocated starting from 1 while the address effectively transmitted on the bus has base 0. Consequently, if for example it is wanted to access to the register *DigitalOutputsA* it is necessary to compose the *frame* using the address 0xA201



111

Fieldbus DS30 – DS5x

Many registers detailed in the table have been already described in chapter 6.3 System registers, therefore following are reported only the details of the new registers.

7.3.1 RegTableVer

It helps to know the registers map version. Future evolutions of the product could bring to a different organization of the registers and it is important that the *master* device is able to ascertain that the version of the registers table in use is compatible with its own implementation.

7.3.2 ProductCode

It allows to know the type of product connected with.

This information is useful to validate the net or to automatically adapt oneself to a specific configuration of the machine.

In the following table is reported the correspondence between the code and the product:

Co	ode	Product
Dec	Hex	
1281	0x0501	DS5x41(A)
1280	0x0500	DS5x44(A)
1282	0x0502	DS5x48(A)
1284	0x0504	DS5x73(A)
1286	0x0506	DS5x76(A)
1288	0x0508	DS5x78(A)
1290	0x050A	DS5x84(A)
1292	0x050C	DS5x87(A)
1294	0x050E	DS5x98

7.3.3 FirmwareVer

It is a 2 bytes register useful to trace the origin of the firmware version present in the drive.

The version is represented by two number pairs divided by a decimal dot. The number pair before the decimal dot is given by the most significant byte of the register represented in hexadecimal notation, while the pair after the dot is the less significant byte, always in hexadecimal notation. If for example the value of the *FirmwareVer* register is 533 (in hexadecimal 0x0215) it means that the software version present in the drive is 2.15.



DS30 – DS5x Fieldbus

7.3.4 HardwareRev

It is a 2 bytes register useful to know the hardware version of the drive.

The revision number is represented by two number pairs divided by a decimal dot.

The number pair before the decimal dot is given by the most significant byte, represented in hexadecimal notation, of the register while the number pair after the decimal dot is given by the less significant byte, always represented in hexadecimal notation. If for example the value of the register is 259 (in hexadecimal 0x0103) the hardware revision of the product is 1.03.

7.3.5 SpecialVersion

It is a 2 bytes register which assumes a value different from 0 when the hardware of the product has been personalized and consequently differs from the standard one.

The special version code is composed by a 4 figures number. The first two figures are given by the most significant byte of the resister represented in hexadecimal notation, while the second two figures are the less significant byte of the register, always represented in hexadecimal notation. If for example the value of the register is 802 (in hexadecimal 0x0322) this means that the product is the special version code 322.

7.3.6 SerialNumber

It helps to know the serial number of the product. It is a 4 bytes register whose decimal value represents directly the SN of the drive.

If for example the value of the register is 7136335 (in hexadecimal notation 0x006CE44F) it means that the serial number of the product is 07136335 (the serial number is always composed by 8 figures).



8 Technical data

The following are the electric, physical and mechanical details of each single drive.

	DS3041A DS5x41A				
Symbol	Description		Value		Unit
_	-	Min	Тур	Max	
Vac	Power supply AC voltage	16		36	Vac
If	Phase current (effective current)	0.3		1.4	Arms
Vacbrk	Permanent breakdown voltage			42	Vac
Vach	Over voltage protection intervention	36.5		39	Vac
Vacl	Under voltage protection intervention	12.5		14.5	Vac
Tchh	Thermal protection intervention threshold	82	86	94	°C
Tchl	Thermal protection restoration threshold	60	62	66	°C
Plss	Power lost on the drive			7	W
MI	Motor inductance seen by the drive	0.8		50	mH
Vdi	Digital input voltage range	3		28	Vdc
Vdibrk	Digital input breakdown voltage	-30		+30	Vdc
Idi	Digital input supply current	4	6	8	mA
Vdo	Digital output voltage range	1		30	Vdc
Vdobrk	Digital output breakdown voltage	-0.5		37	Vdc
Vdoz	Output zener diode voltage	37	39	42	Vdc
Ido	Digital output current range			60	mA
Idobrk	Digital output breakdown current	120			mA
Pwdo	Digital output dissipable power	1,		300	mW
Vai	Analog input voltage range	-10		+10	Vdc
Vaibrk	Analog input breakdown voltage	-45		+45	Vdc
Rai	Analog input impedance		47		ΚΩ
ADrai	A/D converter resolution		11	-	bit
ADst	A/D converter conversion time		10		msec
ADsoff	A/D converter start offset		1	2	%fs
ADdoff	A/D converter offset drift		0.3	0.5	%fs
ADline	A/D converter linearity error		1	2	%fs
Vao	Analog output voltage range	0		+10	Vdc
Iao	Analog output current range			10	mA
Iasc	Analog output current range Analog output short circuit current			20	mA
Rao	Analog output impedance			1	Ω
DArai	D/A converter resolution		10	<u> </u>	bit
DAIG	D/A converter resolution D/A converter update		10		msec
DAsoff	D/A converter start offset		0.3	1	%fs
DASoff	D/A converter start offset D/A converter offset drift		0.3	0.3	%fs
DAline	D/A converter linearity error		0.3	1.5	%fs
Prt	Protections / Diagnostics / Alarms	Over/	Under volt		
	Trotections / Diagnostics / Alarms		erheating,		
	Mechanical specifications		, or riou ting,	Broak pric	430
FDh	Height Height		100.4	Ī	mm
FDI	Depth		119.0		mm
FDw	Width		22.5		mm
FDnw	Weight		185		g
	Rated range of use	1	. 50		<u> </u>
FCa	Altitude			2000	m
Idr	If current degrading every 1000m beyond the FCa altitude value		5		%
FCt	Temperature	0		40	°C
FCh	Humidity (no condensing)	5		90	<u> </u>
	Conditions of storage and transpo			70	/0
SCa	Altitude Conditions of storage and transport	,, t		4000	m
SCt	Temperature	-20		70	oC m
SCh	Humidity (no condensing)	5		95	<u>%</u>
JUII	Framilianty (no condensing)	ິ		70	-70



DS3041 DS5x41						
Symbol	Description		Value		Unit	
	, , , , , , , , , , , , , , , , , , ,	Min	Тур	Max		
Vp	Power supply DC voltage	18		50	Vdc	
İf	Phase current (effective current)	0.3		1.4	Arms	
Vprp	Allowed ripple (100Hz)			8	Vpp	
Vpbrk	Permanent breakdown voltage	-0.5		56	Vdc	
Vph	Over voltage protection intervention	50.2		51.5	Vdc	
Vpl	Under voltage protection intervention	16.0		17.8	Vdc	
Tchh	Thermal protection intervention threshold	82	86	94	°C	
Tchl	Thermal protection restoration threshold	60	62	66	°C	
Plss	Power lost on the drive			5	W	
MI	Motor inductance seen by the drive	0.8		50	mH	
Vdi	Digital input voltage range	3		28	Vdc	
Vdibrk	Digital input breakdown voltage	-30		+30	Vdc	
Idi	Digital input supply current	4	6	8	mA	
Vdo	Digital output voltage range	1		30	Vdc	
Vdobrk	Digital output breakdown voltage	-0.5	0.0	37	Vdc	
Vdoz	Output zener diode voltage	37	39	42	Vdc	
Ido	Digital output current range	100		60	mA m A	
Idobrk Pwdo	Digital output breakdown current	120		200	mA mW	
Vai	Digital output dissipable power	10		300	mW Vdc	
Vaibrk	Analog input voltage range Analog input breakdown voltage	-10 -45		+10	Vdc	
Rai	Analog input impedance	-40	47	+43	ΚΩ	
ADrai	A/D converter resolution		11		bit	
ADIT	A/D converter resolution A/D converter conversion time		10		msec	
ADsoff	A/D converter start offset		1	2	%fs	
ADdoff	A/D converter offset drift		0.3	0.5	%fs	
ADline	A/D converter linearity error		1	2	%fs	
Vao	Analog output voltage range	0	-	+10	Vdc	
Iao	Analog output current range			10	mA	
Iasc	Analog output short circuit current			20	mA	
Rao	Analog output impedance			1	Ω	
DArai	D/A converter resolution		10	•	bit	
DAud	D/A converter update		10		msec	
DAsoff	D/A converter start offset		0.3	1	%fs	
DAdoff	D/A converter offset drift		0.1	0.3	%fs	
DAline	D/A converter linearity error		0.3	1.5	%fs	
Prt	Protections / Diagnostics / Alarms		Under volta			
		0	verheating,	Break ph	ase	
	Mechanical specifications		100 :	1		
FDh	Height		100.4		mm	
FDI	Depth	47.	119.0	CE.	mm	
FDw	Width	17.5	(22.5 for E	JS5X)	mm	
FDnw	Weight Rated range of use		185		g	
FCa	Altitude			2000	m	
Idr	If current degrading every 1000m beyond the FCa altitude		5	2000	m %	
	value		J			
FCt	Temperature	0		40	٥C	
FCh	Humidity (no condensing)	5		90	%	
	Conditions of storage and transpo	ort				
SCa	Altitude			4000	m	
SCt	Temperature	-20		70	°C	
SCh	Humidity (no condensing)	5		95	%	



DS3044A DS5x44A Description Value Unit Symbol Min Тур Max Vac Power supply AC voltage 18 36 Vac Phase current (effective current) 1 4 Arms Vacbrk Permanent breakdown voltage 42 Vac Vac Vach 36.5 39 Over voltage protection intervention Vacl Under voltage protection intervention 12.5 14.5 Vac **Tchh** Thermal protection intervention threshold 90 95 °C 85 Thermal protection restorartion threshold 70 °C **Tchl** 60 65 Power lost on the drive W **Piss** 12 Motor inductance seen by the drive ΜI 0.8 50 mH Vdi Digital input voltage range 3 28 Vdc Vdibrk Digital input breakdown voltage -30 Vdc +30 Idi Digital input supply current 4 6 8 mΑ Vdo Digital output voltage range 30 Vdc 1 Vdobrk Digital output breakdown voltage -0.5 37 Vdc Vdoz Vdc Output zener diode voltage 37 39 42 Ido Digital output current range 60 mΑ Idobrk Digital output breakdown current 120 mΑ 300 mW Pwdo Digital output dissipable power Vai Analog input voltage range Vdc -10 +10Analog input breakdown voltage Vaibrk -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit A/D converter conversion time 10 **ADst** msec **ADsoff** A/D converter start offset 1 2 %fs **ADdoff** A/D converter offset drift 0.3 0.5 %fs %fs **ADline** A/D converter linearity error 2 Vao Analog output voltage range 0 +10 Vdc Iao Analog output current range 10 mΑ Iasc Analog output short circuit current 20 mΑ Analog output impedance Rao 1 Ω **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 0.3 %fs DAdoff D/A converter offset drift 0.3%fs 0.1**DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics /Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** FDh 100.4 Height mm 119.0 FDI Depth mm **FDw** Width 35 mm **FDnw** Weight 215 g Rated range of use FCa Altitude 2000 m If current degrading every 1000m beyond the FCa altitude 5 Idr % value Temperature ٥C **FCt** 0 40 Humidity (no condensing) % **FCh** 5 90 Conditions of storage and transport 4000 **SCa** Altitude m -20 ٥C SCt Temperature 70 SCh Humidity (no condensing) 95 %



DS3044 DS5x44 Value Unit Symbol Description Min Тур Max ۷p Power supply DC voltage 20 50 Vdc Phase current (effective current) 1 4 Arms Vprp Allowed ripple (100Hz) 8 Vpp Vdc Vpbrk -0.5 Permanent breakdown voltage 60 56.0 57.5 Vdc Vph Over voltage protection intervention Vpl 19.7 Vdc Under voltage protection intervention 18.5 90 95 °C **Tchh** Thermal protection intervention threshold 85 Thermal protection restoration threshold °C **Tchl** 60 65 70 **Piss** Power lost on the drive 8 W ΜI Motor inductance seen by the drive 0.8 50 mΗ Vdi 28 Digital input voltage range 3 Vdc Vdibrk Digital input breakdown voltage -30 +30 Vdc Digital input supply current Idi 6 4 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc -0.5 Digital output breakdown voltage 37 Vdoz Output zener diode voltage 37 39 Vdc 42 Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo 300 mW Digital output dissipable power Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution bit 11 **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 **ADdoff** A/D converter offset drift 0.5 %fs **ADline** A/D converter linearity error 2 %fs Analog output voltage range Vao +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Analog output short circuit current mΑ Iasc Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit DAud D/A converter update 10 msec DAsoff D/A converter start offset 1 %fs 0.3**DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** FDh Height 100.4 mm FDI 119.0 Depth mm FDw 17.5 (22.5 for DS5x) Width mm **FDnw** Weight 185 g Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 **FCh** Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m ٥C **SCt** Temperature 20 70 SCh Humidity (no condensing) 5 95 %



DS3048A DS5x48A Symbol Description Value Unit Min Тур Max Vac Power supply AC voltage 18 36 Vac Ιf Phase current (effective current) 3 8 Arms Vacbrk Permanent breakdown voltage 42 Vac Vach 40 Vac Over voltage protection intervention 42 Vacl 14 15.6 Vac Under voltage protection intervention **Tchh** Thermal protection intervention threshold 85 90 95 °C °C Thermal protection restoration threshold Tchl 60 65 70 Power lost on the drive W **Piss** 21 Motor inductance seen by the drive 0.5 ΜI 30 mΗ Vdi Digital input voltage range 28 Vdc Vdibrk -30 Vdc Digital input breakdown voltage +30 Idi Digital input supply current 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Digital output breakdown voltage -0.5 37 Vdc Vdoz 39 Vdc Output zener diode voltage 42 37 Ido Digital output current range 60 mΑ Idobrk Digital output breakdown current 120 mΑ 300 mW Pwdo Digital output dissipable power Vai -10 Vdc Analog input voltage range +10 Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit A/D converter conversion time 10 **ADst** msec **ADsoff** A/D converter start offset 1 2 %fs **ADdoff** A/D converter offset drift 0.3 0.5 %fs **ADline** %fs A/D converter linearity error 2 Analog output voltage range Vao 0 +10 Vdc Analog output current range 10 Iao mA **Iasc** Analog output short circuit current 20 mΑ Rao Analog output impedance 1 Ω **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 0.3 %fs D/A converter offset drift DAdoff 0.3%fs 0.1**DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase Mechanical specifications **FDh** Height 100.4 mm FDI Depth 119.0 mm **FDw** Width 35 mm 350 **FDnw** Weight g Rated range of use FCa Altitude 2000 m If current degrading every 1000m beyond the FCa altitude 5 Idr % value Temperature °С **FCt** 40 0 **FCh** Humidity (no condensing) % 5 90 Conditions of storage and transport 4000 **SCa** Altitude m SCt -20 ٥C Temperature 70 **SCh** Humidity (no condensing) 95 %



DS3048 DS5x48 Symbol Value Unit Description Min Тур Max ۷p Power supply DC voltage 20 50 Vdc 8 Ιf Phase current (effective current) 3 Arms Vprp Allowed ripple (100Hz) 8 Vpp Vdc Vpbrk -0.5 Permanent breakdown voltage 60 Vph 56.0 57.5 Vdc Over voltage protection intervention Vpl 19.7 Vdc Under voltage protection intervention 18.5 °C 90 **Tchh** Thermal protection intervention threshold 85 95 °C 70 **Tchl** Thermal protection intervention threshold 60 65 W **Piss** Power lost on the drive 15 ΜI Motor inductance seen by the drive 0.5 30 mΗ Vdi 28 Vdc Digital input voltage range 3 Vdibrk Digital input breakdown voltage -30 +30 Vdc Digital input supply current Idi 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc -0.5 37 Digital output breakdown voltage Vdoz Output zener diode voltage 37 39 42 Vdc Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo mW Digital output dissipable power 300 Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 **ADdoff** A/D converter offset drift 0.5 %fs **ADline** A/D converter linearity error 2 %fs Vao Analog input voltage range +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Analog output short circuit current mA Iasc Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 1 %fs 0.3 **DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** 100.4 **FDh** Height $\mathbf{m}\mathbf{m}$ FDI 119.0 Depth mm **FDw** Width 35 mm **FDnw** Weight 295 g Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 FCh Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m SCt ٥C Temperature 20 70 % SCh Humidity (no condensing) 5 95



DS3073A DS5x73A Symbol Value Unit Description Min Тур Max Vac Power supply AC voltage 20 65 Vac 0.8 Ιf Phase current (effective current) 3 Arms Vacbrk Permanent breakdown voltage 75 Vac Vach 69 Vac Over voltage protection intervention 73 Vacl 16 18.6 Vac Under voltage protection intervention **Tchh** Thermal protection intervention threshold 85 90 95 °C °C Thermal protection restoration threshold Tchl 60 65 70 Power lost on the drive W **Piss** 10 Motor inductance seen by the drive 0.8 50 ΜI mΗ Vdi Digital input voltage range 28 Vdc Vdibrk -30 Vdc Digital input breakdown voltage +30 Idi Digital input supply current 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Digital output breakdown voltage -0.5 37 Vdc Vdoz 39 Vdc Output zener diode voltage 42 37 Ido Digital output current range 60 mΑ Idobrk Digital output breakdown current 120 mΑ 300 mW Pwdo Digital output dissipable power Vai -10 Vdc Analog input voltage range +10 Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit A/D converter conversion time 10 **ADst** msec **ADsoff** A/D converter start offset 1 2 %fs **ADdoff** A/D converter offset drift 0.3 0.5 %fs **ADline** %fs A/D converter linearity error 2 Analog output voltage range Vao 0 +10 Vdc Analog output current range 10 Iao mA **Iasc** Analog output short circuit current 20 mΑ Rao Analog output impedance 1 Ω **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 0.3 %fs D/A converter offset drift DAdoff 0.3%fs 0.1**DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase Mechanical specifications **FDh** Height 100.4 mm FDI Depth 119.0 mm **FDw** Width 35 mm 215 **FDnw** Weight g Rated range of use FCa Altitude 2000 m If current degrading every 1000m beyond the FCa altitude 5 Idr % value Temperature °С **FCt** 40 0 **FCh** Humidity (no condensing) % 5 90 Conditions of storage and transport 4000 **SCa** Altitude m SCt -20 ٥C Temperature 70 **SCh** Humidity (no condensing) 95 %



DS3073 DS5x73 Symbol Value Unit Description Min Тур Max ۷p Power supply DC voltage 24 90 Vdc 0.8 Ιf Phase current (effective current) 3 Arms Vprp Allowed ripple (100Hz) 15 Vpp Vdc Vpbrk Permanent breakdown voltage -0.5 105 Vph 95 98 Vdc Over voltage protection intervention Vpl Under voltage protection intervention 22.5 23.5 Vdc °C 90 **Tchh** Thermal protection intervention threshold 85 95 °C 70 **Tchl** Thermal protection restoration threshold 60 65 W **Piss** Power lost on the drive 8 ΜI Motor inductance seen by the drive 0.8 50 mΗ Vdi 28 Vdc Digital input voltage range 3 Vdibrk Digital input breakdown voltage -30 +30 Vdc Digital input supply current Idi 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc Digital output breakdown voltage -0.5 37 Vdoz Output zener diode voltage 37 39 42 Vdc Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo mW Digital output dissipable power 300 Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ bit **ADrai** A/D converter resolution 11 **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 0.5 **ADdoff** A/D converter offset drift %fs **ADline** A/D converter linearity error 2 %fs Analog output voltage range Vao +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Iasc Analog output short circuit current mA Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 1 %fs 0.3 **DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** FDh Height 100.4 $\mathbf{m}\mathbf{m}$ FDI 119.0 Depth mm **FDw** 17.5 (22.5 for DS5x) Width mm **FDnw** Weight 185 g Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 FCh Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m SCt ٥C Temperature 20 70 % SCh Humidity (no condensing) 5 95



DS3076A DS5x76A Symbol Description Value Unit Min Тур Max Vac Power supply AC voltage 20 65 Vac Ιf Phase current (effective current) 6 Arms Vacbrk Permanent breakdown voltage 75 Vac Vach 69 Vac Over voltage protection intervention 73 Vacl 16 18.6 Vac Under voltage protection intervention **Tchh** Thermal protection intervention threshold 90 95 °C 85 °C Thermal protection restoration threshold Tchl 60 65 70 Power lost on the drive W **Piss** 20 Motor inductance seen by the drive 0.6 ΜI 40 mΗ Vdi Digital input voltage range 28 Vdc Vdibrk -30 Vdc Digital input breakdown voltage +30 Idi Digital input supply current 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Digital output breakdown voltage -0.5 37 Vdc Vdoz 39 Vdc Output zener diode voltage 42 37 Ido Digital output current range 60 mΑ Idobrk Digital output breakdown current 120 mΑ 300 mW Pwdo Digital output dissipable power Vai -10 Vdc Analog input voltage range +10 Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit A/D converter conversion time 10 **ADst** msec **ADsoff** A/D converter start offset 1 2 %fs **ADdoff** A/D converter offset drift 0.3 0.5 %fs **ADline** %fs A/D converter linearity error 2 Analog output voltage range Vao 0 +10 Vdc Analog output current range 10 Iao mA **Iasc** Analog output short circuit current 20 mΑ Rao Analog output impedance 1 Ω **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 0.3 %fs D/A converter offset drift DAdoff 0.3%fs 0.1**DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase Mechanical specifications **FDh** Height 100.4 mm FDI Depth 119.0 mm **FDw** Width 35 mm 350 **FDnw** Weight g Rated range of use FCa Altitude 2000 m If current degrading every 1000m beyond the FCa altitude 5 Idr % value Temperature °С **FCt** 40 0 **FCh** Humidity (no condensing) % 5 90 Conditions of storage and transport 4000 **SCa** Altitude m SCt -20 ٥C Temperature 70 **SCh** Humidity (no condensing) 95 %



DS3076 DS5x76 Symbol Value Unit Description Min Тур Max ۷p Power supply DC voltage 24 90 Vdc Ιf Phase current (effective current) 6 Arms Vprp Allowed ripple (100Hz) 15 Vpp Vdc Vpbrk -0.5 105 Permanent breakdown voltage Vph 95 98 Vdc Over voltage protection intervention Vpl 22.5 23.5 Vdc Under voltage protection intervention °C 90 **Tchh** Thermal protection intervention threshold 85 95 °C 70 **Tchl** Thermal protection restoration threshold 60 65 W **Piss** Power lost on the drive 15 ΜI Motor inductance seen by the drive 0.6 40 mΗ Vdi 28 Vdc Digital input voltage range 3 Vdibrk Digital input breakdown voltage -30 +30 Vdc Digital input supply current Idi 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc Digital output breakdown voltage -0.5 37 Vdoz Output zener diode voltage 37 39 42 Vdc Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo mW Digital output dissipable power 300 Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ bit **ADrai** A/D converter resolution 11 **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 **ADdoff** A/D converter offset drift 0.5 %fs **ADline** A/D converter linearity error 2 %fs Analog output voltage range Vao +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Analog output short circuit current mA Iasc Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 1 %fs 0.3 **DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** 100.4 FDh Height $\mathbf{m}\mathbf{m}$ FDI 119.0 Depth mm **FDw** Width 35 mm **FDnw** Weight 295 gr Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 FCh Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m SCt ٥C Temperature 20 70 % SCh Humidity (no condensing) 5 95



DS3078A DS5x78A Symbol Description Value Unit Min Тур Max Vac Power supply AC voltage 20 65 Vac 10 Ιf Phase current (effective current) 4 Arms Vacbrk Permanent breakdown voltage 75 Vac Vach 69 Vac Over voltage protection intervention 73 Vacl 16 18.6 Vac Under voltage protection intervention **Tchh** Thermal protection intervention threshold 85 90 95 °C °C Thermal protection restoration threshold Tchl 60 65 70 Power lost on the drive W **Piss** 24 Motor inductance seen by the drive 0.5 ΜI 30 mΗ Vdi Digital input voltage range 28 Vdc Vdibrk -30 Vdc Digital input breakdown voltage +30 Idi Digital input supply current 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Digital output breakdown voltage -0.5 37 Vdc Vdoz 39 Vdc Output zener diode voltage 42 37 Ido Digital output current range 60 mΑ Idobrk Digital output breakdown current 120 mΑ 300 mW Pwdo Digital output dissipable power Vai Vdc Analog input voltage range -10 +10 Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit A/D converter conversion time 10 **ADst** msec **ADsoff** A/D converter start offset 1 2 %fs **ADdoff** A/D converter offset drift 0.3 0.5 %fs **ADline** %fs A/D converter linearity error 2 Analog output voltage range Vao 0 +10 Vdc Analog output current range 10 Iao mA **Iasc** Analog output short circuit current 20 mΑ Rao Analog output impedance 1 Ω **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 0.3 %fs D/A converter offset drift DAdoff 0,3 %fs 0.1**DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase Caratteristiche fisiche **FDh** Height 100.4 mm FDI Depth 119.0 mm **FDw** Width 35 mm 350 **FDnw** Weight gr Rated range of use FCa Altitude 2000 m If current degrading every 1000m beyond the FCa altitude 5 Idr % value Temperature °С **FCt** 40 0 **FCh** Humidity (no condensing) % 5 90 Conditions of storage and transport 4000 **SCa** Altitude m SCt -20 ٥C Temperature 70 **SCh** Humidity (no condensing) 95 %



DS3078 DS5x78 Simbolo Valore Unità Descrizione Min Tipico Max ۷p Power supply DC voltage 24 90 Vdc 10 Ιf Phase current (effective current) 4 Arms Vprp Allowed ripple (100Hz) 15 Vpp Vdc Vpbrk -0.5 105 Permanent breakdown voltage Vph 95 98 Vdc Over voltage protection intervention Vpl 22.5 23.5 Vdc Under voltage protection intervention °C 90 **Tchh** Thermal protection intervention threshold 85 95 °C Thermal protection restoration threshold 70 **Tchl** 60 65 W **Piss** Power lost on the drive 15 ΜI Motor inductance seen by the drive 0.5 30 mΗ Vdi 28 Vdc Digital input voltage range 3 Vdibrk Digital input breakdown voltage -30 +30 Vdc Digital input supply current Idi 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc -0.5 37 Digital output breakdown voltage Vdoz Output zener diode voltage 37 39 42 Vdc Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo mW Digital output dissipable power 300 Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 **ADdoff** A/D converter offset drift 0.5 %fs **ADline** A/D converter linearity error 2 %fs Analog output voltage range Vao +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Analog output short circuit current mA Iasc Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 1 %fs 0.3 **DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** 100.4 FDh Height $\mathbf{m}\mathbf{m}$ FDI 119.0 Depth mm **FDw** Width 35 mm **FDnw** Weight 295 g Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 FCh Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m SCt ٥C Temperature 20 70 % SCh Humidity (no condensing) 5 95



DS3084A DS5x84A Symbol Description Value Unit Min Тур Max Vac Power supply AC voltage 35 115 Vac Ιf Phase current (effective current) 2 4 Arms Vacbrk Permanent breakdown voltage 142 Vac Vach 126 120 Vac Over voltage protection intervention Vacl 31 33.6 Vac Under voltage protection intervention **Tchh** Thermal protection intervention threshold 85 90 95 °C °C Thermal protection restoration threshold Tchl 60 65 70 Power lost on the drive W **Piss** 20 Motor inductance seen by the drive ΜI 1 50 mΗ Vdi Digital input voltage range 3 28 Vdc Vdibrk Vdc Digital input breakdown voltage -30 +30 Idi Digital input supply current 4 6 8 mΑ Vdo Digital output voltage range 30 Vdc 1 Vdobrk Digital output breakdown voltage -0.5 37 Vdc Vdoz 39 Vdc Output zener diode voltage 42 37 Ido Digital output current range 60 mΑ Idobrk Digital output breakdown current 120 mΑ 300 mW Pwdo Digital output dissipable power Vai -10 Vdc Analog input voltage range +10 Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit A/D converter conversion time 10 **ADst** msec **ADsoff** A/D converter start offset 1 2 %fs **ADdoff** A/D converter offset drift 0.3 0.5 %fs **ADline** %fs A/D converter linearity error 2 Analog output voltage range Vao 0 +10 Vdc Analog output current range 10 Iao mA **Iasc** Analog output short circuit current 20 mΑ Rao Analog output impedance 1 Ω **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 0.3 %fs D/A converter offset drift DAdoff 0.3%fs 0.1**DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase Mechanical specifications **FDh** Height 100.4 mm FDI Depth 119.0 mm **FDw** Width 35 mm 350 **FDnw** Weight g Rated range of use FCa Altitude 2000 m If current degrading every 1000m beyond the FCa altitude 5 Idr % value Temperature °С **FCt** 40 0 **FCh** Humidity (no condensing) % 5 90 Conditions of storage and transport 4000 **SCa** Altitude m SCt -20 ٥C Temperature 70 **SCh** Humidity (no condensing) 95 %



DS3084 DS5x84 Symbol Value Unit Description Min Тур Max ۷p Power supply DC voltage 45 160 Vdc Ιf Phase current (effective current) 4 Arms Vprp Allowed ripple (100Hz) 25 Vpp Vdc Vpbrk -0.5 210 Permanent breakdown voltage Vph 177 181 Vdc Over voltage protection intervention Vpl Vdc Under voltage protection intervention 26 27 °C 90 **Tchh** Thermal protection intervention threshold 85 95 °C Thermal protection restoration threshold 70 **Tchl** 60 65 W **Piss** Power lost on the drive 15 ΜI Motor inductance seen by the drive 50 mΗ Vdi 3 28 Vdc Digital input voltage range Vdibrk Digital input breakdown voltage -30 +30 Vdc Digital input supply current Idi 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc -0.5 37 Digital output breakdown voltage Vdoz Output zener diode voltage 37 39 42 Vdc Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo mW Digital output dissipable power 300 Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 **ADdoff** A/D converter offset drift 0.5 %fs **ADline** A/D converter linearity error 2 %fs Analog output voltage range Vao +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Analog output short circuit current mA Iasc Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 1 %fs 0.3 **DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** 100.4 FDh Height $\mathbf{m}\mathbf{m}$ FDI 119.0 Depth mm **FDw** Width 35 mm **FDnw** Weight 295 g Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 FCh Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m SCt ٥C Temperature 20 70 % SCh Humidity (no condensing) 5 95



DS3087A DS5x87A Symbol Description Value Unit Min Тур Max Vac Power supply AC voltage 35 115 Vac 8.5 Ιf Phase current (effective current) 4 Arms Vacbrk Permanent breakdown voltage 142 Vac Vach 120 Vac Over voltage protection intervention 126 Vacl 31 33.6 Vac Under voltage protection intervention **Tchh** Thermal protection intervention threshold 90 95 °C 85 °C Thermal protection restoration threshold Tchl 60 65 70 Power lost on the drive W **Piss** 36 Motor inductance seen by the drive 0.6 ΜI 35 mΗ Vdi Digital input voltage range 28 Vdc Vdibrk -30 Vdc Digital input breakdown voltage +30 Idi Digital input supply current 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Digital output breakdown voltage -0.5 37 Vdc Vdoz 39 Vdc 42 Output zener diode voltage 37 Ido Digital output current range 60 mΑ Idobrk Digital output breakdown current 120 mΑ 300 mW Pwdo Digital output dissipable power Vai Vdc Analog input voltage range -10 +10 Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit A/D converter conversion time 10 **ADst** msec **ADsoff** A/D converter start offset 1 2 %fs **ADdoff** A/D converter offset drift 0.3 0.5 %fs **ADline** %fs A/D converter linearity error 2 Analog output voltage range Vao 0 +10 Vdc Analog output current range 10 Iao mA **Iasc** Analog output short circuit current 20 mΑ Rao Analog output impedance 1 Ω **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 0.3 %fs D/A converter offset drift DAdoff 0.3%fs 0.1**DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase Mechanical specifications **FDh** Height 100.4 mm FDI Depth 119.0 mm **FDw** Width 35 mm 350 **FDnw** Weight g Rated range of use FCa Altitude 2000 m If current degrading every 1000m beyond the FCa altitude 5 Idr % value Temperature °С **FCt** 40 0 **FCh** Humidity (no condensing) % 5 90 Conditions of storage and transport 4000 **SCa** Altitude m SCt -20 ٥C Temperature 70 **SCh** Humidity (no condensing) 95 %




DS3087 DS5x87 Symbol Value Unit Description Min Тур Max ۷p Power supply DC voltage 45 160 Vdc 8.5 Ιf Phase current (effective current) 4 Arms Vprp Allowed ripple (100Hz) 25 Vpp Vdc Vpbrk -0.5 210 Permanent breakdown voltage Vph 177 181 Vdc Over voltage protection intervention Vpl Vdc Under voltage protection intervention 26 27 °C 90 **Tchh** Thermal protection intervention threshold 85 95 °C Thermal protection restoration threshold 70 **Tchl** 60 65 W **Piss** Power lost on the drive 20 ΜI Motor inductance seen by the drive 0.6 35 mΗ Vdi 28 Vdc Digital input voltage range 3 Vdibrk Digital input breakdown voltage -30 +30 Vdc Digital input supply current Idi 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc -0.5 37 Digital output breakdown voltage Vdoz Output zener diode voltage 37 39 42 Vdc Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo mW Digital output dissipable power 300 Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ **ADrai** A/D converter resolution 11 bit **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 **ADdoff** A/D converter offset drift 0.5 %fs **ADline** A/D converter linearity error 2 %fs Analog output voltage range Vao +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Analog output short circuit current mA Iasc Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 1 %fs 0.3 **DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** 100.4 **FDh** Height $\mathbf{m}\mathbf{m}$ FDI 119.0 Depth mm **FDw** Width 35 mm **FDnw** Weight 295 g Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 FCh Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m SCt ٥C Temperature 20 70 % SCh Humidity (no condensing) 5 95



DS3098 DS5x98 Symbol Description Value Unit Min Typic Max Vdc ۷p Power supply DC voltage 45 240 Phase current (effective current) 10 Ιf 4 Arms Vprp Allowed ripple (100Hz) 30 Vpp Vdc Vpbrk Permanent breakdown voltage -0.5 265 Over voltage protection intervention Vph 242 255 Vdc Vpl Under voltage protection intervention Vdc 35 37 °C 90 **Tchh** Thermal protection intervention threshold 85 95 °C 70 **Tchl** Thermal protection restoration threshold 60 65 W **Piss** Power lost on the drive 30 ΜI Motor inductance seen by the drive 0.6 30 mΗ Vdi 28 Vdc Digital input voltage range 3 Digital input breakdown voltage Vdibrk -30 +30 Vdc Digital input supply current Idi 4 6 8 mΑ Vdo Digital output voltage range 1 30 Vdc Vdobrk Vdc Digital output breakdown voltage -0.5 37 Vdoz Output zener diode voltage 37 39 42 Vdc Ido Digital output current range 60 mΑ 120 Idobrk Digital output breakdown current mΑ Pwdo mW Digital output dissipable power 300 Vai Analog input voltage range -10 +10 Vdc Vaibrk Analog input breakdown voltage -45 +45 Vdc Rai Analog input impedance 47 ΚΩ A/D converter resolution bit **ADrai** 11 **ADst** A/D converter conversion time 10 msec **ADsoff** A/D converter start offset %fs 0.3 0.5 **ADdoff** A/D converter offset drift %fs **ADline** A/D converter linearity error 2 %fs Analog output voltage range Vao +10 Vdc 0 Iao Analog output current range 10 mΑ 20 Iasc Analog output short circuit current mA Rao Analog output impedance Ω 1 **DArai** D/A converter resolution 10 bit **DAud** D/A converter update 10 msec **DAsoff** D/A converter start offset 1 %fs 0.3 **DAdoff** D/A converter offset drift 0.1 0.3 %fs **DAline** D/A converter linearity error 0.3 1.5 %fs Prt Protections / Diagnostics / Alarms Over/Under voltage, Short circuit Overheating, Break phase **Mechanical specifications** 100.4 **FDh** Height $\mathbf{m}\mathbf{m}$ FDI 119.0 Depth mm **FDw** Width 35 mm **FDnw** Weight 295 g Rated range of use FCa 2000 Altitude m Idr If current degrading every 1000m beyond the FCa altitude 5 % value **FCt** ٥C Temperature 0 40 FCh Humidity (no condensing) 5 90 % Conditions of storage and transport SCa Altitude 4000 m SCt ٥C Temperature 20 70 % SCh Humidity (no condensing) 5 95







LAM Technologies Viale Ludovico Ariosto, 492/D 50019 Sesto Fiorentino Firenze - ITALY

> Ph. +39 055 4207746 Fax +39 055 4207651

www.lamtechnologies.com

General information info@lamtechnologies.com
Technical support support@lamtechnologies.com
Sales information sales@lamtechnologies.com