Nestora Brew Smart Kettle: User Manual

Model NK-500 | Edition 2 | August 2026

Model NK-500 | 1.2 L | 1500 W | 220-240 V, 50 Hz | Please read before first use and keep for reference.

1. Safety instructions

- Use the kettle only with its own power base. Place the base on a flat, dry, heat-resistant surface.
- Never fill above the **MAX** line (1.2 L) or below the **MIN** line (0.3 L). Overfilling can cause hot water to spit out.
- Do not immerse the kettle, base or cord in water. Wipe the base with a damp cloth only.
- The outer body and lid become hot. Lift the kettle by its handle only, and keep it out of reach of children.
- Do not open the lid while the water is boiling. Wait 30 seconds after boiling before opening it.
- Stop using the kettle and contact support if the cord, plug or body is damaged.

2. What is in the box

- Nestora Brew Smart Kettle (NK-500)
- Power base with 1 m cord
- Removable limescale filter (fitted in the spout)
- Quick start card and warranty card

3. First use

1. Remove all packaging and stickers from inside and outside the kettle.
2. Fill with water to the MAX line, close the lid and place the kettle on its base.
3. Press **Boil** and let the water reach 100°C. Pour it away. Repeat once more.
4. The kettle is now ready to use.

4. Using temperature presets

Place the filled kettle on its base, press the **Temp** button until the preset you want lights up, then press **Start**. The kettle beeps when the water is ready and then holds the temperature for 30 minutes (keep-warm). Press **Start** again to cancel at any time.

Preset	Temperature	Suggested use
Green tea	80°C	Green and white teas
Oolong	90°C	Oolong and herbal infusions
Black tea	95°C	Black tea and masala chai
Coffee	93°C	Pour-over, French press, instant coffee
Boil	100°C	Soups, noodles, baby formula (cool before serving)

5. Cleaning and descaling

Unplug the kettle and let it cool fully before cleaning. Wipe the outside with a soft damp cloth. Rinse the limescale filter under running water once a week.

Descale every 4 weeks (every 2 weeks if your water is hard):

1. Fill the kettle to the halfway mark with water and add 2 tablespoons of citric acid (or 200 ml of white vinegar).
2. Boil, then leave the solution for 30 minutes.
3. Pour it away, rinse the kettle twice with clean water and boil fresh water once before use.

6. Troubleshooting

Problem	Likely cause	What to do
Kettle does not turn on	Not seated on the base, or no power	Re-seat the kettle, check the plug and socket, try another socket
Display shows E1	Dry-boil protection: too little water	Unplug, let it cool for 10 minutes, fill above the MIN line and restart
Display shows E2	Temperature sensor fault	Unplug for 5 minutes and restart. If E2 returns, contact support
Water tastes of plastic	New kettle	Boil and discard water two to three times
White flakes in water	Limescale	Descale (section 5) and clean the filter
Water leaks from the base	Lid not closed, or crack in the body	Close the lid fully. If it persists, stop using the kettle and contact support
Beeps but keep-warm stops early	Keep-warm lasts 30 minutes	Press Start again to reheat

7. Specifications

Item	Value
Capacity	1.2 L (MIN 0.3 L)
Power	1500 W
Voltage	220-240 V, 50 Hz
Material	Stainless steel inner, BPA-free outer lid
Cord length	1 m
Auto shut-off and dry-boil protection	Yes
Keep-warm	30 minutes

8. Warranty

The kettle has a **12-month warranty** from the date of delivery against manufacturing defects. It does not cover limescale buildup, damage from drops, use with a different power base, or repairs by anyone other than Nestora service. To claim, email support@nestora.example with your order number and a short video of the fault.