FIG. NO.	ITEM NO.	PART NO.	NAME AND DESCRIPTION	QUANTITY PER 3-71	4-71	6-71
57	5.5190	5168826	Tube Assy., expansion tank overflow	1	1	1
57	5.5190	143343	Elbow, 5/16"x90° inv. fl. tube	1	1	1
-	-	137398	Nut, 5/16" inv. fl. tube	1	1	1
-	5.5377	5186345	Tube Assy., raw water pump inlet	1	1	1
-	-	113177	Plug, 3/4" brass pipe	1	1	1
-	-	179847	Bolt, 3/8"-16x2" hex. hd.	2	2	2
-	-	116093	Washer, 3/8" flat	2	2	2
-	-	5158741	Gasket, water flange	1	1	1
-	5.5380	5185442	Tube Assy., raw water pump outlet	1	1	1
-	-	179839	Bolt, 3/8"-16x1" hex. hd.	2	2	2
-	-	116093	Washer, 3/8" flat	2	2	2
-	-	5158741	Gasket, raw water flange	1	1	1
-	-	5186526	Tube Assy., heat exchanger water inlet (intermediate) (PTO units)	1		
-	-	5175818	Tube Assy., heat exchanger water inlet (intermediate) (PTO units)		1	
-	-	5174535	Tube Assy., heat exchanger water inlet (intermediate) (PTO units)			1
-	5.5430	5187458	Tube Assy., heat exchanger water inlet (intermediate) (generator sets)	1		
-	5.5430	5187459	Tube Assy., heat exchanger water inlet (intermediate) (generator sets)		1	
-	5.5430	5187460	Tube Assy., heat exchanger water inlet (intermediate) (generator sets)			1
57	5.5440	5175866	Tube Assy., heat exchanger water inlet	1	1	1
-	-	5159444#	Elbow, heat exchanger water inlet	1	1	1
57	5.5440	186629	Bolt, 5/16"-18x1" hex. hd.	4	4	4
-	-	103320	Lockwasher, 5/16"	4	4	4
57	5.5460	5158747	Gasket, heat exchanger water inlet tube	1	1	1
-	-	3222708	Hose (1 1/2"x2 3/4")	2	2	2
-	-	111619	Clamp, 1 7/8" dia.	4	4	4
3,57	5.5550	5167753	Tube Assy., heat exchanger water outlet	1	1	1
57	5.5550	186629	Bolt, 5/16"-18x1" hex. hd.	4	4	4
-	-	103320	Lockwasher, 5/16"	4	4	4
57	5.5570	5158747	Gasket, heat exchanger water outlet tube	1	1	1
57	5.5580	3222708	Hose, heat exchanger water outlet tube (1 1/2"x2 3/4")	1	1	1
57	5.5580	111619	Clamp, 1 7/8" dia. hose	2	2	2
3,57	5.5600	5164407	Tube Assy., exhaust manifold water inlet	1	1	1
-	-	5163834	Washer, exhaust manifold water inlet tube	2	2	2
57	5.5600	123197	Nut, 5/16"-18 hex.	2	2	2
57	5.5610	5156319	Gasket, exhaust manifold flange	1	1	1
57	5.5620	5164199	Stud, exhaust manifold water inlet tube (2 7/8")	1	1	1
57	5.5620	5163867	Stud, exhaust manifold water inlet tube (1 7/32")	1	1	1
			RAW WATER PUMP			
58	5.6001	5186250	Pump Assy., raw water (includes indented items)	1	1	1
-	-	179857	Bolt, 7/16"-14x7/8" hex. hd. (to engine)	1	1	1
-	-	179882	Bolt, 1/2"-13x1 1/8" hex. hd. (to engine)	4	4	4
-	-	103322	Lockwasher, 7/16"	1	1	1
-	-	103323	Lockwasher, 1/2"	4	4	4
58	5.6010	5193551	Adaptor, raw water pump drive	1	1	1
58	5.6020	5193550	Body, raw water pump	1	1	1
58	5.6020	5193556	Plate, raw water pump body wear	1	1	1
-	-	141343	Pin, 3/16"x5/16" dowel	1	1	1
58	5.6020	120233	Bolt, 3/8"-16x1" hex. hd. (to adaptor)	6	6	6
-	-	120382	Lockwasher, 3/8"	6	6	6
58	5.6035	5193554	Cam, raw water pump body offset	1	1	1
58	5.6035	114366	Screw, 1/4"-20x1/2" fil. hd. (cam)	1	1	1
58	5.6090	5193555	Cover, raw water pump	1	1	1
58	5.6090	114366	Screw, 1/4"-20x1/2" fil. hd. (cover)	5	5	5
58	5.6100	5193562	Gasket, raw water pump cover	1	1	1
58	5.6120	5193552	Shaft, raw water pump	1	1	1
58	5.6130	954799	Bearing, raw water pump	1	1	1
58	5.6140	5193569	Ring, raw water pump bearing retainer (small)	1	1	1
58	5.6140	5179222	Ring, raw water pump bearing retainer (large)	1	1	1
58	5.6160	5193561	Seal, raw water pump bearing (1 1/16" I.D.)	1	1	1
58	5.6160	5193559	Seal, raw water pump bearing (1 11/32" I.D.)	1	1	1

Used when raw water pump is not furnished.